


BASIC COMPILER FOR MICROCHIP DSPIC30/33 AND PIC24
MICROCONTROLLERS

mikroBasic

for dsPIC30/33 and PIC24

Making it simple



**SUPPORTED
from V5.0**

Develop your applications quickly and easily with the world's most advanced BASIC compiler for dsPIC30/33 and PIC24 Microcontrollers (all families).

Highly sophisticated IDE provides the power you need with the simplicity of a Windows based point-and-click environment.

With useful implemented tools, many practical code examples, broad set of built-in routines, and a comprehensive Help, mikroBasic makes fast and reliable tool, which can satisfy the needs of experienced engineers and beginners alike.

manual
user's

DISCLAIMER:

mikroBasic and this manual are owned by mikroElektronika and are protected by copyright law and international copyright treaty. Therefore, you should treat this manual like any other copyrighted material (e.g., a book). The manual and the compiler may not be copied, partially or as a whole without the written consent from the mikroElektronika. The PDF-edition of the manual can be printed for private or local use, but not for distribution. Modifying the manual or the compiler is strictly prohibited.

HIGH RISK ACTIVITIES

The mikroBasic compiler is not fault-tolerant and is not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of the Software could lead directly to death, personal injury, or severe physical or environmental damage ("High Risk Activities"). mikroElektronika and its suppliers specifically disclaim any express or implied warranty of fitness for High Risk Activities.

LICENSE AGREEMENT:

By using the mikroBasic compiler, you agree to the terms of this agreement. Only one person may use licensed version of mikroBasic compiler at a time.

Copyright © mikroElektronika 2003 - 2007.

This manual covers mikroBasic for dsPIC30/33 and PIC24 version 5.0 and the related topics. New versions may contain changes without prior notice.

COMPILER BUG REPORTS:

The compiler has been carefully tested and debugged. It is, however, not possible to guarantee a 100% error free product. If you would like to report a bug, please contact us at the address support@mikroe.com. Please include the following information in your bug report:

- Your operating system
- Version of mikroBasic
- Code sample
- Description of a bug

CONTACT US:

mikroElektronika

Voice: + 381 (11) 30 66 377, + 381 (11) 30 66 378

Fax: + 381 (11) 30 66 379

Web: www.mikroe.com

E-mail: office@mikroe.com

Support: support@mikroe.com

dsPIC30/33 and PIC24, PICmicro and MPLAB is a Registered trademark of Microchip company. Windows is a Registered trademark of Microsoft Corp. All other trade and/or services marks are the property of the respective owners.

mikroBASIC User's manual





Table of Contents


CHAPTER 1	mikroBasic IDE
CHAPTER 2	Building Applications
CHAPTER 3	mikroBasic Language Reference
CHAPTER 4	mikroBasic Libraries

QUICK OVERVIEW	1
Code Editor	3
Code Assistant [CTRL+SPACE]	4
Parameter Assistant [CTRL+SHIFT+SPACE]	4
Routines List	5
Auto Correct	6
Comment/Uncomment	6
Bookmarks	6
Goto Line	6
CODE EXPLORER	7
Software Simulator	8
Watch Window	9
Stopwatch Window	11
RAM Window	11
ERROR WINDOW	13
STATISTICS	14
Memory Usage Window	14
Procedures (Graph) Window	14
Procedures (Locations) Window	15
RAM Window	15
ROM Window	16
INTEGRATED TOOLS	17
USART Terminal	17
ASCII Chart	18
7 Segment Display Decoder	19
Filter Designer	20
UDP Terminal	21
Graphic LCD Bitmap Editor	22
LCD Custom Character	23
KEYBOARD SHORTCUTS	24



PROJECTS	.28
New Project	.28
Editing Project	.29
SOURCE FILES	.30
Search Paths	.30
Managing Source Files	.30
Compilation	.32
ERROR MESSAGES	.33
Compiler Error Messages	.33
Hint and Warning Messages	.36
Linker Error Messages	.37
mikroICD (In-Circuit Debugger)	.38
mikroICD Debugger Options	.39
mikroICD Debugger Example	.40
mikroICD (In-Circuit Debugger) Overview	.44
mikroBasic SPECIFICS	.50
Predefined Globals and Constants	.50
Accessing Individual Bits	.51
Interrupts	.52
Code Optimization	.53
Creating User's Libraries	.54
dsPIC30/33 and PIC24 Specifics	.55
LEXICAL ELEMENTS	.56
Whitespace	.56
Comments	.57
TOKENS	.58
LITERALS	.59
Floating Point Literals	.60
Character Literals	.61
String Literals	.61

IDENTIFIERS	.64
Case Sensitivity	.64
Uniqueness and Scope	.64
Identifier Examples	.64
PUNCTUATORS	.65
Brackets	.65
Parentheses	.65
Colon	.66
Dot	.66
Organization of Main Module	.67
Organization of Other Modules	.68
SCOPE AND VISIBILITY	.70
Scope	.70
Visibility	.70
MODULES	.71
Include Clause	.71
Main Module	.72
VARIABLES	.74
Variables and dsPIC30/33 and PIC24	.74
CONSTANTS	.75
LABELS	.76
SYMBOLS	.77
FUNCTIONS AND PROCEDURES	.78
Functions	.78
Procedures	.79
TYPES	.81
Type Categories	.81
SIMPLE TYPES	.82
ARRAYS	.83



STRINGS	.84
POINTERS	.85
STRUCTURES	.86
Structure Member Access	.87
TYPES CONVERSIONS	.88
Implicit Conversion	.88
Explicit Conversion	.89
OPERATORS	.90
Operators Precedence and Associativity	.90
Arithmetic Operators	.91
Bitwise Operators	.93
Boolean Operators	.97
EXPRESSIONS	.98
STATEMENTS	.99
Assignment Statements	.99
Conditional Statements	.100
Iteration Statements (Loops)	.104
Jump Statements	.107
asm Statement	.111
DIRECTIVES	.112
Compiler Directives	.112
Linker Directives	.114
Chr	.117
BUILT-IN ROUTINES	.117
ClearBit	.118
SetBit	.118
Ord	.118
Dec	.119
Inc	.119
TestBit	.119

Delay_ms	120
Delay_us	120
VDelay_ms_p24_p33	121
VDelay_ms_p30	121
Clock_Mhz	122
Clock_Khz	122
Delay_Cyc	122
Get_Fosc_kHz	123
LIBRARY ROUTINES	124
Library Routines	125
ADC Library	125
Adc_Read	126
Adc1_Read	127
Adc2_Read	128
Adc_Read	129
Library Example	129
Hardware Connection	131
Library Routines	132
Advanced SPI Ethernet Library	132
EthSetGateWayAddr	135
EthSetIPMask	135
EthSetMACAddr	135
EthSetIPAddr	135
MACIsTxReady	136
MACInit	136
EthInit	136
MACGet	137
MACGetHeader	137
MACDiscardRx	138
MACGetArray	138
MACPut	139

MACPutHeader	139
MACPutArray	140
MACFlush	140
MACSetRxBuffer	141
MACDiscardTx	141
MACSetTxBuffer	142
MACReserveTxBuffer	143
MACSetDuplex	144
MACGetFreeRxSize	144
ARPPut	145
ARPGet	145
IPIsTxReady	146
ARPInit	146
IPSetTxBuffer	147
IPPutArray	148
IPPutHeader	148
IPGetHeader	149
IPGetArray	150
IPSetRxBuffer	151
ICMPPut	152
ICMPIsTxReady	152
ICMPGet	153
TCPListen	154
TCPInit	154
TCPConnect	155
TCPIsConnected	156
TCPIsPutReady	157
TCPDisconnect	157
TCPFlush	158
TCPPut	158
TCPIsGetReady	159


x

page

TCPGet	159
TCPGetArray	160
TCPDiscard	160
TCPTick	161
TCPProcess	161
UDPOpen	162
UDPInit	162
UDPClose	163
UDPIsPutReady	164
UDPFlush	165
UDPPut	165
UDPGet	166
UDPIsGetReady	166
UDPProcess	167
UDPDiscard	167
UDPOpenSocket	168
UDPRead	168
UDPWrite	168
HTTPServer	169
HTTPInit	169
StackTask	169
StackInit	169
Library Example	170
Hardware Connection	175
Button	176
Button Library	176
CAN Library	177
Library Routines	177
CAN1SetOperationMode	178
CAN1GetOperationMode	179
CAN1Initialize	180

CAN1SetBaudRate	181
CAN1SetMask	182
CAN1SetFilter	183
CAN1Read	184
CAN1Write	185
CAN2SetOperationMode	186
CAN2GetOperationMode	187
CAN2Initialize	188
CAN2SetBaudRate	189
CAN2SetMask	190
CAN2SetFilter	191
CAN2Read	192
CAN2Write	193
CAN Constants	194
Library Example	197
Hardware Connection	199
Library Routines	200
CANSPI Library	200
CANSPI1SetOperationMode	201
CANSPI1GetOperationMode	202
CANSPI1Init	203
CANSPI1SetBaudRate	204
CANSPI1SetMask	205
CANSPI1SetFilter	206
CANSPI1Read	207
CANSPI1Write	208
CANSPI2GetOperationMode	209
CANSPI2SetOperationMode	209
CANSPI2Init	210
CANSPI2SetBaudRate	211
CANSPI2SetMask	212

CANSPI2SetFilter	.213
CANSPI2Read	.214
CANSPI2Write	.215
CANSPI Constants	.216
Library Example	.220
Hardware Connection	.223
Library Routines	.224
Compact Flash Library	.224
Cf_Init	.225
Cf_Enable	.226
Cf_Detect	.226
Cf_Read_Init	.227
Cf_Disable	.227
Cf_Read_Byte	.228
Cf_Write_Init	.228
Cf_Read_Sector	.229
Cf_Write_Byte	.229
Cf_Write_Sector	.230
Cf_Fat_Init	.231
Cf_Fat_QuickFormat	.232
Cf_Fat_Assign	.233
Cf_Fat_Read	.234
Cf_Fat_Reset	.234
Cf_Fat_Delete	.235
Cf_Fat_Append	.235
Cf_Fat_Rewrite	.235
Cf_Fat_Set_File_Date	.236
Cf_Fat_Write	.236
Cf_Fat_Get_File_Size	.237
Cf_Fat_Get_File_Date	.237
Cf_Fat_Get_Swap_File	.238



Library Example	240
Hardware Connection	245
Library Routines :	246
DSP Library	246
IIR_Radix	247
FIR_Radix	247
FFT	248
IFFT	249
VectorPower	250
Vector_Set	250
BitReverseComplex	250
VectorScale	251
Vector_Subtract	251
Vector_Multiply	252
Vector_Negate	252
Vector_Max	253
Vector_Min	253
Vector_Correlate	254
Vector_Dot	254
Vector_Add	255
Vector_Convolve	255
Matrix_Subtract	256
Matrix_Transpose	256
Matrix_Multiply	257
Matrix_Scale	257
Matrix_Add	258
ECAN Library	259
Library Routines	260
ECAN1DmaChannellnit	261
ECAN1GetOperationMode	262
ECAN1SetOperationMode	262

ECAN1Initialize	.263
ECAN1FilterDisable	.264
ECAN1SelectTxBuffers	.264
ECAN1SetBufferSize	.265
ECAN1FilterEnable	.265
ECAN1SetBaudRate	.266
ECAN1SetMask	.267
ECAN1SetFilter	.268
ECAN1Read	.269
ECAN1Write	.270
ECAN2DmaChannellnit	.271
ECAN2SetOperationMode	.272
ECAN2Initialize	.273
ECAN2FilterDisable	.274
ECAN2SelectTxBuffers	.274
ECAN2SetBufferSize	.275
ECAN2FilterEnable	.275
ECAN2SetBaudRate	.276
ECAN2SetMask	.277
ECAN2SetFilter	.278
ECAN2Read	.279
ECAN2Write	.280
ECAN Constants	.281
Library Example	.285
Hardware Connection	.288
Eeprom_Erase	.289
Library Routines	.289
EEPROM Library	.289
Eeprom_Read	.290
Eeprom_Erase_Block	.290
Eeprom_Write_Block	.291

Eeprom_Write	.291
Library Example	.292
Flash Memory Library	.294
Library Routines	.295
Flash_Write_Block	.296
Flash_Erase32	.296
Flash_Write_Compact	.297
Flash_Write_Init	.298
Flash_Write_Loadlatch4	.299
Flash_Write_Loadlatch4_Compact	.300
Flash_Write_DoWrite	.301
Flash_Read4_Compact	.302
Flash_Read4	.302
Flash_Write	.303
Flash_Erase	.303
Flash_Write_Compact	.304
Flash_Read_Compact	.305
Flash_Read	.305
Library Example	.306
Library Routines	.309
GLCD Library	.309
Glcd_Init	.310
Glcd_Config	.311
Glcd_Set_X	.312
Glcd_Set_Side	.312
Glcd_Read_Data	.313
Glcd_Set_Page	.313
Glcd_Fill	.314
Glcd_Write_Data	.314
Glcd_Line	.315
Glcd_Dot	.315

Glcd_H_Line	.316
Glcd_V_Line	.316
Glcd_Box	.317
Glcd_Rectangle	.317
Glcd_Set_Font	.318
Glcd_Circle	.318
Glcd_Write_Char	.319
Glcd_Image	.320
Glcd_Write_Text	.320
Library Example	.321
Hardware Connection	.323
Library Routines	.324
I2C Library	.324
I2C1_Start	.325
I2C1_Init	.325
I2C1_Read	.326
I2C1_Wait_For_Idle	.326
I2C1_Restart	.326
I2C1_Stop	.327
I2C1_Write	.327
I2C2_Init	.328
I2C2_Wait_For_Idle	.329
I2C2_Read	.329
I2C2_Restart	.329
I2C2_Stop	.330
I2C2_Write	.330
I2C_Init	.331
I2C_Restart	.332
I2C_Start	.332
I2C_Read	.333
I2C_Wait_For_Idle	.333

I2C_Stop	334
I2C_Write	334
Library Example	335
Hardware Connection	336
Keypad_Key_Press	337
Keypad_Init	337
Library Routines	337
Keypad Library	337
Keypad_Key_Click	338
Library Example	338
Hardware Connection	340
Library Routines	341
LCD Custom Library	341
Lcd_Out	342
Lcd_Init	342
Lcd_Chr	343
Lcd_Out_Cp	343
Lcd_Cmd	344
Lcd_Chr_Cp	344
LCD Commands	345
Library Example	346
Hardware Connection	347
Library Routines	348
LCD8 (8-bit interface) Custom Library	348
Lcd8_Init	349
Lcd8_Config	350
Lcd8_Out_Cp	351
Lcd8_Out	351
Lcd8_Chr	352
Lcd8_Chr_Cp	352
Lcd8_Cmd	353


Library Example	.353
LCD Commands	.354
Hardware Connection	.355
Library Routines	.356
Manchester Code Library	.356
Man_Receive_Config	.357
Man_Receive	.358
Man_Receive_Init	.358
Man_Send	.359
Man_Send_Init	.359
Man_Send_Config	.359
Man_Synchro	.360
Library Example	.361
Hardware Connection	.362
Multi Media Card Library	.363
Mmc_Init	.364
Library Routines	.364
Mmc_Write_Sector	.365
Mmc_Read_Sector	.365
Mmc_Read_Csd	.366
Mmc_Read_Cid	.366
Mmc_Fat_Init	.367
Mmc_Fat_QuickFormat	.368
Mmc_Fat_Assign	.369
Mmc_Fat_Read	.370
Mmc_Fat_Reset	.370
Mmc_Fat_Delete	.371
Mmc_Fat_Rewrite	.371
Mmc_Fat_Append	.371
Mmc_Set_File_Date	.372
Mmc_Fat_Write	.372

Mmc_Fat_Get_File_Size	.373
Mmc_Fat_Get_File_Date	.373
Mmc_Fat_Get_Swap_File	.374
Library Example	.376
Hardware Connection	.382
Library Routines	.383
OneWire Library	.383
Ow_Read	.384
Ow_Reset	.384
Ow_Write	.385
Library Example	.386
Hardware Connection	.388
Library Routines	.389
Port Expander Library	.389
Expander_Init	.390
Expander_Write_Byte	.391
Expander_Read_Byte	.391
Expander_Read_PortA	.392
Expander_Read_PortB	.393
Expander_Read_PortAB	.394
Expander_Write_PortA	.395
Expander_Write_PortB	.396
Expander_Write_PortAB	.397
Expander_Set_DirectionPortA	.398
Expander_Set_DirectionPortB	.398
Expander_Set_DirectionPortAB	.399
Expander_Set_PullUpsPortA	.399
Expander_Set_PullUpsPortAB	.400
Expander_Set_PullUpsPortB	.400
Library Example	.401
Hardware Connection	.402

xx

page

Ps2_Init	.403
Library Routines	.403
PS/2 Library	.403
Ps2_Config	.404
Ps2_Key_Read	.405
Special Function Keys	.406
Library Example	.407
Pwm_Init	.408
Library Routines	.408
PWM Library	.408
Pwm_Set_Duty	.409
Pwm_Start	.409
Pwm_Stop	.410
Library Example	.411
Hardware Connection	.412
Library Routines	.413
PWM Motor Library	.413
Pwm_Mc_Init	.414
Pwm_Mc_Set_Duty	.415
Pwm_Mc_Stop	.416
Pwm_Mc_Start	.416
Library Example	.417
Hardware Connection	.418
RS-485 Library	.419
Library Routines	.419
RS485Master_Init	.420
RS485Master_Receive	.420
RS485Slave_Init	.421
RS485Master_Send	.421
RS485Slave_Send	.422



RS485Slave_Receive	.422
Message format and CRC calculations	.423
Library Example	.424
Hardware Connection	.426
Soft_I2C_Init	.427
Library Routines	.427
Software I2C Library	.427
Soft_I2C_Read	.428
Soft_I2C_Start	.428
Soft_I2C_Stop	.429
Soft_I2C_Write	.429
Library Example	.430
Soft_Spi_Config	.433
Library Routines	.433
Software SPI Library	.433
Soft_Spi_Init	.434
Soft_Spi_Read	.434
Library Example	.435
Soft_Spi_Write	.435
Soft_Uart_Init	.436
Library Routines	.436
Software UART Library	.436
Soft_Uart_Write	.437
Soft_Uart_Read	.437
Library Example	.438
Sound_Play	.439
Sound_Init	.439
Library Routines	.439
Sound Library	.439
Hardware Connection	.440
Library Example	.440

Library Routines	.441
SPI Library	.441
Spi1_Init	.442
Spi1_Init_Advanced	.443
Spi1_Read	.445
Spi2_Init	.446
Spi1_Write	.446
Spi2_Init_Advanced	.447
Spi2_Read	.449
Spi_Init	.450
Spi2_Write	.450
Spi_Init_Advanced	.451
Spi_Read	.453
Spi_Set_Active	.454
Spi_Write	.454
Library Example	.455
Hardware Connection	.456
Library Routines	.457
SPI Ethernet Library	.457
SPI_Ethernet_doPacket	.458
SPI_Ethernet_Init	.458
SPI_Ethernet_getByte	.459
SPI_Ethernet_putByte	.459
SPI_Ethernet_UserTCP	.460
SPI_Ethernet_UserUDP	.461
Library Example	.462
Hardware Connection	.464
Library Routines	.465
SPI Graphic LCD Library	.465
Spi_Glcd_Config	.466
Spi_Glcd_Config	.466

Spi_Glcd_Set_Page	.467
Spi_Glcd_Set_Side	.467
Spi_Glcd_Read_Data	.468
Spi_Glcd_Set_X	.468
Spi_Glcd_Fill	.469
Spi_Glcd_Write_Data	.469
Spi_Glcd_Line	.470
Spi_Glcd_Dot	.470
Spi_Glcd_H_Line	.471
Spi_Glcd_V_Line	.471
Spi_Glcd_Box	.472
Spi_Glcd_Rectangle	.472
Spi_Glcd_Circle	.473
Spi_Glcd_Set_Font	.474
Spi_Glcd_Write_Char	.475
Spi_Glcd_Image	.476
Spi_Glcd_Write_Text	.476
Library Example	.477
Hardware Connection	.479
Library Routines	.480
SPI LCD Library (4-bit interface)	.480
Spi_Lcd_Init	.481
Spi_Lcd_Config	.481
Spi_Lcd_Out_Cp	.482
Spi_Lcd_Out	.482
Spi_Lcd_Chr_Cp	.483
Spi_Lcd_Chr	.483
Library Example (default pin settings)	.484
Spi_Lcd_Cmd	.484
LCD Commands	.485
Hardware Connection	.486

Library Routines	.487
SPI LCD8 (8-bit interface) Library	.487
Spi_Lcd8_Init	.488
Spi_Lcd8_Config	.488
Spi_Lcd8_Out_Cp	.489
Spi_Lcd8_Out	.489
Spi_Lcd8_Chrcp	.490
Spi_Lcd8_Chrc	.490
Library Example (default pin settings)	.491
Spi_Lcd8_Cmd	.491
LCD Commands	.492
Hardware Connection	.493
SPI T6963C Graphic LCD Library	.494
Library Routines	.495
Spi_T6963C_Init	.496
Spi_T6963C_writeCommand	.497
Spi_T6963C_writeData	.497
Spi_T6963C_fill	.498
Spi_T6963C_waitReady	.498
Spi_T6963C_setPtr	.498
Spi_T6963C_dot	.499
Spi_T6963C_write_char	.500
Spi_T6963C_write_text	.501
Spi_T6963C_rectangle	.502
Spi_T6963C_line	.502
Spi_T6963C_circle	.503
Spi_T6963C_box	.503
Spi_T6963C_sprite	.504
Spi_T6963C_image	.504
Spi_T6963C_set_cursor	.505
Spi_T6963C_setBit	.505

Spi_T6963C_clearBit	.505
Spi_T6963C_displayTxtPanel	.506
Spi_T6963C_displayGrPanel	.506
Spi_T6963C_negBit	.506
Spi_T6963C_panelFill	.507
Spi_T6963C_setTxtPanel	.507
Spi_T6963C_setGrPanel	.507
Spi_T6963C_cursor_height	.508
Spi_T6963C_txtFill	.508
Spi_T6963C_grFill	.508
Spi_T6963C_cursor	.509
Spi_T6963C_text	.509
Spi_T6963C_graphics	.509
Spi_T6963C_cursor_blink	.510
Library Example	.510
Hardware Connection	.514
T6963C Graphic LCD Library	.515
Library Routines	.516
T6963C_Init	.517
T6963C_writeCommand	.518
T6963C_writeData	.518
T6963C_fill	.519
T6963C_waitReady	.519
T6963C_setPtr	.519
T6963C_dot	.520
T6963C_write_char	.521
T6963C_write_text	.522
T6963C_rectangle	.523
T6963C_line	.523
T6963C_circle	.524
T6963C_box	.524

T6963C_sprite	.525
T6963C_image	.525
T6963C_setBit	.526
T6963C_clearBit	.526
T6963C_set_cursor	.526
T6963C_displayTxtPanel	.527
T6963C_displayGrPanel	.527
T6963C_negBit	.527
T6963C_panelFill	.528
T6963C_setTxtPanel	.528
T6963C_setGrPanel	.528
T6963C_cursor_height	.529
T6963C_txtFill	.529
T6963C_grFill	.529
T6963C_cursor	.530
T6963C_text	.530
T6963C_graphics	.530
Library Example	.531
T6963C_cursor_blink	.531
Hardware Connection	.536
Library Routines	.537
UART Library	.537
Uart1_Init	.538
Uart1_Init_Advanced	.539
Uart1_Read_Char	.540
Uart1_Data_Ready	.540
Uart1_Read_Text	.541
Uart1_Write_Text	.542
Uart1_Write_Char	.542
Uart2_Init	.543
Uart2_Init_Advanced	.544

Uart2_Read_Char	.545
Uart2_Data_Ready	.545
Uart2_Read_Text	.546
Uart2_Write_Char	.547
Uart2_Write_Text	.547
Uart_Init	.548
Uart_Init_Advanced	.549
Uart_Read_Char	.550
Uart_Data_Ready	.550
Uart_Read_Text	.551
Uart_Write_Char	.552
Uart_Write_Text	.552
Uart_Set_Active	.553
Library Example	.554
Hardware Connection	.555
Library Routines	.556
Conversions Library	.556
ShortToStr	.557
ByteToStr	.557
WordToStr	.558
WordToStrWithZeros	.558
LongintToStr	.559
IntToStr	.559
LongWordToStr	.560
WordToHex	.560
FloatToStr	.561
StrToWord	.562
StrToInt	.562
Bcd2Dec16	.563
Dec2Bcd	.563
Dec2Bcd16	.564


acos	.565
Library Routines	.565
Math Library	.565
ceil	.566
atan2	.566
atan	.566
asin	.566
fabs	.567
exp	.567
cosh	.567
cos	.567
log	.568
ldexp	.568
frexp	.568
floor	.568
sin	.569
pow	.569
modf	.569
log10	.569
tanh	.570
tan	.570
sqrt	.570
sinh	.570
Library Routines	.571
Setjmp	.571
Setjmp Library	.571
Longjmp	.572
Library Example	.573
String Library	.574
Memcmp	.575
Memchr	.575

Memset	.576
Memmove	.576
Memcpy	.576
Strcmp	.577
Strchr	.577
Strcat	.577
Strlen	.578
Strcspn	.578
Strcpy	.578
Strncpy	.579
Strncmp	.579
Strncat	.579
Strstr	.580
Strspn	.580
Strrchr	.580
Strpbrk	.580
Time_dateToEpoch	.581
Library Routines	.581
Time Library	.581
Time_dateDiff	.582
Time_epochToDate	.582
Library Example	.583
TimeStruct type definition	.584
Lo	.585
Library Routines	.585
Util Library	.585
Highest	.586
Higher	.586
Hi	.586
Length	.587
HiWord	.587

xxx

page

LoWord	.587
Contact us:	.588




mikroBasic IDE

QUICK OVERVIEW

mikroBasic is a powerful, feature rich development tool for dsPIC30/33 and PIC24 micros. It has been designed to provide the customer with the easiest possible solution for developing applications for embedded systems, without compromising performance or control.

Highly advanced IDE, broad set of hardware libraries, comprehensive documentation and plenty of ready to run examples should be more than enough to get you started in programming dsPIC30/33 and PIC24 microcontrollers.



mikroBasic for dsPIC30/33 and PIC24 is an user-friendly and intuitive environment:

- The Code Editor features adjustable Syntax Highlighting, Code Assistant, Parameters Assistant, Auto Correct for common typos and Code Templates (Auto Complete).
- The Code Explorer (with Keyboard shortcut browser and Quick Help browser) is at your disposal for easier project management.
- The Error Window displays all errors detected during compiling and linking.
- The source-level Software Simulator lets you debug executable logic step-by-step by watching the program flow.
- The New Project Wizard is used to create a project in a fast, reliable, and easy way.
- Help files are syntax and context sensitive.
- Like in any modern Windows application, you may customize the layout of mikroBasic for dsPIC30/33 and PIC24 to suit your needs best.

CODE EDITOR

The Code Editor is an advanced text editor fashioned to satisfy needs of professionals. General code editing is the same as working with any standard text-editor, including familiar Copy, Paste and Undo actions, common for Windows environment.


Advanced Editor Features:

- Adjustable Syntax Highlighting
- Code Assistant
- Parameter Assistant
- Code Templates (Auto Complete)
- Auto Correct for common typos
- Bookmarks and Goto Line



Tools Icon.


You can configure the Syntax Highlighting, Code Templates and Auto Correct from the Editor Settings dialog. To access the Settings, click **Tools > Preferences** from the drop-down menu, click the Preferences Icon or press F12 key.



Code Assistant [CTRL+SPACE]

If you type the first few letters of a word and then press Ctrl+Space, all valid identifiers matching the letters you have typed will be shown in a floating panel (see the image below). Now you can keep typing to narrow the choice, or you can select one from the list using the keyboard arrows and Enter.

ma



Parameter Assistant [CTRL+SHIFT+SPACE]


The Parameter Assistant will be automatically invoked when you open parenthesis “(” or press Shift+Ctrl+Space. If the name of a valid function precedes parenthesis, then the expected parameters will be displayed in a floating panel. As you type the actual parameter, the next expected parameter becomes bold.

channel as word

Adc_Read (|

Routines List

If you press Ctrl+L, the Routines List Window will appear. All valid functions and procedures will be listed in this window (see the image below). Select the routine and double-click it or press Enter to move to the definition of the selected routine.



Code Templates [CTR+J]

You can insert the Code Template by typing the name of a template (for instance, proc), then press Ctrl+J and the Code Editor will automatically generate a code.



Tools Icon.

You can add your own templates to the list. Select **Tools > Preferences** from the drop-down menu, or click the Preferences Icon and then select the Auto Complete Tab. Here you can enter the appropriate keyword, description and code of your template.



Tools Icon.

Auto Correct

The Auto Correct feature corrects common typing mistakes. To access the list of recognized typos, select **Tools > Preferences** from the drop-down menu, or click the Preferences Icon and then select the Auto Correct Tab. You can also add your own preferences to the list.



Comment /
Uncomment Icon.

Comment/Uncomment

Also, the Code Editor has a feature to comment or uncomment the selected code by simple click of a mouse, using the Comment Icon and Uncomment Icon from the Code Toolbar..

Bookmarks

Bookmarks make navigation through a large code easier.

To set a bookmark, use Ctrl+Shift+number.

To jump to a bookmark, use Ctrl+number.

Goto Line

The Goto Line option makes navigation through a large code easier.

Use the shortcut Ctrl+G to activate this option.


CODE EXPLORER

The Code Explorer is placed to the left of the main window by default and gives clear view of each item declared inside the source code. You can jump to a declaration of any item by double clicking it. To expand/collapse the treeview in the Code Explorer, use the icon .



Collapse/Expand
All Icon.

Also, there are two more tab windows available in the Code Explorer. QHelp Tab lists all available built-in and library functions, for a quick reference. Double-clicking a routine in the QHelp view opens the relevant Help topic. The Keyboard Tab lists all available keyboard shortcuts in mikroBasic for dsPIC30/33 and PIC24.



Software Simulator



Start Debugger.

The Source-level Software Simulator is an integral component of the mikroBasic for dsPIC30/33 and PIC24 environment. It is designed to simulate operations of the Microchip dsPIC30/33 and PIC24 MCUs and assist the users in debugging Basic code written for these devices.

After you have successfully compiled your project, you can run the Software Simulator by selecting **Run > Start Debugger** from the drop-down menu, or by clicking the Start Debugger Icon . Starting the Software Simulator makes more options available: Step Into, Step Over, Step Out, Run to Cursor, etc. Line that is to be executed is color highlighted (blue by default).

Note: The Software Simulator simulates the program flow and execution of instruction lines, but it cannot fully emulate dsPIC30/33 and PIC24 device behavior, i.e. it doesn't update timers, interrupt flags, etc.

Name	Description	Function Key
Start Debugger	Start Software Simulator.	[F9]
Run/Pause Debugger	Run or pause Software Simulator.	[F6]
Stop Debugger	Stop Software Simulator.	[Ctrl+F2]
Toggle Breakpoints	Toggle breakpoint at the current cursor position. To view all breakpoints, select Run > View Breakpoints from the drop-down menu. Double clicking an item in the Breakpoints Window List locates the breakpoint.	[F5]
Run to cursor	Execute all instructions between the current instruction and cursor position.	[F4]
Step Into	Execute the current Basic (single or multi-cycle) instruction, then halt. If the instruction is a routine call, enter the routine and halt at the first instruction following the call.	[F7]
Step Over	Execute the current Basic (single or multi-cycle) instruction, then halt.	[F8]
Step Out	Execute all remaining instructions in the current routine, return and then halt.	[Ctrl+F8]

Watch Window

The Software Simulator Watch Window is the main Software Simulator window which allows you to monitor program items while simulating your program. To show the Watch Window, select **View > Debug Windows > Watch Window** from the drop-down menu.


The Watch Window displays variables and registers of the MCU, along with their addresses and values.

There are two ways of adding variable/register to the watch list:




ADD Button

- by its real name (variable's name in "Basic" code). Just select desired variable/register from **Select variable from list** drop-down menu and click the Add Button .
- by its name ID (assembly variable name). Simply type name ID of the variable/register you want to display into **Search the variable by assembly name** box and click the Add Button .



Remove Button

Variables can also be removed from the Watch Window, just select the variable that you want to remove and then click the Remove Button.





Add All Button

Add All Button adds all variables.




Remove All Button

Remove All Button removes all variables.

You can also expand/collapse complex variables, i.e. struct type variables, strings...


Values are updated as you go through the simulation. Recently changed items are colored red.



Properties Button

Double clicking a variable or clicking the Properties Button opens the Edit Value window in which you can assign a new value to the selected variable/register. Also, you can choose the format of variable/register representation between decimal, hexadecimal, binary, float or character. All representations except float are unsigned by default. For signed representation click the check box next to the ***Signed*** label.

An item's value can be also changed by double clicking item's value field and typing the new value directly.



Stopwatch Window

The Software Simulator Stopwatch Window is available from the drop-down menu, **View > Debug Windows > Stopwatch**.

The Stopwatch Window displays a *current count* of cycles/time since the last Software Simulator action. *Stopwatch* measures the execution time (number of cycles) from the moment Software Simulator has started and can be reset at any time. Delta represents the number of cycles between the lines where Software Simulator action has started and ended.

Note: The user can change the clock in the Stopwatch Window, which will recalculate values for the latest specified frequency. Changing the clock in the Stopwatch Window does not affect actual project settings – it only provides a simulation.



RAM Window

The Software Simulator RAM Window is available from the drop-down menu, **View > Debug Windows > RAM**.


The RAM Window displays a map of MCU's RAM, with recently changed items colored red. You can change value of any field by double-clicking it.

RAM									
	00	02	04	06	08	0A	0C	0E	ASCII
0000	0BFE	0000	0000	0000	0000	0000	0000	0000	p<VT>
0010	0000	0000	0000	0000	0000	0000	0000	0800	<BS>
0020	0BFE	0000	0000	0000	0000	0000	0000	0B66	p<VT>f<VT>
0030	0000	0000	0000	0000	0000	0000	0000	0000	
0040	0000	0000	0800	0000	0000	0000	0000	0000	...<BS>
0050	0000	0000	0000	0000	0000	0000	0000	0000	
0060	0000	0000	0000	0000	0000	0000	0000	0000	
0070	0000	0000	0000	0000	0000	0000	0000	0000	
0080	0000	0000	0000	0000	0000	0000	0000	0000	
0090	0000	0000	0000	0000	0000	0000	0000	0000	
00A0	0000	0000	0000	0000	0000	0000	0000	0000	
00B0	0000	0000	0000	0000	0000	0000	0000	0000	
00C0	0000	0000	0000	0000	0000	0000	0000	0000	
00D0	0000	0000	0000	0000	0000	0000	0000	0000	
00E0	0000	0000	0000	0000	0000	0000	0000	0000	
00F0	0000	0000	0000	0000	0000	0000	0000	0000	
0100	0000	0000	0000	0000	0000	0000	0000	0000	

ERROR WINDOW

In case that errors are encountered during compiling, the compiler will report them and won't generate a hex file. The Error Window will be prompted at the bottom of the main window by default.

The Error Window is located under message tab, and displays location and type of errors the compiler has encountered. The compiler also reports warnings and hints, but these do not affect the output. Only errors can interfere with the generation of hex.



Double click the message line in the Error Window to highlight the line where the error has been encountered.

Right-Click the message line to enable copying the message text to Clipboard.

For more information on errors recognized by the compiler consult the Error Messages.

STATISTICS




Statistics Icon.

After successful compilation, you can review statistics of your code. Select **View > View Statistics** from the drop-down menu, or click the Statistics Icon . There are five tab windows:


Memory Usage Window

Provides overview of RAM and ROM usage in form of histogram.




Procedures (Graph) Window

Displays procedures and functions in form of histogram, according to their memory allotment.



Procedures (Locations) Window

Displays how procedures and functions are distributed in microcontroller's memory.



RAM Window


Summarizes all GPRs and SFRs and their addresses. It also displays symbolic names of variables and their addresses.

The RAM window displays the addresses and symbolic names of General purpose registers (GPR) and Special function registers (SFR).

General purpose registers (GPR)		Special function registers (SFR)	
Address	Register	Address	Register
0x0C62	__lib_lcdcustom___mdb7	0x0000	w0
0x0C64	__lib_lcdcustom___mdb6	0x0002	w1
0x0C66	__lib_lcdcustom___mdb5	0x0004	w2
0x0C68	__lib_lcdcustom___mdb4	0x0006	w3
0x0C6A	__lib_lcdcustom___mrs	0x0008	w4
0x0C6C	__lib_lcdcustom___mrw	0x000A	w5
0x0C6E	__lib_lcdcustom___menable	0x000C	w6
0x0C70	__lib_lcdcustom_dataat	0x000E	w7
0x0C72	__lib_lcdcustom_ctllat	0x0010	w8
0x0C74	__lib_lcdcustom_lcdcmdstatus	0x0012	w9
0x0C76	__lib_lcdcustom_tmprdata	0x0014	w10
0x0C78	__lib_lcdcustom_tmprdata	0x0016	w11
0x0C78	__lib_lcdcustom_tmprdata	0x0018	w12
0x0C78	__lib_lcdcustom_tmprdata	0x001A	w13
0x0C78	__lib_lcdcustom_tmprdata	0x001C	w14
0x0C78	__lib_lcdcustom_tmprdata	0x001E	w15
0x0C78	__lib_lcdcustom_tmprdata	0x02C8	PORTB
0x0C78	__lib_lcdcustom_tmprdata	0x02D4	PORTD

ROM Window

Lists op-codes and their addresses in form of a human readable hex code.




INTEGRATED TOOLS



USART
Terminal
Icon

USART Terminal

mikroBasic for dsPIC30/33 and PIC24 includes the USART communication terminal for RS232 communication. You can launch it from the drop-down menu **Tools > USART Terminal** or by clicking the Terminal Icon.





ASCII
Chart
Icon


ASCII Chart

The ASCII Chart is a handy tool, particularly useful when working with LCD display. You can launch it from the drop-down menu **Tools** > **Ascii chart** or by clicking the View ASCII Chart Icon.

ASCII Chart																
	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	NUL	SOH	STX	ETX	EOT	ENQ	ACK	BEL	BS	HT	LF	VT	FF	CR	SO	SI
1	DLE	DC1	DC2	DC3	DC4	NAK	SYN	ETB	CAN	EM	SUB	ESC	FS	GS	RS	US
2	SPC	!	"	#	\$	%	—	'	(	)	*	+	,	-	.	/
3	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
4	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
5	P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	_
6	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
7	p	q	r	s	t	u	v	w	x	y	z	{		}	~	DEL
8	€	□	,	f	„	...	†	‡	^	%o	Š	◀	œ	□	Ž	□
9	□	‘	’	“	”	•	—	—	~	™	š	›	œ	□	ž	ÿ
A		i	¢	£	¤	¥	¦	§	¨	©	ª	«	¬	-	®	¯
B	°	±	²	³	´	µ	¶	·	,	¹	º	»	¼	½	¾	¿
C	À	Á	Â	Ã	Ä	Å	Æ	Ç	È	É	Ê	Ë	Ì	Í	Î	Ï
D	Ð	Ñ	Ò	Ó	Ô	Õ	Ö	×	Ø	Ù	Ú	Û	Ü	Ý	Þ	ß
E	à	á	â	ã	ä	å	æ	ç	è	é	ê	ë	ì	í	î	ï
F	ð	ñ	ò	ó	ô	õ	ö	÷	ø	ù	ú	û	ü	ý	þ	ÿ


7 Segment Display Decoder

The 7 Segment Display Decoder is a convenient visual panel which returns decimal/hex value for any viable combination you would like to display on 7seg. Click on the parts of 7 segment image to get the requested value in the edit boxes. You can launch it from the drop-down menu **Tools > Seven Segment Decoder**.




Filter Designer

The Filter designer is a tool for designing FIR and IIR filters. It has an user-friendly visual interface for setting filter parameters. Filter designer output is mikroBasic for dsPIC30/33 and PIC24 compatible code. You can launch it from the drop-down menu **Tools › Filter Designer Tool**.




UDP Terminal

mikroBasic for dsPIC30/33 and PIC24 includes the UDP Terminal. You can launch it from the drop-down menu **Tools > UDP Terminal**.



Graphic LCD Bitmap Editor


mikroBasic for dsPIC30/33 and PIC24 includes the Graphic LCD Bitmap Editor. Output is mikroBasic for dsPIC30/33 and PIC24 compatible code. You can launch it from the drop-down menu **Tools** > **GLCD Bitmap Editor**.



LCD Custom Character

mikroBasic for dsPIC30/33 and PIC24 includes the LCD Custom Character.

Output is mikroBasic for dsPIC30/33 and PIC24 compatible code. You can launch it from the drop-down menu **Tools** > **LCD Custom Character**.



KEYBOARD SHORTCUTS

Below is a complete list of keyboard shortcuts available in mikroBasic for dsPIC30/33 and PIC24 IDE. You can also view keyboard shortcuts in the Code Explorer window, tab Keyboard.

IDE Shortcuts

F1	Help
Ctrl+N	New Unit
Ctrl+O	Open
Ctrl+F9	Compile
Shift+F9	Compile All
F11	Program
Ctrl+F11	Compile and Program
F12	Preferences
Ctrl+Shift+E	Edit Project
Shift+F4	View Breakpoints
Ctrl+Shift+F5	Clear Breakpoints

Basic Editor shortcuts


F3	Find Next
Alt+F3	Find in Files
Ctrl+A	Select All
Ctrl+C	Copy
Ctrl+F	Find
Ctrl+H	Replace
Ctrl+P	Print
Ctrl+S	Save Unit
Ctrl+Shift+S	Save All
Ctrl+V	Paste
Ctrl+X	Cut
Ctrl+Y	Delete Line
Ctrl+Z	Undo
Ctrl+Shift+Z	Redo

Advanced Editor shortcuts

Ctrl+Space	Code Assistant
Ctrl+Shift+Space	Parameters Assistant
Ctrl+D Find	Declaration
Ctrl+E	Incremental Search
Ctrl+G	Goto Line
Ctrl+J	Insert Code Template
Ctrl+L	Procedures List
Ctrl+/ Ctrl+Shift+.	Toggle Line Comment
Ctrl+Shift+,	Comment Code
Ctrl+number	Uncomment Code
Ctrl+Shift+number	Goto Bookmark
Ctrl+Shift+I	Set Bookmark
Ctrl+Shift+U	Indent Selection
TAB	Unindent Selection
Shift+TAB	Indent Selection
Alt+Select	Unindent Selection
Ctrl+Alt+Select	Select Columns
	Select Columns

Debugger Shortcuts

F4	Run to Cursor
F5	Toggle Breakpoint
F6	Run/Pause Debugger
F7	Step Into
F8	Step Over
F9	Start Debugger
Ctrl+F2	Stop Debugger
Ctrl+F5	Add to Watch
Ctrl+F8	Step Out



Building Applications

Creating applications in mikroBasic is easy and intuitive. Project Wizard allows you to set up your project in just few clicks: name your application, select chip, set flags, and get going.

mikroBasic allows you to distribute your projects in as many units as you find appropriate. You can then share your mikroCompiled Libraries (.mcl files) with other developers without disclosing the source code.

PROJECTS

mikroBasic for dsPIC30/33 and PIC24 organizes applications into projects, consisting of a single project file (extension .dbp) and one or more .dbas source files. You can compile source files only if they are a part of the project.

The project file contains the following information:

- project name and optional description,
- target device,
- device flags (config word),
- device clock,
- list of the project source files with paths.


New Project



New Project.

The easiest way to create a project is by means of the New Project Wizard, drop-down menu **Project** › **New Project** or by clicking the New Project Icon . Just fill the dialog with desired values (project name and description, location, device, clock, config word) and mikroBasic for dsPIC30/33 and PIC24 will create an appropriate project file.

There is also a slider for dsPIC30/33 and PIC24 data memory usage. You can specify static and dynamic memory consumption. Static memory is assigned for global variables and dynamic memory is assigned for local variables. Neither static nor dynamic memory can occupy more than 80 % of total data memory space.



Editing Project



Edit Project.

Afterwards, you can change project settings from the drop-down menu **Project** > **Edit Project** or by clicking the Edit Project Icon . You can rename the project, modify its description, change chip, clock, config word, etc.

To delete a project, simply delete the folder in which the project file (extension .dbp) is stored.

SOURCE FILES

Source files containing Basic code should have extension `.dbas`. List of source files relevant to application is stored in project file with extension `.dbp`, along with other project information. You can compile source files only if they are a part of the project.

Search Paths

You can specify your own custom search paths: select **Tools** › **Preferences** from the drop-down menu and then select **Search Path**.

When including source files with the `uses` clause, mikroBasic for dsPIC30/33 and PIC24 will look for the file in the following locations according to this particular order:

1. mikroBasic for dsPIC30/33 and PIC24 installation folder › “defs” folder
2. mikroBasic for dsPIC30/33 and PIC24 installation folder › “uses” folder
3. the project folder (folder which contains the project file `.dbp`)
4. your custom search paths

Managing Source Files

Creating new source file


To create a new source file, do the following:



New File.

1. Select **File** › **New** from the drop-down menu, or press `Ctrl+N`, or click the New File Icon .
2. A new tab will be opened. It is a new source file. Select **File** › **Save As** from the drop-down menu and name it as you wish.

If you use the New Project Wizard, an empty source file named after the project with extension `.dbas`, is created automatically. mikroBasic for dsPIC30/33 and PIC24 does not require you to have a source file named the same as the project, it's just a matter of convenience.



Opening an Existing File



Open File.

1. Select **File** > **Open** from the drop-down menu, or press Ctrl+O, or click the Open File Icon . In Open Dialog browse to the location of the file that you want to open, select it and click the Open button.
2. The selected file is displayed in its own tab. If the selected file is already open, its current Editor tab will become active.

Printing an Open File



Print File.

1. Make sure that the window containing the file that you want to print is the active window.
2. Select **File** > **Print** from the drop-down menu, or press Ctrl+P.
3. In the Print Preview Window, set a desired layout of the document and click the OK button. The file will be printed on the selected printer.

Saving File



Save File.

1. Make sure that the window containing the file that you want to save is the active window.
2. Select **File** > **Save** from the drop-down menu, or press Ctrl+S, or click the Save File Icon .

Saving File Under a Different Name



Save File As.

1. Make sure that the window containing the file that you want to save is the active window.
2. Select **File** > **Save As** from the drop-down menu. The New File Name dialog will be displayed.
3. In this dialog, browse to the folder where you want to save the file.
4. In the File Name field, modify a name of the file that you want to save.
5. Click the Save button.

Closing a File



Close File.

1. Make sure that the tab containing the file that you want to close is the active tab.
2. Select File > Close from the drop-down menu, or right click the tab of the file that you want to close.
3. If the file has been changed since it was last saved, you will be prompted to save your changes.

COMPILATION



Build Project
Icon

Compilation

When you have created a project and written a source code, it's time to compile it. Select **Project** › **Build** from the drop-down menu, or click the Build Project Icon from the Compiler Toolbar.

Progress bar will appear to inform you about the status of compiling. If there are some errors, you will be notified in the Error Window. If no errors are encountered, mikroBasic for dsPIC30/33 and PIC24 will generate output files.

Output Files

Upon successful compilation, mikroBasic for dsPIC30/33 and PIC24 will generate output files in the project folder (a folder which contains the project file .dbp). Output files are summarized below:

Intel HEX file (.hex)

Intel style hex records. Use this file to program dsPIC30/33 and PIC24 MCU.

Binary mikro Compiled Library (.mcl)

mikro Compiled Library. Binary distribution of application that can be included in other projects.

List File (.lst)

Overview of the dsPIC30/33 and PIC24 memory allotment: instruction addresses, registers, routines and labels.

Assembler File (.asm)

Human-readable assembly with symbolic names, extracted from the List File.



View Assembly
Icon.

Assembly View

After compiling the program in mikroBasic for dsPIC30/33 and PIC24, you can click the View Assembly icon or select View › View Assembly from the drop-down menu to review the generated assembly code (.asm file) in a new tab window. Assembly is human-readable with symbolic names. All physical addresses and other information can be found in the Statistics Window or List File (.lst).

ERROR MESSAGES

Compiler Error Messages

Message	Message Number
Error: "%s" is not valid identifier	1
Error: Unknown type "%s"	2
Error: Identifier "%s" was not declared	3
Error: Expected "%s" but "%s" found	4
Error: Argument is out of range	5
Error: Syntax error in additive expression	6
Error: File "%s" not found	7
Error: Invalid command "%s"	8
Error: Not enough parameters	9
Error: Too many parameters	10
Error: Too many characters	11
Error: Actual and formal parameters must be identical	12
Error: Invalid ASM instruction: "%s"	13
Error: Identifier "%s" has been already declared	14
Error: Syntax error in multiplicative expression	15
Error: Definition file for "%s" is corrupted	16

Message	Message Number
Error: ORG directive is currently supported for interrupts only	17
Error: Not enough ROM	18
Error: Not enough RAM	19
Error: External procedure "%s" used in "%s" was not found	20
Error: Internal error: "%s"	21
Error: Unit cannot recursively use itself	22
Error: "%s" cannot be used out of loop	23
Error: Supplied and formal parameters do not match ("%s" to "%s")	24
Error: Constant cannot be assigned to	25
Error: Constant array must be declared as global	26
Error: Incompatible types ("%s" to "%s")	27
Error: Too many characters ("%s")	28
Error: Soft_Uart cannot be initialized with selected baud rate/device clock	29
Error: Main label cannot be used in modules	30
Error: Break/Continue cannot be used out of loop	31
Error: Preprocessor Error: "%s"	32
Error: Expression is too complicated	33

Message	Message Number
Error: Duplicated label "%s"	34
Error: Complex type cannot be declared here	35
Error: Record is empty	36
Error: Unknown type "%s"	37
Error: File not found "%s"	38
Error: Constant parameter cannot be passed by reference	39
Error: Pointer parameter cannot be passed by reference	40
Error: Improper use of operator "%s"	41
Error: Exit cannot be called from the main block	42
Error: Array parameter must be passed by reference	43
Error: Error occured while compiling "%s"	44
Error: Recursive types are not allowed	45
Error: Adding strings is not allowed, use "strcat" procedure instead	46
Error: Cannot declare pointer to array, use pointer to structure which has array field	47
Error: Return value of the function "%s" is not defined	48
Error: Assignment to for loop variable is not allowed	49
Error: "%s" is allowed only in the main program	50

Message	Message Number
Error: Start address of "%s" has already been defined	51
Error: Simple constant cannot have a fixed address	52
Error: Invalid date/time format	53

Hint and Warning Messages

Message	Message Number
Hint: Variable "%s" has been declared, but not used	1
Warning: Variable "%s" is not initialized	2
Warning: Return value of the function "%s" is not defined	3
Hint: Constant "%s" has been declared, but not used	4
Warning: Identifier "%s" overrides declaration in unit "%s"	5
Warning: Generated baud rate is "%s" bps (error = "%s" percent)	6
Warning: Result size may exceed destination array size	7
Warning: Infinite loop	8
Warning: Implicit typecast performed from "%s" to "%s"	9
Hint: Unit "%s" has been recompiled	10
Hint: Variable "%s" has been eliminated by optimizer	11
Warning: Implicit typecast of integral value to pointer	12

Message	Message Number
Warning: Library "%s" was not found in search path	13
Warning: Interrupt context saving has been turned off	14

Linker Error Messages


Message	Message Number
Linker error: "%s" "%s"	1
Warning: Variable "%s" is not initialized	2
Warning: Return value of the function "%s" is not defined	3
Hint: Constant "%s" has been declared, but not used	4
Warning: Identifier "%s" overrides declaration in unit "%s"	5
Linker error: Constant "%s" was not found	6
Linker error: Address of the routine has already been defined	7

mikroICD (In-Circuit Debugger)

The mikroICD is a highly effective tool for **Real-Time debugging** on hardware level. The mikroICD debugger enables you to execute the mikroBasic for dsPIC30/33 and PIC24 program on the host dsPIC30/33 or PIC24 microcontroller and view variable values, Special Function Registers (SFRs), RAM, CODE and EEPROM along with the mikroICD code execution on hardware.


Step No. 1

If you have appropriate hardware and software for using the mikroICD select **mikroICD Debug** Build Type before compiling the project.



Step No. 2

Choosing the mikroICD Debug build type will select the mikroICD Debugger automatically. The Debugger Tool can also be selected from the **Debugger > Select Debugger** drop-down menu.



Compile the project and program dsPIC30/33 or PIC24 MCU.

Step No. 3



Start Debugger

Run the mikroICD by selecting **Run > Start Debugger** from the drop-down menu or by clicking the Start Debugger Icon . Starting Debugger makes more options available: Step Into, Step Over, Run to Cursor, etc. Line that is to be executed is color highlighted (blue by default). There is also notification about the program execution, Watch Window Status Bar will be colored yellow during the program execution.

mikroICD Debugger Options

Name	Description	Function Key
Start Debugger	Start Debugger.	[F9]
Run/Pause Debugger	Run or pause Debugger.	[F6]
Stop Debugger	Stop Debugger.	[Ctrl+F2]
Toggle Breakpoints	Toggle breakpoint at the current cursor position. To view all breakpoints, select Run > View Breakpoints from the drop-down menu. Double clicking an item in the Breakpoints Window List locates the breakpoint.	[F5]
Run to cursor	Execute all instructions between the current instruction and cursor position.	[F4]
Step Into	Execute the current Basic (single or multi-cycle) instruction, then halt. If the instruction is a routine call, enter the routine and halt at the first instruction following the call.	[F7]
Step Over	Execute the current Basic (single or multi-cycle) instruction, then halt.	[F8]
Step Out	Execute all remaining instructions in the current routine, return and then halt.	[Ctrl+F8]

Note: when the mikroICD is halted MCU peripherals are not active.

mikroICD Debugger Example

Here is a step-by-step mikroICD Debugger Example.

Step No. 1

First you have to write a program. By using this example we will show how the mikroICD operates:

```

program LCD4bitTest
dim txt as string[16]
      i as byte
main:
    ADPCFG = $1FFF
    txt = "mikroElektronika"
    Lcd_Init_EasyDsPIC4()
    Lcd_Cmd(LCD_CURSOR_OFF)
    Lcd_Cmd(LCD_FIRST_ROW)
    for i = 1 to 16
      Lcd_Chrc(1, i, txt[i-1])
    next i
end.

```


Step No. 2

After successful compilation and MCU programming press **F9** to start the mikroICD. After the mikroICD initialization a blue active line should appear.

```

20 program LCD4bitTest
  .
  .
  . dim txt as string[16]
  .   i as byte
  .
  .
25 main:
  .   ADPCFG = $1FFF
  .
  .   txt = "mikroElektronika"
  .
  .
30   Lcd_Init_EasyDsPIC4()
  .
  .   Lcd_Cmd(LCD_CURSOR_OFF)
  .   Lcd_Cmd(LCD_FIRST_ROW)
  .
  .
35   for i = 1 to 16
  .     Lcd_Chrc(1, i, txt[i-1])
  .   next i
  . end.
  .

```




Step No. 3

We will debug the program line by line. To execute code line by line press **[F8]**. It is not recommended to the user to use Step Into **[F7]** and Step Over **[F8]** over Delay routines and routines containing delays. In this case the user should use Run to cursor **[F4]** function or Run **[F6]** function combined with Breakpoints.

41


page

```
20 program LCD4bitTest
  .
  . dim txt as string[16]
  .   i as byte
  .
25 main:
26   ADPCFG = $1FFF
  .
  .   txt = "mikroElektronika"
  .
30   Lcd_Init_EasyDsPIC4()
  .
  .   Lcd_Cmd(LCD_CURSOR_OFF)
  .   Lcd_Cmd(LCD_FIRST_ROW)
  .
35   for i = 1 to 16
  .     Lcd_Chrc(1, i, txt[i-1])
  .   next i
  . end.
```



All changes are read from MCU and loaded into the Watch Window. Note that ADPCFG has changed its value to 0x1FFF.

```
20 program LCD4bitTest
  .
  . dim txt as string[16]
  .   i as byte
  .
25 main:
  .   ADPCFG = $1FFF
  .
28   txt = "mikroElektronika"
  .
30   Lcd_Init_EasyDsPIC4()
  .
  .   Lcd_Cmd(LCD_CURSOR_OFF)
  .   Lcd_Cmd(LCD_FIRST_ROW)
  .
35   for i = 1 to 16
  .     Lcd_Chrc(1, i, txt[i-1])
  .   next i
  . end.
```



Step No. 4

Step Into [F7], Step Over [F8] and Step Out [Ctrl+F8] are mikroICD debugger functions that are used in stepping mode. There is also a Real-Time mode supported by the mikroICD. Functions that are used in the Real-Time mode are Run/Pause Debugger [F6] and Run to cursor [F4]. Pressing F4 executes the code until the program reaches the cursor position line.

```

• program LCD4bitTest;
•
• var txt : string[16];
•     i : byte;
25
• begin
•
•     ADPCFG := $1FFF;
30  txt := 'mikroElektronika';
•
•     Lcd_Init_EasyDsPIC4();
•
•     Lcd_Cmd(LCD_CURSOR_OFF);
•
35  Lcd_Cmd(LCD_FIRST_ROW);
•
•     for i := 1 to 16 do
•         Lcd_Chrc(1,i,txt[i-1]);
•
40 end.
```

Name	Value	Address
ADPCFG	0x1FFF	0x02A8
i	34	0x0C89
txt	{...}	0x0C78

PC= 0x00047C Time= 0.00 us


Step No. 5

Run(Pause) Debugger [F6] and Toggle Breakpoints [F5] are mikroICD debugger functions that are used in the Real-Time mode. Pressing **F5** marks the line selected by the user for breakpoint. **F6** executes code until the breakpoint is reached. After reaching that breakpoint Debugger halts. Here in our example we will use breakpoints for writing a word "mikroElektronika" char by char on LCD . Breakpoint is set on `LCD_Chr` and the program will stop every time this function is reached. After reaching breakpoint we must press F6 again to continue the program execution.


```

20 program LCD4bitTest
.
.
. dim txt as string[16]
.   i as byte
.
.
25 main:
.   ADPCFG = $1FFF
.
.   txt = "mikroElektronika"
.
.
30 Lcd_Init_EasyDsPIC4()
.
.
32 | Lcd_Cmd(LCD_CURSOR_OFF)
.   Lcd_Cmd(LCD_FIRST_ROW)
.
.
35 for i = 1 to 16
.   Lcd_Chr(1, i, txt[i-1])
.   next i
. end.
.

```



Breakpoints are divided into two groups: hardware and software breakpoints. The hardware breakpoints are placed in the MCU and provide fastest debugging. Number of hardware breakpoints is limited. There are 4 for the PIC24 and dsPIC33 family while for the dsPIC30 family this number depends on the MCU used. If all hardware breakpoints are used, then the next breakpoint will be software breakpoint. These breakpoints are placed inside the mikroICD and simulate hardware breakpoints. Software breakpoints are much slower than hardware breakpoints. These differences between hardware and software breakpoints are not visible in the mikroICD software but their different timings are quite notable. That's why it is important to know that there are two types of breakpoints.



mikroICD (In-Circuit Debugger) Overview

Watch Window

Debugger Watch Window is the main Debugger window which allows you to monitor program execution. To show the Watch Window, select **Debug Windows** › **Watch Window** from the **View** drop-down menu.


The Watch Window displays variables and registers of the MCU, along with their addresses and values. Values are updated along with the mikroICD code execution on hardware. Recently changed items are coloured red.

There are two ways of adding variable/register to the watch list:



ADD Button

- by its real name (variable's name in "Basic" code). Just select wanted variable/register from **Select variable from list** drop-down menu and click the Add Button .
- by its name ID (assembly variable name). Simply type name ID of the variable/register you want to display into **Search for variable by assembly name** box and click the Add Button .



Remove Button

Variables can also be removed from the Watch Window. You just need to select the variable that you want to remove and click the Remove Button .




Add All Button

Add All Button adds all variables.



Remove All Button


Remove All Button removes all variables.





Double clicking a variable or clicking the Properties Button opens the Edit value window in which you can assign a new value to the selected variable/register. Also, you can choose the format of variable/register representation between decimal, hexadecimal, binary, float or character. All representations except float are unsigned by default. For signed representation click the check box next to the **Signed** label.

An item's value can also be changed by double clicking item's value field and typing the new value directly.




EEPROM Window

To show the mikroICD EEPROM Window, select **Debug Windows > EEPROM** from the **View** drop-down menu.

The EEPROM window shows current content of the MCU's internal EEPROM. There are two action buttons concerning the EEPROM watch window :


- **Flush EEPROM** writes data from the EEPROM window into MCU's internal EEPROM.
- **Read EEPROM** reads data from MCU's internal EEPROM and loads it up into the EEPROM window.



Code Window

To show the mikroICD Code Window, select **Debug Windows** > **Code** from the **View** drop-down menu. The Code window shows code (hex format) written into the MCU. There is an action button concerning the Code window :

Read Code reads code from the MCU and loads it up into the Code Window. Code reading is resources-consuming operation, so the user should wait until the reading is over.




RAM Window

To show the mikroICD RAM window, select **Debug Windows** › **RAM** from the **View** drop-down menu.


The RAM Window displays the map of MCU's RAM, with recently changed items colored red.

The user can edit and change the values in the RAM window whose content will be written to the MCU before the next instruction execution.



Common Errors

- Programming the MCU while the mikroICD is active.
- Debugging Release build version of the program with the mikroICD debugger.
- Debugging program code which has been changed, but has not been compiled and programmed into the MCU.
- Selecting an empty line in the code for Run to cursor [**F4**] and Toggle Breakpoints [**F5**] functions.
- Trying to Step Into [**F7**] the mikroBasic for dsPIC30/33 and PIC24 Library routines. Use Step Over [**F8**] command for these routines



mikroBasic Language Reference

Why BASIC in the first place? The answer is simple: it is legible, easy-to-learn, structured programming language, with sufficient power and flexibility needed for programming microcontrollers. Whether you had any previous programming experience, you will find that writing programs in mikroBasic is very easy. This chapter will help you learn or recollect BASIC syntax, along with the specifics of programming dsPIC30/33 and PIC24 microcontrollers.

mikroBasic SPECIFICS

Predefined Globals and Constants

In order to facilitate dsPIC30/33 and PIC24 programming, mikroBasic for dsPIC30/33 and PIC24 implements a number of predefined globals and constants.

SFRs and related constants

All dsPIC30/33 and PIC24 SFRs are implicitly declared as global variables of volatile word type. These identifiers have an external linkage, and are visible in the entire project. When creating a project, the mikroBasic for dsPIC30/33 and PIC24 will include an appropriate (*.dbas) file from defs folder, containing declarations of available SFRs and constants (such as PORTB, ADPCFG, etc). All identifiers are in upper case, identical to nomenclature in the Microchip datasheets.

For a complete set of predefined globals and constants, look for “Defs” in the mikroBasic for dsPIC30/33 and PIC24 installation folder, or probe the Code Assistant for specific letters (Ctrl+Space in the Code Editor).

Math constants

In addition, several commonly used math constants are predefined in mikroBasic for dsPIC30/33 and PIC24:

PI	=	3.1415926
PI_HALF	=	1.5707963
TWO_PI	=	6.2831853
E	=	2.7182818

Accessing Individual Bits

mikroBasic for dsPIC30/33 and PIC24 allows you to access individual bits of 16-bit variables. Simply use the direct member selector (.) with a variable, followed by a number 0..15, with 15 being the most significant bit.

For example:

```
' If RB0 is set, set RC0:
if PORTB.0 = 1 then
    PORTC.0 = 1
end if
```

There is no need of any special declarations. This kind of selective access is an intrinsic feature of mikroBasic for dsPIC30/33 and PIC24 and can be used anywhere in the code.

Constants with value known in the compile-time can be used instead of numbers 0..15, for example:

```
const pin5 = 5
...
' Set PORTB pin5
PORTB.pin5 = 1
```


Interrupts

The dsPIC30/33 and PIC24 interrupt controller module reduces numerous peripheral interrupt request signals to a single interrupt request signal to the dsPIC30/33 and PIC24 CPU and has the following features:

- Up to 8 processor exceptions and software traps
- 7 user-selectable priority levels
- Interrupt Vector Table (IVT) with up to 62 vectors (dsPIC30) or up to 118 vectors (dsPIC33 and PIC24)
- A unique vector for each interrupt or exception source
- Fixed priority within a specified user priority level
- Alternate Interrupt Vector Table (AIVT) for debug support

ISRs are organized in IVT. ISR is defined as a standard function but with the `org` directive following it, connecting the function with specific interrupt vector. For example `org 0x1A` is IVT address of Timer1 interrupt source of the dsPIC 30F3014 MCU. For more information on IVT refer to the dsPIC30/33 and PIC24 Family Reference Manual.

Function Calls from Interrupt


Calling functions from the interrupt routine is possible. The compiler takes care about the registers being used, both in "interrupt" and in "main" thread, and performs "smart" context-switching between two of them, saving only the registers that have been used in both threads. It is not recommended to use a function call from interrupt. In case of doing that take care of stack depth.

Example

Here is a simple procedure which inverts state of PORTB upon each interrupt from Timer1:

```
program TestTimer1

sub procedure Timer1Int org $1A
    '** it is necessary to clear manually the interrupt flag:
    IFS0 = IFS0 and $FFF7    ' Clear TMR1IF
    '** user code starts here
    LATB = not PORTB        ' Invert PORTB
    '** user code ends here
end sub
```



Code Optimization

Optimizer has been added to extend compiler usability, cut down the amount of generated code and speed-up its execution. The main features are:

Constant folding

All expressions that can be evaluated in the compile time (i.e. constant) are being replaced by their results. (3 + 5 -> 8);

Constant propagation

When a constant value is being assigned to a certain variable, the compiler recognizes this and replaces the use of that variable by a constant in the following code, as long as the value of a variable remains unchanged.

Copy propagation

The compiler recognizes that two variables have the same value and eliminates one of them further in the code.

Value numbering

The compiler "recognizes" if two expressions yield the same result and can therefore eliminate the entire computation for one of them.

"Dead code" elimination

The code snippets that are not being used elsewhere in the programme do not affect the final result of the application. They are automatically removed.

Stack allocation

Temporary registers (Stacks) are being used more rationally, allowing VERY complex expressions to be evaluated with a minimum stack consumption.

Local vars optimization

No local variables are being used if their result does not affect some of the global or volatile variables.


Better code generation and local optimization

Code generation is more consistent and more attention is paid to implement specific solutions for the code "building bricks" that further reduce output code size.

Creating User's Libraries

mikroBasic for dsPIC30/33 and PIC24 allows you to create your own libraries. In order to create a library in mikroBasic for dsPIC30/33 and PIC24 follow the steps bellow:

- Create a new Basic file, see Managing Source Files
- Save the file in the compiler's Uses folder:
DriveName:\Program Files\Mikroelektronika\mikroBasic dsPIC\Uses\
- Write a code for your library and save it
- Open the definition file for the MCU that you want to use.
This file is placed in the compiler's Defs folder:
DriveName:\Program Files\Mikroelektronika\mikroBasic dsPIC\Defs\
and it is named `pMCU_NAMEdef.dbas`, for example `p30F4013def.dbas`
- Add the `Name_Of_Your_Library` to the definition file for the MCU:
Repeat this step for each MCU that you want to use with your library
- Restart the compiler



dsPIC30/33 and PIC24 Specifics

55

page

In order to get the most from the mikroBasic for dsPIC30/33 and PIC24 compiler, the user should be familiar with certain aspects of dsPIC30/33 and PIC24 MCU. This knowledge is not essential, but it can provide a better understanding of the dsPIC30/33 and PIC24's capabilities and limitations, and their impact on the code writing as well.

Types Efficiency

First of all, the user should know that dsPIC30/33 and PIC24's ALU, which performs arithmetic operations, is optimized for working with 16-bit types. Although mikroBasic for dsPIC30/33 and PIC24 is capable of handling types like byte, char or short, dsPIC30/33 and PIC24 will generate a better code for 16-bit types word and integer type so use byte, char and short only in places where you can significantly save RAM (e.g. for arrays `dim a as byte[30]`).

Nested Calls Limitations

There are no Nested Calls Limitations, except by RAM size. A Nested call represents a function call within the function body, either to itself (recursive calls) or to another function.

Recursive calls, as a form of cross-calling, are supported by mikroBasic for dsPIC30/33 and PIC24, but they should be used very carefully due to dsPIC30/33 and PIC24 stack and memory limitations. Also calling functions from interrupt is allowed. Calling function from both interrupt and main thread is allowed. Be careful because this programming technique may cause unpredictable results if common resources are used in both main and interrupt.

Limits of Indirect Approach Through PSV

Constant aggregates are stored in Flash and are accessible through PSV, which means that there can be max 32KByte of constants.

LEXICAL ELEMENTS

These topics provide a formal definition of the mikroBasic for dsPIC30/33 and PIC24 lexical elements. They describe different categories of word-like units (tokens) recognized by the language.

In tokenizing phase of compilation, the source code file is parsed (that is, broken down) into tokens and whitespace. The tokens in mikroBasic are derived from a series of operations performed on your programs by the compiler.

A mikroBasic program starts as a sequence of ASCII characters representing the source code, created by keystrokes using a suitable text editor (such as the mikroBasic Code Editor). The basic program unit in mikroBasic is a file. This usually corresponds to a named file located in RAM or on disk, having the extension `.dbas`.

Whitespace

Whitespace is a collective name given to spaces (blanks), horizontal and vertical tabs, and comments. Whitespace serves to indicate where tokens start and end, but beyond this function, any surplus whitespace is discarded.

For example, the two sequences

```
dim tmp as byte  
dim j as word
```

and

```
dim tmp as byte  
dim j as word
```

are lexically equivalent and parse identically.

Newline Character

Newline character (CR/LF) is not a whitespace in BASIC, and serves as a statement terminator/separator. In mikroBasic for dsPIC30/33 and PIC24, however, you may use newline to break long statements into several lines. Parser will first try to get the longest possible expression (across lines if necessary), and then check for statement terminators.

Whitespace in Strings

The ASCII characters representing whitespace can occur within string literals, where they are protected from the normal parsing process (they remain as a part of the string). For example, statement

```
some_string = "mikro foo"
```

parses to four tokens, including a single string literal token:

```
some_string
=
"mikro foo"
newline character
```

Comments

Comments are pieces of text used to annotate a program, and are technically another form of whitespace. Comments are for the programmer's use only; they are stripped from the source text before parsing.

Use the apostrophe to create a comment:

```
' Any text between an apostrophe and the end of the
' line constitutes a comment. May span one line only.
```

There are no multi-line comments in mikroBasic for dsPIC30/33 and PIC24.

TOKENS

Token is the smallest element of a mikroBasic for dsPIC30/33 and PIC24 program, meaningful to the compiler. The parser separates tokens from the input stream by creating the longest token possible using the input characters in a left-to-right scan.

mikroBasic for dsPIC30/33 and PIC24 recognizes the following kinds of tokens:

- keywords
- identifiers
- constants
- operators
- punctuators (also known as separators)

Token Extraction Example

Here is an example of token extraction. See the following code sequence:

```
end_flag = 0
```

The compiler would parse it into four tokens:

```
end_flag      ' variable identifier
=             ' assignment operator
0             ' literal
newline       ' statement terminator
```

Note that `end_flag` would be parsed as a single identifier, rather than the keyword `end` followed by the identifier `_flag`.

LITERALS

Literals are tokens representing fixed numeric or character values.

The data type of a constant is deduced by the compiler using such clues as numeric value and format used in the source code.

Integer Literals

Integral values can be represented in decimal, hexadecimal or binary notation.

In decimal notation, numerals are represented as a sequence of digits (without commas, spaces or dots), with optional prefix + or - operator to indicate the sign. Values default to positive (6258 is equivalent to +6258).

The dollar-sign prefix (\$) or the prefix 0x indicates a hexadecimal numeral (for example, \$8F or 0x8F).

The percent-sign prefix (%) indicates a binary numeral (for example, %0101).

Here are some examples:

```
11      ' decimal literal
$11     ' hex literal, equals decimal 17
0x11    ' hex literal, equals decimal 17
%11     ' binary literal, equals decimal 3
```

The allowed range of values is imposed by the largest data type in mikroBasic for dsPIC30/33 and PIC24 – longword. The compiler will report an error if the literal exceeds 4294967295 (\$FFFFFFFF).

Floating Point Literals

A floating-point value consists of:

- Decimal integer
- Decimal point
- Decimal fraction
- e or E and a signed integer exponent (optional)

You can omit either decimal integer or decimal fraction (but not both).

Negative floating constants are taken as positive constants with the unary operator minus (-) prefixed.

mikroBasic limits floating-point constants to the range of
 $\pm 1.17549435082 * 10^{-38} .. \pm 6.80564774407 * 10^{38}$.

Here are some examples:

```
0.           ' = 0.0
-1.23        ' = -1.23
23.45e6      ' = 23.45 * 10^6
2e-5         ' = 2.0 * 10^-5
3E+10        ' = 3.0 * 10^10
.09E34       ' = 0.09 * 10^34
```

Character Literals

Character literal is one character from the extended ASCII character set, enclosed with quotes (for example, "A"). Character literal can be assigned to variables of byte and char type (variable of byte will be assigned the ASCII value of the character). Also, you can assign character literal to a string variable.

String Literals

String literal is a sequence of characters from the extended ASCII character set, enclosed with quotes. Whitespace is preserved in string literals, i.e. parser does not “go into” strings but treats them as single tokens.

Length of string literal is a number of characters it consists of. String is stored internally as the given sequence of characters plus a final null character. This null character is introduced to terminate the string, it does not count against the string's total length.

String literal with nothing in between the quotes (null string) is stored as a single null character.

You can assign string literal to a string variable or to an array of char.

Here are several string literals:

"Hello world!"	' message, 12 chars long
"Temperature is stable"	' message, 21 chars long
" "	' two spaces, 2 chars long
"C"	' letter, 1 char long
""	' null string, 0 chars long

The quote itself cannot be a part of the string literal, i.e. there is no escape sequence. You could use the built-in function Chr to print a quote: Chr(34). Also, see String Splicing.

KEYWORDS

Keywords are special-purpose words which cannot be used as normal identifier names.

Beside standard BASIC keywords, all relevant SFR are defined as global variables and represent reserved words that cannot be redefined (for example: `PORTB`, `TMR1`, `T1CON`, etc). Probe Code Assistant for specific letters (Ctrl+Space in Editor) or refer to Predefined Globals and Constants.

Also, mikroBasic includes a number of predefined identifiers used in libraries. You could replace them by your own definitions, if you plan to develop your own libraries. For more information, see mikroBasic Libraries.

Here is the alphabetical listing of keywords in mikroBasic for dsPIC30/33 and PIC24:

abs	datedf	include	nothing	short
and	datepart	input	now	sin
appactivate	dateserial	instr	nper	single
array	datevalue	int	npv	sln
as	ddb	integer	object	space
asc	deftype	ipmt	oct	spc
asm	dim	irr	on	sqr
atn	dir	is	open	static
attribute	div	isarray	option	step
base	do	isdate	or	stop
beep	doevents	isempty	org	str
boolean	double	iserror	pmt	strcomp
byref	each	ismissing	ppmt	strconv
byte	else	isnull	print	string
call	empty	isnumeric	private	sub
case	end	isobject	procedure	switch
cbool	environ	kill	property	syd
cbyte	eof	lbound	pset	system
ccur	eqv	lcase	public	tab
cdate	erase	left	put	tan
cdate	err	len	pv	then
cdbl	error	let	qbcolor	time
char	exit	line	raise	timer
chdir	exp	loc	randomize	timeserial
chdrive	explicit	lock	rate	timevalue
chr	fileattr	lof	real	to
cint	filecopy	log	redim	trim
circle	filedatetime	long	register	typedef
class	filelen	longint	rem	typename
clear	fix	loop	reset	ubound
clng	float	lset	resume	ucase
close	for	ltrim	return	unlock
command	form	me	rgb	until
compare	format	mid	right	val
const	freefile	minute	rmdir	variant
cos	fv	mirr	rnd	vartype
createobject	get	mkdir	rset	version
csng	getattr	mod	rtrim	volatile
cstr	getobject	module	second	weekday
curdir	gosub	month	seek	wend
currency	goto	msgbox	select	while
cvar	hex	name	sendkeys	width
cverr	hour	new	set	with
date	if	next	setattr	word
dateadd	iif	not	sgn	write
	imp	not	shell	xor

IDENTIFIERS

Identifiers are arbitrary names of any length given to functions, variables, symbolic constants, user-defined data types and labels. All these program elements will be referred to as objects throughout the help (don't be confused with the meaning of object in object-oriented programming).

Identifiers can contain letters from a to z and A to Z, the underscore character “_” and digits from 0 to 9. First character must be a letter or an underscore, i.e. identifier cannot begin with a numeral.

Case Sensitivity

mikroBasic for dsPIC30/33 and PIC24 is not case sensitive, so `Sum`, `sum`, and `suM` are equivalent identifiers.

Uniqueness and Scope

Although identifier names are arbitrary (within the rules stated), errors result if the same name is used for more than one identifier within the same scope. Simply, duplicate names are *illegal* within the same scope. For more information, refer to Scope and Visibility.

Identifier Examples

Here are some valid identifiers:

```
temperature_V1
Pressure
no_hit
dat2string
SUM3
_vtext
```

... and here are some invalid identifiers:

```
7temp          ' NO -- cannot begin with a numeral
%higher        ' NO -- cannot contain special characters
xor            ' NO -- cannot match reserved word
j23.07.04      ' NO -- cannot contain special characters (dot)
```

PUNCTUATORS

The mikroBasic punctuators (also known as separators) are:

- [] – Brackets
- () – Parentheses
- , – Comma
- :
- Colon
- .
- Dot

Brackets

Brackets [] indicate single and multidimensional array subscripts:

```
dim alphabet as byte[ 30]
' ...
alphabet[ 2] = "c"
```

For more information, refer to Arrays.

Parentheses

Parentheses () are used to group expressions, isolate conditional expressions and indicate function calls and function declarations:

```
d = c * (a + b)           ' Override normal precedence
if (d = z) then ...       ' Useful with conditional statements
func()                   ' Function call, no arguments
sub function func2(dim n as word)
                           ' Function declaration w/ parameters
```

For more information, refer to Operators Precedence and Associativity, Expressions, or Functions and Procedures.

Comma

Comma (,) separates the arguments in function calls:

```
Lcd_Out(1, 1, txt)
```

Furthermore, the comma separates identifiers in declarations:

```
dim i, j, k as word
```

The comma also separates elements in initialization lists of constant arrays:

```
const MONTHS as byte[ 12] = (31,28,31,30,31,30,31,31,30,31,30,31)
```

Colon

Colon (:) is used to indicate a labeled statement:

```
start:  nop  
    '...'  
goto start
```

For more information, refer to Labels.

Dot

Dot (.) indicates access to a structure member. For example:

```
person.surname = "Smith"
```

For more information, refer to Structures.

Dot is a necessary part of floating point literals. Also, dot can be used for accessing individual bits of registers in mikroBasic.

PROGRAM ORGANIZATION

mikroBasic for dsPIC30/33 and PIC24 imposes strict program organization. Below you can find models for writing legible and organized source files. For more information on file inclusion and scope, refer to Modules and to Scope and Visibility.

Organization of Main Module

Basically, a main source file has two sections: declaration and program body. Declarations should be in their proper place in the code, organized in an orderly manner. Otherwise, the compiler may not be able to comprehend the program correctly.

When writing code, follow the model presented below.

Main module should look like this:

```

program <program name>
include <include other modules>

'*****
' * Declarations (globals):
'*****

' symbols declarations
symbol ...

' constants declarations
const ...

' structures declarations
structure ...

' variables declarations
dim ...

' procedures declarations
sub procedure procedure_name(...)
    <local declarations>
    ...
end sub

' functions declarations
sub function function_name(...) as return_type
    <local declarations>
    ...
end sub

'*****
' * Program body:
'*****

main:
    ' write your code here
end.

```

Organization of Other Modules

Modules other than main start with the keyword `module`. Implementation section starts with the keyword `implements`. Follow the model presented below.

Other modules should look like this:

```

module <module name>
include <include other modules>

'*****
'* Interface (globals):
'*****
' symbols declarations
symbol ...

' constants declarations
const ...

' structures declarations
structure ...

' variables declarations
dim ...

' procedures prototypes
sub procedure procedure_name(...)

' functions prototypes
sub function function_name(...) as return_type

'*****
'* Implementation:
'*****

implements

' constants declarations
const ...

' variables declarations
dim ...

' procedures declarations
sub procedure procedure_name(...)
    <local declarations>
    ...
end sub

' functions declarations
sub function function_name(...) as return_type
    <local declarations>
    ...
end sub
end.

```

SCOPE AND VISIBILITY

Scope

The scope of identifier is a part of the program in which the identifier can be used to access its object. There are different categories of scope, depending on how and where identifiers are declared:

Place of declaration	Scope
Identifier is declared in the declaration section of the main module, out of any function or procedure.	Scope extends from the point where it is declared to the end of the current file, including all routines enclosed within that scope. These identifiers have a <i>file scope</i> and are referred to as <i>globals</i> .
Identifier is declared in the function or procedure	Scope extends from the point where it is declared to the end of the current routine. These identifiers are referred to as <i>locals</i> .
Identifier is declared in the interface section of the module	Scope extends the interface section of a module from the point where it is declared to the end of the module, and to any other module or program that uses that module. The only exception are symbols which have a scope limited to the file in which they are declared.
Identifier is declared in the implementation section of the module, but not within any function or procedure	Scope extends from the point where it is declared to the end of the module. The identifier is available to any function or procedure in the module.

Visibility

The visibility of an identifier is a region of the program source code from where a legal access to the identifier's associated object can be made .

Scope and visibility usually coincide, though there are circumstances under which an object becomes temporarily hidden by the appearance of a duplicate identifier: the object still exists but the original identifier cannot be used to access it until the scope of the duplicate identifier is ended.

Technically, visibility cannot exceed scope, but scope can exceed visibility.

MODULES

In mikroBasic for dsPIC30/33 and PIC24, each project consists of a single project file and one or more module files. The project file, with extension `.dbp` contains information on the project, while modules, with extension `.dbas`, contain the actual source code. See Program Organization for a detailed look at module arrangement.

Modules allow you to:

- break large programs into encapsulated modules that can be edited separately,
- create libraries that can be used in different projects,
- distribute libraries to other developers without disclosing the source code.

Each module is stored in its own file and compiled separately; compiled modules are linked to create an application. To build a project, the compiler needs either a source file or a compiled module file for each module.

Include Clause

mikroBasic includes modules by means of the include clause. It consists of the reserved word `include`, followed by a quoted module name. Extension of the file should not be included.

You can include one file per include clause. There can be any number of the include clauses in each source file, but they all must be stated immediately after the program (or module) name.

Here's an example:

```
program MyProgram

include "utils"
include "strings"
include "MyUnit"

...
```

For the given module name, the compiler will check for the presence of `.mcl` and `.dbas` files, in order specified by search paths.

- If both `.dbas` and `.mcl` files are found, the compiler will check their dates and include the newer one in the project. If the `.dbas` file is newer than the `.mcl`, then `.dbas` file will be recompiled and new `.mcl` will be created, overwriting the old `.mcl`.
- If only the `.dbas` file is found, the compiler will create the `.mcl` file and include it in the project;
- If only the `.mcl` file is present, i.e. no source code is available, the compiler will include it as found;
- If none of the files found, the compiler will issue a “File not found” warning.

Main Module

Every project in mikroBasic requires a single main module file. The main module is identified by the keyword `program` at the beginning. It instructs the compiler where to “start”.


After you have successfully created an empty project with Project Wizard, Code Editor will display a new main module. It contains the bare-bones of the program:

```
program MyProject

    ' main procedure
main:
    ' Place program code here
end.
```

Other than comments, nothing should precede the keyword `program`. After the program name, you can optionally place the `include` clauses.

Place all global declarations (constants, variables, labels, routines, structures) before the label `main`.



Other Modules

Modules other than main start with the keyword `module`. Newly created blank module contains the bare-bones:

```
module MyModule

implements

end.
```

Other than comments, nothing should precede the keyword `module`. After the module name, you can optionally place the `include` clauses.

Interface Section

Part of the module above the keyword `implements` is referred to as *interface* section. Here, you can place global declarations (constants, variables, labels, routines, structures) for the project.

Do not define routines in the interface section. Instead, state the prototypes of routines (from implementation section) that you want to be visible outside the module. Prototypes must exactly match the declarations.

Implementation Section

Implementation section hides all the irrelevant innards from other modules, allowing encapsulation of code.

Everything declared below the keyword `implements` is *private*, i.e. has its scope limited to the file. When you declare an identifier in the implementation section of a module, you cannot use it outside the module, but you can use it in any block or routine defined within the module.

By placing the prototype in the interface section of the module (above the `implements`) you can make the routine *public*, i.e. visible outside of module. Prototypes must exactly match the declarations.

VARIABLES

Variable is an object whose value can be changed during the runtime. Every variable is declared under unique name which must be a valid identifier. This name is used for accessing the memory location occupied by the variable.

Variables are declared in the declaration part of the file or routine — each variable needs to be declared before it is used. Global variables (those that do not belong to any enclosing block) are declared below the include statements, above the label `main`.

Specifying a data type for each variable is mandatory. mikroBasic syntax for variable declaration is:

```
dim identifier_list as type
```

Here, *identifier_list* is a comma-delimited list of valid identifiers, and type can be any data type.

For more details refer to Types and Types Conversions. For more information on variables' scope refer to the chapter Scope and Visibility.

Here are a few examples:

```
dim i, j, k as byte
dim counter, temp as word
dim samples as longint[ 100]
```

Variables and dsPIC30/33 and PIC24

Every declared variable consumes part of RAM memory. Data type of variable determines not only the allowed range of values, but also the space a variable occupies in RAM memory. Bear in mind that operations using different types of variables take different time to be completed. mikroBasic for dsPIC30/33 and PIC24 recycles local variable memory space – local variables declared in different functions and procedures share the same memory space, if possible.

There is no need to declare SFR explicitly, as mikroBasic for dsPIC30/33 and PIC24 automatically declares relevant registers as global variables of `word`. For example: `W0`, `TMR1`, etc.

CONSTANTS

Constant is a data whose value cannot be changed during the runtime. Using a constant in a program consumes no RAM memory. Constants can be used in any expression, but cannot be assigned a new value.

Constants are declared in the declaration part of the program or routine, with the following syntax:

```
const constant_name [as type] = value
```

Every constant is declared under unique *constant_name* which must be a valid identifier. It is a tradition to write constant names in uppercase. Constant requires you to specify *value*, which is a literal appropriate for the given *type*. *type* is optional and in the absence of it, the compiler assumes the “smallest” type that can accommodate *value*.

Note: You cannot omit *type* if declaring a constant array.

Here are a few examples:

```
const MAX as longint = 10000
const MIN = 1000           ' compiler will assume word type
const SWITCH = "n"         ' compiler will assume char type
const MSG = "Hello"        ' compiler will assume string type
const MONTHS as byte[ 12] = (31,28,31,30,31,30,31,31,30,31,30,31)
```


LABELS

Labels serve as targets for the `goto` and `gosub` statements. Mark the desired statement with label and colon like this:

```
label_identifier : statement
```

No special declaration of label is necessary in mikroBasic for dsPIC30/33 and PIC24.

Name of the label needs to be a valid identifier. The labeled statement and `goto/gosub` statement must belong to the same block. Hence it is not possible to jump into or out of routine. Do not mark more than one statement in a block with the same label.

Note: The label `main` marks the entry point of a program and must be present in the main module of every project. See Program Organization for more information.

Here is an example of an infinite loop that calls the procedure `Beep` repeatedly:

```
loop:  
    Beep  
goto loop
```

SYMBOLS

mikroBasic symbols allow you to create simple macros without parameters. You can replace any line of code with a single identifier alias. Symbols, when properly used, can increase code legibility and reusability.

Symbols need to be declared at the very beginning of the module, right after the module name and (optional) include clauses. Check Program Organization for more details. Scope of a symbol is always limited to the file in which it has been declared.

Symbol is declared as:

```
symbol alias = code
```

Here, *alias* must be a valid identifier which you will use throughout the code. This identifier has a file scope. The *code* can be any line of code (literals, assignments, function calls, etc).

Using a symbol in the program consumes no RAM – the compiler will simply replace each instance of a symbol with the appropriate line of code from the declaration.

Here is an example:

```
symbol MAXALLOWED = 216           ' Symbol as alias for numeric
                                   ' value
symbol PORT = PORTC               ' Symbol as alias for SFR
symbol MYDELAY = Delay_ms(1000)   ' Symbol as alias for procedure
                                   ' call

dim cnt as byte ' Some variable

'...
main:

if cnt > MAXALLOWED then
    cnt = 0
    PORT.1 = 0
    MYDELAY
end if
```

Note: Symbols do not support macro expansion in a way the C preprocessor does.

FUNCTIONS AND PROCEDURES

Functions and procedures, collectively referred to as *routines*, are subprograms (self-contained statement blocks) which perform a certain task based on a number of input parameters. When executed, a function returns value while procedure does not.

Functions

Function is declared like this:

```
sub function function_name(parameter_list) as return_type  
    [ local declarations ]  
    function body  
end sub
```

function_name represents a function's name and can be any valid identifier. *return_type* is a type of return value and can be any simple type. Within parentheses, *parameter_list* is a formal parameter list similar to variable declaration. In mikroBasic for dsPIC30/33 and PIC24, parameters are always passed to a function by value. To pass an argument by address, add the keyword byref ahead of identifier.

Local declarations are optional declarations of variables and/or constants, local for the given function. *Function body* is a sequence of statements to be executed upon calling the function.

Calling a function

A function is called by its name, with actual arguments placed in the same sequence as their matching formal parameters. The compiler is able to coerce mismatching arguments to the proper type according to implicit conversion rules. Upon a function call, all formal parameters are created as local objects initialized by values of actual arguments. Upon return from a function, a temporary object is created in the place of the call and it is initialized by the value of the function result. This means that function call as an operand in complex expression is treated as the function result. In standard Basic, a *function_name* is automatically created local variable that can be used for returning a value of a function. mikroBasic for dsPIC30/33 and PIC24 also allows you to use the automatically created local variable result to assign the return value of a function if you find function name to be too ponderous. If the return value of a function is not defined the compiler will report an error.

Function calls are considered to be *primary expressions* and can be used in situations where expression is expected. A function call can also be a self-contained statement and in that case the return value is discarded.

Example

Here's a simple function which calculates x^n based on input parameters x and n ($n > 0$):

```
sub function power(dim x, n as byte) as longint
dim i as byte
    result = 1
    if n > 0 then
        for i = 1 to n
            result = result*x
        next i
    end if
end sub
```

Now we could call it to calculate, say, 3^{12} :

```
tmp = power(3, 12)
```

Procedures

Procedure is declared like this:

```
sub procedure procedure_name(parameter_list)
    [ local declarations ]
    procedure body
end sub
```

procedure_name represents a procedure's name and can be any valid identifier. Within parentheses, *parameter_list* is a formal parameter list similar to variable declaration. In mikroBasic for dsPIC30/33 and PIC24, parameters are always passed to procedure by value; to pass argument by address, add the keyword byref ahead of identifier.

Local declarations are optional declaration of variables and/or constants, local for the given procedure. *Procedure body* is a sequence of statements to be executed upon calling the procedure.

Calling a procedure

A procedure is called by its name, with actual arguments placed in the same sequence as their matching formal parameters. The compiler is able to coerce mismatching arguments to the proper type according to implicit conversion rules. Upon procedure call, all formal parameters are created as local objects initialized by values of actual arguments.

Procedure call is a self-contained statement.

Example

Here's an example procedure which transforms its input time parameters, preparing them for output on LCD:

```
sub procedure time_prep(dim byref sec, min, hr as byte)  
    sec = ((sec and $F0) >> 4)*10 + (sec and $0F)  
    min = ((min and $F0) >> 4)*10 + (min and $0F)  
    hr   = ((hr and $F0) >> 4)*10 + (hr and $0F)  
end sub
```

mikroBasic for dsPIC30/33 and PIC24 is strictly typed language, which means that every variable and constant need to have a strictly defined type, known at the time of compilation.

The type serves:

- to determine correct memory allocation required,
- to interpret the bit patterns found in the object during subsequent accesses,
- in many type-checking situations, to ensure that illegal assignments are trapped.

mikroBasic for dsPIC30/33 and PIC24 supports many standard (predefined) and user-defined data types, including signed and unsigned integers of various sizes, arrays, strings, pointers and structures.

Type Categories

Types can be divided into:

- simple types
- arrays
- strings
- pointers
- structures (user defined types)

SIMPLE TYPES

Simple types represent types that cannot be divided into more basic elements and are the model for representing elementary data on machine level. Basic memory unit in mikroBasic for dsPIC30/33 and PIC24 has 16 bits.

Here is an overview of simple types in mikroBasic for dsPIC30/33 and PIC24:

Type	Size	Range
byte, char	8-bit	0 .. 255
short	8-bit	-127 .. 128
word	16-bit	0 .. 65535
integer	16-bit	-32768 .. 32767
longword, dword	32-bit	0 .. 4294967295
longint	32-bit	-2147483648 .. 2147483647
float	32-bit	$\pm 1.17549435082 \cdot 10^{-38} \dots$ $\pm 6.80564774407 \cdot 10^{38}$

You can assign signed to unsigned or vice versa only using the explicit conversion. Refer to Types Conversions for more information.

ARRAYS

An array represents an indexed collection of elements of the same type (called the base type). Since each element has a unique index, arrays, unlike sets, can meaningfully contain the same value more than once.

Array Declaration

Array types are denoted by constructions of the form:

```
type[ array_length]
```

Each of elements of an array is numbered from 0 through *array_length* - 1. Every element of an array is of *type* and can be accessed by specifying array name followed by element's index within brackets.

Here are a few examples of array declaration:

```
dim weekdays as byte[ 7]
dim samples as word[ 50]

main:
    ' Now we can access elements of array variables, for example:
    samples[ 0] = 1
    if samples[ 37] = 0 then
        ...
```

Constant Arrays

Constant array is initialized by assigning it a comma-delimited sequence of values within parentheses. For example:

```
'Declare a constant array which holds number of days in each month:
const MONTHS as byte[ 12] = (31,28,31,30,31,30,31,31,30,31,30,31)
```

Note that indexing is zero based; in the previous example, number of days in January is MONTHS[0] and number of days in December is MONTHS[11] .

The number of assigned values must not exceed the specified length. Vice versa is possible, when the trailing “excess” elements will be assigned zeroes.

For more information on arrays of char, refer to Strings.

STRINGS

A string represents a sequence of characters equivalent to an array of `char`. It is declared like this:

```
string[ string_length]
```

The specifier *string_length* is a number of characters a string consists of. The string is stored internally as the given sequence of characters plus a final `null` character (zero). This appended “stamp” does not count against string’s total length.

A null string (“”) is stored as a single `null` character.

You can assign string literals or other strings to string variables. The string on the right side of an assignment operator has to be shorter than another one, or of equal length. For example:

```
dim msg1 as string[ 20]
dim msg2 as string[ 19]

main:
    msg1 = "This is some message"
    msg2 = "Yet another message"
    msg1 = msg2 ' this is ok, but vice versa would be illegal
```

Alternately, you can handle strings element–by–element. For example:

```
dim s as string[ 5]
' ...
s = "mik"
' s[0] is char literal "m"
' s[1] is char literal "i"
' s[2] is char literal "k"
' s[3] is zero
' s[4] is undefined
' s[5] is undefined
```

Be careful when handling strings in this way, since overwriting the end of a string will cause an unpredictable behavior.

Note

mikroBasic for dsPIC30/33 and PIC24 includes String Library which automatizes string related tasks.

POINTERS

A pointer is a data type which holds a memory address. While a variable accesses that memory address directly, a pointer can be thought of as a reference to that memory address.

To declare a pointer data type, add a caret prefix (^) before type. For example, if you are creating a pointer to an `integer`, you would write:

```
^integer
```

To access the data at the pointer's memory location, you add a caret after the variable name. For example, let's declare variable `p` which points to `word`, and then assign the pointed memory location value 5:

```
dim p as ^word
'...
p^ = 5
```

A pointer can be assigned to another pointer. However, note that only address, not value, is copied. Once you modify the data located at one pointer, the other pointer, when dereferenced, also yields modified data.

@ Operator

The @ operator returns the address of a variable or routine, i.e. @ constructs a pointer to its operand. The following rules are applied to @:

- If `x` is a variable, @`x` returns the address of `x`.
- If `F` is a routine (a function or procedure), @`F` returns `F`'s entry point (the result is of longint).

STRUCTURES

A structure represents a heterogeneous set of elements. Each element is called a *member*; the declaration of a structure type specifies a name and type for each member. The syntax of a structure type declaration is

```
structure structname
    dim member1 as type1
    '...
    dim membern as typen
end structure
```

where *structname* is a valid identifier, each type denotes a type, and each *member* is a valid identifier. The scope of a member identifier is limited to the structure in which it occurs, so you don't have to worry about naming conflicts between member identifiers and other variables.

For example, the following declaration creates a structure type called *Dot*:

```
structure Dot
    dim x as float
    dim y as float
end structure
```

Each *Dot* contains two members: *x* and *y* coordinates; memory is allocated when you instantiate the structure, like this:

```
dim m, n as Dot
```

This variable declaration creates two instances of *Dot*, called *m* and *n*.

A member can be of the previously defined structure type. For example:

```
' Structure defining a circle:
structure Circle
    dim radius as float
    dim center as Dot
end structure
```

Structure Member Access

You can access the members of a structure by means of dot (.) as a direct member selector. If we had declared the variables `circle1` and `circle2` of the previously defined type `Circle`:

```
dim circle1, circle2 as Circle
```

we could access their individual members like this:

```
circle1.radius = 3.7  
circle1.center.x = 0  
circle1.center.y = 0
```

You can also commit assignments between complex variables, if they are of the same type:

```
circle2 = circle1 ' This will copy values of all members
```

TYPES CONVERSIONS

Conversion of variable of one type to variable of another type is typecasting. mikroBasic for dsPIC30/33 and PIC24 supports both implicit and explicit conversions for built-in types.

Implicit Conversion

Compiler will provide an automatic implicit conversion in the following situations:

- statement requires an expression of particular type (according to language definition) and we use an expression of different type,
- operator requires an operand of particular type and we use an operand of different type,
- function requires a formal parameter of particular type and we pass it an object of different type,
- `result` does not match the declared function return type.

Promotion

When operands are of different types, implicit conversion promotes the less complex to the more complex type taking the following steps:

<code>byte/char</code>	<code>-></code>	<code>word</code>
<code>short</code>	<code>-></code>	<code>integer</code>
<code>short</code>	<code>-></code>	<code>longint</code>
<code>integer</code>	<code>-></code>	<code>longint</code>
<code>integral</code>	<code>-></code>	<code>float</code>

Higher bytes of extended unsigned operand are filled with zeroes. Higher bytes of extended signed operand are filled with bit sign (if number is negative, fill higher bytes with one, otherwise with zeroes).

Higher bytes of extended unsigned operand are filled with zeroes. Higher bytes of extended signed operand are filled with bit sign (if number is negative, fill higher bytes with one, otherwise with zeroes). For example:

```
dim a as byte
dim b as word
'...
a = $FF
b = a ' a is promoted to word, b becomes $00FF
```

Clipping

In assignments and statements that require an expression of particular type, destination will store the correct value only if it can properly represent the result of expression, i.e. if the result fits in destination range.

If expression evaluates to more complex type than expected excess data will be simply clipped (the higher bytes are lost).

```
dim i as byte
dim j as word
'...
j = $FF0F
i = j ' i becomes $0F, higher byte $FF is lost
```

Explicit Conversion

Explicit conversion can be executed at any point by inserting type keyword (`byte`, `word`, `short`, `integer`, `longint`, or `float`) ahead of the expression to be converted. The expression must be enclosed in parentheses. Explicit conversion can be performed only on the operand left of the assignment operator.

Special case is the conversion between signed and unsigned types. Explicit conversion between signed and unsigned data does not change binary representation of data — it merely allows copying of source to destination.

For example:

```
dim a as byte
dim b as short
'...
b = -1
a = byte(b) ' a is 255, not 1

' This is because binary representation remains
' 11111111; it's just interpreted differently now
```

You cannot execute explicit conversion on the operand left of the assignment operator:

```
word(b) = a ' Compiler will report an error
```

OPERATORS

Operators are tokens that trigger some computation when applied to variables and other objects in an expression.

There are four types of operators in mikroBasic for dsPIC30/33 and PIC24:

- Arithmetic Operators
- Bitwise Operators
- Boolean Operators
- Relational Operators

Operators Precedence and Associativity

There are 4 precedence categories in mikroBasic for dsPIC30/33 and PIC24. Operators in the same category have equal precedence with each other.

Each category has an associativity rule: left-to-right, or right-to-left. In the absence of parentheses, these rules resolve the grouping of expressions with operators of equal precedence.

Precedence	Operands	Operators	Associativity
4	1	@ not + -	right-to-left
3	2	* / div mod and << >>	left-to-right
2	2	+ - or xor	left-to-right
1	2	= <> < > <= >=	left-to-right

Arithmetic Operators

Arithmetic operators are used to perform mathematical computations. They have numerical operands and return numerical results. Since the char operators are technically bytes, they can be also used as unsigned operands in arithmetic operations.

All arithmetic operators associate from left to right.

Operator	Operation	Operands	Result
+	addition	byte, short, word, integer, longint, long-word, float	byte, short, word, integer, longint, long-word, float
-	subtraction	byte, short, word, integer, longint, long-word, float	byte, short, word, integer, longint, long-word, float
*	multiplication	byte, short, word, integer, longint, long-word, float	word, integer, longint, long-word, float
/	division, floating-point	byte, short, word, integer, longint, long-word, float	float
div	division, rounds down to nearest integer	byte, short, word, integer, longint, long-word	byte, short, word, integer, longint, long-word
mod	modulus, returns the remainder of integer division (cannot be used with floating points)	byte, short, word, integer, longint, long-word	byte, short, word, integer, longint, long-word

Division by Zero

If 0 (zero) is used explicitly as the second operand (i.e. `x div 0`), the compiler will report an error and will not generate code. But in case of implicit division by zero: `x div y`, where y is 0 (zero), dsPIC MCU will generate the *division by zero trap*.

Unary Arithmetic Operators

Operator - can be used as a prefix unary operator to change sign of a signed value. Unary prefix operator + can be used, but it doesn't affect data.

For example:

```
b = -a;
```

Relational Operators


Use relational operators to test equality or inequality of expressions. All relational operators return TRUE or FALSE. All relational operators associate from left to right.

Operator	Operation
=	equal
<>	not equal
>	greater than
<	less than
>=	greater than or equal
<=	less than or equal

Relational Operators in Expressions

The equal sign (=) can also be an assignment operator, depending on context. Precedence of arithmetic and relational operators was designated in such a way to allow complex expressions without parentheses to have expected meaning:

```
if aa + 5 >= bb - 1.0 / cc then
    ' same as: if (aa + 5) >= (bb - (1.0 / cc)) then
    dd = My_Function()
end if
```



Bitwise Operators

Use the bitwise operators to modify the individual bits of numerical operands.

Bitwise operators associate from left to right. The only exception is the bitwise complement operator not which associates from right to left.

Bitwise Operators Overview

Operator	Operation
<code>and</code>	bitwise AND; compares pairs of bits and generates a 1 result if both bits are 1, otherwise it returns 0
<code>or</code>	bitwise (inclusive) OR; compares pairs of bits and generates a 1 result if either or both bits are 1, otherwise it returns 0
<code>xor</code>	bitwise exclusive OR (XOR); compares pairs of bits and generates a 1 result if the bits are complementary, otherwise it returns 0
<code>not</code>	bitwise complement (unary); inverts each bit
<code><<</code>	bitwise shift left; moves the bits to the left, it discards the far left bit and assigns 0 to the right most bit.
<code>>></code>	bitwise shift right; moves the bits to the right, discards the far right bit and if unsigned assigns 0 to the left most bit, otherwise sign extends

Logical Operations on Bit Level

and	0	1
0	0	0
1	0	1

or	0	1
0	0	1
1	1	1

xor	0	1
0	0	1
1	1	0

not	0	1
	1	0

The bitwise operators `and`, `or`, and `xor` perform logical operations on the appropriate pairs of bits of their operands. The operator `not` complements each bit of its operand. For example:

```
$1234 and $5678           ' equals $1230
```

```
' because ..
```

```
' $1234 : 0001 0010 0011 0100
```

```
' $5678 : 0101 0110 0111 1000
```

```
' -----
```

```
'   and : 0001 0010 0011 0000
```

```
' .. that is, $1230
```

```
' Similarly:
```

```
$1234 or $5678             ' equals $567C
```

```
$1234 xor $5678            ' equals $444C
```

```
not $1234                  ' equals $EDCB
```

Unsigned and Conversions

If number is converted from less complex to more complex data type, the upper bytes are filled with zeroes. If number is converted from more complex to less complex data type, the data is simply truncated (upper bytes are lost).

For example:

```
dim a as byte
dim b as word
' ...
a = $AA
b = $F0F0
b = b and a
' a is extended with zeroes; b becomes $00A0
```

Signed and Conversions

If number is converted from less complex to more complex data type, the upper bytes are filled with ones if sign bit is 1 (number is negative); the upper bytes are filled with zeroes if sign bit is 0 (number is positive). If number is converted from more complex to less complex data type, the data is simply truncated (the upper bytes are lost).

For example:

```
dim a as byte
dim b as word
' ...
a = -12
b = $70FF
b = b and a

' a is sign extended, upper byte is $FF;
' b becomes $70F4
```

Bitwise Shift Operators

The binary operators `<<` and `>>` move the bits of the left operand by a number of positions specified by the right operand, to the left or right, respectively. Right operand has to be positive and less than 255.

With shift left (`<<`), left most bits are discarded, and “new” bits on the right are assigned zeroes. Thus, shifting unsigned operand to the left by n positions is equivalent to multiplying it by 2^n if all discarded bits are zero. This is also true for signed operands if all discarded bits are equal to the sign bit.

With shift right (`>>`), right most bits are discarded, and the “freed” bits on the left are assigned zeroes (in case of unsigned operand) or the value of the sign bit (in case of signed operand). Shifting operand to the right by n positions is equivalent to dividing it by 2^n .



Boolean Operators

Although mikroBasic for dsPIC30/33 and PIC24 does not support the boolean type, you have Boolean operators at your disposal for building complex conditional expressions. These operators conform to standard Boolean logic, and return either `TRUE` (all ones) or `FALSE` (zero):

Operator	Operation
<code>and</code>	logical AND
<code>or</code>	logical OR
<code>xor</code>	logical exclusive OR (XOR)
<code>not</code>	logical negation

Boolean operators associate from left to right. The negation operator `not` associates from right to left.

EXPRESSIONS

An expression is a sequence of operators, operands, and punctuators that returns a value.

The *primary expressions* include: literals, constants, variables and function calls. From them, using operators, more complex expressions can be created. Formally, expressions are defined recursively: subexpressions can be nested up to the limits of memory.

Expressions are evaluated according to certain conversion, grouping, associativity and precedence rules that depend on the operators used, presence of parentheses, and data types of the operands. The precedence and associativity of the operators are summarized in Operator Precedence and Associativity. The way operands and subexpressions are grouped does not necessarily specify the actual order in which they are evaluated by mikroBasic for dsPIC30/33 and PIC24.

STATEMENTS

Statements define algorithmic actions within a program. Each statement needs to be terminated by a newline character (CR/LF).

The simplest statements include assignments, routine calls and jump statements. They can be combined to form loops, branches and other structured statements. In the absence of specific jump and selection statements, they are executed sequentially in order of appearance in the source code.

Refer to:

- Assignment Statements
- Conditional Statements
- Iteration Statements (Loops)
- Jump Statements
- asm Statement

Assignment Statements

Assignment statements have the following form:

```
variable = expression
```

The statement evaluates *expression* and assigns its value to *variable*. All rules of implicit conversion are applied. *Variable* can be any declared variable or array element, and *expression* can be any expression.

Do not confuse the assignment with relational operator = which tests for equality. mikroBasic for dsPIC30/33 and PIC24 will interpret the meaning of the character = from the context.

Conditional Statements

Conditional or selection statements select from alternative courses of action by testing certain values. There are two types of selection statements:

- if
- select case

If Statement

Use the keyword `if` to implement a conditional statement. The syntax of the `if` statement has the following form:


```
if expression then
    statements
[ else
    other statements ]
end if
```

When *expression* evaluates to true, *statements* execute. If *expression* is false, *other statements* execute. The *expression* must convert to a boolean type; otherwise, the condition is ill-formed. The `else` keyword with an alternate block of statements (*other statements*) is optional.

Nested if statements

Nested if statements require additional attention. A general rule is that the nested conditionals are parsed starting from the innermost conditional, with each `else` bound to the nearest available `if` on its left:

```
if expression1 then
if expression2 then
    statement1
else
    statement2
end if
end if
```



The compiler treats the construction in this way:

```
if expression1 then
  if expression2 then
    statement1
  else
    statement2
  end if
end if
```

In order to force the compiler to interpret our example the other way around, we have to write it explicitly:

```
if expression1 then
  if expression2 then
    statement1
  end if
else
  statement2
end if
```

Select Case Statement

Use the *select case* statement to pass control to a specific program branch, based on a certain condition. The *select case* statement consists of selector expression (condition) and list of possible values. The syntax of the *select case* statement is:


```
select case selector
  case value_1
    statements_1
  ...
  case value_n
    statements_n
  [case else
    default_statements]
end select
```

selector is an expression which should evaluate as integral value. *values* can be literals, constants or expressions and *statements* can be any statements. The *case else* clause is optional.

First, the *selector* expression (condition) is evaluated. The *select case* statement then compares it against all available *values*. If the match is found, the *statements* following the match evaluate, and the *select case* statement terminates. In case there are multiple matches, the first matching statement will be executed. If none of the *values* matches the *selector*, then *default_statements* in the *case else* clause (if there is one) are executed.

Here is a simple example of the *select case* statement:

```
select case operator
  case "*"
    res = n1 * n2
  case "/"
    res = n1 / n2
  case "+"
    res = n1 + n2
  case "-"
    res = n1 - n2
  case else
    res = 0
    cnt = cnt + 1
end select
```



Also, you can group values together for a match. Simply separate the items by commas:

```
select case reg
  case 0
    opmode = 0
  case 1,2,3,4
    opmode = 1
  case 5,6,7
    opmode = 2
end select
```

Nested Case Statements

Note that the `select case` statements can be nested – *values* are then assigned to the innermost enclosing `select case` statement.

Iteration Statements (Loops)

Iteration statements let you loop a set of statements. There are three forms of iteration statements in mikroBasic for dsPIC30/33 and PIC24:

- for
- while
- do

You can use the statements `break` and `continue` to control the flow of a loop statement. `break` terminates the statement in which it occurs, while `continue` begins executing the next iteration of the sequence.

For Statement

The `for` statement implements an iterative loop and requires you to specify the number of iterations. The syntax of the `for` statement is:

```
for counter = initial_value to final_value [ step step_value]
    statements
next counter
```


counter is a variable being increased by *step_value* with each iteration of the loop. The parameter *step_value* is an optional integral value, and defaults to 1 if omitted. Before the first iteration, counter is set to *initial_value* and will be incremented until it reaches (or exceeds) the *final_value*. With each iteration, statements will be executed.

initial_value and *final_value* should be expressions compatible with *counter*; statements can be any statements that do not change the value of *counter*.

Note that the parameter *step_value* may be negative, allowing you to create a countdown.

Here is an example of calculating scalar product of two vectors, *a* and *b*, of length *n*, using the `for` statement:

```
s = 0
for i = 0 to n-1
    s = s + a[ i ] * b[ i ]
next i
```



Endless Loop

The `for` statement results in an endless loop if `final_value` equals or exceeds the range of the `counter`'s type.

While Statement

Use the `while` keyword to conditionally iterate a statement. The syntax of the `while` statement is:

```
while expression
    statements
wend
```

statements are executed repeatedly as long as *expression* evaluates true. The test takes place before *statements* are executed. Thus, if *expression* evaluates false on the first pass, the loop does not execute.

Here is an example of calculating scalar product of two vectors, using the `while` statement:

```
s = 0
i = 0
while i < n
    s = s + a[ i] * b[ i]
    i = i + 1
wend
```

Probably the easiest way to create an endless loop is to use the statement:

```
while TRUE
    ' ...
wend
```

Do Statement


The `do` statement executes until the condition becomes true. The syntax of the `do` statement is:

```
do  
    statements  
loop until expression
```

statements are executed repeatedly until *expression* evaluates true. *expression* is evaluated *after* each iteration, so the loop will execute *statements* at least once.

Here is an example of calculating scalar product of two vectors, using the `do` statement:

```
s = 0  
i = 0  
do  
    s = s + a[ i ] * b[ i ]  
    i = i + 1  
loop until i = n
```



Jump Statements

A jump statement, when executed, transfers control unconditionally. There are five such statements in mikroBasic for dsPIC30/33 and PIC24:

- break
- continue
- exit
- goto
- gosub

Break Statement

Sometimes, you might need to stop the loop from within its body. Use the break statement within loops to pass control to the first statement following the innermost loop (for, while, or do).

For example:

```
' Wait for CF card to be plugged; refresh every second
while true
    Lcd_Out(1, 1, "No card inserted")
    if Cf_Detect() = 1 then
        break
    end if
    Delay_ms(1000)
wend

' Now we can work with CF card ...
Lcd_Out(1, 1, "Card detected  ")
```

Continue Statement

You can use the continue statement within loops to “skip the cycle”:

- continue statement in the for loop moves program counter to the line with keyword for
- continue statement in the while loop moves program counter to the line with loop condition (top of the loop),
- continue statement in the do loop moves program counter to the line with loop condition (bottom of the loop).


```
' continue jumps here
for i = ...
...
  continue
...
next i
```

```
' continue jumps here
while condition
...
  continue
...
wend
```

```
do
...
  continue
...
' continue jumps here
loop until condition
```

Exit Statement

The `exit` statement allows you to break out of a routine (function or procedure). It passes the control to the first statement following the routine call.

Here is a simple example:

```
sub procedure Proc1()
dim error as byte
... ' we're doing something here
if error = TRUE then
  exit
end if
... ' some code, which won't be executed if error is true
end sub
```

Note: If breaking out of a function, return value will be the value of the local variable `result` at the moment of exit.

Goto Statement

Use the `goto` statement to unconditionally jump to a local label — for more information, refer to Labels. The syntax of the `goto` statement is:

```
goto label_name
```

This will transfer control to the location of a local label specified by *label_name*. The `goto` line can come before or after the label.

Label and `goto` statement must belong to the same block. Hence it is not possible to jump into or out of a procedure or function.

You can use `goto` to break out from any level of nested control structures. Never jump into a *loop* or other structured statement, since this can have unpredictable effects.

The use of `goto` statement is generally discouraged as practically every algorithm can be realized without it, resulting in legible structured programs. One possible application of the `goto` statement is breaking out from deeply nested control structures:

```
for i = 0 to n
  for j = 0 to m
    ...
    if disaster
      goto Error
    end if
    ...
  next j
next i
.
.
.
Error: ' error handling code
```

Gosub Statement


Use the `gosub` statement to unconditionally jump to a local label — for more information, refer to Labels. The syntax of the `gosub` statement is:

```
gosub label_name  
...  
label_name:  
...  
return
```

This will transfer control to the location of a local label specified by `label_name`. Also, the calling point is remembered. Upon encountering the `return` statement, program execution will continue with the next statement (line) after `gosub`. The `gosub` line can come before or after the label.

It is not possible to jump into or out of routine by means of `gosub`. Never jump *into* a loop or other structured statement, since this can have unpredictable effects.

Note: Like with `goto`, the use of `gosub` statement is generally discouraged. mikroBasic for dsPIC30/33 and PIC24 supports `gosub` only for the sake of backward compatibility. It is better to rely on functions and procedures, creating legible structured programs.



asm Statement

mikroBasic for dsPIC30/33 and PIC24 allows embedding assembly in the source code by means of the `asm` statement. Note that you cannot use numerals as absolute addresses for register variables in assembly instructions. You may use symbolic names instead (listing will display these names as well as addresses).

You can group assembly instructions with the `asm` keyword:

```
asm
    block of assembly instructions
end asm
```

mikroBasic comments are not allowed in embedded assembly code. Instead, you may use one-line assembly comments starting with semicolon.

If you plan to use a certain mikroBasic variable in embedded assembly only, be sure to at least initialize it (assign it initial value) in mikroBasic code; otherwise, the linker will issue an error. This is not applied to predefined globals such as `PORTB`.

For example, the following code will not be compiled because the linker won't be able to recognize the variable `myvar`:

```
program test

dim myvar as word

main:
    asm
        MOV #10, W0
        MOV W0, _myvar
    end asm
end.
```

Adding the following line (or similar) above the `asm` block would let linker know that variable is used:

```
myvar = 20
```

DIRECTIVES

Directives are words of special significance which provide additional functionality regarding compilation and output.

The following directives are at your disposal:

- Compiler directives for conditional compilation,
- Linker directives for object distribution in memory.

Compiler Directives

Any line in source code with leading # is taken as a compiler directive. The initial # can be preceded or followed by whitespace (excluding new lines). The compiler directives are not case sensitive.

You can use conditional compilation to select particular sections of code to compile while excluding other sections. All compiler directives must be completed in the source file in which they begun.

Directives #DEFINE and #UNDEFINE

Use directive #DEFINE to define a conditional compiler constant (“flag”). You can use any identifier for a flag, with no limitations. No conflicts with program identifiers are possible because the flags have a separate name space. Only one flag can be set per directive.

For example:

```
#DEFINE extended_format
```

Use #UNDEFINE to undefine (“clear”) previously defined flag.

Directives #IFDEF, #ELSEIF and #ELSE

Conditional compilation is carried out by the #IFDEF directive. #IFDEF tests whether a flag is currently defined or not; i.e. whether the previous #DEFINE directive has been processed for that flag and is still in force. The directive #IFDEF is terminated by the #ENDIF directive and can have any number of the #ELSEIF clauses and an optional #ELSE clause:

```
#IFDEF flag THEN
    block of code
[ #ELSEIF flag_1 THEN
    block of code 1
...
#ELSEIF flag_n THEN
    block of code n ]
[ #ELSE
    alternate block of code ]
#ENDIF
```

First, #IFDEF checks if *flag* is set by means of #DEFINE. If so, only *block of code* will be compiled. Otherwise, the compiler will check flags *flag_1* .. *flag_n* and execute the appropriate *block of code i*. Eventually, if none of the flags is set, *alternate block of code* in #ELSE (if any) will be compiled.

#ENDIF ends the conditional sequence. The result of the preceding scenario is that only one section of code (possibly empty) is passed on for further processing. The processed section can contain further conditional clauses, nested to any depth; each #IFDEF must be matched with a closing #ENDIF.

Here is an example:

```
' Uncomment the appropriate flag for your application:
'#DEFINE resolution8
'#DEFINE resolution10
'#DEFINE resolution12
#IFDEF resolution8 THEN
    ... ' code specific to 8-bit resolution
#ELSEIF resolution10 THEN
    ... ' code specific to 10-bit resolution
#ELSEIF resolution12 THEN
    ... ' code specific to 12-bit resolution
#ELSE
    ... ' default code
#ENDIF
```

Predefined Flags

The compiler sets directives upon completion of project settings, so the user doesn't need to define certain flags.

Here is an example:

```
#IFDEF P30F4013 ' If dsPIC30F4013 MCU is selected
#IFDEF P30      ' P30F4013 and P30 flags will be automatically defined
```

Linker Directives

mikroBasic for dsPIC30/33 and PIC24 uses internal algorithm to distribute objects within memory. If you need to have a variable or routine at the specific predefined address, use the linker directives `absolute` and `org`.

Note: You must specify an even address when using the linker directives.

Directive `absolute`

The directive `absolute` specifies the starting address in RAM for a variable. If the variable spans more than 1 word (16-bit), higher words will be stored at the consecutive locations.

The `absolute` directive is appended to the declaration of a variable:

```
dim x as word absolute 0x32
' Variable x will occupy 1 word (16 bits) at address 0x32

dim y as longint absolute 0x34
' Variable y will occupy 2 words at addresses 0x34 and 0x36
```

Be careful when using `absolute` directive, as you may overlap two variables by accident. For example:

```
dim i as word absolute 0x42
' Variable i will occupy 1 word at address 0x42;

dim jj as longint absolute 0x40
' Variable will occupy 2 words at 0x40 and 0x42; thus,
' changing i changes jj at the same time and vice versa
```


Note: You must specify an even address when using the directive `absolute`.

Directive org

The directive `org` specifies the starting address of a routine in ROM. It is appended to the declaration of routine. For example:

```
sub procedure proc(dim par as word) org 0x200
' Procedure will start at the address 0x200;
...
end sub
```

Note: You must specify an even address when using the directive `org`.



mikroBasic Libraries

mikroBasic provides a number of built-in and library routines which can help you develop your applications faster and easier. Hardware libraries for ADC, Advanced SPI Ethernet, Button, CAN, CANSPI, Compact Flash, DSP, Enhanced CAN, EEPROM, Flash Memory, Graphic LCD, I²C, Keypad, LCD Custom (4-bit interface), LCD8 Custom (8-bit interface), Manchester Code, Multi Media Card, OneWire, Port Expander, PS/2, PWM, PWM Motor, RS-485, Software I²C, Software SPI, Software UART, Sound, SPI, SPI Ethernet, SPI Graphic LCD, SPI LCD, SPI LCD8, Spi T6963C Graphic LCD, T6963C Graphic LCD, UART as well as utilities like Conversions, Math, Setjmp, String, Time, Util and Built-in Routines are included along with practical, ready-to-use code examples.

BUILT-IN ROUTINES


mikroBasic for dsPIC30/33 and PIC24 compiler provides a set of useful built-in utility functions. Built-in functions do not have any special requirements. You can use them in any part of your project.

`Vdelay_ms`, `Delay_Cyc` and `Get_Fosc_kHz` are actual Basic routines. Their sources can be found in the `delays.dbas` file located in the `uses` folder of the compiler.

```
Chr
Ord
SetBit
ClearBit
TestBit
Inc
Dec
Delay_us
Delay_ms
VDelay_ms_p30
VDelay_ms_p24_p33
Delay_Cyc
Clock_Khz
Clock_Mhz
Get_Fosc_kHz
```

Chr

Prototype	sub function <code>Chr(dim code as byte) as char</code>
Returns	Returns a character associated with the specified character code.
Description	Function returns a character associated with the specified character <code>code</code>. Numbers from 0 to 31 are the standard non-printable ASCII codes. This is an “inline” routine; the code is generated in the place of the call.
Example	<code>c = Chr(10)</code> <i>' returns the linefeed character</i>



Ord

Prototype	sub function Ord(dim character as char) as byte
Returns	ASCII code of the character.
Description	Function returns ASCII code of the character. This is an “inline” routine; the code is generated in the place of the call
Example	c = Ord("A") ' returns 65

SetBit

Prototype	sub procedure SetBit(dim byref register as word, dim rbit as word)
Returns	Nothing.
Description	Function sets the bit rbit of register. Parameter rbit needs to be a variable or literal with value 0..15. For more information on register identifiers see Predefined Globals and Constants . This is an “inline” routine; the code is generated in the place of the call.
Example	SetBit(PORTB, 2) ' Set RB2

ClearBit

Prototype	sub procedure ClearBit(dim byref register as word, dim rbit as word)
Returns	Nothing.
Description	Function clears the bit rbit of register. Parameter rbit needs to be a variable or literal with value 0..15. For more information on register identifier see Predefined Globals and Constants. This is an “inline” routine; the code is generated in the place of the call.
Example	ClearBit(PORTC, 7) ' Clear RC7

TestBit

Prototype	sub function TestBit(dim register, rbit as word) as word
Returns	If the bit is set, returns 1, otherwise returns 0.
Description	Function tests if the bit rbit of register is set. If set, function returns 1, otherwise returns 0. Parameter rbit needs to be a variable or literal with value 0..15. For more information on register identifiers see Predefined Globals and Constants. This is an “inline” routine; the code is generated in the place of the call.
Example	flag = TestBit(PORTE, 2) ' 1 if RE2 is set, otherwise 0

Inc

Prototype	sub procedure Inc(dim byref par as longint)
Returns	Nothing.
Description	Increases parameter par by 1.
Example	p = 4 Inc(p) ' p is now 5

Dec

Prototype	sub procedure Dec(dim byref par as longint)
Returns	Nothing.
Description	Decreases parameter par by 1.
Example	p = 4 Dec(p) ' p is now 3



Delay_us

Prototype	sub procedure Delay_us(dim Time_In_us as word)
Returns	Nothing.
Description	Creates a software delay in duration of Time_In_us microseconds. This is an “inline” routine; the code is generated in the place of the call, so the call doesn’t count against the nested call limit. Parameters : - Time_In_us: delay time in microseconds. Valid values: constant values, range of applicable constants depends on the oscillator frequency
Example	Delay_us(10) ' Ten microseconds pause

Delay_ms


Prototype	sub procedure Delay_ms(dim Time_In_ms as word)
Returns	Creates a software delay in duration of Time_In_ms milliseconds. This is an “inline” routine; the code is generated in the place of the call, so the call doesn’t count against the nested call limit. Parameters : - Time_In_ms: delay time in milliseconds. Valid values: constant values, range of applicable constants depends on the oscillator frequency Note:For generating delays with variable as input parameter use the Vdelay_ms routine.
Description	Nothing.
Example	Delay_ms(1000) ' One second pause

VDelay_ms_p30

Prototype	sub procedure VDelay_ms_p30(dim Time_ms as word)
Description	Creates a software delay in duration of Time_ms milliseconds. Generated delay is not as precise as the delay created by Delay_ms. Parameters : - Time_ms: delay time in milliseconds Note: VDelay_ms_p30 is a library function rather than a built-in routine; it is presented in this topic for the sake of convenience. Note: VDelay_ms_p30 can be used only with dsPIC30 family MCUs.
Example	<pre>dim pause as word ... VDelay_ms_p30(pause) ' ~ one second pause</pre>

VDelay_ms_p24_p33

Prototype	sub procedure VDelay_ms_p24_p33(dim Time_ms as word)
Description	Creates a software delay in duration of Time_ms milliseconds. Generated delay is not as precise as the delay created by Delay_ms. Parameters : - Time_ms: delay time in milliseconds Note: VDelay_ms_p24_p33 is a library function rather than a built-in routine; it is presented in this topic for the sake of convenience. Note: VDelay_ms_p24_p33 can be used only with dsPIC33 and PIC24 family MCUs.
Example	<pre>dim pause as word ... VDelay_ms_p24_p33(pause) ' ~ one second pause</pre>



Delay_Cyc

123

page

Prototype	sub procedure Delay_Cyc(dim x as word , dim y as word)
Returns	Nothing.
Description	Creates a delay based on MCU clock. Delay lasts for $x \times 16384 + y$ MCU clock cycles. Parameters : - x: NumberOfCycles divided by 16384 - y: remainder of the NumberOfCycles/16384 division Note: Delay_Cyc is a library function rather than a built-in routine; it is presented in this topic for the sake of convenience.
Example	<code>Delay_Cyc(1, 10) ' 1x16384 + 10 = 16394 cycles pause</code>

Clock_Khz

Prototype	sub function Clock_Khz() as longint
Returns	Device clock in KHz, rounded to the nearest integer.
Description	Returns device clock in KHz, rounded to the nearest integer. This is an “inline” routine; the code is generated in the place of the call.
Example	<code>clk = Clock_Khz()</code>

Clock_Mhz

Prototype	sub function Clock_Mhz() as word
Returns	Device clock in MHz, rounded to the nearest integer.
Description	Returns device clock in MHz, rounded to the nearest integer. This is an “inline” routine; the code is generated in the place of the call.
Example	<code>clk = Clock_Mhz()</code>

Get_Fosc_kHz

Prototype	<code>sub function Get_Fosc_kHz () as longint</code>
Returns	Device clock in KHz.
Description	Function returns device clock in KHz, rounded to the nearest integer. Note: Get_Fosc_kHz is a library function rather than a built-in routine; it is presented in this topic for the sake of convenience.
Example	<code>clk = Get_Fosc_kHz ()</code>

LIBRARY ROUTINES

mikroBasic for dsPIC30/33 and PIC24 provides a set of libraries which simplify the initialization and use of dsPIC30/33 and PIC24 and their modules:

Hardware Libraries

- ADC Library
- Advanced SPI Ethernet Library
- Button Library
- CAN Library
- CANSPI Library
- Compact Flash Library
- DSP Library
- Enhanced CAN Library
- EEPROM Library
- Flash Memory Library
- Graphic LCD Library
- I²C Library
- Keypad Library
- LCD Custom (4-bit interface) Library
- LCD8 Custom (8-bit interface) Library
- Manchester Code Library
- Multi Media Card Library
- OneWire Library
- Port Expander Library
- PS/2 Library
- PWM Library
- PWM Motor Library
- RS-485 Library
- Software I²C Library
- Software SPI Library
- Software UART Library
- Sound Library
- SPI Library
- SPI Ethernet Library
- SPI Graphic LCD Library
- SPI LCD Library
- SPI LCD8 Library
- Spi T6963C Graphic LCD Library
- T6963C Graphic LCD Library
- UART Library

Utilities

- Conversions Library
- Math Library
- Setjmp Library
- String Library
- Time Library
- Util Library

ADC Library

ADC (Analog to Digital Converter) module is available with a number of dsPIC30/33 and PIC24 MCU modules. ADC is an electronic circuit that converts continuous signals to discrete digital numbers. ADC Library provides a comfortable work with the module.

Library Routines

dsPIC30 and PIC24FJ Functions


`ADC_Read`

dsPIC33F and PIC24HJ Functions

`Adc1_Read`

`Adc2_Read`

`Adc_Read`



dsPIC30 and PIC24FJ Functions


Adc_Read

Prototype	<code>sub function Adc_Read(dim channel as word) as word</code>
Returns	10-bit or 12-bit (MCU dependent) unsigned value from the specified <code>channel</code> .
Description	The function reads the specified analog channel input. The internal ADC dsPIC30F and PIC24FJ module is set to: - single channel conversion - unsigned integer data format - auto-convert - VRef+ : AVdd, VRef- : AVss - instruction cycle clock - conversion clock : 32*Tcy - auto-sample time : 31TAD Parameters : - <code>channel</code> represents the channel from which the analog value is to be acquired. Refer to the appropriate Datasheet for channel-to-pin mapping. Note: The function sets the appropriate bit in the ADPCFG registers in order to enable analog function of the selected pin.
Requires	The dsPIC30F and PIC24FJ MCU with built-in ADC module. Datasheet documentation for specific device should be consulted. Before using the function, be sure to configure the appropriate TRISx bits to configure pins as inputs.
Example	<pre>dim k as word ... k = Adc_Read(10) 'read analog value from channel 10</pre>

dsPIC33F and PIC24HJ Functions

Adc1_Read

Prototype	sub function Adc1_Read(dim channel, AdcMode as word) as word
Returns	10-bit or 12-bit (depending on selected mode) unsigned value from the specified channel.
Description	The function reads the specified analog channel input. This library works with the ADC1 module. The internal ADC dsPIC33FJ and PIC24HJ module is set to: - single channel conversion - unsigned integer data format - auto-convert - VRef+ : AVdd, VRef- : AVss - instruction cycle clock - conversion clock : 32*Tcy - auto-sample time : 31TAD Parameters : - channel represents the channel from which the analog value is to be acquired. Refer to the appropriate Datasheet for channel-to-pin mapping. - AdcMode represents ADC resolution. Valid values: ADC_10bit and ADC_12bit. These are library predefined constants, ADC_10bit=0 and ADC_12bit=1. Note: The function sets the appropriate bit in the ADPCFG registers in order to enable analog function of the selected pin.
Requires	The dsPIC33FJ and PIC24HJ MCU with built-in ADC1 module. Datasheet documentation for specific device should be consulted. Before using the function, be sure to configure the appropriate TRISx bits to designate pins as inputs.
Example	<pre> dim k as word ... k = Adc1_Read(10, ADC_10bit) <i>'read analog value from channel 10 in 10-bit resolution</i> </pre>



Adc2_Read

Prototype	<code>sub function Adc2_Read(dim channel, AdcMode as word) as word</code>
Returns	10-bit or 12-bit (depending on selected mode) unsigned value from the specified <code>channel</code> .
Description	The function reads the specified analog channel input. This library works with the ADC2 module. The internal ADC dsPIC33FJ and PIC24HJ module is set to: - single channel conversion - unsigned integer data format - auto-convert - VRef+ : AVdd, VRef- : AVss - instruction cycle clock - conversion clock : 32*Tcy - auto-sample time : 31TAD Parameters : - <code>channel</code> represents the channel from which the analog value is to be acquired. Refer to the appropriate Datasheet for channel-to-pin mapping. - <code>AdcMode</code> represents ADC resolution. Valid values: <code>ADC_10bit</code> and <code>ADC_12bit</code>. These are library predefined constants, <code>ADC_10bit=0</code> and <code>ADC_12bit=1</code>. Note: The function sets the appropriate bit in the ADPCFG registers to enable analog function of the selected pin.
Requires	The dsPIC33FJ and PIC24HJ MCU with built-in ADC2 module. Datasheet documentation for specific device should be consulted. Before using the function, be sure to configure the appropriate TRISx bits to designate pins as inputs.
Example	<pre>dim k as word ... k = Adc2_Read(10, ADC_10bit) 'read analog value from channel 10 in 10-bit resolution</pre>

Adc_Read

Prototype	<code>sub function Adc_Read(dim channel, AdcMode as word) as word</code>
Returns	10-bit or 12-bit (depending on selected mode) unsigned value from the specified <code>channel</code> .
Description	This function calls <code>Adc1_Read</code> . It is kept to maintain backwards compatibility with the previous versions of mikroBasic for dsPIC30/33 and PIC24.
Requires	The dsPIC33FJ and PIC24HJ MCU with built-in ADC1 module. Datasheet documentation for specific device should be consulted. Before using the function, be sure to configure the appropriate TRISx bits to designate pins as inputs.
Example	<pre>dim k as word ... k = Adc_Read(10, ADC_10bit) 'read analog value from channel 10 in 10-bit resolution</pre>

Library Example

dsPIC30 and PIC24FJ Functions

This code snippet reads analog value from channel 10 and sends its lower byte over UART1.

```
program ADC_test

dim adcRes as word
txt as string[ 5]

main:
    TRISB.10 = 1 ' set pin as input - needed for ADC to work

    Uart1_Init(9600)

    while true
        adcRes = Adc_Read(10)
        WordToStr(adcRes, txt)
        Uart1_Write_Text(txt)
        Delay_ms(50)
    wend

end.
```

dsPIC33F and PIC24HJ Functions

This simple example reads analog value from channel 10 in 12-bit resolution and sends its lower byte via UART1.

```
program ADC_test

dim k as word


main:
    TRISB.10 = 1    ' set pin as input - needed for ADC to work

    Uart1_Init(9600)

    while TRUE
        k = Adc_Read(10, ADC_12bit)
        Uart1_Write_Char(k)
        Delay_ms(50)
    wend

end.
```


Hardware Connection



Advanced SPI Ethernet Library

This library is designed to simplify handling of the underlying hardware (ENC28J60). However, a certain level of knowledge about the Ethernet and Ethernet-based protocols (ARP, IP, TCP/IP, UDP/IP, ICMP/IP) is expected from the user. The Ethernet is a high-speed and versatile protocol, but not a simple one. Once you get used to it, you will make your favorite dsPIC30/33 and PIC24 available to a much broader audience than you could do with the RS232/485 (UART) or CAN.

The ENC28J60 is a stand-alone Ethernet controller with an industry standard Serial Peripheral Interface (SPI™). It is designed to serve as an Ethernet network interface for any controller equipped with SPI.

The ENC28J60 meets all the IEEE 802.3 specifications. It incorporates a number of packet filtering schemes to limit incoming packets. It also provides an internal DMA module for fast data throughput and hardware assisted IP checksum calculations. Communication with the host controller is implemented via two interrupt pins and the SPI, with data rates of up to 10 Mb/s. Two ENC28J60 pins are dedicated for LED link and network activity indication.

Note: This library uses TIMER1 for timeout logic.

Library Routines

Ethernet Initialization

```
EthSetMACAddr
EthSetIPAddr
EthSetIPMask
EthSetGateWayAddr
EthInit
```

Media Access Control Layer (MAC)

MACInit
MACIsTxReady
MACGetHeader
MACGet
MACGetArray
MACDiscardRx
MACPutHeader
MACPut
MACPutArray
MACFlush
MACDiscardTx
MACSetTxBuffer
MACSetRxBuffer
MACReserveTxBuffer
MACGetFreeRxSize
MACSetDuplex

Address Resolution Protocol (ARP and ARPTask)

ARPGet
ARPPut
ARPInit

Internet Protocol (IP)

IPIsTxReady
IPSetTxBuffer
IPPutHeader
IPPutArray
IPGetHeader
IPGetArray
IPSetRxBuffer

Internet Control Message Protocol(ICMP)

ICMPIsTxReady
ICMPPut
ICMPGet

Transmission Control Protocol (TCP)

TCPInit
 TCPListen
 TCPConnect
 TCPIsConnected
 TCPDisconnect
 TCPIsPutReady
 TCPPut
 TCPFlush
 TCPIsGetReady
 TCPGet
 TCPGetArray
 TCPDiscard
 TCPProcess
 TCPTick

User Datagram Protocol (UDP)

UDPInit
 UDPOpen
 UDPClose
 UDPIsPutReady
 UDPPut
 UDPFlush
 UDPIsGetReady
 UDPGet
 UDPDiscard
 UDPProcess
 UDPWrite
 UDPRead
 UDPOpenSocket

Other

StackInit
 StackTask
 HTTPInit
 HTTPServer

EthSetMACAddr

Prototype	sub procedure EthSetMACAddr(dim MACByte1, MACByte2, MACByte3, MACByte4, MACByte5, MACByte6 as byte)
Returns	Nothing.
Description	This routine sets MAC address.
Requires	Nothing.
Example	<i>' Sets MAC address</i> EthSetMACAddr(0, 2, 4, 6, 8, 10)

EthSetIPAddr


Prototype	sub procedure EthSetIPAddr(dim IpByte1, IpByte2, IpByte3, IpByte4 as byte)
Description	This routine sets IP address.
Requires	Nothing.
Example	<i>' Sets IP address</i> EthSetIPAddr(192,168,20,1)

EthSetIPMask

Prototype	sub procedure EthSetIPMask(dim IPMaskByte1, IPMaskByte2, IPMaskByte3, IPMaskByte4 as byte)
Description	This routine sets IP address mask.
Requires	Nothing.
Example	<i>' Sets address mask</i> EthSetIPMask(255,255,255,0)

EthSetGateWayAddr

Prototype	sub procedure EthSetGateWayAddr(dim GateWayByte1, GateWayByte2, GateWayByte3, GateWayByte4 as byte)
Description	This routine sets Gateway IP address.
Requires	Nothing.
Example	<i>' Sets Gateway IP address</i> EthSetGateWayAddr(192,168,20,1)



EthInit

137

page

Prototype	sub procedure EthInit(dim byref RstPort as word , dim RstPin as word , dim byref CSPORT as word , dim CSPin as word)
Description	This routine initializes NIC and global variable needed for Ethernet connection.
Requires	EthSetMACAddr, EthSetIPAddr, EthSetIPMask need to be set before calling this routine. Calling EthSetGateWayAddr before this routine is optional.
Example	<pre>' Initializes Ethernet connection EthInit (PORTF,0,PORTF,1)</pre>

MACInit

Prototype	sub procedure MACInit(dim byref RstPort as word , dim RstPin as word , dim byref CSPORT as word , dim CSPin as word)
Description	This function initializes MAC layer. It initializes internal buffers and resets the NIC to a known state. All pending transmissions and receptions are discarded.
Requires	Nothing.
Example	<pre>' Initialize MAC Module MACInit (PORTF,0,PORTF,1)</pre>

MACIsTxReady


Prototype	sub function MACIsTxReady() as byte
Returns	(<>0) - If at least one MAC transmit buffer is empty. (=0) - If all MAC transmit buffers are full.
Description	This function indicates whether at least one MAC transmit buffer is empty or not.
Requires	Nothing.
Example	<pre>' Check MAC transmit readiness... if (MACIsTxReady() <> 0) then ' Transmit buffer is empty, transmit a message. ... end if</pre>

MACGetHeader

Prototype	sub function MACGetHeader (dim byref remote as MAC_ADDR, dim byref type as byte) as byte
Returns	(<>0) : If a data packet is received and found to be valid. All parameters are populated. (=0) : If no data packet is received or found to be invalid.
Description	This function checks the MAC receive buffer; if any packet is found, it returns the remote host and data packet information. Remote specifies Remote MAC address and type represents Data packet type. Possible values for type parameter are: MAC_IP (An IP data packet is received), MAC_ARP (An ARP data packet is received) MAC_UNKNOWN (An unknown or unsupported data packet is received).
Requires	Nothing.
Example	<pre> ' Get possible data packet info. if (MACGetHeader(RemoteNodeMAC, PacketType) <> 0) then ' A packet is received, process it. ... ' Once done, discard it. MACDiscardRx() ... end if </pre>

MACGet

Prototype	sub function MACGet () as byte
Returns	Data byte.
Description	This function returns the next byte from an active transmit or receive buffer.
Requires	MACGetHeader, MACPutHeader, MACSetRxBuffer or MACSetTxBuffer must be called.
Example	<pre> ' Get possible data packet info. if (MACGetHeader(RemoteNode, PacketType) <> 0) then ' A packet is received, process it. data = MACGet() ... ' When done, discard it. MACDiscardRx() ... end if </pre>



MACGetArray

Prototype	<code>sub function MACGetArray(dim byref val as byte, dim len as word) as word</code>
Returns	Total number of bytes fetched.
Description	This function fetches an array of bytes from the active transmit or receive buffer. val represents pointer to a byte array and len represents number of bytes to fetch.
Requires	MACGetHeader, MACPutHeader,MACSetRxBuffer or MACSetTxBuffer must be called.
Example	<pre> ' Get possible data packet info. if (MACGetHeader(RemoteNode, PacketType) <> 0) then ' A packet is received, process it. actualCount = MACGetArray(data, count) ... end if </pre>

MACDiscardRx


Prototype	<code>sub procedure MACDiscardRx()</code>
Returns	Nothing.
Description	This function discards the active receive buffer data and marks that buffer as free.
Requires	Nothing.
Example	<pre> ' Get possible data packet info. if (MACGetHeader(RemoteNode, PacketType) <> 0) then ' A packet is received, process it. actualCount = MACGetArray(data, count) ... ' Done processing it. Discard it. MACDiscardRx() ... end if </pre>

MACPutHeader

Prototype	sub procedure MACPutHeader(dim byref remote as MAC_ADDR, dim type as byte, dim dataLen as word)
Returns	Nothing.
Description	This function assembles the MAC header and loads it to an active transmit buffer. remote - Remote node MAC address, type - Type of data packet being sent. Possible values for this parameter are: MAC_IP(An IP data packet is to be transmitted) and MAC_ARP(An ARP data packet is to be transmitted), data - Number of bytes for this packet, including IP header.
Requires	Nothing.
Example	<pre> ' Check to see if at least one transmit buffer is empty if (MACIsTxReady() <> 0) then ' Assemble IP packet with total IP packet size of 100 bytes ' including IP header. MACPutHeader(RemoteNodeMAC, MAC_IP, 100) ... end if </pre>

MACPut

Prototype	sub procedure MACPut(dim val as byte)
Returns	Nothing.
Description	This function loads the given data byte into an active transmit or receive buffer. val - Data byte to be written.
Requires	MACGetHeader, MACPutHeader, MACSetRxBuffer or MACSetTxBuffer must be called.
Example	<pre> ' Check to see if at least one transmit buffer is empty if (MACIsTxReady() <> 0) then ' Assemble IP packet with total IP packet size of 100 bytes ' including IP header. MACPutHeader(RemoteNodeMAC, MAC_IP, 100) ' Now put the actual IP data bytes MACPut(\$55) ... end if </pre>



MACPutArray

Prototype	<code>sub procedure MACPutArray(dim byref val as byte, dim len as word)</code>
Returns	Nothing.
Description	This function writes an array of data bytes into an active transmit or receive buffer. <i>val</i> - Data bytes to be written. <i>len</i> - Total number of bytes to write.
Requires	MACGetHeader, MACPutHeader, MACSetTxBuffer or MACSetRxBuffer must be called.
Example	<pre>' Check to see if at least one transmit buffer is empty if (MACIsTxReady() <> 0) then ' Assemble IP packet with total IP packet size of 100 bytes ' including IP header. MACPutHeader(RemoteNodeMAC, MAC_IP, 100) ' Now put the actual IP data bytes MACPut(\$55) MACPutArray(data, count) ... end if</pre>

MACFlush


Prototype	<code>sub procedure MACFlush()</code>
Description	This function marks active transmit buffer as ready for transmission.
Requires	MACPutHeader or MACSetTxBuffer must be called.
Example	<pre>' Check to see if at least one transmit buffer is empty if (MACIsTxReady() <> 0) then ' Assemble IP packet with total IP packet size of 100 bytes ' including IP header. MACPutHeader(RemoteNodeMAC, MAC_IP, 100) ' Put the actual IP data bytes MACPut(\$55) MACPutArray(data, count) ... ' Now transmit it. MACFlush() ... end if</pre>

MACDiscardTx

Prototype	sub procedure MACDiscardTx(dim buffer as BUFFER)
Description	This function discards given transmit buffer content and marks it as free.
Requires	Nothing.
Example	<pre> ' Check to see if at least one transmit buffer is empty if (MACIsTxReady() <> 0) then ' Assemble IP packet with total IP packet size of 100 bytes ' including IP header. MACPutHeader(RemoteNodeMAC, MAC_IP, 100) ' Get current transmit buffer buffer = MACGetTxBuffer() ' Reserve it. MACReserveTxBuffer(Buffer) ' Put the actual IP data bytes ... ' Now transmit it. MACFlush() ' No longer need this buffer MACDiscardTx(buffer) ... end if </pre>

MACSetRxBuffer

Prototype	sub procedure MACSetRxBuffer(dim offset as word)
Description	This function sets the access location for the active receive buffer. offset - Location (with respect to beginning of buffer) where next access is to occur.
Requires	Nothing.
Example	<pre> ' Get possible data packet info. if (MACGetHeader(RemoteNode, PacketType) <> 0) then ' A packet is received, process it. actualCount = MACGetArray(data, count) ... ' Fetch data beginning at offset 20 MACSetRxBuffer(20) data = MACGet() ... end if </pre>




MACSetTxBuffer

Prototype	<code>sub procedure MACSetTxBuffer(dim buffer as BUFFER, dim offset as word)</code>
Description	This function sets the access location for a given transmit buffer and makes that transmit buffer active. <i>buffer</i> - A transmit buffer where this access offset will be applied. <i>offset</i> - Location (with respect to beginning of buffer) where next access is to occur.
Requires	Nothing.
Example	<pre>' Check to see if at least one transmit buffer is empty if (MACIsTxReady() <> 0) then ' Assemble IP packet with total IP packet size of 100 bytes ' including IP header. MACPutHeader(RemoteNodeMAC, MAC_IP, 100) ' Get current transmit buffer buffer = MACGetTxBuffer() ' Put the actual IP data bytes ... ' Calculate the checksum of data packet ' that is being transmitted ... ' Now update the checksum in this packet. ' To update the checksum, set transmit ' buffer access to checksum MACSetTxBuffer(buffer, checksumLocation) ... ' Now transmit it. MACFlush() ... end if</pre>

MACReserveTxBuffer

Prototype	sub procedure MACReserveTxBuffer(dim buffer as BUFFER)
Description	This function reserves a given transmit buffer and marks it as unavailable. This function is useful for TCP layer where a message will be queued until it is correctly acknowledged by remote host. <i>buffer</i> - A transmit buffer to reserve. This value must be a valid transmit buffer identifier as returned by the MACGetTxBuffer function.
Requires	Nothing.
Example	<pre> ' Check to see if at least one transmit buffer is empty if (MACIsTxReady() <> 0) then ' Transmit IP packet with total IP packet size of 100 bytes ' including IP header. MACPutHeader(RemoteNodeMAC, MAC_IP, 100) ' Get current transmit buffer buffer = MACGetTxBuffer() ' Reserve it, to be discarded when ACK is received. MACReserveTxBuffer(buffer) ' Put the actual IP data bytes ... ' Calculate the checksum of data packet ' that is being transmitted ... ' Now update the checksum in this packet. ' To update the checksum, set transmit buffer ' access to checksum MACSetTxBuffer(buffer, checksumLocation) ... ' Now transmit it. MACFlush() ... end if </pre>



MACGetFreeRxSize

Prototype	sub function MACGetFreeRxSize() as word
Returns	Total number of bytes available for future data packets.
Description	This function returns total receive buffer size available for future data packets.
Requires	Nothing.
Example	<pre>' Get available receive buffer size freeRxBuffer = MACGetFreeRxSize()</pre>

MACSetDuplex


Prototype	sub procedure MACSetDuplex(dim DuplexState as DUPLEX)
Returns	Nothing.
Description	This routine sets FULL-DUPLEX or HALF-DUPLEX communication mode. Input value can be 1 for FULL-DUPLEX, 0 for HALF-DUPLEX and 2 for NIC defined communication mode.
Requires	Nothing.
Example	<pre>MACSetDuplex(1) ' FULL-DUPLEX communication is set</pre>

ARPGet

Prototype	sub function ARPGet(dim byref remote as NODE_INFO, dim byref opCode as byte) as byte
Returns	(<>0) - If a valid ARP packet that was addressed to a local host was fetched; remote and opCode contain valid values. (=0) - Either unknown ARP code was fetched or this packet was not addressed to a local host.
Description	This function fetches complete ARP packet and returns necessary information. remote - Remote node information such as MAC and IP addresses. opCode - ARP code. Possible values for this parameter are: ARP_REPLY ("ARP Reply" packet is received), ARP_REQUEST ("ARP Request" packet is received), ARP_UNKNOWN (An unknown ARP packet is received).
Requires	MACGetHeader is already called AND Received MAC packet type = MAC_ARP
Example	<pre> ' If MAC packet is received... if (MACGetHeader(RemoteNode, PacketType) <> 0) then ' If this is an ARP packet, fetch it. if (PacketType = MAC_ARP) then ' This is ARP packet. ARPGet(RemoteNode, ARPCode) ... </pre>

ARPPut

Prototype	sub procedure ARPPut(dim byref remote as NODE_INFO, dim opCode as byte)
Description	This function loads MAC buffer with valid ARP packet. remote - Remote node information such as MAC and IP addresses. opCode - ARP code. Possible values for this parameter are: ARP_REPLY (Transmit this packet as "ARP Reply"), ARP_REQUEST (Transmit this packet as "ARP Request").
Requires	ARPIsTxReady = TRUE
Example	<pre> ' Check to see if transmit buffer is available if (ARPIsTxReady() <> 0) then ' Transmit it ARPPut(RemoteNode, ARP_REQUEST) ... </pre>



ARPInit


Prototype	sub procedure ARPInit()
Description	This function initializes the ARPTask state machine and prepares it to handle ARP requests and replies.
Requires	Nothing.
Example	<pre>' Initialize ARPTask ARPInit() ...</pre>

IPIsTxReady

Prototype	sub function IPIsTxReady() as byte
Returns	(<>0) - If there is at least one transmit buffer empty. (=0) - If there is no empty transmit buffer.
Description	This is a macro that calls MACIsTxReady in turn.
Requires	Nothing.
Example	<pre>' If IP transmit buffer is ready, transmit IP packet if (IPIsTxReady() <> 0) then ' Assemble IP packet. IPPutHeader(Remote, MAC_TCP, IPPacketLen) ...</pre>

IPSetTxBuffer

Prototype	sub procedure IPSetTxBuffer(dim buffer as BUFFER, dim offset as word)
Returns	Nothing.
Description	This is a macro to allow higher level layer set transmit buffer access pointer. This macro takes IP header into account before calling MACSetTxBuffer. <i>buffer</i> - Transmit buffer identifier whose access pointer is to be set. <i>offset</i> - An offset with respect to IP Data.
Requires	Nothing.
Example	<pre> ' If IP transmit buffer is ready, transmit IP packet if (IPIsTxReady() <> 0) then ' Assemble IP packet. IPPutHeader(Remote, MAC_TCP, IPPacketLen) ' Get current transmit buffer id. buffer = MACGetTxBuffer() ' Load transmit data ... ' Calculate checksum checkHi:checkLo ... ' Update the checksum. IPSetTxBuffer(buffer, checkLocation) MACPut (checkHi) MACPut (checkLo) ... </pre>



IPPutHeader

149

page


Prototype	sub function IPPutHeader(dim byref remote as NODE_INFO, dim protocol as byte, dim len as word) as word
Returns	Nothing.
Description	This function assembles a valid IP header and loads it into active transmit buffer. remote - Remote node information such as MAC and IP addresses. protocol - Protocol to use for this data packet. Possible values for this parameter are: IP_PROT_ICMP (Assemble this packet as ICMP), IP_PROT_TCP (Assemble this packet as TCP segment), IP_PROT_UDP (Assemble this packet as UDP segment). len - Total length of IP data bytes, excluding IP header.
Requires	IPIsTxReady = TRUE
Example	<pre> ' Check to see if transmit buffer is available if (IPIsTxReady() <> 0) then ' Load the header IPPutHeader(RemoteNode, IP_PROT_ICMP, ICMP_HEADER_SIZE+dataLen) ' Load ICMP data IPPutArray(ICMPData, dataLen) ' Mark it as ready to be transmitted MACFlush() ... </pre>

IPPutArray

Prototype	sub procedure IPPutArray(dim byref buffer as byte, dim len as word)
Returns	Nothing.
Description	This macro loads an array of bytes into the active transmit buffer. buffer - Data array to be loaded. len - Total number of items in data array.
Requires	IPIsTxReady = TRUE
Example	<pre> ' Check to see if transmit buffer is available if (IPIsTxReady() <> 0) then ' Load the header IPPutHeader(RemoteNode, IP_PROT_ICMP, ICMP_HEADER_SIZE+dataLen) ' Load ICMP data IPPutArray(ICMPData, dataLen) ' Mark it as ready to be transmitted MACFlush() ... </pre>

IPGetHeader

Prototype	sub function IPGetHeader(dim byref localIP as IP_ADDR, dim byref remote as NODE_INFO, dim byref protocol as byte, dim byref len as word) as byte
Returns	($\neq 0$) - A valid IP packet was received. Remote IP address, packet protocol and packet length parameters are populated. (=0) - An invalid IP packet was received. Parameters are not populated.
Description	This function fetches the IP header from the active transmit buffer and validates it. localIP - Local node information such as MAC and IP addresses, remote - Remote node information such as MAC and IP addresses, protocol - Protocol associated with this IP packet. Possible values for this parameter are: IP_PROT_ICMP (This is an ICMP packet), IP_PROT_TCP (This is a TCP packet), IP_PROT_UDP (This is a UDP packet), all others Unknown protocol. len - Total length of IP data in this packet.
Requires	MACGetHeader = TRUE
Example	<pre> ' Check to see if any packet is ready if (MACGetHeader(RemoteMACAddr, PacketType) $\neq$ 0) then ' Check what kind of protocol it is if (PacketType = MAC_IP) then ' This is IP packet. Fetch it. IPGetHeader(Local, Remote, IPProtocol, IPLen) ' Process this IP packet. ... ' When done processing this packet, discard it MACDiscardRx() end if else ' This is not an IP packet. Handle it ... </pre>




IPGetArray

Prototype	<code>sub function IPGetArray(dim byref val as byte, dim len as word) as word</code>
Returns	Total number of bytes fetched.
Description	This macro fetches an array of bytes from an active transmit or receive buffer. <code>val</code> - data buffer. <code>len</code> - Number of bytes to fetch.
Requires	IPGetHeader, IPPutHeader, IPSetRxBuffer or IPSetTxBuffer must be called.
Example	<pre>' Check to see if any packet is ready if (MACGetHeader(RemoteMACAddr, PacketType) <> 0) then ' Check what kind of protocol it is if (PacketType = MAC_IP) then ' This is IP packet. Fetch it. IPGetHeader(Remote, IPProtocol, IPLen) ' Get 20 bytes of data IPGetArray(IPData, 20) ... ' When done processing this packet, discard it MACDiscardRx() end if else ' This is not an IP packet. Handle it ...</pre>

IPSetRxBuffer

Prototype	sub procedure IPSetRxBuffer(dim offset as word)
Returns	Nothing.
Description	This macro allows a higher level layer to set the receive buffer access pointer. It takes the IP header into account before calling MACSetRxBuffer. <i>offset</i> - An offset with respect to IP Data.
Requires	Nothing.
Example	<pre> ' Check to see if any packet is ready if (MACGetHeader(RemoteMACAddr, PacketType) <> 0) then ' Check what kind of protocol it is if (PacketType = MAC_IP) then ' This is IP packet. Fetch it. IPGetHeader(Remote, IPProtocol, IPLen) ' Fetch 20th byte within IP data. IPSetRxBuffer(20) data = MACGet() ... // When done processing this packet, discard it MACDiscardRx() end if else ' This is not an IP packet. Handle it ... </pre>



ICMPlsTxReady


Prototype	sub function ICMPlsTxReady() as byte
Returns	(<>0) - If there is at least one transmit buffer empty. (=0) - If there is no empty transmit buffer.
Description	This macro determines if at least one transmit buffer is empty.
Requires	Nothing.
Example	<pre>' If IP transmit buffer is ready, transmit IP packet if (ICMPlsTxReady() <> 0) then ' Transmit ICMP packet. ...</pre>

ICMPPut

Prototype	sub procedure ICMPPut(dim byref remote as NODE_INFO, dim code as ICMP_CODE, dim byref data as byte, dim len as byte, dim id, seq as word)
Returns	Nothing.
Description	This function assembles a valid ICMP packet and transmits it. remote - Remote node information such as MAC and IP addresses, code - ICMP code to be used for this ICMP packet. Possible values for this parameter are: ICMP_ECHO_REPLY (This is an ICMP Echo reply packet), ICMP_ECHO_REQUEST (This is an ICMP Echo request packet). data - ICMP data. len - ICMP data length. id - ICMP packet identifier. seq - ICMP packet sequence number.
Requires	IPIsTxReady = TRUE
Example	<pre>' Check to see if transmit buffer is available if (ICMPlsTxReady() <> 0) then ' Transmit ICMP packet. ICMPPut(RemoteNode, ICMP_ECHO_REPLY, data, datalen, id, seq) ' Done. ICMP is put into transmit queue. ...</pre>

ICMPGet

Prototype	<code>sub procedure ICMPGet(dim byref remote as NODE_INFO, dim byref code as ICMP_CODE, dim byref data, len as byte, dim byref id, seq as word)</code>
Returns	($\neq 0$) - A valid ICMP packet was received. All parameters are populated. (=0) - An invalid ICMP packet was received. Parameters are not populated.
Description	This function fetches the ICMP header from the active transmit buffer and validates it. remote - Remote node information such as MAC and IP addresses. code - ICMP code for received ICMP packet. Possible values for this parameter are: ICMP_ECHO_REPLY (An ICMP Echo reply packet is received), ICMP_ECHO_REQUEST (An ICMP Echo request packet is received), for all others (An unknown/unsupported packet is received). data - ICMP data. len - ICMP data length. id - ICMP packet identifier. seq - ICMP packet sequence number.
Requires	IPGetHeader = TRUE PacketType = IP_PROT_ICMP
Example	<pre> ' Check to see if any packet is ready if (IPGetHeader(Remote, IPProtocol, IPLen) <> 0) then ' Check what kind of protocol it is if (IPProtocol = IP_PROT_ICMP) then ' This is ICMP packet. Fetch it. ICMPGet(ICMPCode, data, dataLen, id, seq) ' Process this ICMP packet. ... ' When done processing this packet, discard it MACDiscardRx() end if else ' This is not an ICMP packet. Handle it ... </pre>



TCPInit


Prototype	sub procedure TCPInit()
Description	This function initializes the TCP state machine and prepares it for multiple TCP connections.
Requires	Nothing.
Example	<pre>' Initialize TCP TCPInit()</pre>

TCPListen

Prototype	sub function TCPListen(dim port as TCP_PORT) as TCP_SOCKET
Returns	A valid socket identifier if there is at least one free socket. INVALID_SOCKET if there is no socket available.
Description	This function assigns one of the available sockets to listen on given TCP port. port - TCP Port number on which to listen.
Requires	Nothing.
Example	<pre>... httpSocket = TCPListen(80) If (httpSocket = INVALID_SOCKET) then ' Socket is not available ' Return error. ...</pre>

TCPConnect

Prototype	sub function TCPConnect(dim byref remote as NODE_INFO, dim port as TCP_PORT) as TCP_SOCKET
Returns	A valid socket identifier if there is at least one free socket. INVALID_SOCKET if there is no socket available.
Description	This function initiates a connection request to a remote host on a given remote port. remote - Remote host that needs to be connected. port - TCP Port number on remote host to connect to.
Requires	Nothing.
Example	<pre> ... ftpSocket = TCPConnect(RemoteNode, 21) if (ftpSocket = INVALID_SOCKET) then ' Socket is not available ' Return error. ... </pre>



TCPIsConnected


Prototype	<code>sub function TCPIsConnected(dim socket as TCP_SOCKET) as byte</code>
Returns	($\neq 0$) If given socket is connected to remote host. (=0) If given socket is not connected to remote host.
Description	This function determines whether a given socket is connected to remote host or not. socket - Socket identifier for which the connection is to be checked.
Requires	Nothing.
Example	<pre>ftpSocket = TCPConnect(RemoteNode, 21) if (ftpSocket = INVALID_SOCKET) then ' Socket is not available ' Return error. end if else smState = SM_CONNECT_WAIT ' Wait for connection... if (TCPIsConnected(ftpSocket) <> 0) then smState = SM_CONNECTED ...</pre>

TCPDisconnect

Prototype	sub procedure TCPDisconnect (dim socket as TCP_SOCKET)
Returns	Nothing.
Description	This function requests remote host to disconnect.
Requires	TCPIsPutReady = TRUE
Example	<pre>' Disconnect TCPDisconnect (ftpSocket) ...</pre>

TCPIsPutReady

Prototype	sub function TCPIsPutReady (dim socket as TCP_SOCKET) as byte
Returns	($\neq 0$) - If given socket is ready to transmit. (=0) - If given socket is not connected or there is no transmit buffer ready.
Description	This function determines if a socket is ready to transmit. A socket is ready to transmit when it is connected to a remote host and when its transmit buffer is empty. <i>socket</i> - Socket identifier that needs to be checked.
Requires	Nothing.
Example	<pre>if (TCPIsPutReady(ftpSocket) $\neq$ 0) then ' Send data ...</pre>



TCPPut

Prototype	sub function TCPPut(dim socket as TCP_SOCKET, dim data as byte) as byte
Returns	(≤ 0) - If a given data byte was successfully loaded into the transmit buffer and there is room for more data. (=0) - If a given data byte was successfully loaded into the transmit buffer and there is no room for more data.
Description	This function loads a data byte into the transmit buffer for a given socket. socket - Socket identifier that needs to be checked. data - Data byte to be loaded.
Requires	TCPIsPutReady = TRUE
Example	<pre> ... if (TCPIsPutReady(ftpSocket) <> 0) then ' Send data TCPPut(ftpSocket, dataByte) ... </pre>

TCPFlush


Prototype	sub procedure TCPFlush(dim socket as TCP_SOCKET)
Returns	Nothing.
Description	This function marks given socket transmit buffer as ready to be transmitted. socket - Socket identifier that needs to be transmitted.
Requires	Nothing.
Example	<pre> ... if (TCPIsPutReady(ftpSocket) <> 0) then ' Send data TCPPut(ftpSocket, dataByte) ... ' Now transmit it. TCPFlush(ftpSocket) ... </pre>

TCPIsGetReady

Prototype	sub function TCPIsGetReady(dim socket as TCP_SOCKET) as byte
Returns	Nothing.
Description	(<>0) - If given socket contains received data. (=0) - If given socket does not contain any data.
Requires	This function determines if the given socket contains received data. socket - Socket identifier that needs to be transmitted.
Example	<pre> ... ' Fetch data if (TCPIsGetReady(httpSocket) <> 0) then ' Fetch data ... </pre>

TCPGet

Prototype	sub function TCPGet(dim socket as TCP_SOCKET, dim byref data as byte) as byte
Returns	(<>0) - If a byte is read. (=0) - If no byte is read.
Description	This function fetches one data byte from a given socket receive buffer. socket - Socket identifier that needs to be fetched. data - Data byte that is read.
Requires	TCPIsGetReady = TRUE
Example	<pre> ... ' Fetch data if (TCPIsGetReady(httpSocket) <> 0) then ' Fetch data TCPGet(httpSocket, dataByte) ... </pre>



TCPGetArray

Prototype	sub function TCPGetArray(dim socket as TCP_SOCKET, dim byref data as byte[1024] , dim count as word) as word
Returns	Total number of data bytes read.
Description	This function fetches a data array from a given socket receive buffer. <i>socket</i> - Socket identifier that needs to be fetched. <i>data</i> - Data array that is read. <i>count</i> - Total number of bytes to read.
Requires	TCPIsGetReady = TRUE
Example	<pre> ... ' Fetch data if (TCPIsGetReady(httpSocket) <> 0) then ' Fetch 20 bytes of data TCPGetArray(httpSocket, buffer, 20) ... </pre>

TCPDiscard


Prototype	sub function TCPDiscard(dim socket as TCP_SOCKET) as byte
Returns	(<>0) - If receive buffer for given socket was successfully discarded. (=0) - If receive buffer for given socket was already discarded.
Description	This function releases the receive buffer associated with a given socket. <i>socket</i> - Socket identifier that needs to be transmitted.
Requires	Nothing.
Example	<pre> ... ' Fetch 20 bytes of data TCPGetArray(httpSocket, buffer, 20) ' Process data. ... ' Release the buffer. TCPDiscard(httpSocket) ... </pre>

TCPProcess

Prototype	sub function TCPProcess (dim byref remote as NODE_INFO, dim len as word) as byte
Returns	($\diamond$ 0) - If this function (task) has completely processed current packet. (=0) - If this function (task) has partially processed current packet.
Description	This function acts as "TCPTask". It fetches an already received TCP packet and executes the TCP State machine for matching sockets. This function must be called only when a TCP packet is received.
Requires	IPGetHeader = TRUE IPProtocol = IP_PRO_TCP
Example	... if (TCPProcess(RemoteNode, IPDataCount) $\diamond$ 0) then smState = SM_STACK_IDLE ... end if

TCPTick

Prototype	sub procedure TCPTick()
Description	This function acts as another "TCPTask" in addition to TCPProcess. This function checks time-out conditions for all sockets and attempts to recover from them.
Requires	IPGetHeader = TRUE IPProtocol = IP_PRO_TCP
Example	TCPTick()



UDPInit


Prototype	sub procedure UDPInit()
Description	This function initializes the UDP module and prepares it for multiple UDP connections.
Requires	Nothing.
Example	<pre>' Initialize UDP UDPInit()</pre>

UDPOpen

Prototype	sub function UDPOpen(dim localPort as UDP_PORT, dim byref remoteNode as NODE_INFO, dim remotePort as TCP_PORT) as UDP_SOCKET
Returns	A valid socket identifier if there is at least one free socket. INVALID_UDP_SOCKET if there is no socket available.
Description	This function prepares the next available UDP socket on a given port for possible data transfer. Either the local or remote node may initiate the data transfer. localPort - Local UDP port number on which data transfer will occur. remoteNode - Remote host that contains remotePort. remotePort - UDP Port number on remote host to transfer the data to and from.
Requires	Nothing.
Example	<pre>... ' Talk to a remote DHCP server. DHCPsocket = UDPOpen(68, DHCPserverNode, 67) if (DHCPsocket = INVALID_UDP_SOCKET) then ' Socket is not available ' Return error. else ' Broadcast DHCP Broadcast message. ... </pre>

UDPClose

Prototype	sub procedure UDPClose(dim socket as UDP_SOCKET)
Description	This function closes a given UDP socket and declares it as a free socket. socket - Identifier of socket that needs to be closed.
Requires	Nothing.
Example	<pre> ... ' Talk to a remote DHCP server. DHCPsocket = UDPOpen(68, DHCPServerNode, 67) if (DHCPsocket = INVALID_UDP_SOCKET) then ' Socket is not available ' Return error. else ' Send DHCP request... ... ' Close the socket UDPClose(DHCPsocket) ... </pre>



UDPIsPutReady


Prototype	<code>sub function UDPIsPutReady(dim socket as UDP_SOCKET) as byte</code>
Returns	($\neq 0$) - If a given socket is ready to transmit. (=0) - If there is no transmit buffer ready.
Description	This macro determines if a given socket is ready to transmit. A socket is ready to transmit when at least one of the MAC transmit buffers is empty. It also sets the given socket as an active UDP socket. <i>socket</i> - Identifier of the socket that needs to be checked and set active.
Requires	Nothing.
Example	<pre>' Talk to a remote DHCP server. DHCPsocket = UDPOpen(68, DHCPserverNode, 67) if (DHCPsocket = INVALID_UDP_SOCKET) then ' Socket is not available ' Return error. else ' Broadcast DHCP Broadcast message. smState = SM_BROADCAST end if if (UDPIsPutReady(DHCPsocket) $\neq$ 0) then ' Socket is ready to transmit. Transmit the data... ...</pre>

UDPPut

Prototype	sub function UDPPut(dim data as byte) as byte
Returns	(<>0) - If a given data byte was successfully loaded into the transmit buffer and there is room for more data. (=0) - If a given data byte was successfully loaded into the transmit buffer and there is no room for more data.
Description	This function loads a data byte into the transmit buffer for an active socket. data - Data byte to be loaded.
Requires	UDPIsPutReady = TRUE
Example	<pre> ... if (UDPIsPutReady(DHCPsocket) <> 0) then ' Socket is ready to transmit. Transmit the data... ' Note that there is DHCPsocket parameter in UDPPut. ' This UDPPut call will use active socket ' as set by UDPIsPutReady() - that is DHCPsocket. UDPPut(\$55) ... </pre>

UDPFlush

Prototype	sub procedure UDPFlush()
Returns	Nothing.
Description	This function marks the active socket transmit buffer as ready to be transmitted.
Requires	UDPPut() is already called and the requested UDP socket is set as the active socket by calling UDPIsPutReady().
Example	<pre> ... if (UDPIsPutReady(DHCPsocket) <> 0) then ' Socket is ready to transmit. Transmit the data... ' Note that there is DHCPsocket parameter in UDPPut. ' This UDPPut call will use active socket ' as set by UDPIsPutReady() - that is DHCPsocket. UDPPut(\$55) ... ' Now transmit it. UDPFlush() ... </pre>



UDPIsGetReady

Prototype	sub function UDPIsGetReady(dim socket as UDP_SOCKET) as byte
Returns	(<>0) - If a given socket contains received data. (=0) - If a given socket does not contain any data.
Description	This function determines if the given socket contains received data. It also sets a given socket as an active socket. socket - Identifier for the socket that needs to be transmitted and set active.
Requires	UDPOpen() is already called. The value of socket must be that returned by UDPOpen() call.
Example	<pre>if (UDPIsGetReady(DHCPSocket) <> 0) then ' Socket does contain some data. Fetch it and process it. ... end if ...</pre>

UDPGet


Prototype	sub function UDPGet(dim byref data as byte) as byte
Returns	(<>0) If a byte is read. (=0) If no byte is read.
Description	This function fetches one data byte from an active socket receive buffer. data - Data byte that is read.
Requires	UDPIsGetReady = TRUE
Example	<pre>... if (UDPIsGetReady(DHCPSocket) <> 0) then ' Socket does contain some data. Fetch it all. ' buffer is a pointer to BYTE. while (UDPGet(Buffer)<>0) inc(buffer) ' Process it. ... ' Discard the socket buffer. ... wend ...</pre>

UDPDiscard

Prototype	sub function UDPDiscard as byte
Returns	Nothing.
Description	This function releases the receive buffer associated with an active socket.
Requires	Nothing.
Example	<pre> ... if (UDPIsGetReady(DHCPSocket) <> 0) then ' Socket does contain some data. Fetch it all. ' buffer is a pointer to BYTE. while (UDPGet(Buffer)<>0) inc(buffer) ' Process it. ... ' Discard the socket buffer. UDPDiscard() wend ... </pre>

UDPProcess

Prototype	sub function UDPProcess(dim byref remote as NODE_INFO, dim len as word) as byte
Returns	(<>0) - If this function (task) has completely processed the current packet. (=0) - If this function (task) has partially processed the current packet.
Description	This function acts as "UDPTask". It fetches an already received UDP packet and assigns it to a matching UDP socket. This function must be called only when a UDP packet is received. remote - Remote node from which the current UDP packet was received. len - Total length of UDP packet length, including UDP header.
Requires	IPGetHeader = TRUE IPProtocol = IP_PRO_UDP
Example	<pre> ... if (UDPProcess(RemoteNode, IPDataCount) <> 0) then smState = SM_STACK_IDLE ... </pre>



UDPWrite

Prototype	sub function UDPWrite(dim UDPSocket as word , dim byref UDPBuffer as byte , dim NoBytes as byte) as byte
Returns	Number of written bytes.
Description	Sends data over UDP protocol. UDPSocket - Writes data to this socket. UDPBuffer - Data to be sent. NoBytes.
Requires	Requires UDPInit and UDPOpenSocket.
Example	<pre>socket = UDPOpenSocket(10001, 192,168,20,1, 10001) ' assign socket for UDP protocol numofbytes = UDPWrite(socket, mydata)</pre>

UDPRead

Prototype	sub function UDPRead(dim UDPSocket as word , dim byref UDPBuffer as byte) as byte
Returns	Number of read bytes.
Description	Reads data over UDP protocol. UDPSocket - Reads data from this socket. UDPBuffer - Data to be read.
Requires	Requires UDPInit and UDPOpenSocket.
Example	<pre>socket = UDPOpenSocket(10001, 192,168,20,1, 10001) ' assign socket for UDP protocol numofbytes = UDPRead(socket, mydata)</pre>

UDPOpenSocket

Prototype	sub function UDPOpenSocket(dim LocUDPPort as word , dim RemoteIPByte1, RemoteIPByte2, RemoteIPByte3, RemoteIPByte4 as byte , dim RemUDPPort as word) as word
Returns	Number of initialized UDP socket.
Description	Opens socket for UDP communication with remote node. LocUDPPort - NIC Udp port, RemoteIPByte1 ... RemoteIPByte4 - Remote host IP address, RemUDPPort - Remote host UDP port.
Requires	Requires UDPInit.
Example	<pre>socket = UDPOpenSocket(10001, 192,168,20,1, 10001) ' assign socket for UDP protocol</pre>

StackInit

Prototype	sub procedure StackInit(dim byref RstPort as word , dim RstPin as word , dim byref CSPORT as word , dim CSPin as word)
Returns	Nothing.
Description	This routine initializes stack and its components.
Requires	Nothing.
Example	StackInit(PORTF, 0, PORTF, 1) ' initialize stack

StackTask

Prototype	sub procedure StackTask()
Returns	Nothing.
Description	This routine executes Stack FSM.
Requires	StackInit() must be called before calling this routine.
Example	StackTask()

HTTPInit

Prototype	sub procedure HTTPInit()
Returns	Nothing.
Description	This routine initializes HTTP protocol.
Requires	Nothing.
Example	HTTPInit()

HTTPServer

Prototype	sub procedure HTTPServer()
Returns	Nothing.
Description	This routine starts HTTP server.
Requires	HTTPInit() must be called before using this routine.
Example	HTTPServer()

Library Example

The following example is a simple demonstration of the Advanced SPI Ethernet Library. dsPIC is assigned an IP address of 192.168.20.60, and will respond to ping if connected to a local area network.

```
program SerialEthernet

include "__Lib_SerEthIP"
include "__Lib_SerEthTCP"
include "MikroEDemoPage"

const TICKS_PER_SECOND = 100
const TICK_SECOND as longint = TICKS_PER_SECOND

const
    DISPLAY          = 0
    LED_D2           = 0x00
    LED_D3           = 0x01
    ANALOGINPUT_0    = 0x02
    ANALOGINPUT_1    = 0x03
    SETTLED_D2       = 0x04
    SETTLED_D3       = 0x05

const HTTP_DEFAULT_PAGE as string[ 19] = "CENTER.HTM"
const EXECUTE_PAGE as string[ 19]      = "EXECUTE.CGI"
const UNKNOWN_PAGE as string[ 20]     = "UNKNOWN.HTM"

const BaudRate          = 9600
      DefaultUDPPort = 10001

structure xxx
    dim ss as ^byte
end structure

dim main_socket as word
    Buffer0      as byte[ 10]
    Buffer1      as byte[ 10]
    Bbuffer     as byte[ 20]
    i           as word
    t           as longint

    IFS0bits    as word absolute $084 volatile register
    IEC0bits    as word absolute $08C volatile register
    T1CONbits   as word absolute $104 volatile register

// continues...
```


// continued...

```
sub function TickGetDiff(dim a, b as longint) as longint
    if( a < b ) then
        result = longint(0xFFFFFFFF - b) + a
    else
        result = longint( a - b )
    end if
end sub
```

```
sub procedure Interrupt_T1() org 0x001A
    TimeOutUpdate()
end sub
```

```
sub procedure ReadAnalogInputs()
    dim ADCResult as word
        ADCFVal as longint

    ADCResult = Adc_Read(0)
    ADCFVal = (ADCResult * 5000) >> 12
    WordToStrWithZeros(adcfval, Buffer0)
    Buffer0[ 5] = Buffer0[ 4]
    Buffer0[ 4] = Buffer0[ 3]
    Buffer0[ 3] = Buffer0[ 2]
    Buffer0[ 0] = " "
    Buffer0[ 2] = "."
    Buffer0[ 6] = " "
    Buffer0[ 7] = "√"
    Buffer0[ 8] = 0

    'IntToStr(ADCResult, Buffer0);
    ADCResult = Adc_Read(1)
    ADCFVal = (ADCResult * 5000) >> 12
    WordToStrWithZeros(adcfval, Buffer1)
    Buffer1[ 5] = Buffer1[ 4]
    Buffer1[ 4] = Buffer1[ 3]
    Buffer1[ 3] = Buffer1[ 2]
    Buffer1[ 0] = " "
    Buffer1[ 2] = "."
    Buffer1[ 6] = " "
    Buffer1[ 7] = "√"
    Buffer1[ 8] = 0
end sub
```

// continues...

```
// continued...
```

```

sub procedure HTTPExecCmd(dim byref argv as xxx[ 20] , dim argc as
byte)
    dim comm as byte
        i, Vvar as byte
        chptr as ^byte

    i = 0
    comm = argv[ i ].ss^ - "0"
    select case comm
        case DISPLAY
            Vvar = argv[ 1 ].ss^ - "0"
            select case Vvar
                case LED_D2
                    LATD.2 = LATD.2 xor 1

                case LED_D3
                    LATD.3 = LATD.3 xor 1
            end select

            chptr = argv[ 0 ].ss
            for i = 0 to 12
                chptr^ = EXECUTE_PAGE[ i]
                chptr = chptr + 1
            next i

        case else
            chptr = argv[ 0 ].ss
            for i = 0 to strlen(EXECUTE_PAGE)
                chptr^ = EXECUTE_PAGE[ i]
                chptr = chptr + 1
            next i
        end select
    end sub

sub function HTTPGetVar(dim Vvar as byte, dim ref as word, dim Vval
as ^byte) as word
    select case Vvar
        case LED_D2
            if( LATD and 0x04) <> 0 then
                Vval^ = "1"
            else
                Vval^ = "0"
            end if

// continues...

```

// continued...

```

case LED_D3
    if( LATD and 0x08 ) <> 0 then
        Vval^ = "1"
    else
        Vval^ = "0"
    end if

case ANALOGINPUT_0
    Vval^ = Buffer0[ byte(ref)]
    if( Buffer0[ byte(ref)] = 0 ) then
        result = 0xFFFF
        exit
    end if
    ref      = ref + 1
    result = ref
    exit

case ANALOGINPUT_1
    Vval^ = Buffer1[ byte(ref)]
    if( Buffer1[ byte(ref)] = 0 ) then
        result = 0xFFFF
        exit
    end if
    ref      = ref + 1
    result = ref
    exit

case SETTLED_D2
    if( LATD and 0x04 ) <> 0 then
        Vval^ = "0"
    else
        Vval^ = "1"
    end if

case SETTLED_D3
    if( LATD and 0x08 ) <> 0 then
        Vval^ = "0"
    else
        Vval^ = "1"
    end if

end select
    result = 0xFFFF
end sub

// continues...

```

```
// continues...
main:
    i = 0
    t = 0
    ADPCFG = 0xFFFF
    PORTD = 0
    TRISD = 0
    PORTB = 0
    TRISB = 0
    ' Set up analog inputs
    TRISB = TRISB or 0x03
    ' Set up the LED's.
    LATD = 0x00
    LATD = LATD or 0x0C
    TRISD = 0x00

    EthSetIPAddr(192, 168, 20, 60)
    EthSetMACAddr(0x00, 0x02, 0x04, 0x06, 0x08, 0x0A)
    EthSetIPMask(0xFF, 0xFF, 0xFF, 0x00)
    EthSetGatewayAddr(192, 168, 20, 60)

    EthInit( @PORTG, 13, @PORTG, 12 )

    ' Open UDP communication sockets needed
    main_socket = UDPOpenSocket(DefaultUDPPort, 192, 168, 20, 1,
DefaultUDPPort)

    ' main loop
while true
        if( TickGetDiff(TickGet(), t) >= TICK_SECOND/2 ) then
            t = TickGet()
            LATD = LATD xor 1
        end if

        StackTask()

        '*
        '* Process incoming UDP packets and send a reply if needed.
        '* User specific code.
        '*


        i = UDPRead(main_socket, @Bbuffer)
        if( i <> 0 ) then
            Bbuffer[ i ] = 0
            UDPWrite(main_socket, @Bbuffer, strlen(Bbuffer))
        end if

        HTTPServer()
        ReadAnalogInputs()
    wend
end.
```

Hardware Connection

176

page





Button Library

The mikroBasic for dsPIC30/33 and PIC24 Button Library provides routines for detecting button presses and debouncing (eliminating the influence of contact flickering upon pressing a button).

Button

Prototype	<code>sub function Button(dim byref port as word, dim pin as byte, dim time as word, dim ActiveState as byte) as word</code>
Returns	- 1 if the pin was in the active state for given period. - 0 otherwise
Description	The function eliminates the influence of contact flickering upon pressing a button (debouncing). The Button pin is tested just after the function call and once again after the debouncing period has expired. If the pin was in the active state in both cases then the function returns 1. Parameters : - port: button port address - pin: button pin - time: debouncing period in milliseconds - ActiveState: determines what is considered as active state. Valid values: 0 (logical zero) and 1 (logical one) Note: There is no need to declare button pin as input. Button function does this automatically.
Example	Example reads buttons RB1..RB0 and displays button states on PORTF : <pre>program Button_Test main: ADPCFG = \$FFFF TRISF = \$0000 LATF = \$AAAA Delay_ms(200) LATF = \$0000 while true ' if button on portb.0 is 5v for 100ms if Button(PORTB, 0, 100, 1) = 1 then LATF = \$0001 else if Button(PORTB, 1, 100, 1) = 1 then LATF = \$0002 end if end if wend</pre>

CAN Library

mikroBasic for dsPIC30/33 and PIC24 provides a library (driver) for working with the dsPIC30F CAN module.

The CAN is a very robust protocol that has error detection and signalization, self-checking and fault confinement. Faulty CAN data and remote frames are re-transmitted automatically, similar to the Ethernet.

Data transfer rates depend on distance. For example, 1 Mbit/s can be achieved at network lengths below 40m while 250 Kbit/s can be achieved at network lengths below 250m. The greater distance the lower maximum bitrate that can be achieved. The lowest bitrate defined by the standard is 200Kbit/s. Cables used are shielded twisted pairs.

CAN supports two message formats:


- Standard format, with 11 identifier bits and
- Extended format, with 29 identifier bits

Note: Consult the CAN standard about CAN bus termination resistance.

Library Routines

CAN1SetOperationMode
CAN1GetOperationMode
CAN1Initialize
CAN1SetBaudRate
CAN1SetMask
CAN1SetFilter
CAN1Read
CAN1Write

CAN2SetOperationMode
CAN2GetOperationMode
CAN2Initialize
CAN2SetBaudRate
CAN2SetMask
CAN2SetFilter
CAN2Read
CAN2Write



The following routines are for an internal use by the library only:

- RegsToCAN1ID
- CAN1IDToRegs
- RegsToCAN2ID
- CAN2IDToRegs


Be sure to check CAN constants necessary for using some of the functions.

CAN1SetOperationMode

Prototype	sub procedure CAN1SetOperationMode(dim mode, WAIT as word)
Returns	Nothing.
Description	Sets the CAN1 module to requested mode. Parameters : - mode: CAN module operation mode. Valid values: CAN_OP_MODE constants. See CAN constants. - WAIT: CAN1 mode switching verification request. If WAIT = 0, the call is non-blocking. The function does not verify if the CAN1 module is switched to requested mode or not. The caller must use CAN1GetOperationMode to verify correct operation mode before performing mode specific operation. If WAIT <> 0, the call is blocking – the function won't "return" until the requested mode is set.
Requires	The CAN1 routines are supported only by MCUs with the CAN1 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus.
Example	<pre>' set the CAN1 module into configuration mode ' (wait inside CAN1SetOperationMode until this mode is set) CAN1SetOperationMode(CAN_MODE_CONFIG, 0xFF)</pre>

CAN1GetOperationMode

Prototype	sub function CAN1GetOperationMode() as word
Returns	Current operation mode.
Description	The function returns current operation mode of the CAN1 module. Check the <code>CAN_OP_MODE</code> constants (see CAN constants) or device datasheet for operation mode codes.
Requires	The CAN1 routines are supported only by MCUs with the CAN1 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus.
Example	<pre>' check whether the CAN1 module is in Normal mode ' and if it is then do something. if (CAN1GetOperationMode() = CAN_MODE_NORMAL) then ... end if</pre>




CAN1Initialize

Prototype	sub procedure CAN1Initialize(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, CAN_CONFIG_FLAGS as word)
Description	Initializes the CAN1 module. The internal dsPIC30F CAN1 module is set to: - Disable CAN capture - Continue CAN operation in Idle mode - Do not abort pending transmissions - Fcan clock : 4*Tcy (Fosc) - Baud rate is set according to the given parameters - CAN mode is set to Normal - Filter and mask registers IDs are set to zero - Filter and mask message frame type is set according to the CAN_CONFIG_FLAGS value The SAM, SEG2PHTS, WAKFIL and DBEN bits are set according to the CAN_CONFIG_FLAGS value. Parameters: - SJW as defined in MCU's datasheet (CAN1 Module) - BRP as defined in MCU's datasheet (CAN1 Module) - PHSEG1 as defined in MCU's datasheet (CAN1 Module) - PHSEG2 as defined in MCU's datasheet (CAN1 Module) - PROPSEG as defined in MCU's datasheet (CAN1 Module) - CAN_CONFIG_FLAGS is formed from predefined constants. See CAN constants Note: CAN mode NORMAL will be set on exit.
Requires	The CAN1 routines are supported only by MCUs with the CAN1 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus.
Example	<pre>' initialize the CAN1 module with appropriate baud rate and ' message acceptance flags along with the sampling rules dim can_config_flags as word ... can_config_flags = CAN_CONFIG_SAMPLE_THRICE and CAN_CONFIG_PHSEG2_PRG_ON and CAN_CONFIG_STD_MSG and CAN_CONFIG_DBL_BUFFER_ON and CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_LINE_FILTER_OFF CAN1Initialize(1,3,3,3,1,can_config_flags) ' initialize the CAN1 module</pre>

CAN1SetBaudRate

Prototype	sub procedure CAN1SetBaudRate(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, CAN_CONFIG_FLAGS as word)
Description	Sets CAN1 baud rate. Due to complexity of the CAN protocol, you can not simply force a bps value. Instead, use this function when CAN1 is in Config mode. Refer to datasheet for details. The SAM, SEG2PHTS and WAKFIL bits are set according to the CAN_CONFIG_FLAGS value. Refer to datasheet for details. Parameters: - SJW as defined in MCU's datasheet (CAN1 Module) - BRP as defined in MCU's datasheet (CAN1 Module) - PHSEG1 as defined in MCU's datasheet (CAN1 Module) - PHSEG2 as defined in MCU's datasheet (CAN1 Module) - PROPSEG as defined in MCU's datasheet (CAN1 Module) - CAN_CONFIG_FLAGS is formed from predefined constants. See CAN constants
Requires	The CAN1 routines are supported only by MCUs with the CAN1 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus. CAN1 must be in Config mode, otherwise the function will be ignored. See CAN1SetOperationMode.
Example	<pre> ' set required baud rate and sampling rules dim can_config_flags as word ... CAN1SetOperationMode(CAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (CAN1 module must be in config mode ' for baud rate settings) can_config_flags = CAN_CONFIG_SAMPLE_THRICE and ' Form value to be used CAN_CONFIG_PHSEG2_PRG_ON and ' with CAN1Initialize CAN_CONFIG_STD_MSG and CAN_CONFIG_DBL_BUFFER_ON and CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_LINE_FILTER_OFF CAN1SetBaudRate(1,3,3,3,1,can_config_flags) ' set the CAN1 module baud rate </pre>




CAN1SetMask

Prototype	<code>sub procedure CAN1SetMask(dim CAN_MASK as word, dim val as longint, dim CAN_CONFIG_FLAGS as word)</code>
Description	The function sets mask for advanced filtering of messages. Parameters: - CAN_MASK: CAN module mask number. Valid values: CAN_MASK constants. See CAN constants - val: mask register value. This value is bit-adjusted to appropriate buffer mask registers - CAN_CONFIG_FLAGS: selects type of message to filter. Valid values: CAN_CONFIG_ALL_VALID_MSG, CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_STD_MSG, CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_XTD_MSG. (see CAN constants)
Requires	The CAN1 routines are supported only by MCUs with the CAN1 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus. CAN1 must be in Config mode, otherwise the function will be ignored. See CAN1SetOperationMode.
Example	<pre>' set appropriate filter mask and message type value CAN1SetOperationMode(CAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (CAN1 module must be in config mode ' for mask settings) ' Set all B1 mask bits to 1 (all filtered bits are relevant) ' Note that -1 is just a cheaper way to write 0xFFFFFFFF. ' Complement will do the trick and fill it up with ones. CAN1SetMask(CAN_MASK_B1, -1, CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_XTD_MSG)</pre>

CAN1SetFilter

Prototype	sub procedure CAN1SetFilter(dim CAN_FILTER as word , dim val as longint , dim CAN_CONFIG_FLAGS as word)
Description	The function sets message filter. Parameters: - CAN_FILTER: CAN module filter number. Valid values: CAN_FILTER constants. See CAN constants - val: filter register value. This value is bit-adjusted to appropriate filter registers - CAN_CONFIG_FLAGS: selects type of message to filter. Valid values: CAN_CONFIG_STD_MSG and CAN_CONFIG_XTD_MSG. See CAN constants
Requires	The CAN1 routines are supported only by MCUs with the CAN1 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus. CAN1 must be in Config mode, otherwise the function will be ignored. See CAN1SetOperationMode.
Example	<pre>' set appropriate filter value and message type CAN1SetOperationMode(CAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (CAN1 module must be ' in config mode for filter settings) ' Set id of filter B1_F1 to 3: CAN1SetFilter(CAN_FILTER_B1_F1, 3, CAN_CONFIG_XTD_MSG)</pre>




CAN1Read

Prototype	<code>sub function CAN1Read(dim byref id as longint, dim byref data as byte[1], dim dataLen, CAN_RX_MSG_FLAGS as word) as word</code>
Returns	- 0 if nothing is received - 0xFFFF if one of the Receive Buffers is full (message received)
Description	If at least one full Receive Buffer is found, it will be processed in the following way: - Message ID is retrieved and stored to location pointed by id pointer - Message data is retrieved and stored to array pointed by data pointer - Message length is retrieved and stored to location pointed by dataLen pointer - Message flags are retrieved and stored to location pointed by CAN_RX_MSG_FLAGS pointer Parameters: - id: message identifier address - data: an array of bytes up to 8 bytes in length - dataLen: data length address - CAN_RX_MSG_FLAGS: message flags address. For message receive flags format refer to the CAN_RX_MSG_FLAGS constants (see CAN constants).
Requires	The CAN1 routines are supported only by MCUs with the CAN1 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus. The CAN1 module must be in a mode in which receiving is possible. See CAN1SetOperationMode.
Example	<pre>' check the CAN1 module for received messages. ' If any was received do something. dim msg_rcvd, rx_flags, data_len as word data as byte[8] msg_id as longint ... CAN1SetOperationMode(CAN_MODE_NORMAL,0xFF) ' set NORMAL mode '(CAN1 module must be in mode in which receive is possible) ... rx_flags = 0 ' clear message flags if (msg_rcvd = CAN1Read(msg_id, data, data_len, rx_flags) <> 0) then ... end if</pre>

CAN1Write

Prototype	sub function CAN1Write(dim id as longint, dim byref data as byte[1] , dim dataLen, CAN_TX_MSG_FLAGS as word) as word
Returns	- 0 if all Transmit Buffers are busy - 0xFFFF if at least one Transmit Buffer is available
Description	If at least one empty Transmit Buffer is found, the function sends message in the queue for transmission. Parameters: - id: CAN1 message identifier. Valid values: 11 or 29 bit values, depending on message type (standard or extended) - Data: data to be sent - DataLen: data length. Valid values: 0..8 - CAN_TX_MSG_FLAGS: message flags. Valid values: CAN_TX_MSG_FLAGS constants. See CAN constants.
Requires	The CAN1 routines are supported only by MCUs with the CAN1 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus. The CAN1 module must be in mode in which transmission is possible. See CAN1SetOperationMode.
Example	<pre>' send message extended CAN message with appropriate ID and data dim tx_flags as word data as byte[8] msg_id as longint ... CAN1SetOperationMode(CAN_MODE_NORMAL,0xFF) ' set NORMAL mode ' (CAN1 must be in mode in which transmission is possible) tx_flags = CAN_TX_PRIORITY_0 and CAN_TX_XTD_FRAME and CAN_TX_NO_RTR_FRAME ' set message flags CAN1Write(msg_id, data, 1, tx_flags)</pre>




CAN2SetOperationMode

Prototype	<code>sub procedure CAN2SetOperationMode(dim mode, WAIT as word)</code>
Description	Sets the CAN2 module to requested mode. Parameters : - <code>mode</code>: CAN2 module operation mode. Valid values: CAN_OP_MODE constants. See CAN constants. - <code>WAIT</code>: CAN2 mode switching verification request. If <code>WAIT = 0</code>, the call is non-blocking. The function does not verify if the CAN2 module is switched to requested mode or not. The caller must use CAN2GetOperationMode to verify correct operation mode before performing mode specific operation. If <code>WAIT <> 0</code>, the call is blocking – the function won't "return" until the requested mode is set.
Requires	The CAN2 routines are supported only by MCUs with the CAN2 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus.
Example	<pre>' set the CAN2 module into configuration mode ' (wait inside CAN2SetOperationMode until this mode is set) CAN2SetOperationMode(CAN_MODE_CONFIG, 0xFF)</pre>

CAN2GetOperationMode

Prototype	sub function CAN2GetOperationMode() as word
Returns	Current operation mode.
Description	The function returns current operation mode of the CAN2 module. Check CAN_OP_MODE constants (see CAN constants) or device datasheet for operation mode codes.
Requires	The CAN2 routines are supported only by MCUs with the CAN2 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus.
Example	<pre>' check whether the CAN2 module is in Normal mode ' and if it is then do something. if (CAN2GetOperationMode() = CAN_MODE_NORMAL) then ... end if</pre>




CAN2Initialize

Prototype	sub procedure CAN2Initialize(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, CAN_CONFIG_FLAGS as word)
Description	Initializes the CAN2 module. The internal dsPIC30F CAN2 module is set to: - Disable CAN capture - Continue CAN operation in Idle mode - Do not abort pending transmissions - Fcan clock : 4*Tcy (Fosc) - Baud rate is set according to the given parameters - CAN mode is set to Normal - Filter and mask registers IDs are set to zero - Filter and mask message frame type is set according to the CAN_CONFIG_FLAGS value The SAM, SEG2PHTS, WAKFIL and DBEN bits are set according to the CAN_CONFIG_FLAGS value. Parameters: - SJW as defined in MCU's datasheet (CAN2 Module) - BRP as defined in MCU's datasheet (CAN2 Module) - PHSEG1 as defined in MCU's datasheet (CAN2 Module) - PHSEG2 as defined in MCU's datasheet (CAN2 Module) - PROPSEG as defined in MCU's datasheet (CAN2 Module) - CAN_CONFIG_FLAGS is formed from predefined constants. See CAN constants Note: CAN mode NORMAL will be set on exit.
Requires	The CAN2 routines are supported only by MCUs with the CAN2 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus.
Example	<pre>' initialize the CAN2 module with appropriate baud rate ' and message acceptance flags along with the sampling rules dim can_config_flags as word ... can_config_flags = CAN_CONFIG_SAMPLE_THRICE and ' Form value to be used CAN_CONFIG_PHSEG2_PRG_ON and ' with CAN2Initialize CAN_CONFIG_STD_MSG and CAN_CONFIG_DBL_BUFFER_ON and CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_LINE_FILTER_OFF CAN2Initialize(1,3,3,3,1,can_config_flags) ' initialize the CAN2</pre>

CAN2SetBaudRate

Prototype	sub procedure CAN2SetBaudRate(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, CAN_CONFIG_FLAGS as word)
Description	Sets CAN2 baud rate. Due to complexity of the CAN protocol, you can not simply force a bps value. Instead, use this function when CAN2 is in Config mode. The SAM, SEG2PHTS and WAKFIL bits are set according to the CAN_CONFIG_FLAGS value. Refer to datasheet for details. Parameters: - SJW as defined in MCU's datasheet (CAN2 Module) - BRP as defined in MCU's datasheet (CAN2 Module) - PHSEG1 as defined in MCU's datasheet (CAN2 Module) - PHSEG2 as defined in MCU's datasheet (CAN2 Module) - PROPSEG as defined in MCU's datasheet (CAN2 Module) - CAN_CONFIG_FLAGS is formed from predefined constants. See CAN constants.
Requires	The CAN2 routines are supported only by MCUs with the CAN2 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus. CAN2 must be in Config mode, otherwise the function will be ignored. See CAN2SetOperationMode.
Example	<pre>' set required baud rate and sampling rules dim can_config_flags as word ... CAN2SetOperationMode(CAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode ' (CAN2 module must be in config mode for baud rate settings) can_config_flags = CAN_CONFIG_SAMPLE_THRICE and ' Form value to be used CAN_CONFIG_PHSEG2_PRG_ON and ' with CAN2SetBaudRate CAN_CONFIG_STD_MSG and CAN_CONFIG_DBL_BUFFER_ON and CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_LINE_FILTER_OFF CAN2SetBaudRate(1,3,3,3,1,can_config_flags) ' set the CAN2 module baud rate</pre>




CAN2SetMask

Prototype	<code>sub procedure CAN2SetMask(dim CAN_MASK as word, dim val as longint, dim CAN_CONFIG_FLAGS as word)</code>
Description	The function sets mask for advanced filtering of messages. Parameters: - CAN_MASK: CAN2 module mask number. Valid values: CAN_MASK constants. See CAN constants - val:mask register value. This value is bit-adjusted to appropriate buffer mask registers - CAN_CONFIG_FLAGS: selects type of message to filter. Valid values: CAN_CONFIG_ALL_VALID_MSG, CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_STD_MSG, CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_XTD_MSG. (see CAN constants)
Requires	The CAN2 routines are supported only by MCUs with the CAN2 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus. CAN2 must be in Config mode, otherwise the function will be ignored. See CAN2SetOperationMode.
Example	<pre>' set appropriate filter mask and message type value CAN2SetOperationMode(CAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (CAN2 module must be in config mode ' for mask settings) ' Set all B1 mask bits to 1 (all filtered bits are relevant): ' Note that -1 is just a cheaper way to write 0xFFFFFFFF. ' Complement will do the trick and fill it up with ones. CAN2SetMask(CAN_MASK_B1, -1, CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_XTD_MSG)</pre>

CAN2SetFilter

Prototype	sub procedure CAN2SetFilter(dim CAN_FILTER as word , dim val as longint , dim CAN_CONFIG_FLAGS as word)
Description	The function sets message filter. Parameters: - CAN_FILTER: CAN2 module filter number. Valid values: CAN_FILTER constants (see CAN constants) - val: filter register value. This value is bit-adjusted to appropriate filter registers - CAN_CONFIG_FLAGS: selects type of message to filter. Valid values: CAN_CONFIG_STD_MSG and CAN_CONFIG_XTD_MSG. See CAN constants
Requires	The CAN2 routines are supported only by MCUs with the CAN2 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus. CAN2 must be in Config mode, otherwise the function will be ignored. See CAN2SetOperationMode.
Example	<pre>' set appropriate filter value and message type CAN2SetOperationMode(CAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (CAN2 module must be ' in config mode for filter settings) ' Set id of filter B1_F1 to 3: CAN2SetFilter(CAN_FILTER_B1_F1, 3, CAN_CONFIG_XTD_MSG)</pre>



CAN2Read

Prototype	<code>sub function CAN2Read(dim byref id as longint, dim byref data as byte[1], dim dataLen, CAN_RX_MSG_FLAGS as word) as word</code>
Returns	- 0 if nothing is received - 0xFFFF if one of the Receive Buffers is full (message received)
Description	If at least one full Receive Buffer is found, it will be processed in the following way: - Message ID is retrieved and stored to location pointed by id pointer - Message data is retrieved and stored to array pointed by data pointer - Message length is retrieved and stored to location pointed by dataLen pointer - Message flags are retrieved and stored to location pointed by CAN_RX_MSG_FLAGS pointer Parameters: - id: message identifier address - data: an array of bytes up to 8 bytes in length - dataLen: data length address. - CAN_RX_MSG_FLAGS: message flags address. For message receive flags format refer to the CAN_RX_MSG_FLAGS constants (see CAN constants).
Requires	The CAN2 routines are supported only by MCUs with the CAN2 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus. The CAN2 module must be in a mode in which receiving is possible. See CAN2SetOperationMode.
Example	<pre>' check the CAN2 module for received messages. ' If any was received do something. dim msg_rcvd, rx_flags, data_len as word data as byte[8] msg_id as longint ... CAN2SetOperationMode(CAN_MODE_NORMAL,0xFF) ' set NORMAL mode ' (CAN2 module must be in mode in which receive is possible) ... rx_flags = 0 ' clear message flags if (msg_rcvd = CAN2Read(msg_id, data, data_len, rx_flags)) then ... end if</pre>

CAN2Write

Prototype	sub function CAN2Write(dim id as longint, dim byref data as byte[1] , dim dataLen, CAN_TX_MSG_FLAGS as word) as word
Returns	- 0 if all Transmit Buffers are busy - 0xFFFF if at least one Transmit Buffer is available
Description	If at least one empty Transmit Buffer is found, the function sends message in the queue for transmission. Parameters: - id: CAN2 message identifier. Valid values: 11 or 29 bit values, depending on message type (standard or extended) - Data: data to be sent - DataLen: data length. Valid values: 0..8 - CAN_TX_MSG_FLAGS: message flags. Valid values: CAN_TX_MSG_FLAGS constants. See CAN constants
Requires	The CAN2 routines are supported only by MCUs with the CAN2 module. MCU must be connected to the CAN transceiver (MCP2551 or similar) which is connected to the CAN bus. The CAN2 module must be in mode in which transmission is possible. See CAN2SetOperationMode.
Example	<pre>' send message extended CAN message with appropriate ID and data dim tx_flags as word data as byte[8] msg_id as longint ... CAN2SetOperationMode(CAN_MODE_NORMAL,0xFF) ' set NORMAL mode ' (CAN2 must be in mode in which transmission is possible) tx_flags = ECAN_TX_PRIORITY_0 and ECAN_TX_XTD_FRAME and ECAN_TX_NO_RTR_FRAME ' set message flags CAN2Write(msg_id, data, 1, tx_flags)</pre>

CAN Constants

There is a number of constants predefined in the CAN library. You need to be familiar with them in order to be able to use the library effectively. Check the example at the end of the chapter.

CAN_OP_MODE

CAN_OP_MODE constants define CAN operation mode. The functions CAN1SetOperationMode and CAN2SetOperationMode expect one of them as their argument:

```
const      CAN_MODE_BITS           as word = $E0
           CAN_MODE_NORMAL         as word = 0x00
           CAN_MODE_DISABLE        as word = 0x01
           CAN_MODE_LOOP           as word = 0x02
           CAN_MODE_LISTEN         as word = 0x03
           CAN_MODE_CONFIG         as word = 0x04
           CAN_MODE_LISTEN_ALL     as word = 0x07
```

CAN_CONFIG_FLAGS

CAN_CONFIG_FLAGS constants define flags related to the CAN module configuration. The functions CAN1Initialize, CAN1SetBaudRate, CAN2Initialize, CAN2SetBaudRate expect one of these (or a bitwise combination) as their argument:

```
const
    CAN_CONFIG_DEFAULT           as word = 0xFF      ' 11111111

    CAN_CONFIG_PHSEG2_PRG_BIT    as word = 0x01
    CAN_CONFIG_PHSEG2_PRG_ON     as word = 0xFF      ' XXXXXXXX1
    CAN_CONFIG_PHSEG2_PRG_OFF    as word = 0xFE      ' XXXXXXXX0

    CAN_CONFIG_LINE_FILTER_BIT   as word = 0x02
    CAN_CONFIG_LINE_FILTER_ON    as word = 0xFF      ' XXXXXXXX1X
    CAN_CONFIG_LINE_FILTER_OFF   as word = 0xFD      ' XXXXXXXX0X

    CAN_CONFIG_SAMPLE_BIT        as word = 0x04
    CAN_CONFIG_SAMPLE_ONCE       as word = 0xFF      ' XXXXXX1XX
    CAN_CONFIG_SAMPLE_THRICE     as word = 0xFB      ' XXXXXX0XX

    CAN_CONFIG_MSG_TYPE_BIT      as word = 0x08
    CAN_CONFIG_STD_MSG           as word = 0xFF      ' XXXX1XXX
    CAN_CONFIG_XTD_MSG           as word = 0xF7      ' XXXX0XXX
' continues...
```


' ..continued

```

CAN_CONFIG_DBL_BUFFER_BIT    as word = 0x10
CAN_CONFIG_DBL_BUFFER_ON     as word = 0xFF    ' XXX1XXXX
CAN_CONFIG_DBL_BUFFER_OFF    as word = 0xEF    ' XXX0XXXX

CAN_CONFIG_MATCH_TYPE_BIT    as word = 0x20
CAN_CONFIG_ALL_VALID_MSG     as word = 0xDF    ' XX0XXXXX
CAN_CONFIG_MATCH_MSG_TYPE    as word = 0xFF    ' XX1XXXXX

```

You may use bitwise and to form config byte out of these values. For example:

```

init  = CAN_CONFIG_SAMPLE_THRICE    and
        CAN_CONFIG_PHSEG2_PRG_ON    and
        CAN_CONFIG_STD_MSG          and
        CAN_CONFIG_DBL_BUFFER_ON    and
        CAN_CONFIG_VALID_XTD_MSG    and
        CAN_CONFIG_LINE_FILTER_OFF

...
CANInitialize(1, 1, 3, 3, 1, init)    ' initialize CAN

```

CAN_TX_MSG_FLAGS

CAN_TX_MSG_FLAGS are flags related to transmission of a CAN message:

```

const
CAN_TX_PRIORITY_BITS as word = 0x03
CAN_TX_PRIORITY_0    as word = 0xFC    ' XXXXXX00
CAN_TX_PRIORITY_1    as word = 0xFD    ' XXXXXX01
CAN_TX_PRIORITY_2    as word = 0xFE    ' XXXXXX10
CAN_TX_PRIORITY_3    as word = 0xFF    ' XXXXXX11

CAN_TX_FRAME_BIT      as word = 0x08
CAN_TX_STD_FRAME      as word = 0xFF    ' XXXXX1XX
CAN_TX_XTD_FRAME      as word = 0xF7    ' XXXXX0XX

CAN_TX_RTR_BIT        as word = 0x40
CAN_TX_NO_RTR_FRAME   as word = 0xFF    ' X1XXXXXX
CAN_TX_RTR_FRAME      as word = 0xBF    ' X0XXXXXX

```

You may use bitwise and to adjust the appropriate flags. For example:

```

' form value to be used with CANSendMessage:
send_config = CAN_TX_PRIORITY_0    and
               CAN_TX_XTD_FRAME    and
               CAN_TX_NO_RTR_FRAME

...
CANSendMessage(id, data, 1, send_config)

```

CAN_RX_MSG_FLAGS

CAN_RX_MSG_FLAGS are flags related to reception of CAN message. If a particular bit is set then corresponding meaning is TRUE otherwise it will be FALSE.

```
const
    CAN_RX_FILTER_BITS    as word = 0x0007
    CAN_RX_FILTER_1      as word = 0x00
    CAN_RX_FILTER_2      as word = 0x01
    CAN_RX_FILTER_3      as word = 0x02
    CAN_RX_FILTER_4      as word = 0x03
    CAN_RX_FILTER_5      as word = 0x04
    CAN_RX_FILTER_6      as word = 0x05
    CAN_RX_OVERFLOW      as word = 0x08
    CAN_RX_INVALID_MSG   as word = 0x10
    CAN_RX_XTD_FRAME     as word = 0x20
    CAN_RX_RTR_FRAME     as word = 0x40
    CAN_RX_DBL_BUFFERED  as word = 0x80
```

You may use bitwise and to adjust the appropriate flags. For example:

```
if (MsgFlag and CAN_RX_OVERFLOW) <> 0 then
    ...
    ' Receiver overflow has occurred.
    ' We have lost our previous message.
end if
```

CAN_MASK

CAN_MASK constants define mask codes. The functions CAN1SetMask and CAN2SetMask expect one of these as their argument:

```
const
    CAN_MASK_B1 as word = 0
    CAN_MASK_B2 as word = 1
```

CAN_FILTER

CAN_FILTER constants define filter codes. The functions CAN1SetFilter and CAN2SetFilter expect one of these as their argument:

```
const
    CAN_FILTER_B1_F1 as word = 0
    CAN_FILTER_B1_F2 as word = 1
    CAN_FILTER_B2_F1 as word = 2
    CAN_FILTER_B2_F2 as word = 3
    CAN_FILTER_B2_F3 as word = 4
    CAN_FILTER_B2_F4 as word = 5
```

Library Example

The example demonstrates CAN protocol. The 1st node initiates the communication with the 2nd node by sending some data to its address. The 2nd node responds by sending back the data incremented by 1. The 1st node then does the same and sends incremented data back to the 2nd node, etc.

program Can1st

```

dim Can_Init_Flags, Can_Send_Flags, Can_Rcv_Flags, Rx_Data_Len as word
    RxTx_Data as byte[ 8]
    Tx_ID, Rx_ID as longint
    Msg_Rcvd as word

main:

    ADPCFG = 0xFFFF
    PORTB = 0
    TRISB = 0

    Can_Init_Flags = 0
    Can_Send_Flags = 0
    Can_Rcv_Flags = 0

    Can_Send_Flags = CAN_TX_PRIORITY_0 and           ' Form value to be used
                  CAN_TX_XTD_FRAME and             ' with CANSendMessage
                  CAN_TX_NO_RTR_FRAME

    Can_Init_Flags = CAN_CONFIG_SAMPLE_THRICE and    ' Form value to be used
                  CAN_CONFIG_PHSEG2_PRG_ON and      ' with CANInitialize
                  CAN_CONFIG_XTD_MSG and
                  CAN_CONFIG_DBL_BUFFER_ON and
                  CAN_CONFIG_MATCH_MSG_TYPE and
                  CAN_CONFIG_LINE_FILTER_OFF

    RxTx_Data[ 0] = 9
    CAN1Initialize(1,3,3,3,1,Can_Init_Flags)          ' initialize CAN
    CAN1SetOperationMode(CAN_MODE_CONFIG,0xFF)        ' set CONFIGURATION mode

    CAN1SetMask(CAN_MASK_B1, -1, CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_XTD_MSG)
    ' set all mask1 bits to ones
    CAN1SetMask(CAN_MASK_B2, -1, CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_XTD_MSG)
    ' set all mask2 bits to ones
    CAN1SetFilter(CAN_FILTER_B2_F3,3,CAN_CONFIG_XTD_MSG) 'set id of filter B2_F3 to 3

    CAN1SetOperationMode(CAN_MODE_NORMAL,0xFF)       ' set NORMAL mode

'continues ...

```

```
' continued...

Tx_ID = 12111

CAN1Write(Tx_ID, RxTx_Data, 1, Can_Send_Flags)

while TRUE
    Msg_Rcvd = CAN1Read(Rx_ID , RxTx_Data , Rx_Data_Len, Can_Rcv_Flags)
    if ((Rx_ID = 3) and (Msg_Rcvd <> 0)) <> 0 then
        PORTB = RxTx_Data[ 0] ' output data at PORTB
        RxTx_Data[ 0] = RxTx_Data[ 0] + 1
        Delay_ms(10)
        CAN1Write(Tx_ID, RxTx_Data, 1, Can_Send_Flags) ' send incremented data back
    end if
wend
end.

program Can2nd

dim Can_Init_Flags, Can_Send_Flags, Can_Rcv_Flags, Rx_Data_Len as word
    RxTx_Data as byte[ 8]
    Tx_ID, Rx_ID as longint
    Msg_Rcvd as word
main:
    ADPCFG = 0xFFFF
    PORTB = 0
    TRISB = 0
    Can_Init_Flags = 0
    Can_Send_Flags = 0
    Can_Rcv_Flags = 0
    Can_Send_Flags = CAN_TX_PRIORITY_0 and ' Form value to be used
        CAN_TX_XTD_FRAME and ' with CANSendMessage
        CAN_TX_NO_RTR_FRAME
    Can_Init_Flags = CAN_CONFIG_SAMPLE_THRICE and ' Form value to be used
        CAN_CONFIG_PHSEG2_PRG_ON and ' with CANInitialize
        CAN_CONFIG_XTD_MSG and
        CAN_CONFIG_DBL_BUFFER_ON and
        CAN_CONFIG_MATCH_MSG_TYPE and
        CAN_CONFIG_LINE_FILTER_OFF

    CAN1Initialize(1,3,3,3,1,Can_Init_Flags) ' initialize CAN
    CAN1SetOperationMode(CAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode

    CAN1SetMask(CAN_MASK_B1, -1, CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_XTD_MSG)
    ' set all mask1 bits to ones
    CAN1SetMask(CAN_MASK_B2, -1, CAN_CONFIG_MATCH_MSG_TYPE and CAN_CONFIG_XTD_MSG)
    ' set all mask2 bits to ones
    CAN1SetFilter(CAN_FILTER_B1_F1,12111,CAN_CONFIG_XTD_MSG)
    CAN1SetOperationMode(CAN_MODE_NORMAL,0xFF) ' set NORMAL mode
    ' continues...
```

' continued...

Tx_ID = 3

while TRUE

Msg_Rcvd = CAN1Read(Rx_ID , RxTx_Data , Rx_Data_Len, Can_Rcv_Flags)

if ((Rx_ID = 12111) **and** (Msg_Rcvd <> 0)) <> 0 **then**

PORTB = RxTx_Data[0] ' output data at PORTB

RxTx_Data[0] = RxTx_Data[0] + 1


CAN1Write(Tx_ID, RxTx_Data, 1, Can_Send_Flags) ' send incremented data back

end if

wend

end.

Hardware Connection



CANSPI Library

The SPI module is available with a number of the dsPIC30/33 and PIC24 MCUs. mikroBasic for dsPIC30/33 and PIC24 provides a library (driver) for working with mikroElektronika's CANSPI Add-on boards (with MCP2515 or MCP2510) via SPI interface.

In mikroBasic for dsPIC30/33 and PIC24, each routine of the CAN library has its own CANSPI counterpart with identical syntax. For more information on Controller Area Network, consult the CAN Library. Note that an effective communication speed depends on SPI and certainly is slower than “real” CAN.

Note:

- CANSPI1 library uses SPI1 module for SPI interface.
- CANSPI2 library uses SPI2 module for SPI interface.

Note:

- CANSPI1 module refers to mikroElektronika's CANSPI Add-on board connected to SPI1 module of MCU.
- CANSPI2 module refers to mikroElektronika's CANSPI Add-on board connected to SPI2 module of MCU.

Library Routines

CANSPI1SetOperationMode	CANSPI2SetOperationMode
CANSPI1GetOperationMode	CANSPI2GetOperationMode
CANSPI1Initialize	CANSPI2Initialize
CANSPI1SetBaudRate	CANSPI2SetBaudRate
CANSPI1SetMask	CANSPI2SetMask
CANSPI1SetFilter	CANSPI2SetFilter
CANSPI1Read	CANSPI2Read
CANSPI1Write	CANSPI2Write


Following routines are for the internal use by compiler only:

RegsToCANSPI1ID	RegsToCANSPI2ID
CANSPI1IDToRegs	CANSPI2IDToRegs

Be sure to check the CANSPI constants necessary for using some of the functions.

CANSPI1SetOperationMode

Prototype	sub procedure CANSPI1SetOperationMode(dim mode as byte, dim WAIT as byte)
Description	Sets the CANSPI1 module to requested mode. Parameters : - mode: CANSPI1 module operation mode. Valid values: CANSPI_OP_MODE constants (see CANSPI constants). - WAIT: CANSPI1 mode switching verification request. If WAIT = 0, the call is non-blocking. The function does not verify if the CANSPI1 module is switched to requested mode or not. The caller must use CANSPI1GetOperationMode to verify correct operation mode before performing mode specific operation. If WAIT <> 0, the call is blocking – the function won't "return" until the requested mode is set.
Requires	The CANSPI1 routines are supported only by MCUs with the SPI1 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' set the CANSPI1 module into configuration mode (wait inside ' CANSPI1SetOperationMode until this mode is set) CANSPI1SetOperationMode(CANSPI_MODE_CONFIG, 0xFF)</pre>




CANSPI1GetOperationMode

Prototype	<code>sub function CANSPI1GetOperationMode() as byte</code>
Returns	Current operation mode.
Description	The function returns current operation mode of the CANSPI1 module. Check the CANSPI_OP_MODE constants (see CANSPI constants) or device datasheet for operation mode codes.
Requires	The CANSPI1 routines are supported only by MCUs with the SPI1 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' check whether the CANSPI1 module is in Normal mode ' and if it is do something. if (CANSPI1GetOperationMode() = CANSPI_MODE_NORMAL) then ... end if</pre>

CANSPI1Init

Prototype	sub procedure CANSPI1Init(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, CAN_CONFIG_FLAGS as byte , dim byref RstPort as word , dim RstPin as word , dim byref CSPort as word , dim CSPin as word)
Description	Initializes the CANSPI1 module. Stand-Alone CAN controller in the CANSPI module is set to: - Disable CAN capture - Continue CAN operation in Idle mode - Do not abort pending transmissions - Fcan clock : 4*Tcy (Fosc) - Baud rate is set according to the given parameters - CAN mode : Normal - Filter and mask registers IDs are set to zero - Filter and mask message frame type is set according to the CAN_CONFIG_FLAGS value SAM, SEG2PHTS, WAKFIL and DBEN bits are set according to the CAN_CONFIG_FLAGS value. Parameters: - SJW as defined in CAN controller's datasheet - BRP as defined in CAN controller's datasheet - PHSEG1 as defined in CAN controller's datasheet - PHSEG2 as defined in CAN controller's datasheet - PROPSEG as defined in CAN controller's datasheet - CAN_CONFIG_FLAGS is formed from predefined constants (see CANSPI constants)
Requires	The CANSPI1 routines are supported only by MCUs with the SPI1 module. The SPI1 module needs to be initialized. See the Spi1_Init and Spi1_Init_Advanced routines. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre> dim can_config_flags as word ... can_config_flags = CANSPI_CONFIG_SAMPLE_THRICE and CANSPI_CONFIG_PHSEG2_PRG_ON and CANSPI_CONFIG_STD_MSG and CANSPI_CONFIG_DBL_BUFFER_ON and CANSPI_CONFIG_VALID_XTD_MSG and CANSPI_CONFIG_LINE_FILTER_OFF ... Spi1_Init() ' initialize SPI1 module CANSPI1Init(1,3,3,3,1,can_config_flags, PORTF, 1, PORTF, 0) ' initialize CANSPI1 </pre>




CANSPI1SetBaudRate

Prototype	sub procedure CANSPI1SetBaudRate(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, CAN_CONFIG_FLAGS as byte)
Description	Sets the CANSPI1 module baud rate. Due to complexity of the CAN protocol, you can not simply force a bps value. Instead, use this function when the CANSPI1 module is in Config mode. SAM, SEG2PHTS and WAKFIL bits are set according to the CAN_CONFIG_FLAGS value. Refer to datasheet for details. Parameters: - SJW as defined in CAN controller's datasheet - BRP as defined in CAN controller's datasheet - PHSEG1 as defined in CAN controller's datasheet - PHSEG2 as defined in CAN controller's datasheet - PROPSEG as defined in CAN controller's datasheet - CAN_CONFIG_FLAGS is formed from predefined constants (see CANSPI constants)
Requires	The CANSPI1 module must be in Config mode, otherwise the function will be ignored. See CANSPI1SetOperationMode. The CANSPI1 routines are supported only by MCUs with the SPI1 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' set required baud rate and sampling rules dim can_config_flags as byte ... CANSPI1SetOperationMode(CANSPI_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (CANSPI1 module mast be in ' config mode for baud rate settings) can_config_flags = CANSPI_CONFIG_SAMPLE_THRICE and CANSPI_CONFIG_PHSEG2_PRG_ON and CANSPI_CONFIG_STD_MSG and CANSPI_CONFIG_DBL_BUFFER_ON and CANSPI_CONFIG_VALID_XTD_MSG and CANSPI_CONFIG_LINE_FILTER_OFF CANSPI1SetBaudRate(1, 1, 3, 3, 1, can_config_flags)</pre>

CANSPI1SetMask

Prototype	sub procedure CANSPI1SetMask(dim CAN_MASK as byte, dim val as longint, dim CAN_CONFIG_FLAGS as byte)
Description	Configures mask for advanced filtering of messages. The parameter val is bit-adjusted to the appropriate mask registers. Parameters: - CAN_MASK: CANSPI1 module mask number. Valid values: CANSPI_MASK constants (see CANSPI constants) - val: mask register value - CAN_CONFIG_FLAGS: selects type of message to filter. Valid values: CANSPI_CONFIG_ALL_VALID_MSG, CANSPI_CONFIG_MATCH_MSG_TYPE and CANSPI_CONFIG_STD_MSG, CANSPI_CONFIG_MATCH_MSG_TYPE and CANSPI_CONFIG_XTD_MSG. (see CANSPI constants)
Requires	The CANSPI1 module must be in Config mode, otherwise the function will be ignored. See CANSPI1SetOperationMode. The CANSPI1 routines are supported only by MCUs with the SPI1 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' set the appropriate filter mask and message type value CANSPI1SetOperationMode(CANSPI_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (CANSPI1 module must be in config mode ' for mask settings) ' Set all B1 mask bits to 1 (all filtered bits are relevant): ' Note that -1 is just a cheaper way to write 0xFFFFFFFF. ' Complement will do the trick and fill it up with ones. CANSPI1SetMask(CANSPI_MASK_B1, -1, CANSPI_CONFIG_MATCH_MSG_TYPE and CANSPI_CONFIG_XTD_MSG)</pre>




CANSPI1SetFilter

Prototype	<code>sub procedure CANSPI1SetFilter(dim CAN_FILTER as byte, dim val as longint, dim CAN_CONFIG_FLAGS as byte)</code>
Description	Configures message filter. The parameter val is bit-adjusted to the appropriate filter registers. Parameters: - CAN_FILTER: CANSPI1 module filter number. Valid values: CANSPI_FILTER constants (see CANSPI constants) - val: filter register value - CAN_CONFIG_FLAGS: selects type of message to filter. Valid values: CANSPI_CONFIG_ALL_VALID_MSG, CANSPI_CONFIG_MATCH_MSG_TYPE and CANSPI_CONFIG_STD_MSG, CANSPI_CONFIG_MATCH_MSG_TYPE and CANSPI_CONFIG_XTD_MSG. (see CANSPI constants)
Requires	The CANSPI1 module must be in Config mode, otherwise the function will be ignored. See CANSPI1SetOperationMode. The CANSPI1 routines are supported only by MCUs with the SPI1 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' set the appropriate filter value and message type CANSPI1SetOperationMode(CANSPI_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (CANSPI1 module must be in ' config mode for filter settings) ' Set id of filter B1_F1 to 3: CANSPI1SetFilter(CANSPI_FILTER_B1_F1, 3, CANSPI_CONFIG_XTD_MSG)</pre>

CANSPI1Read

Prototype	sub function CANSPI1Read(dim byref id as longint , dim byref Data as byte [8] , dim byref DataLen as byte , dim byref CAN_RX_MSG_FLAGS as byte) as byte
Returns	- 0 if nothing is received - 0xFFFF if one of the Receive Buffers is full (message received)
Description	If at least one full Receive Buffer is found, it will be processed in the following way: - Message ID is retrieved and stored to location provided by the id parameter - Message data is retrieved and stored to a buffer provided by the Data parameter - Message length is retrieved and stored to location provided by the DataLen parameter - Message flags are retrieved and stored to location provided by the CAN_RX_MSG_FLAGS parameter Parameters: - id: message identifier storage address - Data: data buffer (an array of bytes up to 8 bytes in length) - DataLen: data length storage address. - CAN_RX_MSG_FLAGS: message flags storage address
Requires	The CANSPI1 module must be in a mode in which receiving is possible. See CANSPI1SetOperationMode. The CANSPI1 routines are supported only by MCUs with the SPI1 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre> dim msg_rcvd, rx_flags, data_len as byte data as byte[8] msg_id as longint ... CANSPI1SetOperationMode(CANSPI_MODE_NORMAL,0xFF) ' set NORMAL mode ' (CANSPI1 module must be in mode in which receive is possible) ... rx_flags = 0 ' clear message flags if (msg_rcvd = CANSPI1Read(msg_id, data, data_len, rx_flags)) then ... end if </pre>



CANSPI1Write


Prototype	sub function CANSPI1Write(dim id as longint, dim byref Data as byte[8] , dim DataLen, CAN_TX_MSG_FLAGS as byte) as byte
Returns	- 0 if all Transmit Buffers are busy - 0xFFFF if at least one Transmit Buffer is available
Description	If at least one empty Transmit Buffer is found, the function sends message in the queue for transmission. Parameters: - id: CAN message identifier. Valid values: 11 or 29 bit values, depending on message type (standard or extended) - Data: data to be sent (an array of bytes up to 8 bytes in length) - DataLen: data length. Valid values: 1 to 8 - CAN_RX_MSG_FLAGS: message flags
Requires	The CANSPI1 module must be in mode in which transmission is possible. See CANSPI1SetOperationMode. The CANSPI1 routines are supported only by MCUs with the SPI1 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' send message extended CAN message ' with the appropriate ID and data dim tx_flags as byte data as byte[8] msg_id as longint ... CANSPI1SetOperationMode(CAN_MODE_NORMAL,0xFF) ' set NORMAL mode (CANSPI1 must be in mode in ' which transmission is possible) tx_flags = CANSPI_TX_PRIORITY_0 and CANSPI_TX_XTD_FRAME ' set message flags CANSPI1Write(msg_id, data, 2, tx_flags)</pre>

CANSPI2SetOperationMode

Prototype	sub procedure CANSPI2SetOperationMode(dim mode as byte, dim WAIT as byte)
Description	Sets the CANSPI module to requested mode. Parameters : - mode: CANSPI2 module operation mode. Valid values: CANSPI_OP_MODE constants (see CANSPI constants). - WAIT: CANSPI2 mode switching verification request. If WAIT = 0, the call is non-blocking. The function does not verify if the CANSPI2 module is switched to requested mode or not. The caller must use CANSPI2GetOperationMode to verify correct operation mode before performing mode specific operation. If WAIT <> 0, the call is blocking – the function won't "return" until the requested mode is set.
Requires	The CANSPI2 routines are supported only by MCUs with the SPI2 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' set the CANSPI2 module into configuration mode ' (wait inside CANSPI2SetOperationMode until this mode is set) CANSPI2SetOperationMode(CANSPI_MODE_CONFIG, 0xFF)</pre>

CANSPI2GetOperationMode

Prototype	sub function CANSPI2GetOperationMode() as byte
Returns	Current operation mode.
Description	The CANSPI2 routines are supported only by the MCUs with SPI2 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' check whether the CANSPI2 module is in Normal mode ' and if it is do something. if (CANSPI2GetOperationMode() = CANSPI_MODE_NORMAL) then ... end if</pre>



CANSPI2Init


211

page

Prototype	sub procedure CANSPI2Init(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, CAN_CONFIG_FLAGS as byte , dim byref RstPort as word , dim RstPin as word , dim byref CSPORT as word , dim CSPin as word)
Description	Initializes the CANSPI2 module. Stand-Alone CAN controller in the CANSPI module is set to: - Disable CAN capture - Continue CAN operation in Idle mode - Do not abort pending transmissions - Fcan clock : 4*Tcy (Fosc) - Baud rate is set according to the given parameters - CAN mode : Normal - Filter and mask registers IDs are set to zero - Filter and mask message frame type is set according to the CAN_CONFIG_FLAGS value SAM, SEG2PHTS, WAKFIL and DBEN bits are set according to the CAN_CONFIG_FLAGS value. Parameters: - SJW as defined in CAN controller's datasheet - BRP as defined in CAN controller's datasheet - PHSEG1 as defined in CAN controller's datasheet - PHSEG2 as defined in CAN controller's datasheet - PROPSEG as defined in CAN controller's datasheet - CAN_CONFIG_FLAGS is formed from predefined constants (see CANSPI constants)
Requires	The CANSPI2 routines are supported only by MCUs with the SPI2 module. The SPI2 module needs to be initialized. See Spi2_Init and the Spi2_Init_Advanced routines. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre> dim can_config_flags as word ... can_config_flags = CANSPI_CONFIG_SAMPLE_THRICE and CANSPI_CONFIG_PHSEG2_PRG_ON and CANSPI_CONFIG_STD_MSG and CANSPI_CONFIG_DBL_BUFFER_ON and CANSPI_CONFIG_VALID_XTD_MSG and CANSPI_CONFIG_LINE_FILTER_OFF ... Spi2_Init() ' initialize SPI CANSPI2Initialize(1, 1, 3, 3, 1, can_config_flags) ' initialize CANSPI2 </pre>

CANSPI2SetBaudRate

Prototype	sub procedure CANSPI2SetBaudRate(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, CAN_CONFIG_FLAGS as byte)
Description	Sets the CANSPI2 module baud rate. Due to complexity of the CAN protocol, you can not simply force a bps value. Instead, use this function when the CANSPI2 module is in Config mode. SAM, SEG2PHTS and WAKFIL bits are set according to the CAN_CONFIG_FLAGS value. Refer to datasheet for details. Parameters: - SJW as defined in CAN controller's datasheet - BRP as defined in CAN controller's datasheet - PHSEG1 as defined in CAN controller's datasheet - PHSEG2 as defined in CAN controller's datasheet - PROPSEG as defined in CAN controller's datasheet - CAN_CONFIG_FLAGS is formed from predefined constants (see CANSPI constants)
Requires	The CANSPI2 module must be in Config mode, otherwise the function will be ignored. See CANSPI2SetOperationMode. The CANSPI2 routines are supported only by MCUs with the SPI2 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' set required baud rate and sampling rules dim can_config_flags as byte ... CANSPI2SetOperationMode(CANSPI_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (CANSPI2 module must be in config mode ' for baud rate settings) can_config_flags = CANSPI_CONFIG_SAMPLE_THRICE and CANSPI_CONFIG_PHSEG2_PRG_ON and CANSPI_CONFIG_STD_MSG and CANSPI_CONFIG_DBL_BUFFER_ON and CANSPI_CONFIG_VALID_XTD_MSG and CANSPI_CONFIG_LINE_FILTER_OFF CANSPI2SetBaudRate(1, 1, 3, 3, 1, can_config_flags)</pre>




CANSPI2SetMask

Prototype	<code>sub procedure CANSPI2SetMask(dim CAN_MASK as byte, dim val as longint, dim CAN_CONFIG_FLAGS as byte)</code>
Description	Configures mask for advanced filtering of messages. The parameter val is bit-adjusted to the appropriate mask registers. Parameters: - CAN_MASK: CANSPI2 module mask number. Valid values: CANSPI_MASK constants (see CANSPI constants) - val: mask register value - CAN_CONFIG_FLAGS: selects type of message to filter. Valid values: CANSPI_CONFIG_ALL_VALID_MSG, CANSPI_CONFIG_MATCH_MSG_TYPE and CANSPI_CONFIG_STD_MSG, CANSPI_CONFIG_MATCH_MSG_TYPE and CANSPI_CONFIG_XTD_MSG. (see CANSPI constants)
Requires	The CANSPI2 module must be in Config mode, otherwise the function will be ignored. See CANSPI2SetOperationMode. The CANSPI2 routines are supported only by MCUs with the SPI2 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' set the appropriate filter mask and message type value CANSPI2SetOperationMode(CANSPI_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (CANSPI2 module must be in config mode ' for mask settings) ' Set all B1 mask bits to 1 (all filtered bits are relevant): ' Note that -1 is just a cheaper way to write 0xFFFFFFFF. ' Complement will do the trick and fill it up with ones. CANSPI2SetMask(CANSPI_MASK_B1, -1, CANSPI_CONFIG_MATCH_MSG_TYPE and CANSPI_CONFIG_XTD_MSG)</pre>

CANSPI2SetFilter

Prototype	sub procedure CANSPI2SetFilter(dim CAN_FILTER as byte, dim val as longint, dim CAN_CONFIG_FLAGS as byte)
Description	Configures message filter. The parameter val is bit-adjusted to the appropriate filter registers. Parameters: - CAN_FILTER: CANSPI2 module filter number. Valid values: CANSPI_FILTER constants (see CANSPI constants) - val: filter register value - CAN_CONFIG_FLAGS: selects type of message to filter. Valid values: CANSPI_CONFIG_ALL_VALID_MSG, CANSPI_CONFIG_MATCH_MSG_TYPE and CANSPI_CONFIG_STD_MSG, CANSPI_CONFIG_MATCH_MSG_TYPE and CANSPI_CONFIG_XTD_MSG. (see CANSPI constants)
Requires	The CANSPI2 module must be in Config mode, otherwise the function will be ignored. See CANSPI2SetOperationMode. The CANSPI2 routines are supported only by MCUs with the SPI2 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' set the appropriate filter value and message type CANSPI2SetOperationMode(CANSPI_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (CANSPI2 module must be in config mode ' for filter settings) ' Set id of filter B1_F1 to 3: CANSPI2SetFilter(CANSPI_FILTER_B1_F1, 3, CANSPI_CONFIG_XTD_MSG)</pre>



CANSPI2Read

215

page

Prototype	sub function CANSPI2Read(dim byref id as longint , dim byref Data as byte [8] , dim byref DataLen as byte , dim byref CAN_RX_MSG_FLAGS as byte) as byte
Returns	- 0 if nothing is received - 0xFFFF if one of the Receive Buffers is full (message received)
Description	If at least one full Receive Buffer is found, it will be processed in the following way: - Message ID is retrieved and stored to location provided by the id parameter - Message data is retrieved and stored to a buffer provided by the Data parameter - Message length is retrieved and stored to location provided by the DataLen parameter - Message flags are retrieved and stored to location provided by the CAN_RX_MSG_FLAGS parameter Parameters: - id: message identifier storage address - data: data buffer (an array of bytes up to 8 bytes in length) - dataLen: data length storage address - CAN_RX_MSG_FLAGS: message flags storage address
Requires	The CANSPI2 module must be in a mode in which receiving is possible. See CANSPI2SetOperationMode. The CANSPI2 routines are supported only by MCUs with the SPI2 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre> ' check the CANSPI2 module for received messages. ' If any was received do something. dim msg_rcvd, rx_flags, data_len as byte data as byte[8] msg_id as longint ... CANSPI2SetOperationMode(CANSPI_MODE_NORMAL,0xFF) ' set NORMAL mode ' (CANSPI2 module must be in mode in which receive is possible) ... rx_flags = 0 clear message flags if (msg_rcvd = CANSPI2Read(msg_id, data, data_len, rx_flags)) then ... end if </pre>

CANSPI2Write

Prototype	sub function CANSPI2Write(dim id as longint, dim byref Data as byte[8] , dim DataLen, CAN_TX_MSG_FLAGS as byte) as byte
Returns	- 0 if all Transmit Buffers are busy - 0xFFFF if at least one Transmit Buffer is available
Description	If at least one empty Transmit Buffer is found, the function sends message in the queue for transmission. Parameters: - id: CAN message identifier. Valid values: 11 or 29 bit values, depending on message type (standard or extended) - Data: data to be sent (an array of bytes up to 8 bytes in length) - DataLen: data length. Valid values: 1 to 8 - CAN_RX_MSG_FLAGS: message flags
Requires	The CANSPI2 module must be in mode in which transmission is possible. See CANSPI2SetOperationMode. The CANSPI2 routines are supported only by MCUs with the SPI2 module. MCU has to be properly connected to mikroElektronika's CANSPI Extra Board or similar hardware. See the example of HW connection at the bottom of this page.
Example	<pre>' send message extended CAN message with the ' appropriate ID and data dim tx_flags as byte data as byte[8] msg_id as longint ... CANSPI2SetOperationMode(CAN_MODE_NORMAL,0xFF) ' set NORMAL mode (CANSPI2 must be in mode in ' which transmission is possible) tx_flags = CANSPI_TX_PRIORITY_0 and CANSPI_TX_XTD_FRAME ' set message flags CANSPI2Write(msg_id, data, 2, tx_flags)</pre>

CANSPI Constants

217

page

There is a number of constants predefined in the CANSPI library. You need to be familiar with them in order to be able to use the library effectively. Check the example at the end of the chapter.

CANSPI_OP_MODE

The CANSPI_OP_MODE constants define CANSPI operation mode. The functions CANSPI1SetOperationMode and CANSPI2SetOperationMode expect one of them as their argument:

```
const
    CANSPI_MODE_BITS      as byte = $E0
    CANSPI_MODE_NORMAL    as byte = 0
    CANSPI_MODE_SLEEP     as byte = $20
    CANSPI_MODE_LOOP      as byte = $40
    CANSPI_MODE_LISTEN    as byte = $60
    CANSPI_MODE_CONFIG    as byte = $80
```

CANSPI_CONFIG_FLAGS

The CANSPI_CONFIG_FLAGS constants define flags related to the CANSPI module configuration. The functions CANSPI1Init, CANSPI2Init, CANSPI1SetBaudRate, CANSPI2SetBaudRate, CANSPI1SetMask, CANSPI2SetMask, CANSPI1SetFilter and CANSPI2SetFilter expect one of them (or a bitwise combination) as their argument:

```
const
    CANSPI_CONFIG_DEFAULT      as byte = $FF      ' 11111111

    CANSPI_CONFIG_PHSEG2_PRG_BIT as byte = $01
    CANSPI_CONFIG_PHSEG2_PRG_ON  as byte = $FF      ' XXXXXXX1
    CANSPI_CONFIG_PHSEG2_PRG_OFF as byte = $FE      ' XXXXXXX0

    CANSPI_CONFIG_LINE_FILTER_BIT as byte = $02
    CANSPI_CONFIG_LINE_FILTER_ON  as byte = $FF      ' XXXXXX1X
    CANSPI_CONFIG_LINE_FILTER_OFF as byte = $FD      ' XXXXXX0X

    CANSPI_CONFIG_SAMPLE_BIT      as byte = $04
    CANSPI_CONFIG_SAMPLE_ONCE     as byte = $FF      ' XXXXXX1XX
    CANSPI_CONFIG_SAMPLE_THRICE   as byte = $FB      ' XXXXXX0XX

' continues..
```

' ..continued

```

CANSPI_CONFIG_MSG_TYPE_BIT      as byte = $08
CANSPI_CONFIG_STD_MSG           as byte = $FF      ' XXXX1XXX
CANSPI_CONFIG_XTD_MSG           as byte = $F7      ' XXXX0XXX

CANSPI_CONFIG_DBL_BUFFER_BIT    as byte = $10
CANSPI_CONFIG_DBL_BUFFER_ON     as byte = $FF      ' XXX1XXXX
CANSPI_CONFIG_DBL_BUFFER_OFF    as byte = $EF      ' XXX0XXXX

CANSPI_CONFIG_MSG_BITS          as byte = $60
CANSPI_CONFIG_ALL_MSG           as byte = $FF      ' X11XXXXX
CANSPI_CONFIG_VALID_XTD_MSG     as byte = $DF      ' X10XXXXX
CANSPI_CONFIG_VALID_STD_MSG     as byte = $BF      ' X01XXXXX
CANSPI_CONFIG_ALL_VALID_MSG     as byte = $9F      ' X00XXXXX

```

You may use bitwise and to form config byte out of these values. For example:

```

init = CANSPI_CONFIG_SAMPLE_THRICE and
       CANSPI_CONFIG_PHSEG2_PRG_ON and
       CANSPI_CONFIG_STD_MSG       and
       CANSPI_CONFIG_DBL_BUFFER_ON and
       CANSPI_CONFIG_VALID_XTD_MSG and
       CANSPI_CONFIG_LINE_FILTER_OFF
...
CANSPIInit(1, 1, 3, 3, 1, init)    ' initialize CANSPI

```

CANSPI_TX_MSG_FLAGS

CANSPI_TX_MSG_FLAGS are flags related to transmission of a CAN message:

```

const
CANSPI_TX_PRIORITY_BITS as byte = $03
CANSPI_TX_PRIORITY_0    as byte = $FC      ' XXXXXX00
CANSPI_TX_PRIORITY_1    as byte = $FD      ' XXXXXX01
CANSPI_TX_PRIORITY_2    as byte = $FE      ' XXXXXX10
CANSPI_TX_PRIORITY_3    as byte = $FF      ' XXXXXX11

CANSPI_TX_FRAME_BIT     as byte = $08
CANSPI_TX_STD_FRAME     as byte = $FF      ' XXXXX1XX
CANSPI_TX_XTD_FRAME     as byte = $F7      ' XXXXX0XX

CANSPI_TX_RTR_BIT       as byte = $40
CANSPI_TX_NO_RTR_FRAME  as byte = $FF      ' X1XXXXXX
CANSPI_TX_RTR_FRAME     as byte = $BF      ' X0XXXXXX

```

You may use bitwise `and` to adjust the appropriate flags. For example:

```
' form value to be used with CANSendMessage:
send_config = CANSPI_TX_PRIORITY_0      and
              CANSPI_TX_XTD_FRAME      and
              CANSPI_TX_NO_RTR_FRAME
...
CANSPI1Write(id, data, 1, send_config)
```

CANSPI_TX_MSG_FLAGS

CANSPI_RX_MSG_FLAGS are flags related to reception of CAN message. If a particular bit is set then corresponding meaning is TRUE otherwise it will be FALSE.

```
const
    CANSPI_RX_FILTER_BITS as byte = $07
    CANSPI_RX_FILTER_1   as byte = $00
    CANSPI_RX_FILTER_2   as byte = $01
    CANSPI_RX_FILTER_3   as byte = $02
    CANSPI_RX_FILTER_4   as byte = $03
    CANSPI_RX_FILTER_5   as byte = $04
    CANSPI_RX_FILTER_6   as byte = $05
    CANSPI_RX_OVERFLOW    as byte = $08
    CANSPI_RX_INVALID_MSG as byte = $10
    CANSPI_RX_XTD_FRAME   as byte = $20
    CANSPI_RX_RTR_FRAME   as byte = $40
    CANSPI_RX_DBL_BUFFERED as byte = $80
```

You may use bitwise `and` to adjust the appropriate flags. For example:

```
if (MsgFlag and CANSPI_RX_OVERFLOW) <> 0 then
    ...
    ' Receiver overflow has occurred.
    ' We have lost our previous message.
end if
```

CANSPI_MASK


The CANSPI_MASK constants define mask codes. The functions CANSPI1SetMask and CANSPI1SetMask expect one of them as their argument:

```
const
    CANSPI_MASK_B1 as byte = 0
    CANSPI_MASK_B2 as byte = 1
```


CANSPI_FILTER

The CANSPI_FILTER constants define filter codes. The functions CANSPI1SetFilter and CANSPI2SetFilter expects one of them as their argument:

```
const
    CANSPI_FILTER_B1_F1 as byte = 0
    CANSPI_FILTER_B1_F2 as byte = 1
    CANSPI_FILTER_B2_F1 as byte = 2
    CANSPI_FILTER_B2_F2 as byte = 3
    CANSPI_FILTER_B2_F3 as byte = 4
    CANSPI_FILTER_B2_F4 as byte = 5
```



Library Example

The code is a simple demonstration of CANSPI protocol. This node initiates the communication with the 2nd node by sending some data to its address. The 2nd node responds by sending back the data incremented by 1. This (1st) node then does the same and sends incremented data back to the 2nd node, etc.

```
program CanSPI1st

dim
    Can_Init_Flags, Can_Send_Flags, Can_Rcv_Flags, Rx_Data_Len as byte
    RxTx_Data as string[ 8]
    Tx_ID, Rx_ID as longint
    Msg_Rcvd as byte

main:
    ADPCFG = 0xFFFF
    PORTB  = 0
    TRISB  = 0

    Can_Init_Flags  = 0
    Can_Send_Flags  = 0
    Can_Rcv_Flags   = 0

    Can_Send_Flags = CANSPI_TX_PRIORITY_0 and      ' form value to be used
                     CANSPI_TX_XTD_FRAME and      ' with CANSPISendMessage
                     CANSPI_TX_NO_RTR_FRAME

    Can_Init_Flags = CANSPI_CONFIG_SAMPLE_THRICE and ' form value to be used
                     CANSPI_CONFIG_PHSEG2_PRG_ON and ' with CANSPIInitialize
                     CANSPI_CONFIG_XTD_MSG and
                     CANSPI_CONFIG_DBL_BUFFER_ON and
                     CANSPI_CONFIG_VALID_XTD_MSG

    ' for faster spi communication use Spi_Init_Advanced routine
    Spi1_Init()
    CANSPI1Init(1, 3, 3, 3, 1, Can_Init_Flags, PORTF, 1, PORTF, 0)
    ' initialize external CAN module

    CANSPI1SetOperationMode(CANSPI_MODE_CONFIG,0xFF) ' set CONFIGURATION mode

    ' continues ..
```

```
' continued ..

RxTx_Data[ 0] = 9

Tx_ID = 12111

CANSPI1Write(Tx_ID, RxTx_Data, 1, Can_Send_Flags)
while TRUE
    Msg_Rcvd = CANSPI1Read(Rx_ID, RxTx_Data , Rx_Data_Len,
Can_Rcv_Flags) ' receive data, if any
    if((Rx_ID = 3) and (Msg_Rcvd <> 0)) <> 0) then
        PORTB = RxTx_Data[ 0]
        RxTx_Data[ 0] = RxTx_Data[ 0] + 1 ' output data at portB
        Delay_ms(5)
        CANSPI1Write(Tx_ID, RxTx_Data, 1, Can_Send_Flags)
    end if
wend
end.

program CanSPI2nd

dim Can_Init_Flags,Can_Send_Flags,Can_Rcv_Flags,Rx_Data_Len as byte
    RxTx_Data as byte[ 8]
    Tx_ID, Rx_ID as longint
    Msg_Rcvd as byte


main:

ADPCFG = 0xFFFF
PORTB = 0
TRISB = 0

Can_Init_Flags = 0
Can_Send_Flags = 0
Can_Rcv_Flags = 0

Can_Send_Flags = CANSPI_TX_PRIORITY_0 and ' Form value to be used
                CANSPI_TX_XTD_FRAME and ' with CANSendMessage
                CANSPI_TX_NO_RTR_FRAME

' continues...
```



' continued ..

```

Can_Init_Flags = CANSPI_CONFIG_SAMPLE_THRICE and      ' Form value to be used
                  CANSPI_CONFIG_PHSEG2_PRG_ON and      ' with CANInitialize
                  CANSPI_CONFIG_XTD_MSG and
                  CANSPI_CONFIG_DBL_BUFFER_ON and
                  CANSPI_CONFIG_VALID_XTD_MSG and
                  CANSPI_CONFIG_LINE_FILTER_OFF

' for faster spi communication use Spi_Init_Advanced routine
Spi1_Init()
CANSPI1Init(1,3,3,3,1, Can_Init_Flags, PORTF, 1, PORTF, 0) ' initialize CAN

CANSPI1SetOperationMode(CANSPI_MODE_CONFIG,0xFF)      ' set CONFIGURATION mode

CANSPI1SetMask(CANSPI_MASK_B1, -1, CANSPI_CONFIG_XTD_MSG)
' set all mask1 bits to ones
CANSPI1SetMask(CANSPI_MASK_B2, -1, CANSPI_CONFIG_XTD_MSG)
' set all mask2 bits to ones
CANSPI1SetFilter(CANSPI_FILTER_B2_F3,12111,CANSPI_CONFIG_XTD_MSG)
' set id of filter B2_F3 to 3

CANSPI1SetOperationMode(CANSPI_MODE_NORMAL,0xFF) ' set NORMAL mode


Tx_ID = 3

while TRUE
  Msg_Rcvd = CANSPI1Read(Rx_ID , RxTx_Data , Rx_Data_Len, Can_Rcv_Flags)
  if ((Rx_ID = 12111) and (Msg_Rcvd <> 0)) <> 0 then
    PORTB = RxTx_Data[ 0] ' output data at portB
    RxTx_Data[ 0] = RxTx_Data[ 0] + 1
    CANSPI1Write(Tx_ID, RxTx_Data, 1, Can_Send_Flags)
  end if
wend
end.
```

Hardware Connection

224

page



Compact Flash Library

The Compact Flash Library provides routines for accessing data on Compact Flash card (abbr. CF further in text). CF cards are widely used memory elements, commonly used with digital cameras. Great capacity and excellent access time of only a few microseconds make them very attractive for the microcontroller applications.

In CF card, data is divided into sectors. One sector usually comprises 512 bytes. Routines for file handling, the Cf_Fat routines, are not performed directly but successively through 512B buffer.

Note: Routines for file handling can be used only with FAT16 file system.

Note: Library functions create and read files from the root directory only.

Note: Library functions populate both FAT1 and FAT2 tables when writing to files, but the file data is being read from the FAT1 table only; i.e. there is no recovery if the FAT1 table gets corrupted.

Note: If MMC/SD card has Master Boot Record (MBR), the library will work with the first available primary (logical) partition that has non-zero size. If MMC/SD card has Volume Boot Record (i.e. there is only one logical partition and no MBRs), the library works with entire card as a single partition. For more information on MBR, physical and logical drives, primary/secondary partitions and partition tables, please consult other resources, e.g. Wikipedia and similar.


Note: Before writing operation, make sure not to overwrite boot or FAT sector as it could make your card on PC or digital camera unreadable. Drive mapping tools, such as Winhex, can be of great assistance.

Library Routines

Cf_Init	Cf_Fat_Init
Cf_Detect	Cf_Fat_QuickFormat
Cf_Enable	Cf_Fat_Assign
Cf_Disable	Cf_Fat_Reset
Cf_Read_Init	Cf_Fat_Read
Cf_Read_Byte	Cf_Fat_Rewrite
Cf_Write_Init	Cf_Fat_Append
Cf_Write_Byte	Cf_Fat_Delete
Cf_Read_Sector	Cf_Fat_Write
Cf_Write_Sector	Cf_Fat_Set_File_Date
	Cf_Fat_Get_File_Date
	Cf_Fat_Get_File_Size
	Cf_Fat_Get_Swap_File

Cf_Init

Prototype	<pre>sub procedure Cf_Init(dim byref port_A012 as word, dim pin_A0, pin_A1, pin_A2 as word, dim byref port_RDY as word, dim pin_RDY as word, dim byref port_WE as word, dim pin_WE as word, dim byref port_OE as word, dim pin_OE as word, dim byref port_CD1 as word, dim pin_CD1 as word, dim byref port_CE1 as word, dim pin_CE1 as word, dim byref port_Data as word)</pre>
Description	- Initializes ports appropriately for communication with CF card. Parameters : - port_A012: address pins port. - pin_A2, pin_A1, pin_A0: address pins - port_RDY: ready signal port address - pin_RDY: ready signal pin - port_WE: write enable port address - pin_WE: write enable pin - port_OE: output enable port address - pin_OE: output enable pin - port_CD1: chip detect port address - pin_CD1: chip detect pin - port_CE1: chip enable port address - pin_CE1: chip enable pin - port_Data: data port. Pins <7:0> are used.
Example	<pre>'----- Init for EasydsPIC2 sub procedure Cf_Init_EASYdsPIC2() Cf_Init(PORTB,8,9,10, PORTC,15, PORTC,14, PORTC,13, PORTB,12, PORTB,11, PORTB) end sub '----- Init for dsPICPRO sub procedure Cf_Init_dsPICPRO2() Cf_Init(PORTD,8,9,10, PORTG,14, PORTG,12, PORTD,11, PORTG,15, PORTG,13, PORTD) end sub</pre>



Cf_Detect

Prototype	<code>sub function Cf_Detect() as word</code>
Returns	- 1 - if CF card was detected - 0 - otherwise
Description	Checks for presence of CF card by reading the chip detect pin. Important: The dsPIC30 family MCU and CF card voltage levels are different. The user must ensure that MCU's pin connected to CD line can read CF card Logical One correctly.
Requires	The corresponding MCU ports must be appropriately initialized for CF card. See Cf_Init.
Example	<pre>' Wait until CF card is inserted: while (Cf_Detect() = 0) nop</pre>

Cf_Enable


Prototype	<code>sub procedure Cf_Enable()</code>
Returns	Nothing.
Description	Enables the device. Routine needs to be called only if you have disabled the device by means of the Cf_Disable routine. These two routines in conjunction allow you to free/occupy data line when working with multiple devices.
Requires	The corresponding MCU ports must be appropriately initialized for CF card. See Cf_Init.
Example	<pre>' enable compact flash Cf_Enable()</pre>

Cf_Disable

Prototype	<code>sub procedure Cf_Disable()</code>
Returns	Nothing.
Description	Routine disables the device and frees the data lines for other devices. To enable the device again, call <code>Cf_Enable</code> . These two routines in conjunction allow you to free/occupy data line when working with multiple devices.
Requires	The corresponding MCU ports must be appropriately initialized for CF card. See <code>Cf_Init</code> .
Example	<pre>' disable compact flash Cf_Disable()</pre>

Cf_Read_Init

Prototype	<code>sub procedure Cf_Read_Init(dim address as longint, dim sectcnt as word)</code>
Description	Initializes CF card for reading. Parameters : - address: the first sector to be prepared for reading operation. - sectcnt: number of sectors to be prepared for reading operation.
Requires	The corresponding MCU ports must be appropriately initialized for CF card. See <code>Cf_Init</code> .
Example	<pre>' initialize compact flash for reading from sector 590 Cf_Read_Init(590, 1)</pre>



Cf_Read_Byte

Prototype	sub function Cf_Read_Byte() as word
Returns	Returns a byte read from Compact Flash sector buffer. Note: Higher byte of the unsigned return value is cleared.
Description	Reads one byte from Compact Flash sector buffer location currently pointed to by internal read pointers. These pointers will be autoincremented upon reading.
Requires	The corresponding MCU ports must be appropriately initialized for CF card. See Cf_Init. CF card must be initialized for reading operation. See Cf_Read_Init.
Example	<pre>' Read a byte from compact flash: dim data as byte ... data = Cf_Read_Byte()</pre>

Cf_Write_Init


Prototype	sub procedure Cf_Write_Init(dim address as longint , dim sectcnt as word)
Description	Initializes CF card for writing. Parameters : - address: the first sector to be prepared for writing operation. - sectcnt: number of sectors to be prepared for writing operation.
Requires	The corresponding MCU ports must be appropriately initialized for CF card. See Cf_Init.
Example	<pre>' initialize compact flash for writing to sector 590 Cf_Write_Init(590, 1)</pre>

Cf_Write_Byte

Prototype	sub procedure Cf_Write_Byte(dim data as byte)
Description	Writes a byte to Compact Flash sector buffer location currently pointed to by writing pointers. These pointers will be autoincremented upon reading. When sector buffer is full, its content will be transfered to appropriate flash memory sector. Parameters : - data: byte to be written.
Requires	The corresponding MCU ports must be appropriately initialized for CF card. See Cf_Init. CF card must be initialized for writing operation. See Cf_Write_Init.
Example	<pre>dim data as byte ... data = 0xAA Cf_Write_Byte(data)</pre>

Cf_Read_Sector

Prototype	sub procedure Cf_Read_Sector(dim sector_number as longint, dim byref buffer as byte[512])
Description	Reads one sector (512 bytes). Read data is stored into buffer provided by the buffer parameter. Parameters : - sector_number: sector to be read. - buffer: data buffer of at least 512 bytes in length.
Requires	The corresponding MCU ports must be appropriately initialized for CF card. See Cf_Init.
Example	<pre>' read sector 22 dim data as byte[512] ... Cf_Read_Sector(22, data)</pre>




Cf_Write_Sector

Prototype	<code>sub procedure Cf_Write_Sector(dim sector_number as longint, dim byref buffer as byte[512])</code>
Returns	Nothing.
Description	Writes 512 bytes of data provided by the buffer parameter to one CF sector. Parameters : - sector_number: sector to be written to. - buffer: data buffer of 512 bytes in length.
Requires	The corresponding MCU ports must be appropriately initialized for CF card. See Cf_Init.
Example	<pre>' write to sector 22 dim data as byte[512] ... Cf_Write_Sector(22, data)</pre>

Cf_Fat_Init

Prototype	<pre>sub function Cf_Fat_Init(dim byref port_A012 as word, dim pin_A0, pin_A1, pin_A2 as word, dim byref port_RDY as word, dim pin_RDY as word, dim byref port_WE as word, dim pin_WE as word, dim byref port_OE as word, dim pin_OE as word, dim byref port_CD1 as word, dim pin_CD1 as word, dim byref port_CE1 as word, dim pin_CE1 as word, dim byref port_Data as word) as word</pre>
Returns	- 0 - if CF card was detected and successfully initialized - 1 - if FAT16 boot sector was not found - 255 - if card was not detected
Description	Initializes CF card, reads CF FAT16 boot sector and extracts data needed by the library. Parameters : - port_A012: address pins port. - pin_A2, pin_A1, pin_A0: address pins - port_RDY: ready signal port address - pin_RDY: ready signal pin - port_WE: write enable port address - pin_WE: write enable pin - port_OE: output enable port address - pin_OE: output enable pin - port_CD1: chip detect port address - pin_CD1: chip detect pin - port_CE1: chip enable port address - pin_CE1: chip enable pin - port_Data: data port address. Pins <7:0> are used.
Requires	Nothing.
Example	<pre>'--- init the FAT library - dsPICPRO2 if (Cf_Fat_Init(PORTD,8,9,10, PORTG,14, PORTG,12, PORTD,11, PORTG,15, PORTG,13, PORTD) = 0) then ... end if</pre>




Cf_Fat_QuickFormat

Prototype	<pre>sub function Cf_Fat_QuickFormat(dim byref port_A012 as word, dim pin_A0, pin_A1, pin_A2 as word, dim byref port_RDY as word, dim pin_RDY as word, dim byref port_WE as word, dim pin_WE as word, dim byref port_OE as word, dim pin_OE as word, dim byref port_CD1 as word, dim pin_CD1 as word, dim byref port_CE1 as word, dim pin_CE1 as word, dim byref port_Data as word, dim byref cf_fat_label as string[11]) as word</pre>
Returns	- 0 - if CF card was detected, successfully formatted and initialized - 1 - if FAT16 format was unseccessful - 255 - if card was not detected
Description	Formats to FAT16 and initializes CF card. Parameters : - port_A012: address pins port. - pin_A2, pin_A1, pin_A0: address pins - port_RDY: ready signal port address - pin_RDY: ready signal pin - port_WE: write enable port address - pin_WE: write enable pin - port_OE: output enable port address - pin_OE: output enable pin - port_CD1: chip detect port address - pin_CD1: chip detect pin - port_CE1: chip enable port address - pin_CE1: chip enable pin - port_Data: data port address. Pins <7:0> are used. - cf_fat_label: volume label (11 characters in length). If less than 11 characters are provided, the label will be padded with spaces. If an empty string is passed, the volume will not be labeled. Note: This routine can be used instead or in conjunction with the Cf_Fat_Init routine. Note: If CF card already contains a valid boot sector, it will remain unchanged (except volume label field) and only FAT and ROOT tables will be erased. Also, the new volume label will be set.
Example	<pre>'--- format and initialize the FAT library - dsPICPRO2 if (Cf_Fat_QuickFormat(PORTD,8,9,10, PORTG,14, PORTG,12, PORTD,11, PORTG,15, PORTG,13, PORTD, 'mikroE') = 0) then ... end if</pre>

Cf_Fat_Assign

Prototype	<code>sub function Cf_Fat_Assign(dim byref filename as string[2], dim file_cre_attr as byte) as word</code>																											
Returns	- 0 if file does not exist and no new file is created. - 1 if file already exists or file does not exist but a new file is created.																											
Description	Assigns file for file operations (read, write, delete...). All subsequent file operations will be applied to the assigned file. Parameters : - filename: name of the file that should be assigned for file operations. The file name should be in DOS 8.3 (file_name.extension) format. The file name and extension will be automatically padded with spaces by the library if they have less than length required (i.e. "mikro.tx" -> "mikro .tx "), so the user does not have to take care of that. The file name and extension are case insensitive. The library will convert them to the proper case automatically, so the user does not have to take care of that. Also, in order to keep backward compatibility with the first version of this library, file names can be entered as UPPERCASE string of 11 bytes in length with no dot character between the file name and extension (i.e. "MIKROELETXT" -> MIKROELE.TXT). In this case the last 3 characters of the string are considered to be file extension. - file_cre_attr: file creation and attributs flags. Each bit corresponds to the appropriate file attribut: <table><tr><th>BIT</th><th>MASK</th><th>Description</th></tr><tr><td>0</td><td>0x01</td><td>Read Only</td></tr><tr><td>1</td><td>0x02</td><td>Hidden</td></tr><tr><td>2</td><td>0x04</td><td>System</td></tr><tr><td>3</td><td>0x08</td><td>Volume Label</td></tr><tr><td>4</td><td>0x10</td><td>Subdirectory</td></tr><tr><td>5</td><td>0x20</td><td>Archive</td></tr><tr><td>6</td><td>0x40</td><td>Device (internal use only, never found on disk)</td></tr><tr><td>7</td><td>0x80</td><td>File creation flag. If the file does not exist and this flag is set, a new file with specified name will be created.</td></tr></table> Note: Long File Names (LFN) are not supported.	BIT	MASK	Description	0	0x01	Read Only	1	0x02	Hidden	2	0x04	System	3	0x08	Volume Label	4	0x10	Subdirectory	5	0x20	Archive	6	0x40	Device (internal use only, never found on disk)	7	0x80	File creation flag. If the file does not exist and this flag is set, a new file with specified name will be created.
BIT	MASK	Description																										
0	0x01	Read Only																										
1	0x02	Hidden																										
2	0x04	System																										
3	0x08	Volume Label																										
4	0x10	Subdirectory																										
5	0x20	Archive																										
6	0x40	Device (internal use only, never found on disk)																										
7	0x80	File creation flag. If the file does not exist and this flag is set, a new file with specified name will be created.																										
Requires	CF card and CF library must be initialized for file operations. See Cf_Fat_Init.																											
Example	<code>' create file with archive attribut if it does not already exist Cf_Fat_Assign("MIKRO007.TXT",0xA0)</code>																											



Cf_Fat_Reset

235

page

Prototype	sub procedure Cf_Fat_Reset(dim byref size as longint)
Returns	Nothing.
Description	Opens currently assigned file for reading. Parameters : - size: buffer to store file size to. After file has been open for reading its size is returned through this parameter.
Requires	CF card and CF library must be initialized for file operations. See Cf_Fat_Init. File must be previously assigned. See Cf_Fat_Assign.
Example	<pre>dim size as longint ... Cf_Fat_Reset(size)</pre>

Cf_Fat_Read

Prototype	sub procedure Cf_Fat_Read(dim byref bdata as byte)
Description	Reads a byte from currently assigned file opened for reading. Upon function execution file pointers will be set to the next character in the file. Parameters : - bdata: buffer to store read byte to. Upon this function execution read byte is returned through this parameter.
Requires	CF card and CF library must be initialized for file operations. See Cf_Fat_Init. File must be previously assigned. See Cf_Fat_Assign. File must be open for reading. See Cf_Fat_Reset.
Example	<pre>dim character as byte ... Cf_Fat_Read(character)</pre>

Cf_Fat_Rewrite


Prototype	sub procedure Cf_Fat_Rewrite()
Returns	Nothing.
Description	Opens currently assigned file for writing. If the file is not empty its content will be erased.
Requires	CF card and CF library must be initialized for file operations. See Cf_Fat_Init. The file must be previously assigned. See Cf_Fat_Assign.
Example	<i>' open file for writing</i> Cf_Fat_Rewrite()

Cf_Fat_Append

Prototype	sub procedure Cf_Fat_Append()
Returns	Nothing.
Description	Opens currently assigned file for appending. Upon this function execution file pointers will be positioned after the last byte in the file, so any subsequent file writing operation will start from there.
Requires	CF card and CF library must be initialized for file operations. See Cf_Fat_Init. File must be previously assigned. See Cf_Fat_Assign.
Example	<i>' open file for appending</i> Cf_Fat_Append()

Cf_Fat_Delete

Prototype	sub procedure Cf_Fat_Delete()
Description	Deletes currently assigned file from CF card.
Requires	CF card and CF library must be initialized for file operations. See Cf_Fat_Init. File must be previously assigned. See Cf_Fat_Assign.
Example	<i>' delete current file</i> Cf_Fat_Delete()



Cf_Fat_Write

237

page

Prototype	sub procedure Cf_Fat_Write(dim byref fdata as byte [12] , dim data_len as word)
Returns	Nothing.
Description	Writes requested number of bytes to currently assigned file opened for writing. Parameters : - fdata: data to be written. - data_len: number of bytes to be written
Requires	CF card and CF library must be initialized for file operations. See Cf_Fat_Init. File must be previously assigned. See Cf_Fat_Assign. File must be open for writing. See Cf_Fat_Rewrite or Cf_Fat_Append.
Example	dim file_contents as array [42] ... Cf_Fat_Write(file_contents, 42) ' write data to the assigned file

Cf_Fat_Set_File_Date


Prototype	sub procedure Cf_Fat_Set_File_Date(dim year as word , dim month as byte , dim day as byte , dim hours as byte , dim mins as byte , dim seconds as byte)
Returns	Nothing.
Description	Sets the date/time stamp. Any subsequent file writing operation will write this stamp to currently assigned file's time/date attributs. Parameters : - year: year attribute. Valid values: 1980-2107 - month: month attribute. Valid values: 1-12 - day: day attribute. Valid values: 1-31 - hours: hours attribute. Valid values: 0-23 - mins: minutes attribute. Valid values: 0-59 - seconds: seconds attribute. Valid values: 0-59
Requires	CF card and CF library must be initialized for file operations. See Cf_Fat_Init. File must be previously assigned. See Cf_Fat_Assign. File must be open for writing. See Cf_Fat_Rewrite or Cf_Fat_Append.
Example	Cf_Fat_Set_File_Date(2005,9,30,17,41,0)

Cf_Fat_Get_File_Date

Prototype	sub procedure Cf_Fat_Get_File_Date(dim byref year as word , dim byref month as byte , dim byref day as byte , dim byref hours as byte , dim byref mins as byte)
Description	Reads time/date attributes of currently assigned file. Parameters : - year: buffer to store year attribute to. Upon function execution year attribute is returned through this parameter. - month: buffer to store month attribute to. Upon function execution month attribute is returned through this parameter. - day: buffer to store day attribute to. Upon function execution day attribute is returned through this parameter. - hours: buffer to store hours attribute to. Upon function execution hours attribute is returned through this parameter. - mins: buffer to store minutes attribute to. Upon function execution minutes attribute is returned through this parameter.
Requires	CF card and CF library must be initialized for file operations. See Cf_Fat_Init. File must be previously assigned. See Cf_Fat_Assign.
Example	<pre> dim year as word month, day, hours, mins as byte ... Cf_Fat_Get_File_Date(year, month, day, hours, mins) </pre>

Cf_Fat_Get_File_Size

Prototype	sub function Cf_Fat_Get_File_Size() as longint
Returns	Size of the currently assigned file in bytes.
Description	This function reads size of currently assigned file in bytes.
Requires	CF card and CF library must be initialized for file operations. See Cf_Fat_Init. File must be previously assigned. See Cf_Fat_Assign.
Example	<pre> dim my_file_size as longint ... my_file_size = Cf_Fat_Get_File_Size() </pre>



Cf_Fat_Get_Swap_File

Prototype	<code>sub function Cf_Fat_Get_Swap_File(dim sectors_cnt as longint, dim byref filename as string[11], dim file_attr as byte) as longint</code>
Returns	- Number of the start sector for the newly created swap file, if there was enough free space on CF card to create file of required size. - 0 - otherwise.
Description	This function is used to create a swap file of predefined name and size on the CF media. If a file with specified name already exists on the media, search for consecutive sectors will ignore sectors occupied by this file. Therefore, it is recommended to erase such file if it exists before calling this function. If it is not erased and there is still enough space for a new swap file, this function will delete it after allocating new memory space for a new swap file. The purpose of the swap file is to make reading and writing to CF media as fast as possible, by using the Cf_Read_Sector() and Cf_Write_Sector() functions directly, without potentially damaging the FAT system. The swap file can be considered as a "window" on the media where the user can freely write/read data. Its main purpose in the mikroBasic's library is to be used for fast data acquisition; when the time-critical acquisition has finished, the data can be re-written into a "normal" file, and formatted in the most suitable way. Parameters: - <code>sectors_cnt</code>: number of consecutive sectors that user wants the swap file to have. - <code>filename</code>: name of the file that should be assigned for file operations. The file name should be in DOS 8.3 (<code>file_name.extension</code>) format. The file name and extension will be automatically padded with spaces by the library if they have less than length required (i.e. "mikro.tx" -> "mikro .tx "), so the user does not have to take care of that. The file name and extension are case insensitive. The library will convert them to the proper case automatically, so the user does not have to take care of that. Also, in order to keep backward compatibility with the first version of this library, file names can be entered as UPPERCASE string of 11 bytes in length with no dot character between the file name and extension (i.e. "MIKROELETXT" -> MIKROELE.TXT). In this case the last 3 characters of the string are considered to be file extension. - <code>file_attr</code>: file creation and attributs flags. Each bit corresponds to the appropriate file attribut: <i>' continues on the next page ...</i>

' continued from the previous page ...

BIT	MASK	Description
0	0x01	Read Only
1	0x02	Hidden
2	0x04	System
3	0x08	Volume Label
4	0x10	Subdirectory
5	0x20	Archive
6	0x40	Device (internal use only, never found on disk)
7	0x80	Not Used


Note: Long File Names (LFN) are not supported.

Requires

CF card and CF library must be initialized for file operations. See Cf_Fat_Init.

Example

```
' Try to create a swap file with archive attribute,
' whose size will be at least 1000 sectors.
' If it succeeds, it sends the No. of start sector over USART
dim size as longint
...
size = Cf_Fat_Get_Swap_File(1000, 'mikroE.txt', 0x20)
if (size <> 0) then
    Usart_Write(0xAA)
    Usart_Write(Lo(size))
    Usart_Write(Hi(size))
    Usart_Write(Higher(size))
    Usart_Write(Highest(size))
    Usart_Write(0xAA)
end if
```



Library Example

This program test routines for reading/writing bytes from/to Compact Flash card and routines for reading/writing Compact Flash card sectors.

```

program Mmc_Fat16_Test

const
    SWAP_FILE_MSG as string[ 15] = "Swap file at: "

dim
    fat_txt as string[ 20]
    file_contents as string[ 50]

    filename as byte[ 14]           ' File names

    loop1, loop12 as word
    character as byte
    i, size as longint

    Buffer as byte[ 512]

sub procedure Glob_Init
    fat_txt = "FAT16 not found"
    file_contents = "XX  CF/SD FAT16 library by Anton Rieckert" + Chr(10) + Chr(0)
    filename = "MIKRO00xTXT" ' File names
end sub

'M-M-M----- Creates new file and writes some data to it
sub procedure M_Create_New_File
    filename[ 7] = "A"
    Cf_Fat_Assign(filename, 0xA0)           ' Will not find file and then create file
    Cf_Fat_Rewrite                          ' To clear file and start with new data
    for loop1 = 1 to 99                     ' We want 5 files on the MMC card
        Uart1_Write_Char(".")
        file_contents[ 0] = (loop1 div 10) + 48
        file_contents[ 1] = (loop1 mod 10) + 48
        'Uart1_Write_Text(file_contents)
        Cf_Fat_Write(file_contents, 42)    ' write data to the assigned file
    next loop1
end sub '~

' .. continues

```

```
' .. continued

'M-M-M----- Creates many new files and writes data to them
sub procedure M_Create_Multiple_Files
  for loop12 = "B" to "Z"
    Uart1_Write_Char(loop12)           ' signal the progress
    filename[ 7] = loop12              ' set filename
    Cf_Fat_Assign(filename, 0xA0)      ' find existing file or create a new one
    Cf_Fat_Rewrite                     ' To clear file and start with new data
    for loop1 = 1 to 44
      file_contents[ 0] = (loop1 div 10) + 48
      file_contents[ 1] = (loop1 mod 10) + 48
      Cf_Fat_Write(file_contents, 42)  ' write data to the assigned file
    next loop1
  next loop12
end sub '~

'M-M-M----- Opens an existing file and rewrites it
sub procedure M_Open_File_Rewrite
  filename[ 7] = "C"
  Cf_Fat_Assign(filename, 0)
  Cf_Fat_Rewrite
  for loop1 = 1 to 55
    file_contents[ 0] = loop1 div 10 + 64
    file_contents[ 1] = loop1 mod 10 + 64
    Cf_Fat_Write(file_contents, 42)    ' write data to the assigned file
  next loop1
end sub '~

'M-M-M----- Opens an existing file and appends data to it
'              (and alters the date/time stamp)
sub procedure M_Open_File_Append
  filename[ 7] = "B"
  Cf_Fat_Assign(filename, 0)
  Cf_Fat_Set_File_Date(2005,6,21,10,35,0)
  Cf_Fat_Append ' Prepare file for append
  Cf_Fat_Write(" for mikroElektronika 2005\n", 27) ' Write data to assigned file
end sub '~

' .. continues
```

```
' .. continued

' M-M-M----Opens an existing file, reads data from it
' and puts it to USART
sub procedure M_Open_File_Read
    filename[ 7] = "B"
    Cf_Fat_Assign(filename, 0)
    Cf_Fat_Reset(size)
    ' To read file, sub procedure returns size of file
    for i = 1 to size
        Cf_Fat_Read(caracter)
        Uart1_Write_Char(caracter) ' Write data to USART
    next i
end sub '~

'M-M-M----- Deletes a file. If file doesn't exist,
'it will first be created
'and then deleted.
sub procedure M_Delete_File
    filename[ 7] = "F"
    Cf_Fat_Assign(filename, 0)
    Cf_Fat_Delete
end sub '~

' M-M-M----- Tests whether file exists,
' and if so sends its creation date
' and file size via USART
sub procedure M_Test_File_Exist(dim fLetter as byte)
    dim
        fsize as longint
        year as word
        month1, day, hour1, minutel as byte
        outstr as byte[ 12]

    filename[ 7] = fLetter
    if (Cf_Fat_Assign(filename, 0) <> 0) then
        '--- file has been found - get its date
        Cf_Fat_Get_File_Date(year, month1, day, hour1, minutel)
        WordToStr(year, outstr)
        Uart1_Write_Text(outstr)
        WordToStr(month1, outstr)
        Uart1_Write_Text(outstr)
        WordToStr(day, outstr)
        Uart1_Write_Text(outstr)
        WordToStr(hour1, outstr)
        Uart1_Write_Text(outstr)
        WordToStr(minutel, outstr)
        Uart1_Write_Text(outstr)

' .. continues
```



```

' .. continued

    '--- get file size
    fsize = Cf_Fat_Get_File_Size
    LongIntToStr(longint(fsize), outstr)
    Uart1_Write_Text(outstr)
  else
    '--- file was not found - signal it
    Uart1_Write_Char(0x55)
    Delay_ms(1000)
    Uart1_Write_Char(0x55)
  end if
end sub  '~

'----- Tries to create a swap file, whose
' size will be at least 100
' sectors (see Help for details)
sub procedure M_Create_Swap_File
  dim i as word

  for i=0 to 511
    Buffer[i] = i
  next i

  size = Cf_Fat_Get_Swap_File(5000, "mikroE.txt", 0x20)
  ' see help on this function for details

  if (size <> 0) then
    LongIntToStr(size, fat_txt)
    Uart1_Write_Text(fat_txt)

    for i=0 to 4999
      Cf_Write_Sector(size, Buffer)
      Inc(size)
      Uart1_Write_Char(".")
    next i
  end if
end sub  '~

' .. continues

```

```
' .. continued
main:
    Glob_Init
    '--- prepare PORTB for signalling
    ADPCFG = 0xFFFF
    PORTB = 0
    TRISB = 0
    '--- set up USART for the file read
    Uart1_Init(19200)
    Uart1_Write_Text("start")
    '--- init the FAT library
    '** dsPIC30F601x, dsPICPro3
    ' use fat16 quick format instead of init routine for format
    CF_fat_Init(PORTG, 0, 1, 2,
                PORTG, 9,
                PORTG, 8,
                PORTG, 7,
                PORTG, 6,
                PORTG, 3,
                PORTD)' data port
                = 0 then

    '**
    Delay_ms(500)
    '--- Test start
    PORTB = 0x0005
    '--- Test routines. Uncomment them one-by-one for test
    M_Create_New_File
    M_Create_Multiple_Files
    Uart1_Write_Char(10)


    M_Open_File_Rewrite
    M_Open_File_Append
    M_Delete_File
    M_Create_Swap_File
    Uart1_Write_Char(10)

    M_Open_File_Read
    Uart1_Write_Char(10)
    M_Test_File_Exist("F")    ' this file will not exist here
    Uart1_Write_Char(10)
    M_Test_File_Exist("B")    ' this file will exist here
    Uart1_Write_Char(10)
else
    Uart1_Write_Text(fat_txt)
end if
'--- Test termination
PORTB = 0xFFFF
end.
```

Hardware Connection

246

page



DSP Library

mikroBasic for dsPIC30/33 and PIC24 includes libraries for DSP engine.

Library Routines :


```
FIR_Radix
IIR_Radix
FFT
IFFT
BitReverseComplex
Vector_Set
VectorPower
Vector_Subtract
VectorScale
Vector_Negate
Vector_Multiply
Vector_Min
Vector_Max
Vector_Dot
Vector_Correlate
Vector_Convolve
Vector_Add
Matrix_Transponse
Matrix_Subtract
Matrix_Scale
Matrix_Multiply
Matrix_Add
```

FIR_Radix

Prototype	sub function FIR_Radix(dim FilterOrder as Word, dim ptrCoeffs as LongInt, dim BuffLength as Word, dim ptrInput as Word, dim Index as Word) as Word
Description	This function applies FIR filter to ptrInput. Input samples must be in Y data space. - FilterOrder is order of the filter + 1. - ptrCoeffs is address of filter coefficients in program memory. - BuffLength represents number of samples ptrInput points to. - ptrInput is address of input samples. - Index index of current sample.
Returns	sum(k=0..N-1) (coef[k]*input[N-k]) - Current sample of processed signal (B[n]) N - buffer length k - Current index

IIR_Radix

Prototype	sub function IIR_Radix(dim BScale as Integer, dim AScale as Integer, dim ptrB as Word, dim ptrA as Word, dim FilterOrder as Word, dim ptrInput as Word, dim Input_Len as Word, dim ptrOutput as Word, dim Index as Word) as Word
Description	This function applies IIR filter to ptrInput. Input and output samples must be in Y data space. - AScale A Scale factor - BScale B Scale factor - ptrB Address of B coefficients (In program memory) - ptrA Address of A coefficients (In program memory) - FilterOrder is order of the filter + 1. - ptrInput is address of input samples. - Input_Len represents number of samples ptrInput points to. - ptrOutput is address of output samples. Output length is equal to Input length. - Index index of current sample.
Returns	y[n]=sum(k=0..N) (Acoef[k]*x[n-k]) - sum(k=1..M) (Bcoef[k]*y[n-k])



FFT


249

page

Prototype	sub procedure FFT(dim log2N as word, dim TwiddleFactorsAddress as LongInt, dim byref Samples as word[1024])
Description	Function applies FFT transformation to input samples, input samples must be in Y data space. - N - buffer length (must be the power of 2). - TwiddleFactorsAddress is address of costant array which contains complex twiddle factors.The array is expected to be in program memory. - Samples array of input samples. Upon completion complex array of FFT samples is placed in the Samples parameter.
Operation	$F(k) = 1/N \cdot \sum_n (f(n) \cdot WN(kn))$, $WN(kn) = \exp[-(j \cdot 2 \cdot \pi \cdot k \cdot n)/N]$ F_n - array of complex input samples n in $\{0, 1, \dots, N-1\}$, and k in $\{0, 1, \dots, N-1\}$, with $N = 2^m$, m element of Z. WN - TwiddleFactors The amplitude of current FFT sample is calculated as: $F[k] = \sqrt{Re[k]^2 + Im[k]^2}$
Note	Complex array of FFT samples is placed in Samples parameter. Input Samples are arranged in manner Re,Im,Re,Im... (where Im is always zero). Output samples are arranged in the same manner but Im parts are different from zero. Output samples are symmetrical (First half of output samples (index from 0 to N/2) is identical to the second half of output samples(index from N/2 to N). Input data is a complex vector such that the magnitude of the real and imaginary parts of each of its elements is less than 0.5. If greater or equal to this value the results could produce saturation. Note that the output values are scaled by a factor of 1/N, with N the length of the FFT. input is expected in natural ordering, while output is produced in bit reverse ordering.

IFFT

Prototype	sub procedure IFFT(dim log2N as word , dim TwiddleFactorsAddress as LongInt , dim byref FftSamples as word [1024])
Description	Function applies IFFT transformation to input samples, input samples must be in Y data space. - N - buffer length (must be the power of 2). - TwiddleFactorsAddress is address of constant array which contains complex twiddle factors. The array is expected to be in program memory. - Samples array of input samples. Upon completion complex array of IFFT samples is placed in the Samples parameter.
Operation	$f(k) = 1/N * \sum_n (F(n) * WN(kn)), WN(kn) = \exp[j * 2 * \pi * k * n / N]$ F_n - array of complex input samples n in {0, 1, ..., N-1}, and k in {0, 1, ..., N-1}, with N = 2^m, m element of Z. WN - TwiddleFactors
Note	Complex array of IFFT samples is placed in Samples parameter. Input Samples are arranged in manner Re,Im,Re,Im... (where Im is always zero). Input data is a complex vector such that the magnitude of the real and imaginary parts of each of its elements is less than 0.5. If greater or equal to this value the results could produce saturation. Note that the output values are scaled by a factor of 1/N, with N the length of the IFFT. Input is expected in bit reverse ordering, while output is produced in natural ordering.



BitReverseComplex

Prototype	<code>sub procedure BitReverseComplex(dim log2N as word, dim byref ReIm as word[1024])</code>
Description	This function does Complex (in-place) Bit Reverse re-organization. - N - buffer length (must be the power of 2). - ReIm - Output Sample(from FFT).
Note	Input samples must be in Y data space.

Vector_Set

Prototype	<code>sub procedure Vector_Set(dim byref input as array[1024] of word, dim size, value as word) ;</code>
Description	Sets size elements of input to value, starting from the first element. Size must be > 0. Length of input is limited by available ram.

VectorPower


Prototype	<code>sub function VectorPower(dim N as word, dim byref Vector as word[1024]) as word</code>
Description	Function returns result of power value (powVal) in radix point 1.15
Operation	<code>powVal = sum (srcV[n] * srcV[n])</code> with n in {0, 1,... , numElems-1}
Input	N = number of the elements in vector(s) (numElems) Vector = ptr to source vector (srcV)
Note	AccuA used, not restored CORCON saved, used, restored

Vector_Subtract

Prototype	sub procedure Vector_Subtract(dim byref dest, v1, v2 as word [1024] , dim numElems as word)
Description	This procedure does subtraction of two vectors. numElems must be less or equal to minimum size of two vectors. - v1 - First Vector - v2 - Second Vector - dest - Result Vector
Operation	dstV[n] = srcV1[n] - srcV2[n] with n in {0, 1,... , numElems-1}
Note	AccuA used, not restored. CORCON saved, used, restored.

VectorScale

Prototype	sub procedure VectorScale(dim N as word , dim ScaleValue as integer , dim byref SrcVector, DestVector as word [1024])
Description	This procedure does vector scaling with scale value. - N - Buffer length - SrcVector - original vector - DestVector - scaled vector - ScaleValue - Scale Value
Operation	dstV[n] = sclVal * srcV[n] , with n in {0, 1,... , numElems-1}
Note	AccuA used, not restored. CORCON saved, used, restored



Vector_Negate

Prototype	<code>sub procedure Vector_Negate(dim byref srcVector, DestVector as word[1024] , dim numElems as word)</code>
Description	This procedure does negation of vector. - srcVector - Original vector - destVector - Result vector - numElems - Number of Elements
Operation	$dstV[n] = (-1)*srcV1[n] + 0,$ $0 \leq n < numElems$
Note	Negate of 0x8000 is 0x7FFF. AccuA used, not restored. CORCON saved, used, restored.

Vector_Multiply


Prototype	<code>sub procedure Vector_Multiply(dim byref v1, v2, dest as word[1024] , dim numElems as word)</code>
Description	This procedure does multiplication of two vectors. numElems must be less or equal to minimum size of two vectors. - v1 - First Vector - v2 - Second Vector - dest - Result Vector
Operation	$dstV[n] = srcV1[n] * srcV2[n]$ with n in {0, 1,... , numElems-1}
Note	AccuA used, not restored. CORCON saved, used, restored

Vector_Min

Prototype	sub function Vector_Min(dim byref Vector as word [1024] , dim numElems as word , dim byref MinIndex as word) as word
Description	This function find min. value in vector. - Vector - Original vector. - numElems - Number of elements - MinIndex - Index of minimum value
Operation	minVal = min {srcV[n], n in {0, 1,...numElems-1} if srcV[i] = srcV[j] = minVal, and i < j, then minIndex = j
Returns	minimum value (minVal)

Vector_Max

Prototype	sub function Vector_Max(dim byref Vector as word [1024] , dim numElems as word , dim byref MaxIndex as word) as word
Description	This function find max. value in vector. - Vector - Original vector. - numElems - Number of elements - MaxIndex - Index of maximum value
Operation	maxVal = max {srcV[n], n in {0, 1,...numElems-1} } if srcV[i] = srcV[j] = maxVal, and i < j, then maxIndex = j
Returns	maximum value (maxVal)



Vector_Dot

Prototype	sub function Vector_Dot(dim byref v1, v2 as word [1024] , dim numElems as word) as word
Description	Procedure calculates vector dot product. - v1 - First vector. - v2 - Second vector - numElems - Number of elements
Operation	dotVal = sum (srcV1[n] * srcV2[n]), with n in {0, 1,... , numElems-1}
Note	AccuA used, not restored. CORCON saved, used, restored.

Vector_Correlate

Prototype	sub procedure Vector_Correlate(dim byref v1, v2, dest as word [1024] , dim numElemsV1, numElemsV2 as word)
Description	Procedure calculates Vector correlation (using convolution). - v1 - First vector. - v2 - Second vector - numElemsV1 - Number of first vector elements - numElemsV2 - Number of second vector elements - dest - Result vector
Operation	r[n] = sum_(k=0:N-1){x[k]*y[k+n]}, where: x[n] defined for 0 <= n < N, y[n] defined for 0 <= n < M, (M <= N), r[n] defined for 0 <= n < N+M-1.

Vector_Convolve

Prototype	sub procedure Vector_Convolve(dim byref v1, v2, dest as word[1024] , dim numElemsV1, numElemsV2 as word)
Description	Procedure calculates Vector using convolution. - v1 - First vector. - v2 - Second vector - numElemsV1 - Number of first vector elements - numElemsV2 - Number of second vector elements - dest - Result vector
Operation	$y[n] = \sum_{(k=0:n)} \{x[k]*h[n-k]\}, 0 \leq n < M$ $y[n] = \sum_{(k=n-M+1:n)} \{x[k]*h[n-k]\}, M \leq n < N$ $y[n] = \sum_{(k=n-M+1:N-1)} \{x[k]*h[n-k]\}, N \leq n < N+M-1$
Note	AccuA used, not restored. CORCON saved, used, restored.

Vector_Add

Prototype	sub procedure Vector_Add(dim byref dest, v1, v2 as word[256] , dim numElems as word)
Description	Procedure calculates vector addition. - v1 - First vector. - v2 - Second vector - numElemsV1 - Number of vector elements - dest - Result vector
Operation	$dstV[n] = srcV1[n] + srcV2[n],$ with n in {0, 1,... , numElems-1}
Note	AccuA used, not restored. CORCON saved, used, restored.



Matrix_Transponse

Prototype	<code>sub procedure Matrix_Transponse(dim byref src, dest as word[1024], dim numRows, numCols as word)</code>
Description	Procedure does matrix transposition. src - Original matrix. dest - Result matrix numRows - Number of matrix rows numCols - Number of matrix columns
Operation	<code>dstM[i][j] = srcM[j][i]</code>

Matrix_Subtract


Prototype	<code>sub procedure Matrix_Subtract(dim byref src1, src2, dest as word[1024], dim numRows, numCols as word)</code>
Description	Procedure does matrix subtraction. - src1 - First matrix. - src2 - Second matrix - dest - Result matrix - numRows - Number of matrix rows - numCols - Number of matrix columns
Operation	<code>dstM[i][j] = srcM1[i][j] - srcM2[i][j]</code>
Note	AccuA used, not restored. AccuB used, not restored. CORCON saved, used, restored.

Matrix_Scale

Prototype	sub procedure Matrix_Scale(dim ScaleValue as word , dim byref src1, dest as word [1024] , dim numRows, numCols as word)
Description	Procedure does matrix scale. - ScaleValue - Scale Value - src1 - Original matrix - dest - Result matrix - numRows - Number of matrix rows - numCols - Number of matrix columns
Operation	dstM[i][j] = sclVal * srcM[i][j]
Note	AccuA used, not restored. CORCON saved, used, restored.

Matrix_Multiply

Prototype	sub procedure Matrix_Multiply(dim byref src1, src2, dest as word [256] , dim numRows1, numCols2, numCols1Rows2 as word)
Description	Procedure does matrix multiply. - src1 - First Matrix - src2 - Second Matrix - dest - Result Matrix - numRows1 - Number of first matrix rows - numCols2 - Number of second matrix columns - numCols1Rows2 - Number of first matrix columns and second matrix rows
Operation	dstM[i][j] = sum_k(srcM1[i][k]*srcM2[k][j]), with i in {0, 1, ..., numRows1-1} j in {0, 1, ..., numCols2-1} k in {0, 1, ..., numCols1Rows2-1}
Note	AccuA used, not restored. CORCON saved, used, restored.



Matrix_Add

Prototype	<code>sub procedure Matrix_Add(dim byref src1, src2, dest as word[1024] , dim numRows, numCols as word)</code>
Description	Procedure does matrix addition. - src1 - First Matrix - src2 - Second Matrix - dest - Result Matrix - numRows1 - Number of first matrix rows - numCols2 - Number of second matrix columns
Operation	<code>dstM[i][j] = srcM1[i][j] + srcM2[i][j]</code>
Note	AccuA used, not restored. CORCON saved, used, restored.

ECAN Library

mikroBasic for dsPIC30/33 and PIC24 provides a library (driver) for working with the dsPIC33FJ and pic24HJ ECAN module.

ECAN is a very robust protocol that has error detection and signalling, self-checking and fault confinement. Faulty ECAN data and remote frames are re-transmitted automatically, similar to the Ethernet.

Data transfer rates depend on distance. For example, 1 Mbit/s can be achieved at network lengths below 40m while 250 Kbit/s can be achieved at network lengths below 250m. The greater distance the lower maximum bitrate that can be achieved. The lowest bitrate defined by the standard is 200Kbit/s. Cables used are shielded twisted pairs.

ECAN supports two message formats:

- Standard format, with 11 identifier bits, and
- Extended format, with 29 identifier bits

ECAN message format and DMA RAM buffer definition can be found in the `ECan_Defs.dbas` header file located in the ECAN project folder. Read this file carefully and make appropriate adjustments for mcu in use. Also, if a new project is to be created, this file has to be copied, adjusted and included into the project with corresponding Search Path updating.

Note: ECAN buffers are located in DMA RAM, so two DMA channels are used for message transfer, one for each direction (ECAN->DMA RAM, DMA RAM->ECAN). See the `ECAN1DmaChannelInit` and `ECAN2DmaChannelInit` routines.

Note: Consult CAN standard about CAN bus termination resistance.

Library Routines

ECAN1DmaChannelInit
 ECAN1SetOperationMode
 ECAN1GetOperationMode
 ECAN1Initialize
 ECAN1SelectTxBuffers
 ECAN1FilterDisable
 ECAN1FilterEnable
 ECAN1SetBufferSize
 ECAN1SetBaudRate
 ECAN1SetMask
 ECAN1SetFilter
 ECAN1Read
 ECAN1Write


ECAN2DmaChannelInit
 ECAN2SetOperationMode
 ECAN2GetOperationMode
 ECAN2Initialize
 ECAN2SelectTxBuffers
 ECAN2FilterDisable
 ECAN2FilterEnable
 ECAN2SetBufferSize
 ECAN2SetBaudRate
 ECAN2SetMask
 ECAN2SetFilter
 ECAN2Read

The following routines are for the internal use by the library only:

- RegsToECAN1ID
- ECAN1IDToRegs
- RegsToECAN2ID
- ECAN2IDToRegs

ECAN1DmaChannelInit

Prototype	sub function ECAN1DmaChannelInit(dim DmaChannel as word , dim ChannelDir as word , dim DmaRamBuffAdd as word) as word
Returns	- 0 - if dma channel parameter is valid - 0x0001 - if dma channel is already in use (busy) - 0xFFFF - if dma channel parameter is invalid
Description	The function preforms initialization of the DMA module for ECAN. Parameters: - DmaChannel: DMA Channel number. Valid values: 0..7. - ChannelDir: transfer direction. Valid values: 1 (dma ram to peripheral) and 0 (peripheral to dma ram). - DmaRamBuffAdd: DMA RAM buffer address. DMA RAM location is MCU dependent, refer to datasheet for valid address range.
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus.
Example	<i>' channel 0 will transfer 8 words from dma ram at 0x4000 to ECAN1</i> <pre>ECAN1DmaChannelInit(0, 1, 0x4000)</pre>



ECAN1SetOperationMode

263

page


Prototype	sub procedure ECAN1SetOperationMode(dim mode as word , dim WAIT as word)
Description	Sets the ECAN1 module to requested mode. Parameters : - mode: ECAN1 module operation mode. Valid values: ECAN_OP_MODE constants. See ECAN constants. - WAIT: ECAN1 mode switching verification request. If WAIT = 0, the call is non-blocking. The function does not verify if the ECAN1 module is switched to requested mode or not. The caller must use ECAN1GetOperationMode to verify correct operation mode before performing mode specific operation. If WAIT <> 0, the call is blocking – the function won't "return" until the requested mode is set and no additional verification is necessary.
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus.
Example	<pre>' set the ECAN1 module into configuration mode (wait inside ' ECAN1SetOperationMode until this mode is set) ECAN1SetOperationMode(ECAN_MODE_CONFIG, 0xFF)</pre>

ECAN1GetOperationMode

Prototype	sub function ECAN1GetOperationMode() as word
Returns	Current operation mode.
Description	The function returns current operation mode of the ECAN1 module. Check the ECAN_OP_MODE constants (see ECAN constants) or device datasheet for operation mode codes.
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus.
Example	<pre>' check whether the ECAN1 module is in Normal mode ' and if it is do something. if (ECAN1GetOperationMode() = ECAN_MODE_NORMAL) then ... end if</pre>

ECAN1Initialize

Prototype	sub procedure ECAN1Initialize(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, ECAN_CONFIG_FLAGS as word)
Description	Initializes the ECAN1 module. The internal ECAN1 module is set to: - Disable ECAN capture - Continue ECAN operation in Idle mode - Abort all pending transmissions - Clear all transmit control registers - Fcan clock : Fcy ($F_{osc}/2$) - Baud rate is set according to given parameters - ECAN mode is set to Normal - Filter and mask registers remain unchanged The SAM, SEG2PHTS, WAKFIL and DBEN bits are set according to the ECAN_CONFIG_FLAGS value. Parameters: - SJW as defined in MCU's datasheet (ECAN1 Module) - BRP as defined in MCU's datasheet (ECAN1 Module) - PHSEG1 as defined in MCU's datasheet (ECAN1 Module) - PHSEG2 as defined in MCU's datasheet (ECAN1 Module) - PROPSEG as defined in MCU's datasheet (ECAN1 Module) - ECAN_CONFIG_FLAGS ECAN module configuration flags. Each bit corresponds to the appropriate ECAN module parameter. Should be formed out of predefined ECAN flag constants. See ECAN constants. Note: ECAN mode NORMAL will be set on exit.
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus.
Example	<pre> ecan_config_flags = ECAN_CONFIG_SAMPLE_THRICE and ECAN_CONFIG_PHSEG2_PRG_ON and ECAN_CONFIG_XTD_MSG and ECAN_CONFIG_MATCH_MSG_TYPE and ECAN_CONFIG_LINE_FILTER_OFF ECAN1Initialize(1, 3, 3, 3, 1, ecan_config_flags) ' initialize the ECAN1 module </pre>



ECAN1SelectTxBuffers

265

page

Prototype	sub function ECAN1SelectTxBuffers(dim txselect as word) as word
Returns	- 0 - if input parameter is valid - 0xFFFF - if input parameter is invalid
Description	The function designates the ECAN1 module's transmit buffers. Parameters: - txselect: transmit buffer select. By setting bits in the txselect lower byte corresponding buffers are enabled for transmission. The ECAN module supports up to 8 transmit buffers. Also, by clearing bits in the txselect lower byte corresponding buffers are enabled for reception.
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN1 module must be initialized. See the ECAN1Initialize routine.
Example	<i>' Buffers 0 and 2 are enabled for transmtion:</i> ECAN1SelectTxBuffers(0x0005)

ECAN1FilterDisable


Prototype	sub procedure ECAN1FilterDisable(dim fltdis as word)
Description	The function disables receive filters. Parameters: - fltdis: filter disable selection parameter. Each bit corresponds to the appropriate filter. By setting bit, the corresponding filter is to be disabled.
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN1 module must be initialized. See the ECAN1Initialize routine.
Example	<i>' Filters 0, 4, 8, 12 are to be disabled:</i> ECAN1FilterDisable(0x1111)

ECAN1FilterEnable

Prototype	sub procedure ECAN1FilterEnable(dim flten as word)
Description	The function enables receive filters. Parameters: - flten: filter enable selection parameter. Each bit corresponds to the appropriate filter. By setting bit, the corresponding filter will be enabled.
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN1 module must be initialized. See the ECAN1Initialize routine.
Example	<pre>' Filters 0, 4, 8, 12 are to be enabled: ECAN1FilterEnable(0x1111)</pre>

ECAN1SetBufferSize

Prototype	sub function ECAN1SetBufferSize(dim Ecan1BuffSize as word) as word
Returns	- 0 - if input parameter is valid - 0xFFFF - if input parameter is invalid
Description	The function configures the total number of receive and transmit buffers in DMA RAM. Parameters: - Ecan1BuffSize: Number of ECAN1 DMA RAM receive and transmit buffers. Valid values: 4, 6, 8, 12, 16, 24, 32. Each buffer is 16 bytes long. Note: The same value should be used for DMA RAM buffer definition in the ECan_Defs.dbas header file located in the ECAN project folder.
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN1 module must be initialized. See the ECAN1Initialize routine.
Example	<pre>' DMA RAM will have 16 rx+tx buffers ECAN1SetBufferSize(16)</pre>




ECAN1SetBaudRate

Prototype	sub procedure ECAN1SetBaudRate(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, ECAN_CONFIG_FLAGS as word)
Description	Sets ECAN1 module baud rate. Due to complexity of the ECAN protocol, you can not simply force the bps value. Instead, use this function when ECAN1 is in Config mode. Refer to datasheet for details. The SAM, SEG2PHTS and WAKFIL bits are set according to the ECAN_CONFIG_FLAGS value. Parameters: - SJW as defined in MCU's datasheet (ECAN1 Module) - BRP as defined in MCU's datasheet (ECAN1 Module) - PHSEG1 as defined in MCU's datasheet (ECAN1 Module) - PHSEG2 as defined in MCU's datasheet (ECAN1 Module) - PROPSEG as defined in MCU's datasheet (ECAN1 Module) - ECAN_CONFIG_FLAGS ECAN module configuration flags. Each bit corresponds to the appropriate ECAN module parameter. Should be formed out of predefined ECAN flag constants. See ECAN constants
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN1 module must be in Config mode, otherwise the function will be ignored. See ECAN1SetOperationMode.
Example	<pre>' set required baud rate and sampling rules dim ecan_config_flags as word ... ECAN1SetOperationMode(ECAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (ECAN1 module must be in ' config mode for baud rate settings) ecan_config_flags = ECAN_CONFIG_SAMPLE_THRICE and ' Form value to be used ECAN_CONFIG_PHSEG2_PRG_ON and ' with ECAN1SetBaudRate ECAN_CONFIG_XTD_MSG and ECAN_CONFIG_MATCH_MSG_TYPE and ECAN_CONFIG_LINE_FILTER_OFF ECAN1SetBaudRate(1, 3, 3, 3, 1, ecan_config_flags) ' set ECAN1 module baud rate</pre>

ECAN1SetMask

Prototype	sub procedure ECAN1SetMask(dim ECAN_MASK as word , dim val as longint , dim ECAN_CONFIG_FLAGS as word)
Description	The function configures appropriate mask for advanced message filtering. Parameters: - ECAN_MASK: ECAN module mask number. Valid values: ECAN_MASK constants. See ECAN constants - val: mask register value. This value is bit-adjusted to appropriate buffer mask registers - ECAN_CONFIG_FLAGS: selects type of messages to filter. Valid values: ECAN_CONFIG_ALL_VALID_MSG, ECAN_CONFIG_MATCH_MSG_TYPE and ECAN_CONFIG_STD_MSG, ECAN_CONFIG_MATCH_MSG_TYPE and ECAN_CONFIG_XTD_MSG. (see ECAN constants).
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN1 module must be in Config mode, otherwise the function will be ignored. See ECAN1SetOperationMode.
Example	<pre>' set appropriate filter mask and message type value ' ECAN1SetOperationMode(ECAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (ECAN1 module must be in ' config mode for mask settings) ' Set all mask0 bits to 1 (all filtered bits are relevant): ' Note that -1 is just a cheaper way to write 0xFFFFFFFF. ' Complement will do the trick and fill it up with ones. ECAN1SetMask(ECAN_MASK_0, -1, ECAN_CONFIG_MATCH_MSG_TYPE and ECAN_CONFIG_XTD_MSG)</pre>




ECAN1SetFilter

Prototype	<code>sub procedure ECAN1SetFilter(dim ECAN_FILTER as word, dim val as longint, dim ECAN_FILTER_MASK as word, dim ECAN_FILTER_RXBUFF as word, dim ECAN_CONFIG_FLAGS as word)</code>
Description	The function configures and enables appropriate message filter. Parameters: - ECAN_FILTER: ECAN module filter number. Valid values: ECAN_FILTER constants. See ECAN constants - val: filter register value. This value is bit-adjusted to appropriate filter registers - ECAN_FILTER_MASK: mask register corresponding to filter. Valid values: ECAN_MASK constants. See ECAN constants - ECAN_FILTER_RXBUFF: receive buffer corresponding to filter. Valid values: ECAN_RX_BUFFER constants. See ECAN constants - ECAN_CONFIG_FLAGS: selects type of messages to filter. Valid values: ECAN_CONFIG_XTD_MSG and ECAN_CONFIG_STD_MSG. See ECAN constants.
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN1 module must be in Config mode, otherwise the function will be ignored. See ECAN1SetOperationMode.
Example	<pre>' set appropriate filter value and message type ECAN1SetOperationMode(ECAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (ECAN1 module must be in config mode ' for filter settings) ' Set id of filter 10 to 3, mask2, receive buffer 7, ' extended messages: ECAN1SetFilter(ECAN_FILTER_10, 3, ECAN_MASK_2, ECAN_RX_BUFFER_7, ECAN_CONFIG_XTD_MSG)</pre>

ECAN1Read

Prototype	sub function ECAN1Read(dim byref id as longint , dim byref data as byte [8] , dim byref dataLen as word , dim byref ECAN_RX_MSG_FLAGS as word) as word
Returns	- 0 if none of Receive Buffers is full - 0xFFFF if at least one of Receive Buffers is full (message received)
Description	If at least one full Receive Buffer is found, it will be processed in the following way: - Message ID is retrieved and stored to location pointed by the id pointer - Message data is retrieved and stored to array pointed by the data pointer - Message length is retrieved and stored to location pointed by the dataLen pointer - Message flags are retrieved and stored to location pointed by the ECAN_RX_MSG_FLAGS pointer Parameters: - id: message identifier address - data: an array of bytes up to 8 bytes in length - dataLen: data length address - ECAN_RX_MSG_FLAGS: message flags address. For message receive flags format refer to the ECAN_RX_MSG_FLAGS constants (see ECAN constants)
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN1 module must be in a mode in which receiving is possible. See ECAN1SetOperationMode.
Example	<pre> ' check the ECAN1 module for received messages. ' If any was received do something. dim msg_rcvd, rx_flags, data_len as word data as byte[8] msg_id as longint ... ECAN1SetOperationMode(ECAN_MODE_NORMAL,0xFF) ' set NORMAL mode (ECAN1 module must be in a mode in which ' receiving is possible) ... rx_flags = 0 ' clear message flags if (msg_rcvd = ECAN1Read(msg_id, data, data_len, rx_flags)) then ... end if </pre>



ECAN1Write

Prototype	<code>sub function ECAN1Write(dim id as longint, dim byref Data as byte[8] , dim DataLen, ECAN_TX_MSG_FLAGS as word) as word</code>
Returns	- 0 if all Transmit Buffers are busy - 0xFFFF if at least one Transmit Buffer is empty and available for transmission
Description	If at least one empty Transmit Buffer is found, the function sends message in the queue for transmission. Parameters: - id: ECAN1 message identifier. Valid values: all 11 or 29 bit values, depending on message type (standard or extended) - Data: data to be sent - DataLen: data length. Valid values: 0..8 - ECAN_TX_MSG_FLAGS: message flags. Valid values: ECAN_TX_MSG_FLAGS constants. See ECAN constants.
Requires	The ECAN1 routines are supported only by MCUs with the ECAN1 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN1 module must be in a mode in which transmission is possible. See ECAN1SetOperationMode.
Example	<pre>' send message extended ECAN message with appropriate ID and data dim tx_flags as word data as byte[8] msg_id as longint ... ECAN1SetOperationMode(ECAN_MODE_NORMAL,0xFF) ' set NORMAL mode ' (ECAN1 must be in a mode in which transmission is possible) tx_flags = ECAN_TX_PRIORITY_0 and ECAN_TX_XTD_FRAME and ECAN_TX_NO_RTR_FRAME ' set message flags ECAN1Write(msg_id, data, 1, tx_flags)</pre>

ECAN2DmaChannelInit

Prototype	sub function ECAN2DmaChannelInit(dim DmaChannel as word , dim ChannelDir as word , dim DmaRamBuffAdd as word) as word
Returns	- 0 - if dma channel parameter is valid - 0x0001 - if dma channel already in use (busy) - 0xFFFF - if dma channel parameter is invalid
Description	The function preforms initialization of the DMA module for ECAN. Parameters: - DmaChannel: DMA Channel number. Valid values: 0..7. - ChannelDir: transfer direction. Valid values: 1 (dma ram to peripheral) and 0 (peripheral to dma ram). - DmaRamBuffAdd: DMA RAM buffer address. DMA RAM location is MCU dependent, refer to datasheet for valid address range.
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus.
Example	<i>'channel 0 will transfer 8 words from dma ram at 0x4000 to ECAN2</i> <pre>ECAN2DmaChannelInit(0, 1, 0x4000)</pre>




ECAN2SetOperationMode

Prototype	<code>sub procedure ECAN2SetOperationMode (dim mode as word, dim WAIT as word)</code>
Description	Sets the ECAN2 module to requested mode. Parameters : - mode: ECAN2 module operation mode. Valid values: ECAN_OP_MODE constants. See ECAN constants. - WAIT: ECAN2 mode switching verification request. If WAIT = 0, the call is non-blocking. The function does not verify if the ECAN2 module is switched to requested mode or not. The caller must use ECAN2GetOperationMode to verify correct operation mode before performing mode specific operation. If WAIT <> 0, the call is blocking – the function won't "return" until the requested mode is set and no additional verification is necessary.
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus.
Example	<pre>' set the ECAN2 module into configuration mode (wait inside ' ECAN2SetOperationMode until this mode is set) ECAN2SetOperationMode (ECAN_MODE_CONFIG, 0xFF)</pre>

ECAN2Initialize

Prototype	sub procedure ECAN2Initialize(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, ECAN_CONFIG_FLAGS as word)
Description	Initializes the ECAN2 module. The internal ECAN2 module is set to: - Disable ECAN capture - Continue ECAN operation in Idle mode - Abort all pending transmissions - Clear all transmit control registers - Fcan clock : Fcy (Fosc/2) - Baud rate is set according to given parameters - ECAN mode is set to Normal - Filter and mask registers remain unchanged The SAM, SEG2PHTS, WAKFIL and DBEN bits are set according to the ECAN_CONFIG_FLAGS value. Parameters: - SJW as defined in MCU's datasheet (ECAN2 Module) - BRP as defined in MCU's datasheet (ECAN2 Module) - PHSEG1 as defined in MCU's datasheet (ECAN2 Module) - PHSEG2 as defined in MCU's datasheet (ECAN2 Module) - PROPSEG as defined in MCU's datasheet (ECAN2 Module) - ECAN_CONFIG_FLAGS ECAN module configuration flags. Each bit corresponds to the appropriate ECAN module parameter. Should be formed out of predefined ECAN flag constants. See ECAN constants
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus.
Example	<pre> dim ecan_config_flags as word ... ecan_config_flags = ECAN_CONFIG_SAMPLE_THRICE and ECAN_CONFIG_PHSEG2_PRG_ON and ECAN_CONFIG_XTD_MSG and ECAN_CONFIG_MATCH_MSG_TYPE and ECAN_CONFIG_LINE_FILTER_OFF ECAN2Initialize(1, 3, 3, 3, 1, ecan_config_flags) ' initialize the ECAN2 module </pre>



ECAN2SelectTxBuffers

Prototype	<code>sub function ECAN2SelectTxBuffers(dim txselect as word) as word</code>
Returns	- 0 - if input parameter is valid - 0xFFFF - if input parameter is invalid
Description	The function designates ECAN2 module's transmit buffers. Parameters: - txselect: transmit buffer select. By setting bits in the txselect lower byte corresponding buffers are enabled for transmission. ECAN supports up to 8 transmit buffers. Also, by clearing bits in the txselect lower byte corresponding buffers are enabled for reception.
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN2 module must be initialized. See the ECAN2Initialize routine.
Example	<i>' Buffers 0 and 2 are enabled for transmission:</i> <code>ECAN2SelectTxBuffers(0x0005)</code>

ECAN2FilterDisable


Prototype	<code>sub procedure ECAN2FilterDisable(dim fltdis as word)</code>
Description	The function disables receive filters. Parameters: - fltdis: filter disable selection parameter. Each bit corresponds to appropriate filter. By setting bit, the corresponding filter will be disabled.
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN2 module must be initialized. See the ECAN2Initialize routine.
Example	<i>' Filters 0, 4, 8, 12 are to be disabled:</i> <code>ECAN2FilterDisable(0x1111)</code>

ECAN2FilterEnable

Prototype	sub procedure ECAN2FilterEnable(dim flten as word)
Description	The function enables receive filters. Parameters: - flten: filter enable selection parameter. Each bit corresponds to appropriate filter. By setting bit, the corresponding filter will be enabled.
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN2 module must be initialized. See the ECAN2Initialize routine.
Example	<pre>' Filters 0, 4, 8, 12 are to be enabled: ECAN2FilterEnable(0x1111)</pre>

ECAN2SetBufferSize

Prototype	sub function ECAN2SetBufferSize(dim Ecan2BuffSize as word) as word
Returns	- 0 - if input parameter is valid - 0xFFFF - if input parameter is invalid
Description	The function configures the overall number of receive and transmit buffers in DMA RAM. Parameters: - Ecan2BuffSize: Number of ECAN2 DMA RAM receive and transmit buffers. Valid values: 4, 6, 8, 12, 16, 24, 32. Each buffer is 16 bytes long. Note: The same value should be used for DMA RAM buffer definition in the ECan_Defs.dbas header file located in the ECAN project folder.
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN2 module must be initialized. See the ECAN2Initialize routine.
Example	<pre>' DMA RAM will have 16 rx+tx buffers ECAN2SetBufferSize(16)</pre>




ECAN2SetBaudRate

Prototype	sub procedure ECAN2SetBaudRate(dim SJW, BRP, PHSEG1, PHSEG2, PROPSEG, ECAN_CONFIG_FLAGS as word)
Description	Sets ECAN2 module baud rate. Due to complexity of the ECAN protocol, you can not simply force the bps value. Instead, use this function when ECAN2 is in Config mode. Refer to datasheet for details. The SAM, SEG2PHTS and WAKFIL bits are set according to the ECAN_CONFIG_FLAGS value. Parameters: - SJW as defined in MCU's datasheet (ECAN2 Module) - BRP as defined in MCU's datasheet (ECAN2 Module) - PHSEG1 as defined in MCU's datasheet (ECAN2 Module) - PHSEG2 as defined in MCU's datasheet (ECAN2 Module) - PROPSEG as defined in MCU's datasheet (ECAN2 Module) - The ECAN_CONFIG_FLAGS ECAN module configuration flags. Each bit corresponds to the appropriate ECAN module parameter. Should be formed out of predefined ECAN flag constants. See ECAN constants.
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN2 module must be in Config mode, otherwise the function will be ignored. See ECAN2SetOperationMode.
Example	<pre>' set required baud rate and sampling rules dim ecan_config_flags as word ... ECAN2SetOperationMode(ECAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode (ECAN2 module mast be in config mode for ' baud rate settings) ecan_config_flags = ECAN_CONFIG_SAMPLE_THRICE and ' Form value to be used ECAN_CONFIG_PHSEG2_PRG_ON and ' with ECAN2SetBaudRate ECAN_CONFIG_XTD_MSG and ECAN_CONFIG_MATCH_MSG_TYPE and ECAN_CONFIG_LINE_FILTER_OFF ECAN2SetBaudRate(1, 3, 3, 3, 1, ecan_config_flags) ' set the ECAN2 module baud rate</pre>

ECAN2SetMask

Prototype	sub procedure ECAN2SetMask(dim ECAN_MASK as word , dim val as longint , dim ECAN_CONFIG_FLAGS as word)
Description	The function configures appropriate mask for advanced message filtering. Parameters: - ECAN_MASK: ECAN module mask number. Valid values: ECAN_MASK constants. See ECAN constants - val:mask register value. This value is bit-adjusted to appropriate buffer mask registers - ECAN_CONFIG_FLAGS: selects type of messages to filter. Valid values: ECAN_CONFIG_ALL_VALID_MSG, ECAN_CONFIG_MATCH_MSG_TYPE and ECAN_CONFIG_STD_MSG, ECAN_CONFIG_MATCH_MSG_TYPE and ECAN_CONFIG_XTD_MSG. (see ECAN constants)
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN2 module must be in Config mode, otherwise the function will be ignored. See ECAN2SetOperationMode.
Example	<pre>' set appropriate filter mask and message type value ECAN2SetOperationMode(ECAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode ' (ECAN2 module must be in config mode for mask settings) ' Set all mask0 bits to 1 (all filtered bits are relevant): ' Note that -1 is just a cheaper way to write 0xFFFFFFFF. ' Complement will do the trick and fill it up with ones. ECAN2SetMask(ECAN_MASK_0, -1, ECAN_CONFIG_MATCH_MSG_TYPE and ECAN_CONFIG_XTD_MSG)</pre>



ECAN2SetFilter

Prototype	<pre>sub procedure ECAN2SetFilter(dim ECAN_FILTER as word, dim val as longint, dim ECAN_FILTER_MASK as word, dim ECAN_FILTER_RXBUFF as word, dim ECAN_CONFIG_FLAGS as word)</pre>
Description	The function configures and enables appropriate message filter. Parameters: - ECAN_FILTER: ECAN module filter number. Valid values: ECAN_FILTER constants. See ECAN constants - val: filter register value. This value is bit-adjusted to appropriate filter registers - ECAN_FILTER_MASK: mask register corresponding to filter. Valid values: ECAN_MASK constants. See ECAN constants - ECAN_FILTER_RXBUFF: receive buffer corresponding to filter. Valid values: ECAN_RX_BUFFER constants. See ECAN constants - ECAN_CONFIG_FLAGS: selects type of messages to filter. Valid values: ECAN_CONFIG_XTD_MSG or ECAN_CONFIG_STD_MSG. See ECAN constants.
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN2 module must be in Config mode, otherwise the function will be ignored. See ECAN2SetOperationMode.
Example	<pre>' set appropriate filter value and message type ECAN2SetOperationMode(ECAN_MODE_CONFIG,0xFF) ' set CONFIGURATION mode ' (ECAN2 module must be in config mode for filter settings) ' Set id of filter 10 to 3, mask2, ' receive buffer 7, extended messages: ECAN2SetFilter(ECAN_FILTER_10, 3, ECAN_MASK_2, ECAN_RX_BUFFER_7, ECAN_CONFIG_XTD_MSG)</pre>

ECAN2Read

Prototype	sub function ECAN2Read(dim byref id as longint, dim byref data as byte[8] , dim byref dataLen as word, dim byref ECAN_RX_MSG_FLAGS as word) as word
Returns	- 0 if none of Receive Buffers is full - 0xFFFF if at least one of Receive Buffers is full (message received)
Description	If at least one full Receive Buffer is found, it will be processed in the following way: - Message ID is retrieved and stored to location pointed by the id pointer - Message data is retrieved and stored to array pointed by the data pointer - Message length is retrieved and stored to location pointed by the dataLen pointer - Message flags are retrieved and stored to location pointed by the ECAN_RX_MSG_FLAGS pointer Parameters: - id: message identifier address - data: an array of bytes up to 8 bytes in length - dataLen: data length address - ECAN_RX_MSG_FLAGS: message flags address. For message receive flags format refer to the ECAN_RX_MSG_FLAGS constants (see ECAN constants)
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN2 module must be in a mode in which receiving is possible. See ECAN2SetOperationMode.
Example	<pre> ' check the ECAN2 module for received messages. ' If any was received do something. dim msg_rcvd, rx_flags, data_len as word data as byte[8] msg_id as longint ... ECAN2SetOperationMode(ECAN_MODE_NORMAL,0xFF) ' set NORMAL mode '(ECAN2 module must be in a mode in which receiving is possible) ... rx_flags = 0 ' clear message flags if (msg_rcvd = ECAN2Read(msg_id, data, data_len, rx_flags)) then ... end if </pre>

ECAN2Write

281

page

Prototype	sub function ECAN2Write(dim id as longint, dim byref Data as byte[8], dim DataLen, ECAN_TX_MSG_FLAGS as word) as word
Returns	- 0 if all Transmit Buffers are busy - 0xFFFF if at least one Transmit Buffer is empty and available for transmission
Description	If at least one empty Transmit Buffer is found, the function sends message in the queue for transmission. Parameters: - id: ECAN2 message identifier. Valid values: all 11 or 29 bit values, depending on message type(standard or extended) - Data: data to be sent - DataLen: data length. Valid values: 0..8 - ECAN_TX_MSG_FLAGS: message flags. Refer to the ECAN_TX_MSG_FLAGS constants. See ECAN constants
Requires	The ECAN2 routines are supported only by MCUs with the ECAN2 module. The microcontroller must be connected to ECAN transceiver which is connected to the ECAN bus. The ECAN2 module must be in a mode in which receiving is possible. See ECAN2SetOperationMode.
Example	<pre> ' send message extended ECAN message with appropriate ID and data dim tx_flags as word data as byte[8] msg_id as longint ... ECAN2SetOperationMode(ECAN_MODE_NORMAL,0xFF) ' set NORMAL mode '(ECAN2 must be in a mode in which transmission is possible) tx_flags = ECAN_TX_PRIORITY_0 and ECAN_TX_XTD_FRAME and ECAN_TX_NO_RTR_FRAME ' set message flags ECAN2Write(msg_id, data, 1, tx_flags) </pre>

ECAN Constants

There is a number of constants predefined in the ECAN library. You need to be familiar with them in order to be able to use the library effectively. Check the example at the end of the chapter.

ECAN_OP_MODE

The ECAN_OP_MODE constants define ECAN operation mode. The functions ECAN1SetOperationMode and ECAN2SetOperationMode expect one of them as their argument:

```
const
    ECAN_MODE_BITS           = 0x00E0
    ECAN_MODE_NORMAL         = 0x00
    ECAN_MODE_DISABLE        = 0x01
    ECAN_MODE_LOOP           = 0x02
    ECAN_MODE_LISTEN         = 0x03
    ECAN_MODE_CONFIG         = 0x04
    ECAN_MODE_LISTEN_ALL     = 0x07
```

ECAN_CONFIG_FLAGS

The ECAN_CONFIG_FLAGS constants define flags related to the ECAN module configuration. The functions ECAN1Initialize, ECAN2Initialize, ECAN1SetBaudRate and ECAN2SetBaudRate expect one of them (or a bitwise combination) as their argument:

```
const
    ECAN_CONFIG_DEFAULT      = 0xFF      ' 11111111

    ECAN_CONFIG_PHSEG2_PRG_BIT = 0x01
    ECAN_CONFIG_PHSEG2_PRG_ON  = 0xFF      ' XXXXXXX1
    ECAN_CONFIG_PHSEG2_PRG_OFF = 0xFE      ' XXXXXXX0

    ECAN_CONFIG_LINE_FILTER_BIT = 0x02
    ECAN_CONFIG_LINE_FILTER_ON  = 0xFF      ' XXXXXX1X
    ECAN_CONFIG_LINE_FILTER_OFF = 0xFD      ' XXXXXX0X

    ECAN_CONFIG_SAMPLE_BIT     = 0x04
    ECAN_CONFIG_SAMPLE_ONCE    = 0xFF      ' XXXXX1XX
    ECAN_CONFIG_SAMPLE_THRICE   = 0xFB      ' XXXXX0XX
```

' continues..

' continued..

```

ECAN_CONFIG_MSG_TYPE_BIT    = 0x08
ECAN_CONFIG_STD_MSG         = 0xFF    ' XXXX1XXX
ECAN_CONFIG_XTD_MSG         = 0xF7    ' XXXX0XXX

ECAN_CONFIG_MATCH_TYPE_BIT  = 0x20
ECAN_CONFIG_ALL_VALID_MSG   = 0xDF    ' XX0XXXXX
ECAN_CONFIG_MATCH_MSG_TYPE  = 0xFF    ' XX1XXXXX

```

You may use bitwise **and** to form config word out of these values. For example:

```

init  = ECAN_CONFIG_SAMPLE_THRICE    and
        ECAN_CONFIG_PHSEG2_PRG_ON    and
        ECAN_CONFIG_STD_MSG          and
        ECAN_CONFIG_MATCH_MSG_TYPE   and
        ECAN_CONFIG_LINE_FILTER_OFF

...
ECAN1Initialize(1, 1, 3, 3, 1, init)  ' initialize ECAN1

```

ECAN_TX_MSG_FLAGS

ECAN_TX_MSG_FLAGS are flags related to transmission of ECAN message. The functions ECAN1Write and ECAN2Write expect one of them (or a bitwise combination) as their argument:

```

const
    ECAN_TX_PRIORITY_BITS = 0x03
    ECAN_TX_PRIORITY_0    = 0xFC    ' XXXXXX00
    ECAN_TX_PRIORITY_1    = 0xFD    ' XXXXXX01
    ECAN_TX_PRIORITY_2    = 0xFE    ' XXXXXX10
    ECAN_TX_PRIORITY_3    = 0xFF    ' XXXXXX11
    ECAN_TX_FRAME_BIT     = 0x08
    ECAN_TX_STD_FRAME     = 0xFF    ' XXXXX1XX
    ECAN_TX_XTD_FRAME     = 0xF7    ' XXXXX0XX
    ECAN_TX_RTR_BIT       = 0x40
    ECAN_TX_NO_RTR_FRAME  = 0xFF    ' X1XXXXXX
    ECAN_TX_RTR_FRAME     = 0xBF    ' X0XXXXXX

```

You may use bitwise **and** to adjust the appropriate flags. For example:

```

' form value to be used with CANSendMessage:
send_config = ECAN_TX_PRIORITY_0 and
               ECAN_TX_XTD_FRAME and
               ECAN_TX_NO_RTR_FRAME

...
ECAN1SendMessage(id, data, 1, send_config)

```


ECAN_RX_MSG_FLAGS


ECAN_RX_MSG_FLAGS are flags related to reception of ECAN message. If a particular bit is set then corresponding meaning is TRUE otherwise it will be FALSE.

```
const
    ECAN_RX_FILTER_BITS = 0x000F ' Use this to access filter
                                   ' bits
    ECAN_RX_FILTER_0    = 0x00    ' filter0 match
    ECAN_RX_FILTER_1    = 0x01    ' filter1 match
    ECAN_RX_FILTER_2    = 0x02    ' ...
    ECAN_RX_FILTER_3    = 0x03
    ECAN_RX_FILTER_4    = 0x04
    ECAN_RX_FILTER_5    = 0x05
    ECAN_RX_FILTER_6    = 0x06
    ECAN_RX_FILTER_7    = 0x07
    ECAN_RX_FILTER_8    = 0x08
    ECAN_RX_FILTER_9    = 0x09
    ECAN_RX_FILTER_10   = 0x0A
    ECAN_RX_FILTER_11   = 0x0B
    ECAN_RX_FILTER_12   = 0x0C
    ECAN_RX_FILTER_13   = 0x0D
    ECAN_RX_FILTER_14   = 0x0E    ' ...
    ECAN_RX_FILTER_15   = 0x0F    ' filter15 match

    ECAN_RX_OVERFLOW    = 0x10    ' Set if Overflowed else cleared
    ECAN_RX_INVALID_MSG = 0x20    ' Set if invalid else cleared
    ECAN_RX_XTD_FRAME   = 0x40
    ' Set if XTD message else cleared
    ECAN_RX_RTR_FRAME   = 0x80
    ' Set if RTR message else cleared
```

You may use bitwise **and** to extract received message status. For example:

```
if (MsgFlag and ECAN_RX_OVERFLOW <> 0) then
    ...
    ' Receiver overflow has occurred.
    ' We have lost our previous message.
end if
```



ECAN_MASK

The ECAN_MASK constants define mask codes. The functions ECAN1SetMask and ECAN2SetMask expect one of them as their argument:

```
const
    ECAN_MASK_0   = 0
    ECAN_MASK_1   = 1
    ECAN_MASK_2   = 2
```

ECAN_FILTER

The ECAN_FILTER constants define filter codes. The functions ECAN1SetFilter and ECAN2SetFilter expects one of them as their argument:

```
const
    ECAN_FILTER_0   = 0
    ECAN_FILTER_1   = 1
    ECAN_FILTER_2   = 2
    ECAN_FILTER_3   = 3
    ECAN_FILTER_4   = 4
    ECAN_FILTER_5   = 5
    ECAN_FILTER_6   = 6
    ECAN_FILTER_7   = 7
    ECAN_FILTER_8   = 8
    ECAN_FILTER_9   = 9
    ECAN_FILTER_10  = 10
    ECAN_FILTER_11  = 11
    ECAN_FILTER_12  = 12
    ECAN_FILTER_13  = 13
    ECAN_FILTER_14  = 14
    ECAN_FILTER_15  = 15
```

Library Example

The code is a simple demonstration of the ECAN protocol.

```

program ECAN_1st

include "ECan_Defs"

dim Can_Init_Flags, Can_Send_Flags, Can_Rcv_Flags as word
                                     ' can flags
    Rx_Data_Len as word           ' received data length in bytes
    RxTx_Data   as byte[ 8]      ' can rx/tx data buffer
    Msg_Rcvd    as word         ' reception flag
    Tx_ID, Rx_ID as longint     ' can rx and tx ID

sub procedure C1Interrupt() org 0x005A      ' ECAN event interrupt
    IFS2.3 = 0                          ' clear ECAN interrupt flag
    if(C1INTF.0 <> 0) then                ' was it tx interrupt?
        C1INTF.0 = 0                      ' if yes clear tx interrupt flag
    end if

    if(C1INTF.1 <> 0) then                ' was it rx interrupt?
        C1INTF.1 = 0                      ' if yes clear rx interrupt flag
    end if
end sub

main:
    ' Set PLL : Fosc = ((Fin/PLLPRE)*PLLDIV)/PLLPOST
    ' (((10MHz/2)*32)/4) = 20MHz
    ' refer the pic24 family datasheet for more details
    CLKDIV = CLKDIV and 0xFFE0          'CLKDIVbits.PLLPRE = 0
    PLLFBD = 0x1E                      'PLLFBDbits.PLLDIV = 0x1E
    CLKDIV = CLKDIV and 0xFF3F          'CLKDIVbits.PLLPOST = 1
    CLKDIV = CLKDIV or 0x00C0

    AD1PCFGH = 0xFFFF                  '
    AD1PCFGL = 0xFFFF                  ' all ports digital I/O
    AD2PCFGL = 0xFFFF                  '

    '{* Clear Interrupt Flags *}

    IFS0 = 0
    IFS1 = 0
    IFS2 = 0
    IFS3 = 0
    IFS4 = 0

    ' continues..

```

```
' continued..

' { * Enable ECAN1 Interrupt *}

IEC2.3    = 1    ' enable ECAN1 interrupts
C1INTE.0  = 1    ' enable ECAN1 tx interrupt
C1INTE.1  = 1    ' enable ECAN1 rx interrupt

PORTB     = 0    ' clear PORTB
TRISB     = 0    ' set PORTB as output,
                  ' for received message data displaying

Can_Init_Flags = 0                                '
Can_Send_Flags = 0                                ' clear flags
Can_Rcv_Flags  = 0                                '

Can_Send_Flags = ECAN_TX_PRIORITY_0 and ' Form value to be used
                  ECAN_TX_XTD_FRAME and ' with CANSendMessage
                  ECAN_TX_NO_RTR_FRAME

Can_Init_Flags = ECAN_CONFIG_SAMPLE_THRICE and
                  ' Form value to be used
                  ECAN_CONFIG_PHSEG2_PRG_ON and
                  ' with CANInitialize
                  ECAN_CONFIG_XTD_MSG and
                  ECAN_CONFIG_MATCH_MSG_TYPE and
                  ECAN_CONFIG_LINE_FILTER_OFF

RxTx_Data[0] = 9 ' set initial data to be sent
ECAN1DmaChannelInit(0, 1, @ECAN1RxTxRAMBuffer)
' init dma channel 0 for
' dma to ECAN peripheral transfer
ECAN1DmaChannelInit(2, 0, @ECAN1RxTxRAMBuffer)
' init dma channel 2 for
' ECAN peripheral to dma transfer
ECAN1Initialize(1, 3, 3, 3, 1, Can_Init_Flags) ' initialize ECAN
ECAN1SetBufferSize(ECAN1RAMBUFFERSIZE)
' set number of rx+tx buffers in DMA RAM

ECAN1SelectTxBuffers(0x000F)
' select transmit buffers
' 0x000F = buffers 0:3 are transmit buffers
ECAN1SetOperationMode(ECAN_MODE_CONFIG, 0xFF)
' set CONFIGURATION mode

' continues..
```

```
' continued..


    ECAN1SetMask(ECAN_MASK_0, -1, ECAN_CONFIG_MATCH_MSG_TYPE and
ECAN_CONFIG_XTD_MSG) ' set all mask1 bits to ones
    ECAN1SetMask(ECAN_MASK_1, -1, ECAN_CONFIG_MATCH_MSG_TYPE and
ECAN_CONFIG_XTD_MSG) ' set all mask2 bits to ones
    ECAN1SetMask(ECAN_MASK_2, -1, ECAN_CONFIG_MATCH_MSG_TYPE and
ECAN_CONFIG_XTD_MSG) ' set all mask3 bits to ones
    ECAN1SetFilter(ECAN_FILTER_10, 3, ECAN_MASK_2, ECAN_RX_BUFFER_7,
ECAN_CONFIG_XTD_MSG) ' set id of filter10 to 3,

' assign mask2 to filter10
' assign buffer7 to filter10
    ECAN1SetOperationMode(ECAN_MODE_NORMAL, 0xFF) ' set NORMAL mode

Tx_ID = 12111 ' set transmit ID

ECAN1Write(Tx_ID, RxTx_Data, 1, Can_Send_Flags)
' send initial message

while TRUE ' endless loop
    Msg_Rcvd = ECAN1Read(Rx_ID , RxTx_Data , Rx_Data_Len,
Can_Rcv_Flags) ' receive message
    if ((Rx_ID = 3) and (Msg_Rcvd <> 0)) <> 0 then
        ' if message received check id
        PORTB = RxTx_Data[ 0]
        ' id correct, output data at PORTB
        Inc(RxTx_Data[ 0] )
        Delay_ms(10)
        ECAN1Write(Tx_ID, RxTx_Data, 1, Can_Send_Flags)
        ' send incremented data back
    end if
wend
end.
```



EEPROM Library

EEPROM data memory is available with a number of dsPIC30 family. mikroBasic for dsPIC30/33 and PIC24 includes a library for comfortable work with MCU's internal EEPROM.


Note: Only dsPIC30 MCUs have EEPROM.

Library Routines

```
Eeprom_Erase
Eeprom_Erase_Block
Eeprom_Read
Eeprom_Write
Eeprom_Write_Block
```

Eeprom_Erase

Prototype	sub procedure Eeprom_Erase(dim address as longint)
Description	Erases a single (16-bit) location from EEPROM. Parameters : - address: address of the EEPROM location to be erased. Note: CPU is not halted for the Data Erase cycle. The user can poll WR bit, use NVMIF or Timer IRQ to detect the end of erase sequence.
Example	<pre>dim eeAddr as longint ... eeAddr = 0x7FFC80 Eeprom_Erase(eeAddr)</pre>



Eeprom_Erase_Block

291

page

Prototype	sub procedure Eeprom_Erase_Block(dim address as longint)
Returns	Nothing.
Description	Erases one EEPROM row (16 words block) from EEPROM. Parameters : - address: starting address of the EEPROM block to be erased. Note: CPU is not halted for the Data Erase cycle. The user can poll WR bit, use NVMIF or Timer IRQ to detect the end of erase sequence.
Example	<pre> dim eeAddr as longint ... eeAddr = 0x7FFC20 Eeprom_Erase_Block(eeAddr) </pre>

Eeprom_Read

Prototype	sub function Eeprom_Read(dim address as longint) as word
Returns	Word from the specified address.
Description	Reads data from specified address. Parameters : - address: address of the EEPROM location to be read.
Requires	It is the user's responsibility to obtain proper address parity (in this case, even).
Example	<pre> dim eeAddr as longint temp as word ... eeAddr = 0x7FFC20 temp = Eeprom_Read(eeAddr) </pre>

Eeprom_Write

Prototype	sub procedure Eeprom_Write(dim address as longint, dim data as word)
Description	Writes data to specified address. Parameters : - address: address of the EEPROM location to be written. - data: data to be written. Note: Specified memory location will be erased before writing starts.
Example	<pre> dim wrAddr as longint eeData as word ... eeData = 0xAAAA wrAddr = 0x7FFC30 Eeprom_Write(wrAddr, eeData) </pre>

Eeprom_Write_Block

Prototype	sub procedure Eeprom_Write_Block(dim address as longint, dim byref data as word[100])
Description	Writes one EEPROM row (16 words block) of data. Parameters : - address: starting address of the EEPROM memory block to be written. - data: data block to be written. Note: Specified memory block will be erased before writing starts.
Requires	It is the user's responsibility to maintain proper address alignment. In this case, address has to be a multiply of 32, which is the size (in bytes) of one row of MCU's EEPROM memory.
Example	<pre> dim wrAddr as longint data as string[16] ... wrAddr = 0x7FFC20 data = "mikroElektronika" Eeprom_Write_Block(wrAddr, data) </pre>

Library Example

The example demonstrates using EEPROM Library. Hardware configurations in this example are made for the dsPICPRO2 board and dsPIC30F6014A.

```

program EEPROM

const    iArr as word[ 16] = ("a", "b", "c", "d", "e", "f", "g",
    "h", "i", "j", "k", "l", "m", "n", "o", 0)

dim eeRead as word
    eeAddr as longint

    dArr as string[ 16]
    iArr1 as word[ 16]
    i as word

main:
    iArr1 = iArr
    '--- disable analog inputs
    ADPCFG = 0xFFFF

    TRISB = 0
    LATB = 0xFFFF
    eeRead = 0xAAAA
    eeAddr = 0x7FFC80
    while(eeRead < 0xAABA)
        Eeprom_Write(eeAddr, eeRead)
        eeRead = eeRead + 1
        while(NVMCON.15 <> 0)
            nop                                ' wait for write to finish,
        wend
        LATB = Eeprom_Read(eeAddr)            ' then, read the just-written
        ' data.

        eeAddr = eeAddr + 2
        Delay_ms(500)
    wend
    '--- write entire row of EEPROM data,...
    Eeprom_Write_Block(0x7FFC20, iArr1)
    while(NVMCON.15 <> 0)
        nop
    wend
    '--- ...read the data back...
    eeRead = 1
    eeAddr = 0x7FFC20
    i = 0

    'continues...

```

```
'continued...

while (eeRead <> 0)
    eeRead  = Eeprom_Read(eeAddr)
    dArr[ i] = Lo(eeRead)
    i       = i + 1
    eeAddr  = eeAddr + 2
wend
'--- ...and display it on LCD.
Lcd_Init_DsPicPro2()
Lcd_Out(2,1, dArr)
end.
```

Flash Memory Library

This library provides routines for accessing microcontroller's (internal) Flash memory.

On the dsPIC30/33 and PIC24, Flash memory is mapped to address space 3:2, which means that every 3 consecutive bytes of Flash have 2 consecutive address locations available. That is why mikroE's library allows data to be written to flash in two ways: "regular" and "compact". In the "regular" mode, which is used for word(16-bit) variables, the 3rd (un-addressable) flash memory byte remains unused. In the "compact" mode, which can be used for 1 byte-sized variables/arrays, all flash bytes are being used.

All dsPIC30/33 and PIC24 MCUs use the RTSP module to perform Read/Erase/Write operations on Flash memory. This, together with the internal structure of the Flash, imposes certain rules to be followed when working with Flash memory:

dsPIC30:

- Erasing can be done only in 32-instructions (64 addresses, 96 bytes) memory blocks. This means that the block start address should be a multiply of 64 (i.e. have 6 lower bits set to zero).
- Data is read and written in 4-instructions (8 addresses, 12 bytes) blocks. This means that the block start address should be a multiply of 8 (i.e. have 3 lower bits set to zero).
- On the dsPIC30s, 2 address locations are assigned on every 3 bytes of (flash) program memory. Due to this specific and non-one-to-one address mapping, the mikroBasic for dsPIC30/33 and PIC24 offers two sets of Flash handling functions: "regular" and "compact".
Using the "regular" set, the user can write one byte of data to a single address, which means that each byte of written data has its own address, but on every 2 written bytes one byte of Flash memory remains empty.
Using the "compact" set, every byte of Flash memory, including those non-addressable, is filled with data; this method can only be used for data organized in bytes. The "compact" functions have `_Compact` as name suffix.
- For run-time FLASH read/write, the dsPIC30's RTSP module is being used. It organizes data into rows and panels. Each row contains write latches that can hold 4 instructions (12 bytes). The number of panels varies from one dsPIC30 MCU model to another. Because of that, the flash write sequence has been split into several operations (`_Write_Init()`, `_Write_LoadLatch4()`, `_Write_DoWrite()`), in order to be usable on all dsPICs.

PIC24 and dsPIC33:

Erasing can be done only in 512-instructions (1024 addresses, 1536 bytes) memory blocks, which means that the block start address should be a multiply of 1024 (i.e. have 10 lower bits set to zero).

Data is read and written in 64-instructions (128 addresses, 192 bytes) blocks. This means that the block start address should be a multiply of 128 (i.e. have 7 lower bits set to zero).

On the dsPIC33 and PIC24s, 2 address locations are assigned on every 3 bytes of (flash) program memory. Due to this specific and non-one-to-one address mapping, the mikroBasic offers two sets of Flash handling functions: "regular" and "compact".

Using the "regular" set, the user can write one byte of data to a single address, which means that each byte of written data has its own address, but on every 2 written bytes one byte of Flash memory remains empty.

Using the "compact" set, every byte of Flash memory, including those non-addressable, is filled with data; this method can only be used for data organized in bytes.

The "compact" functions have `_Compact` as name suffix.

Library Routines

dsPIC30:

`Flash_Erase32`

`Flash_Write_Block`

`Flash_Write_Compact`

`Flash_Write_Init`

`Flash_Write_Loadlatch4`

`Flash_Write_Loadlatch4_Compact`

`Flash_Write_DoWrite`

`Flash_Read4`

`Flash_Read4_Compact`

PIC24 and dsPIC33:


`Flash_Erase`

`Flash_Write`

`Flash_Write_Compact`

`Flash_Read`

`Flash_Read_Compact`



dsPIC30:

Flash_Erase32

297

page


Prototype	sub procedure Flash_Erase32(dim flash_address as longint)
Description	Erases one block (32 instructions, 64 addresses, 96 bytes) from the program FLASH memory. Parameters : - flash_address: starting address of the FLASH memory block
Requires	Note: The user should take care about the address alignment (see the explanation at the beginning of this page).
Example	<i>' erase the 32-instruction block, starting from address 0x006000</i> Flash_Erase32(0x006000)

Flash_Write_Block

Prototype	sub procedure Flash_Write_Block(dim flash_address as longint, dim data_address as word)
Description	Fills one writeable block of Flash memory (4 instructions, 8 addresses, 12 bytes) in the "regular" mode. Addresses and data are being mapped 1-on-1. This also means that the 3rd byte of each program location remains unused. Parameters : - flash_address: starting address of the FLASH memory block - data_address: starting address of the data block to be written
Requires	The block to be written to must be erased first, either from the user code (through the RTSP), or during the programming of MCU. Please note that block size that is to be erased is different from that one that can be written with this function! Note: The user should take care about the address alignment (see the explanation at the beginning of this page).
Example	dim flash_address as longint cArr as string[4] ptr_data as word ... flash_address = 0x006000 cArr = "ABCD" ptr_data = @cArr Flash_Write_Block(flash_address, ptr_data)

Flash_Write_Compact

Prototype	sub procedure Flash_Write_Compact(dim flash_address as longint, dim data_address as word, dim bytes as word)
Description	Fills a portion of Flash memory using the dsPIC30 RTSP module, in the "compact" manner. In this way, several blocks of RTSP's latch can be written in one pass. One latch block contains 4 instructions (8 addresses, 12 bytes). Up to 8 latch blocks can be written in one round, resulting in a total of $8 \times 12 = 96$ bytes. This method uses all available bytes of the program FLASH memory, including those that are not mapped to address space (every 3rd byte). Parameters : - flash_address: starting address of the FLASH memory block - data_address: starting address of the data block to be written - bytes: number of bytes to be written. The amount of bytes to be written must be a multiply of 12, since this is the size of the RTSP's write latch(es).
Requires	The block to be written to must be erased first, either from the user code Flash_Erase32, or during the programming of MCU. Please note that block size that is to be erased is different from the one that can be written with this function! Note: The user should take care about the address alignment (see the explanation at the beginning of this page).
Example	<pre> dim flash_address as longint cArr as string[36] ptr_data as word ... flash_address = 0x006000 cArr = "mikroElektronika12mikroElektronika34" ptr_data = @cArr Flash_Write_Compact(flash_address, ptr_data, 36) </pre>




Flash_Write_Init

Prototype	<code>sub procedure Flash_Write_Init(dim flash_address as longint, dim data_address as word)</code>
Description	Initializes RTSP for write-to-FLASH operation. Parameters : - flash_address: starting address of the FLASH memory block - data_address: starting address of the data block to be written
Requires	The block to be written to must be erased first, either from the user code Flash_Erase32, or during the programming of MCU. Please note that block size that is to be erased is different from that one that can be written with this function! Note: The user should take care about the address alignment (see the explanation at the beginning of this page).
Example	<pre>const iArr as word[8] = ("m", "i", "k", "r", "o", "E", "l", "e") dim ptr_data as word ... ptr_data = @iArr Flash_Write_Init(0x006100, ptr_data) Flash_Write_Loadlatch4() Flash_Write_Loadlatch4() Flash_Write_DoWrite()</pre>

Flash_Write_Loadlatch4

Prototype	sub procedure Flash_Write_Loadlatch4()
Description	Loads the current RTSP write latch with data (4 instructions, 8 addresses, 12 bytes). The data is filled in the "regular" mode.
Requires	The block to be written to must be erased first, either from the user code Flash_Erase32, or during the programming of MCU. Please note that block size that is to be erased is different from that one that can be written with this function! This function is used as a part of the Flash write sequence, therefore the Flash_Write_Init function must be called before this one. This function can be called several times before committing the actual write-to-Flash operation Flash_Write_DoWrite. This depends on the organization of the RTSP module for the certain dsPIC30. Please consult the Datasheet for particular dsPIC30 on this subject.
Example	<pre> const iArr as word[8] = ("m", "i", "k", "r", "o", "E", "l", "e") dim ptr_data as word ... ptr_data = @iArr Flash_Write_Init(0x006100, ptr_data) Flash_Write_Loadlatch4() Flash_Write_Loadlatch4() Flash_Write_DoWrite() </pre>




Flash_Write_Loadlatch4_Compact

Prototype	<code>sub procedure Flash_Write_Loadlatch4_Compact()</code>
Description	Loads the current RTSP write latch with data (4 instructions, 8 addresses, 12 bytes). The data is filled in the "compact" mode.
Requires	The block to be written to must be erased first, either from the user code <code>Flash_Erase32</code>, or during the programming of MCU. Please note that block size that is to be erased is different from that one that can be written with this function! This function is used as a part of the Flash write sequence, therefore the <code>Flash_Write_Init</code> function must be called before this one. This function can be called several times before committing actual write-to-Flash operation <code>Flash_Write_DoWrite</code>. This depends on the organization of the RTSP module for the certain dsPIC30. Please consult the Datasheet for particular dsPIC30 on this subject.
Example	<pre>const iArr as word[8] = ("m", "i", "k", "r", "o", "E", "l", "e") dim ptr_data as word ... ptr_data = @iArr Flash_Write_Init(0x006100, ptr_data) Flash_Write_Loadlatch4_Compact() Flash_Write_Loadlatch4_Compact() Flash_Write_DoWrite()</pre>

Flash_Write_DoWrite

Prototype	sub procedure Flash_Write_DoWrite()
Description	Commits the FLASH write operation.
Requires	The block to be written to must be erased first, either from the user code Flash_Erase32, or during the programming of MCU. Please note that block size that is to be erased is different from that one that can be written with this function! This function is used as a part of the Flash write sequence, therefore Flash_Write_Init and certain number of Flash_Write_Loadlatch4 or Flash_Write_Loadlatch4_Compact function calls must be made before this one. This function is to be called once, at the end of the FLASH write sequence.
Example	<pre> const iArr as word[8] = ("m", "i", "k", "r", "o", "E", "l", "e") dim ptr_data as word ... ptr_data = @iArr Flash_Write_Init(0x006100, ptr_data) Flash_Write_Loadlatch4() Flash_Write_Loadlatch4() Flash_Write_DoWrite() </pre>



Flash_Read4

Prototype	sub procedure Flash_Read4(dim flash_address as longint, dim write_to as word)
Description	Reads one latch row (4 instructions, 8 addresses) in the "regular" mode. Parameters : - flash_address: starting address of the FLASH memory block to be read - write_to: starting address of RAM buffer for storing read data
Requires	Note: The user should take care of the address alignment (see the explanation at the beginning of this page).
Example	<pre> dim flash_address as longint cArr as word[4] ptr_data as word ... flash_address = 0x006000 ptr_data = @cArr Flash_Read4(flash_address, ptr_data) </pre>

Flash_Read4_Compact

Prototype	sub procedure Flash_Read4_Compact(dim flash_address as longint, dim write_to as word)
Description	Reads one latch row (4 instructions, 8 addresses) in the "compact" mode. Parameters : - flash_address: starting address of the FLASH memory block to be read - write_to: starting address of RAM buffer for storing read data
Requires	Note: The user should take care of the address alignment (see the explanation at the beginning of this page).
Example	<pre> dim flash_address as longint cArr as word[8] ptr_data as word ... flash_address = 0x006000 ptr_data = @cArr Flash_Read4_Compact(flash_address, ptr_data) </pre>

PIC24 and dsPIC33:

Flash_Erase

Prototype	sub procedure Flash_Erase(dim address as longint)
Description	Erases one block (512 instructions, 1024 addresses, 1536 bytes) from the program FLASH memory. Parameters : - address: starting address of the FLASH memory block
Requires	Note: The user should take care about the address alignment (see the explanation at the beginning of this page).
Example	<pre>'--- erase the flash memory block, starting from address 0x006400 dim flash_address as longint ... flash_address = 0x006400 Flash_Erase(flash_address)</pre>

Flash_Write

Prototype	sub procedure Flash_Write(dim address as longint, dim byref data as word[64])
Description	Fills one writeable block of Flash memory (64 instructions, 128 addresses, 192 bytes) in the "regular" mode. Addresses and data are being mapped 1-on-1. This also means that the 3rd byte of each program location remains unused. Parameters : - address: starting address of the FLASH memory block - data: data to be written
Requires	The block to be written to must be erased first, either from the user code (through the RTSP), or during the programming of MCU. Please note that block size that is to be erased is different from that one that can be written with this function! Note: The user should take care about the address alignment (see the explanation at the beginning of this page).
Example	<pre>dim data as word[64] = { "m", "i", "k", "r", "o", "E", "l", "e", "k", "t", "r", "o", "n", "i", "k", "a" } ... Flash_Write(0x006500, data)</pre>



Flash_Write_Compact

Prototype	<code>sub procedure Flash_Write_Compact(dim address as longint, dim byref data as byte[192])</code>
Description	Fills a portion of Flash memory (64 instructions, 128 addresses, 192 bytes) using the dsPIC33 and PIC24s RTSP (Run Time Self Programming) module, in the "compact" manner. This method uses all available bytes of the program FLASH memory, including those that are not mapped to address space (every 3rd byte). Parameters : - address: starting address of the FLASH memory block - data: data to be written
Requires	The block to be written to must be erased first, either from the user code (Flash_Erase), or during the programming of MCU. Please note that block size that is to be erased is different from that one that can be written with this function! Note: The user should take care of the address alignment (see the explanation at the beginning of this page).
Example	<pre>dim data as string[192] ... data = "supercalifragillisticexpialidociousABCDEFGHIJKLMNOPQRSTUVWXYZ1234" Flash_Write_Compact(0x006400, data)</pre>

Flash_Read

Prototype	sub procedure Flash_Read(dim address as longint, dim byref write_to as word[100] , dim NoWords as word)
Returns	Address of RAM buffer for storing read data.
Description	Reads required number of words from the flash memory in the "regular" mode. Parameters : address: starting address of the FLASH memory block to be read write_to: starting address of RAM buffer for storing read data NoWords: number of words to be read
Requires	Note: The user should take care of the address alignment (see the explanation at the beginning of this page).
Example	<pre> dim Buffer as word[10] start_address as longint ... Flash_Write(0x006500, data) start_address = 0x6500 Flash_Read(start_address, Buffer, 10) </pre>

Flash_Read_Compact

Prototype	sub procedure Flash_Read_Compact(dim address as longint, dim byref write_to as byte[100] , dim NoBytes as word)
Returns	Address of RAM buffer for storing read data.
Description	Reads required number of bytes from the flash memory in the "compact" mode. Parameters : - address: starting address of the FLASH memory block to be read - write_to: starting address of RAM buffer for storing read data - NoBytes: number of bytes to be read
Requires	Note: The user should take care of the address alignment (see the explanation at the beginning of this page).
Example	<pre> dim Buffer as byte[10] start_address as longint ... Flash_Write(0x006500, data) start_address = 0x6500 Flash_Read(start_address, Buffer, 10) </pre>

Library Example

In these examples, various techniques of reading/writing from/to on-chip FLASH memory are shown.

dsPIC30:

```
program Flash_Test
```

```
const iArr as word[ 8] = ("m", "i", "k", "r", "o", "E", "l", "e")
```

```
dim cArr as string[ 35]
```

```
cArr2 as byte[ 40]
```

```
jhh as word[ 16]
```

```
pv1 as word
```

```
bb as word
```

```
i as word
```

```
main:
```

```
ADPCFG = 0xFFFF
```

```
cArr = "mikroElektronikaYmikroElektronikaXX"
```

```
pv1 = @cArr
```

```
'--- erase the block first
```

```
Flash_Erase32(0x006000)
```

```
'--- write compact format to flash
```

```
Flash_Write_Compact(0x006000, pv1, 36)
```

```
'--- read compact format
```

```
pv1 = @cArr2
```

```
Flash_Read4_Compact(0x006000, pv1)
```

```
pv1 = pv1 + 12
```

```
Flash_Read4_Compact(0x006008, pv1)
```

```
pv1 = pv1 + 12
```

```
Flash_Read4_Compact(0x006010, pv1)
```

```
pv1 = pv1 + 12
```

```
'--- show what has been written
```

```
i = 0
```

```
Uart1_Init(9600)
```

```
Delay_ms(100)
```

```
Uart1_Write_Char("s") Uart1_Write_Char("t") Uart1_Write_Char("a")
```

```
Uart1_Write_Char("r")
```

```
Uart1_Write_Char("t") Uart1_Write_Char(10)
```

```
' continues...
```



```
' continued...

while i <> 35
    bb = cArr2[ i]
    i = i + 1
    Uart1_Write_Char(bb)
wend

'--- now for some non-compact flash-write
jhh = iArr
pv1 = @jhh
Flash_Write_Init(0x006100, pv1)
Flash_Write_Loadlatch4()
Flash_Write_Loadlatch4()
Flash_Write_DoWrite()
end.
```

PIC24 and dsPIC33:

In this example, various read/write techniques to/from the on-chip FLASH memory are shown.

program FLASH_Test

```
const iArr as word[ 64] = ("m", "i", "k", "r", "o", "E", "l", "e", "k", "t",
"r", "o", "n", "i", "k", "a")
dim cArr as string[ 192]
cArr2 as word[ 65]
i as word
```

main:

```
AD1PCFGH = $FFFF
AD1PCFGL = $FFFF
```

```
PORTB = 0x0004
```

```
TRISB = 1
```

```
cArr = "supercalifragillisticexpialidociousABCDEFGHIJKLMNOPQRSTUVWXYZ1234"
```

```
' press RB0 to continue
```

```
while (PORTB.0 = 0)
```

```
    asm
```

```
        nop
```

```
    end asm
```

```
wend
```

```
'--- erase the block first
```

```
Flash_Erase(0x006400)
```

```
'continues...
```

```
'continued...

cArr2 = iArr

for i=16 to 63
    cArr2[ i] = "x"
next i

'--- now for some non-compact flash-write
Flash_Write(0x006500, cArr2)

PORTB = 0x0008

'--- write compact format to flash
for i=64 to 191
    cArr[ i] = "y"
next i

Flash_Write_Compact(0x006400, cArr)

PORTB = 0x0010

'--- read compact format
Flash_Read_Compact(0x006400, cArr, 64)
cArr[ 64] = 0 'termination

'--- show what has been written
i = 0
Uart1_Init(9600)
Uart1_Write_Text("start : ")
Uart1_Write_Char(10)
while(cArr[ i] <> 0)
    Uart1_Write_Char(cArr[ i] )
    i = i + 1
wend

PORTB = 0x0018
end.
```

GLCD Library

mikroBasic for dsPIC30/33 and PIC24 provides a library for drawing and writing on the commonly used Samsung (KS108/KS107) Graphic LCD 128x64.

For creating a custom set of GLCD images use GLCD Bitmap Editor Tool.

Note: mikroElektronika's development system based initialization routines can be found in the setup library files located in the Uses folder.


Library Routines

Basic routines:

```
Glcd_Init  
Glcd_Config  
Glcd_Set_Side  
Glcd_Set_X  
Glcd_Set_Page  
Glcd_Read_Data  
Glcd_Write_Data
```

Advanced routines:

```
Glcd_Fill  
Glcd_Dot  
Glcd_Line  
Glcd_V_Line  
Glcd_H_Line  
Glcd_Rectangle  
Glcd_Box  
Glcd_Circle  
Glcd_Set_Font  
Glcd_Write_Char  
Glcd_Write_Text  
Glcd_Image
```



Glcd_Init

Prototype	<pre>sub procedure Glcd_Init(dim byref cs1_port as word, dim cs1_pin as word, dim byref cs2_port as word, dim cs2_pin as word, dim byref rs_port as word, dim rs_pin as word, dim byref rw_port as word, dim rw_pin as word, dim byref rst_port as word, dim rst_pin as word, dim byref en_port as word, dim en_pin as word, dim byref data_port as word)</pre>
Description	Initializes the GLCD module. Each of the control lines is both port and pin configurable, while data lines must be on a single port (pins <0:7>). Parameters : - cs1_port: chip select 1 signal port address - cs1_pin: chip select 1 signal pin - cs2_port: chip select 2 signal port address - cs2_pin: chip select 2 signal pin - rs_port: register select (data/instruction) signal port address - rs_pin: register select (data/instruction) signal pin - rw_port: read/write signal port address - rw_pin: read/write signal pin - rst_port: reset signal port address - rst_pin: reset signal pin - en_port: enable signal port address - en_pin: enable signal pin - data_port: data port
Example	<pre>' Init for EasydsPIC2 development system Glcd_Init(PORTF, 0, PORTF, 1, PORTD, 0, PORTD, 1, PORTD, 3, PORTD, 2, PORTB)</pre>

Glcd_Config

Prototype	<pre>sub procedure Glcd_Config(dim byref cs1_port as word, dim cs1_pin as word, dim byref cs2_port as word, dim cs2_pin as word, dim byref rs_port as word, dim rs_pin as word, dim byref rw_port as word, dim rw_pin as word, dim byref rst_port as word, dim rst_pin as word, dim byref en_port as word, dim en_pin as word, dim byref data_port_Lo as word, dim byref data_port_Hi as word, dim ports_config as byte)</pre>
Description	Initializes the GLCD module. Each of the control lines is both port and pin configurable. GLCD data lines can be configured on two MCU ports. Parameters : - cs1_port: chip select 1 signal port address - cs1_pin: chip select 1 signal pin - cs2_port: chip select 2 signal port address - cs2_pin: chip select 2 signal pin - rs_port: register select (data/instruction) signal port address - rs_pin: register select (data/instruction) signal pin - rw_port: read/write signal port address - rw_pin: read/write signal pin - rst_port: reset signal port address - rst_pin: reset signal pin - en_port: enable signal port address - en_pin: enable signal pin - data_port_Lo: MCU's port connected to GLCD's D3..D0 data lines - data_port_Hi: MCU's port connected to GLCD's D7..D4 data lines - ports_config: connection descriptor. Valid values: 0..3. The ports_config values determine which nibble of data_port_Lo and data_port_Hi is used: <pre> 0 = data_port_Lo pins<3..0> and data_port_Hi pins<3..0> 1 = data_port_Lo pins<3..0> and data_port_Hi pins<7..4> 2 = data_port_Lo pins<7..4> and data_port_Hi pins<3..0> 3 = data_port_Lo pins<7..4> and data_port_Hi pins<7..4></pre>
Example	<pre>' Init for EasydsPIC3 development system Glcd_Config(PORTB,4,PORTB,5,PORTF,0,PORTF, 1,PORTF, 5,PORTF, 4,PORTB,PORTD, 0) ' or just call the appropriate system based ' initialization routine Glcd_Init_EasyDsPIC3()</pre>



Glcd_Set_Side

Prototype	<code>sub procedure Glcd_Set_Side(dim x_pos as word)</code>
Description	Selects GLCD side. Refer to the GLCD datasheet for detailed explanation. Parameters : - <code>x_pos</code>: position on x-axis. Valid values: 0..127 The parameter <code>x_pos</code> specifies the GLCD side: values from 0 to 63 specify the left side, values from 64 to 127 specify the right side. Note: For side, x axis and page layout explanation see schematic at the bottom of this page.
Requires	GLCD needs to be initialized, see the <code>Glcd_Init</code> and <code>Glcd_Config</code> routines.
Example	The following two lines are equivalent, and both of them select the left side of GLCD: <pre>Glcd_Select_Side(0) Glcd_Select_Side(10)</pre>

Glcd_Set_X


Prototype	<code>sub procedure Glcd_Set_X(dim x_pos as word)</code>
Description	Sets x-axis position to <code>x_pos</code> dots from the left border of GLCD within the selected side. Parameters : - <code>x_pos</code>: position on x-axis. Valid values: 0..63 Note: For side, x axis and page layout explanation see schematic at the bottom of this page.
Requires	GLCD needs to be initialized, see the <code>Glcd_Init</code> and <code>Glcd_Config</code> routines.
Example	<pre>Glcd_Set_X(25)</pre>

Glcd_Set_Page

Prototype	sub procedure Glcd_Set_Page(dim page as word)
Description	Selects page of the GLCD. Parameters : - page: page number. Valid values: 0..7 Note: For side, x axis and page layout explanation see schematic at the bottom of this page.
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines.
Example	Glcd_Set_Page(5)

Glcd_Read_Data

Prototype	sub function Glcd_Read_Data() as word
Returns	One byte from GLCD memory, formatted as a word (16-bit).
Description	Reads data from the current location of GLCD memory and moves to the next location.
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines. GLCD side, x-axis position and page should be set first. See functions Glcd_Set_Side, Glcd_Set_X, and Glcd_Set_Page.
Example	<pre>dim data as word ... data = Glcd_Read_Data()</pre>



Glcd_Write_Data

Prototype	sub procedure Glcd_Write_Data(dim ddata as word)
Description	Writes one byte to the current location in GLCD memory and moves to the next location. Parameters : - ddata: data to be written
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines. GLCD side, x-axis position and page should be set first. See functions Glcd_Set_Side, Glcd_Set_X, and Glcd_Set_Page.
Example	<pre>dim data as byte ... Glcd_Write_Data(data)</pre>

Glcd_Fill


Prototype	sub procedure Glcd_Fill(dim pattern as word)
Description	Fills GLCD memory with the byte pattern. Parameters : - pattern: byte to fill GLCD memory with To clear the GLCD screen, use Glcd_Fill(0). To fill the screen completely, use Glcd_Fill(0xFF).
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines.
Example	<pre>Glcd_Fill(0) ' Clear screen</pre>

Glcd_Dot

Prototype	sub procedure Glcd_Dot(dim x_pos, y_pos, color as word)
Description	Draws a dot on GLCD at coordinates (x_pos, y_pos). Parameters : - x_pos: x position. Valid values: 0..127 - y_pos: y position. Valid values: 0..63 - color: color parameter. Valid values: 0..2 The parameter color determines a dot state: 0 clears dot, 1 puts a dot, and 2 inverts dot state. Note: For x and y axis layout explanation see schematic at the bottom of this page.
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines.
Example	<pre>' Invert the dot in the upper left corner Glcd_Dot(0, 0, 2)</pre>

Glcd_Line

Prototype	sub procedure Glcd_Line(dim x_start, y_start, x_end, y_end as integer, dim color as word)
Description	Draws a line on GLCD. Parameters : - x_start: x coordinate of the line start. Valid values: 0..127 - y_start: y coordinate of the line start. Valid values: 0..63 - x_end: x coordinate of the line end. Valid values: 0..127 - y_end: y coordinate of the line end. Valid values: 0..63 - color: color parameter. Valid values: 0..2 The parameter color determines the line color: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized, see Glcd_Init and Glcd_Config routines.
Example	<pre>' Draw a line between dots (0,0) and (20,30) Glcd_Line(0, 0, 20, 30, 1)</pre>



Glcd_V_Line

317

page

Prototype	sub procedure Glcd_V_Line(dim y_start, y_end, x_pos, color as word)
Description	Draws a vertical line on GLCD. Parameters : - y_start: y coordinate of the line start. Valid values: 0..63 - y_end: y coordinate of the line end. Valid values: 0..63 - x_pos: x coordinate of vertical line. Valid values: 0..127 - color: color parameter. Valid values: 0..2 The parameter color determines the line color: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized, see Glcd_Init and Glcd_Config routines.
Example	<pre>' Draw a vertical line between dots (10,5) and (10,25) Glcd_V_Line(5, 25, 10, 1)</pre>

Glcd_H_Line


Prototype	sub procedure Glcd_H_Line(dim x_start, x_end, y_pos, color as word)
Description	Draws a horizontal line on GLCD. Parameters : - x_start: x coordinate of the line start. Valid values: 0..127 - x_end: x coordinate of the line end. Valid values: 0..127 - y_pos: y coordinate of horizontal line. Valid values: 0..63 - color: color parameter. Valid values: 0..2 The parameter color determines the line color: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized, see Glcd_Init and Glcd_Config routines.
Example	<pre>' Draw a horizontal line between dots (10,20) and (50,20) Glcd_H_Line(10, 50, 20, 1)</pre>

Glcd_Rectangle

Prototype	sub procedure Glcd_Rectangle(dim x_upper_left, y_upper_left, x_bottom_right, y_bottom_right, color as word)
Description	Draws a rectangle on GLCD. Parameters : - x_upper_left: x coordinate of the upper left rectangle corner. Valid values: 0..127 - y_upper_left: y coordinate of the upper left rectangle corner. Valid values: 0..63 - x_bottom_right: x coordinate of the lower right rectangle corner. Valid values: 0..127 - y_bottom_right: y coordinate of the lower right rectangle corner. Valid values: 0..63 - color: color parameter. Valid values: 0..2 The parameter color determines the color of the rectangle border: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines.
Example	<pre>' Draw a rectangle between dots (5,5) and (40,40) Glcd_Rectangle(5, 5, 40, 40, 1)</pre>

Glcd_Box

Prototype	sub procedure Glcd_Box(dim x_upper_left, y_upper_left, x_bottom_right, y_bottom_right, color as word)
Description	Draws a box on GLCD. Parameters : - x_upper_left: x coordinate of the upper left box corner. Valid values: 0..127 - y_upper_left: y coordinate of the upper left box corner. Valid values: 0..63 - x_bottom_right: x coordinate of the lower right box corner. Valid values: 0..127 - y_bottom_right: y coordinate of the lower right box corner. Valid values: 0..63 - color: color parameter. Valid values: 0..2 The parameter color determines the color of the box fill: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines.
Example	<pre>' Draw a box between dots (5,15) and (20,40) Glcd_Box(5, 15, 20, 40, 1)</pre>



Glcd_Circle


Prototype	sub procedure Glcd_Circle(dim x_center, y_center, radius as integer , dim color as word)
Description	Draws a circle on GLCD. Parameters : - x_center: x coordinate of the circle center. Valid values: 0..127 - y_center: y coordinate of the circle center. Valid values: 0..63 - radius: radius size - color: color parameter. Valid values: 0..2 The parameter color determines the color of the circle line: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines.
Example	<i>' Draw a circle with center in (50,50) and radius=10</i> Glcd_Circle(50, 50, 10, 1)

Glcd_Set_Font

Prototype	sub procedure Glcd_Set_Font(dim byref const activeFont as byte , dim aFontWidth, aFontHeight as word , dim aFontOffs as word)
Description	Sets font that will be used with the Glcd_Write_Char and Glcd_Write_Text routines. Parameters : - activeFont: font to be set. Needs to be formatted as an array of char - aFontWidth: width of the font characters in dots. - aFontHeight: height of the font characters in dots. - aFontOffs: number that represents difference between mikroBasic for dsPIC30/33 and PIC24 character set and regular ASCII set (eg. if 'A' is 65 in ASCII character, and 'A' is 45 in mikroBasic for dsPIC30/33 and PIC24 character set, aFontOffs is 20). Demo fonts supplied with the library have an offset of 32, which means that they start with space. The user can use fonts given in the file “__Lib_Glcd_Fonts.dbas” file located in the Uses\Consts folder or create his own fonts.
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines.
Example	<i>' Use the custom 5x7 font "myfont" which starts with space (32):</i> Glcd_Set_Font(@myfont, 5, 7, 32)

Glcd_Write_Char

Prototype	sub procedure Glcd_Write_Char(dim ch, x_pos, page_num, color as word)
Description	Prints character on the GLCD. Parameters : - ch: character to be written - x_pos: character starting position on x-axis. Valid values: 0..(127-FontWidth) - page_num: the number of the page on which character will be written. Valid values: 0..7 - color: color parameter. Valid values: 0..2 The parameter color determines the color of the character: 0 white, 1 black, and 2 inverts each dot. Note: For x axis and page layout explanation see schematic at the bottom of this page.
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines. Use Glcd_Set_Font to specify the font for display; if no font is specified, then default 5x8 font supplied with the library will be used.
Example	<i>' Write character 'C' on the position 10 inside the page 2:</i> <pre>Glcd_Write_Char('C', 10, 2, 1)</pre>



Glcd_Write_Text

321

page

Prototype	sub procedure Glcd_Write_Text(dim byref text as char[40] , dim x_pos, page_num, color as word)
Description	Prints text on GLCD. Parameters : - text: text to be written - x_pos: text starting position on x-axis. - page_num: the number of the page on which text will be written. Valid values: 0..7 - color: color parameter. Valid values: 0..2 The parameter color determines the color of the text: 0 white, 1 black, and 2 inverts each dot. Note: For x axis and page layout explanation, see schematic at the bottom of this page.
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines. Use Glcd_Set_Font to specify the font for display; if no font is specified, then default 5x8 font supplied with the library will be used.
Example	<pre>' Write text "Hello world!" on the position 10 inside the page 2: Glcd_Write_Text("Hello world!", 10, 2, 1)</pre>

Glcd_Image

Prototype	sub procedure Glcd_Image(dim byref constimage as byte)
Description	Displays bitmap on GLCD. Parameters : - image: image to be displayed. Bitmap array can be located in both code and RAM (due to the mikroBasic for dsPIC30/33 and PIC24 pointer to const and pointer to RAM equivalency). Use the mikroBasic's integrated GLCD Bitmap Editor (menu option Tools > GLCD Bitmap Editor) to convert image to a constant array suitable for displaying on GLCD.
Requires	GLCD needs to be initialized, see the Glcd_Init and Glcd_Config routines.
Example	<pre>' Draw image my_image on GLCD Glcd_Image(my_image)</pre>

Library Example

The following example is a simple demonstration of the GLCD Library:

```

program GlcdDemo
include "__Lib_Glcd_Images"

dim ii as byte
      jj as word
      someText as char[ 20]

sub procedure Delay2S
    Delay_ms(2000)
end sub

main:
    ADPCFG = $FFFF
    TBLPAG = 0

    '** dsPICPro3
    Glcd_Init_dsPICPro3
    'Glcd_Init(PORTB, 2, 3, PORTB, 4, 5, 7, 6, PORTD)

    Glcd_Fill(0xAA)
    Delay2S()

    ' Main loop
    while TRUE
        Glcd_Fill(0x00) ' Clear screen

        ' Draw image
        Glcd_Image(truck_bmp)
        Delay2S()

        ' Draw dots
        for jj = 0 to 40
            Glcd_Dot(jj, jj, 1)
        next jj

        Delay2S()

        ' Draw lines
        Glcd_Fill(0x00)
        Glcd_Line(120, 1, 5, 60, 1)
        Delay2S()
        Glcd_Line(12, 42, 5, 60, 1)

        Delay2S()
    ' continues...

```

```
' continued...

Glcd_H_Line(5, 15, 6, 1)
Glcd_V_Line(6, 15, 15, 1)

' Draw rectangle
Glcd_Rectangle(12, 20, 93,57, 1)

Delay2S()

' Draw lines
Glcd_Line(120, 12, 12,60, 1)

Delay2S()

Glcd_H_Line(5, 15, 6, 1)
Glcd_Line(0, 12, 120, 60, 1)
Glcd_V_Line(7, 63, 127, 1)

Delay2S()

' Draw circles
for ii = 1 to 10
    Glcd_Circle(63, 31, 3*ii, 1)
next ii

Delay2S()

' Draw box
Glcd_Box(12, 20, 70, 57, 2)

Delay2S()

Glcd_Fill(0x00)

' Font demo
Glcd_Set_Font(@System3x6, 3, 6, 32)
someText = "SMALL FONT AS 3X6"
Glcd_Write_Text(someText, 20, 5, 1)


Glcd_Set_Font(@FontSystem5x8, 5, 8, 32)
someText = "Large Font 5x8"
Glcd_Write_Text(someText, 3, 4, 1)

Delay2S()
wend
end.
```


Hardware Connection

324

page



I2C Library

The I²C full master I²C module is available with a number of the dsPIC30/33 and PIC24 MCU models. mikroBasic for dsPIC30/33 and PIC24 provides a library which supports the master I²C mode.

Note: For the dsPIC33 and PIC24 MCUs with the multiple I²C modules there are I2C1 (supports I²C1 module), I2C2 (supports I²C2 module) and I2C libraries. I2C library supports I²C1 module and it is kept to maintain backwards compatibility with the previous versions of mikroBasic for dsPIC30/33 and PIC24.

Library Routines

dsPIC30:

```
I2C_Init
I2C_Start
I2C_Restart
I2C_Wait_For_Idle
I2C_Read
I2C_Write
I2C_Stop
```

PIC24 and dsPIC33:


I2C1_Init	I2C2_Init	I2C_Init
I2C1_Start	I2C2_Start	I2C_Start
I2C1_Restart	I2C2_Restart	I2C_Restart
I2C1_Wait_For_Idle	I2C2_Wait_For_Idle	I2C_Wait_For_Idle
I2C1_Read	I2C2_Read	I2C_Read
I2C1_Write	I2C2_Write	I2C_Write
I2C1_Stop	I2C2_Stop	I2C_Stop

I2C1_Init

Prototype	sub procedure I2c1_Init(dim scl as longint)
Description	Initializes the I²C1 module. This function enables the I2C1 module by setting the I2CEN bit. The rest of the bits in I2C1CON register remains unchanged. Default initialization (after reset) of the I2C1 module is: - continue operation in IDLE mode - IPMI mode disabled - 7-bit slave address - slew rate control enabled - general call address disabled - software or receive clock stretching disabled Parameters : - scl: requested serial clock rate. Refer to the MCU's datasheet for correct values of the scl in respect with <i>Fosc</i>.
Requires	MCU with the I ² C1 module. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>' Initialize the I2C1 module with clock_rate=100000 I2C1_Init(100000)</pre>

I2C1_Start

Prototype	sub procedure I2c1_Start()
Description	Determines if the I ² C bus is free and issues START signal.
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C1_Init. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>' Issue START signal I2C1_Start()</pre>



I2C1_Restart

Prototype	<code>sub procedure I2C1_Restart()</code>
Description	Issues repeated START signal.
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C1_Init. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>' Issue RESTART signal I2C1_Restart()</pre>

I2C1_Wait_For_Idle

Prototype	<code>sub procedure I2C1_Wait_For_Idle()</code>
Description	Waits for the I ² C bus to become free. This is a blocking function.
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C1_Init. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>dim data as byte ... I2C1_Wait_For_Idle() I2C1_Write(data) ...</pre>

I2C1_Read


Prototype	<code>sub function I2c1_Read(dim ack as word) as byte</code>
Returns	Received data.
Description	Reads a byte from the I²C bus. Parameters : - ack: acknowledge signal parameter. If the ack==0 acknowledge signal will be sent after reading, otherwise the not acknowledge signal will be sent.
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C1_Init. Also, START signal needs to be issued in order to use this function. See I2C1_Start. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>dim take as byte ... ' Read data and send the not_acknowledge signal take = I2C1_Read(1)</pre>

I2C1_Write

Prototype	sub function I2c1_Write(dim data as byte) as word
Returns	- 0 if there were no errors. - 1 if write collision was detected on the I ² C bus.
Description	Sends data byte via the I ² C bus. Parameters : - data: data to be sent
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C1_Init. Also, START signal needs to be issued in order to use this function. See I2C1_Start. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>dim data as byte error as word ... error = I2C1_Write(data) error = I2C1_Write(0xA3)</pre>

I2C1_Stop

Prototype	sub procedure I2C1_Stop()
Description	Issues STOP signal.
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C1_Init. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>' Issue STOP signal I2C1_Stop()</pre>



I2C2_Init

Prototype	sub procedure I2c2_Init(dim scl as longint)
Description	Initializes the I²C2 module. This function enables the I2C2 module by setting the I2CEN bit. The rest of the bits in I2C2CON register remains unchanged. Default initialization (after reset) of the I2C2 module is: - continue operation in IDLE mode - IPMI mode disabled - 7-bit slave address - slew rate control enabled - general call address disabled - software or receive clock stretching disabled Parameters : - scl: requested serial clock rate. Refer to the MCU's datasheet for correct values of the scl in respect with <i>Fosc</i>.
Requires	MCU with the I ² C2 module. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>' Initialize the I2C2 module with clock_rate=100000 I2C2_Init(100000)</pre>

I2C2_Start

Prototype	sub procedure I2c2_Start()
Description	Determines if the I ² C bus is free and issues START signal.
Requires	MCU with the I ² C2 module. The I ² C2 module must be initialized before using this function. See I2C2_Init. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>' Issue START signal I2C2_Start()</pre>

I2C2_Restart


Prototype	sub procedure I2C2_Restart()
Description	Issues repeated START signal.
Requires	MCU with the I ² C2 module. The I ² C2 module must be initialized before using this function. See I2C2_Init. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>' Issue RESTART signal I2C2_Restart()</pre>

I2C2_Wait_For_Idle

Prototype	sub procedure I2C2_Wait_For_Idle()
Description	Waits for the I ² C bus to become free. This is a blocking function.
Requires	MCU with the I ² C2 module. The I ² C2 module must be initialized before using this function. See I2C2_Init. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>dim data as byte ... I2C2_Wait_For_Idle() I2C2_Write(data) ...</pre>

I2C2_Read

Prototype	sub function I2c2_Read(dim ack as word) as byte
Returns	Received data.
Description	Reads a byte from the I²C bus. Parameters : - ack: acknowledge signal parameter. If the ack==0 acknowledge signal will be sent after reading, otherwise the <i>not acknowledge</i> signal will be sent.
Requires	MCU with the I ² C2 module. The I ² C2 module must be initialized before using this function. See I2C2_Init. Also, START signal needs to be issued in order to use this function. See I2C2_Start. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>dim take as byte ... ' Read data and send the not_acknowledge signal take = I2C2_Read(1)</pre>



I2C2_Write

Prototype	sub function I2c2_Write(dim data as byte) as word
Returns	- 0 if there were no errors. - 1 if write collision was detected on the I ² C bus.
Description	Sends data byte via the I ² C bus. Parameters : - data: data to be sent
Requires	MCU with the I ² C2 module. The I ² C2 module must be initialized before using this function. See I2C2_Init. Also, START signal needs to be issued in order to use this function. See I2C2_Start. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>dim data as byte error as word ... error = I2C2_Write(data) error = I2C2_Write(0xA3)</pre>

I2C2_Stop


Prototype	sub procedure I2C2_Stop()
Description	Issues STOP signal.
Requires	MCU with the I ² C2 module. The I ² C2 module must be initialized before using this function. See I2C2_Init. Supported by the dsPIC33 and PIC24 MCUs only.
Example	<pre>' Issue STOP signal I2C2_Stop()</pre>

I2C_Init

332

page

Prototype	sub procedure I2c_Init(dim scl as longint)
Description	Configures and initializes the I²C1 module with default settings. It is kept to maintain backwards compatibility with the previous versions of mikroBasic for dsPIC30/33 and PIC24. This function enables the I2C module by setting the I2CEN bit. The rest of the bits in I2C control register remains unchanged. Default initialization (after reset) of the I2C module is: - continue operation in IDLE mode - IPMI mode disabled - 7-bit slave address - slew rate control enabled - general call address disabled - software or receive clock stretching disabled Parameters : - scl: requested serial clock rate. Refer to the MCU's datasheet for correct values of scl in respect with <i>Fosc</i>.
Requires	MCU with the I ² C1 module.
Example	<pre>' Initialize the I2C1 module with clock_rate=100000 I2C_Init(100000)</pre>



I2C_Start

Prototype	<code>sub procedure I2C_Start()</code>
Description	Determines if the I ² C1 bus is free and issues START signal.
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C_Init routine.
Example	<code>' Issue START signal I2C_Start()</code>

I2C_Restart


Prototype	<code>sub procedure I2C_Restart()</code>
Description	Issues repeated START signal.
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C_Init routine.
Example	<code>' Issue RESTART signal I2C_Restart()</code>

I2C_Wait_For_Idle

Prototype	sub procedure I2C_Wait_For_Idle()
Description	Waits for the I ² C1 bus to become free. This is a blocking function.
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C_Init routine.
Example	<pre> dim data as byte ... I2C_Wait_For_Idle() I2C_Write(data) ... </pre>

I2C_Read

Prototype	sub function I2c_Read(dim ack as word) as byte
Returns	Received data.
Description	Reads a byte from the I²C1 bus. Parameters : - ack: acknowledge signal parameter. If the ack=0 acknowledge signal will be sent after reading, otherwise the not acknowledge signal will be sent.
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C_Init routine. Also, START signal needs to be issued in order to use this function. See the I2C_Start.
Example	<pre> dim take as byte ... ' Read data and send the not_acknowledge signal take = I2C_Read(1) </pre>



I2C_Write

Prototype	sub function I2c_Write(dim data as byte) as word
Returns	- 0 if there were no errors. - 1 if write collision was detected on the I ² C bus.
Description	Sends data byte via the I ² C1 bus. Parameters : - data: data to be sent
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C_Init routine. Also, START signal needs to be issued in order to use this function. See I2C_Start.
Example	<pre>dim data as byte error as word ... error = I2C_Write(data) error = I2C_Write(0xA3)</pre>

I2C_Stop

Prototype	sub procedure I2C_Stop()
Description	Issues STOP signal.
Requires	MCU with the I ² C1 module. The I ² C1 module must be initialized before using this function. See I2C_Init routine.
Example	<pre>' Issue STOP signal I2C_Stop()</pre>

Library Example

This code demonstrates the use of the I²C library. dsPIC30/33 and PIC24 MCU is connected (SCL, SDA pins) to 24c02 EEPROM. Program sends data to EEPROM (data is written at address 2). Then, we read data via I2C from EEPROM and send its value to PORTB, to check if the cycle was successful (see the figure below how to interface 24c02 to the dsPIC30/33 and PIC24).

```
program I2CEEPROM
dim dAddr as word

main:
    ADPCFG = 0xFFFF
    PORTB  = 0
    TRISB  = 0

    dAddr  = 0x02


    I2c_Init(0x000186A0)
    I2c_Start()
    I2c_Write(0xA2)
    I2c_Write(dAddr)
    I2c_Write(0xF5)
    I2c_Stop()

    Delay_ms(100)

    I2c_Start()
    I2c_Write(0xA2)
    I2c_Write(dAddr)
    I2c_Restart()
    I2c_Write(0xA3)
    PORTB = I2c_Read(1)
    I2c_Stop()
end.
```

' issue I2C start signal
' send byte via I2C (command to 24c02)
' send byte (address of EEPROM location)
' send data (data to be written)

' issue I2C start signal
' send byte via I2C (device address + W)
' send byte (data address)
' issue I2C signal repeated start
' send byte (device address + R)
' Read the data (NOT acknowledge)



Keypad Library

mikroBasic for dsPIC30/33 and PIC24 provides a library for working with 4x4 keypad. The library routines can also be used with 4x1, 4x2, or 4x3 keypad. For explanation of connections see schematic at the bottom of this page.

Library Routines


```
Keypad_Init
Keypad_Key_Press
Keypad_Key_Click
```

Keypad_Init

Prototype	sub procedure Keypad_Init(dim byref port as word)
Description	Initializes given port for working with keypad. Parameters : - port: keypad port. Note: The Keypad library uses lower byte (bits <7..0>) of key_port.
Example	<i>' Initialize PORTB<7:0> pins for communication with keypad</i> Keypad_Init(PORTB)

Keypad_Key_Press

Prototype	sub function Keypad_Key_Press() as word
Returns	The code of a pressed key (1..16), 0 if no key is pressed.
Description	Checks if any key is pressed and returns the key code.
Requires	Port needs to be initialized for working with the Keypad library, see Keypad_Init.
Example	<pre>dim kp as word ... kp = Keypad_Key_Press()</pre>



Keypad_Key_Click

Prototype	<code>sub function Keypad_Key_Click() as word</code>
Returns	The code of a clicked key (1..16), 0 if no key is clicked.
Description	Call to <code>Keypad_Key_Click</code> is a blocking call: the function waits until some key is pressed <i>and</i> released. When released, the function returns 1 to 16, depending on the key. If more than one key is pressed simultaneously the function will wait until all pressed keys are released. After that the function will return the code of the first pressed key.
Requires	Port needs to be initialized for working with the Keypad library, see <code>Keypad_Init</code> .
Example	<code>kp = Keypad_Key_Click()</code>

Library Example

The following code can be used for testing the keypad.

```
program Keypad_4x4_test

dim kp, oldkp as byte
    cnt as word
    txt as string[ 6]

main:
    cnt = 0
    Keypad_Init(PORTF)

    ADPCFG = $FFFF

    Glcd_Init_dsPICPro3()
    Glcd_Fill(0x00)
    Glcd_Set_Font(@FontSystem5x8, 5, 8, 32)
    Glcd_Write_Text("Keypad 4x4 example", 10, 0, 1)
    Glcd_Write_Text("Key pressed :", 10, 3, 1)
    Glcd_Write_Text("Times :", 10, 6, 1)

    oldkp = 1

    while TRUE
        nop
        kp = 0
        ' Wait for key to be pressed
        while kp = 0
            kp = Keypad_Key_Click()
        wend

    ' continues ...
```



```

' .. continued

    if oldkp = kp then
        Inc(cnt)
    else
        cnt = 1
    end if

    oldkp = kp

    ' Prepare value for output
    select case kp
        case 1 kp = 49 ' 1
        case 2 kp = 50 ' 2
        case 3 kp = 51 ' 3
        case 4 kp = 65 ' A
        case 5 kp = 52 ' 4
        case 6 kp = 53 ' 5
        case 7 kp = 54 ' 6
        case 8 kp = 66 ' B
        case 9 kp = 55 ' 7
        case 10 kp = 56 ' 8
        case 11 kp = 57 ' 9
        case 12 kp = 67 ' C
        case 13 kp = 42 ' *
        case 14 kp = 48 ' 0
        case 15 kp = 35 ' #
        case 16 kp = 68 ' D
    end select

    Glcd_Write_Char(kp, 30, 4, 1)

    if cnt = 65535 then
        cnt = 0
    end if

    ' Print on LCD
    WordToStr(cnt, txt)
    Glcd_Write_Text(txt, 10, 7, 1)


wend ' while

end.

```

341

page



LCD Custom Library

mikroBasic for dsPIC30/33 and PIC24 provides a library for communication with LCDs (with HD44780 compliant controllers) through the 4-bit interface. An example of LCD connections is given on the schematic at the bottom of this page.


For creating a custom set of LCD characters use the LCD Custom Character Tool.

Note: mikroElektronika's development system based initialization routines can be found in the setup library files located in the Uses folder.

Note: Only the Lcd_Custom_Config routine uses the RW pin (RW pin is configured as output and set to zero). If the user needs this pin for other purposes, it can be reconfigured after the Lcd_Custom_Config call.

Library Routines

```
Lcd_Init  
Lcd_Out  
Lcd_Out_Cp  
Lcd_Chrc  
Lcd_Chrc_Cp  
Lcd_Cmd
```



Lcd_Init

343

page

Prototype	sub procedure Lcd_Init(dim byref data_port as word , dim db3, db2, db1, db0 as word , dim byref ctrl_port as word , dim rs, ctrl_rw, enable as word)
Description	Initializes LCD with custom pin settings. Parameters : - data_port: data port - db3: data bit 3 - db2: data bit 2 - db1: data bit 1 - db0: data bit 0 - ctrl_port: control port - rs: register select (data/instruction) signal pin - ctrl_rw: read/write signal pin - enable: enable signal pin
Example	<pre>' Init for EasydsPIC3 development system Lcd_Init(PORTB, 3,2,1,0, PORTD, 0,2,1) ' or just call the appropriate system based ' initialization routine Lcd_Init_EasyDsPIC3()</pre>

Lcd_Out

Prototype	sub procedure Lcd_Out(dim row, column as byte , dim byref text as string [20])
Description	Prints text on LCD starting from specified position. Both string variables and literals can be passed as a text. Parameters : - row: starting position row number - column: starting position column number - text: text to be written
Requires	The LCD module needs to be initialized. See the Lcd_Init routine.
Example	<pre>' Write text "Hello!" on LCD starting from row 1, column 3: Lcd_Out(1, 3, "Hello!")</pre>

Lcd_Out_Cp

Prototype	sub procedure Lcd_Out_Cp(dim byref text as string [20])
Description	Prints text on LCD at current cursor position. Both string variables and literals can be passed as a text. Parameters : - text: text to be written
Requires	The LCD module needs to be initialized. See the Lcd_Init routine.
Example	<i>' Write text "Here!" at current cursor position:</i> <pre>Lcd_Out_Cp("Here!")</pre>

Lcd_Chrc

Prototype	sub procedure Lcd_Chrc(dim row, column, out_char as byte)
Description	Prints character on LCD at specified position. Both variables and literals can be passed as a character. Parameters : - row: writing position row number - column: writing position column number - out_char: character to be written
Requires	The LCD module needs to be initialized. See the Lcd_Init routine.
Example	<i>' Write character "i" at row 2, column 3:</i> <pre>Lcd_Chrc(2, 3, "i")</pre>



Lcd_Chrcp

Prototype	<code>sub procedure Lcd_Chrcp(dim out_char as byte)</code>
Description	Prints character on LCD at current cursor position. Both variables and literals can be passed as a character. Parameters : - out_char: character to be written
Requires	The LCD module needs to be initialized. See the Lcd_Init routine.
Example	<pre>' Write character "e" at current cursor position: Lcd_Chrcp("e")</pre>

Lcd_Cmd

Prototype	<code>sub procedure Lcd_Cmd(dim out_char as byte)</code>
Description	Sends command to LCD. Parameters : - out_char: command to be sent Note: Predefined constants can be passed to the function, see Available LCD Commands.
Requires	The LCD module needs to be initialized. See the Lcd_Init routine.
Example	<pre>' Clear LCD display: Lcd_Cmd(LCD_CLEAR)</pre>

LCD Commands

LCD Command	Purpose
LCD_FIRST_ROW	Move cursor to 1st row
LCD_SECOND_ROW	Move cursor to 2nd row
LCD_THIRD_ROW	Move cursor to 3rd row
LCD_FOURTH_ROW	Move cursor to 4th row
LCD_CLEAR	Clear display
LCD_RETURN_HOME	Return cursor to home position, returns a shifted display to original position. Display data RAM is unaffected.
LCD_CURSOR_OFF	Turn off cursor
LCD_UNDERLINE_ON	Underline cursor on
LCD_BLINK_CURSOR_ON	Blink cursor on
LCD_MOVE_CURSOR_LEFT	Move cursor left without changing display data RAM
Lcd_Move_Cursor_Right	Move cursor right without changing display data RAM
LCD_TURN_ON	Turn LCD display on
LCD_TURN_OFF	Turn LCD display off
LCD_SHIFT_LEFT	Shift display left without changing display data RAM
LCD_SHIFT_RIGHT	Shift display right without changing display data RAM

Library Example

```

program LCD4bitTest

dim txt as string[15]

main:
    ADPCFG = $FFFF
    Lcd_Init_EasydsPIC4()

    Lcd_Cmd(LCD_CURSOR_OFF)
    Lcd_Cmd(LCD_FIRST_ROW)

    LCD_Chr_Cp("m") ' m
    LCD_Chr_Cp(105) ' i
    LCD_Chr_Cp(107) ' k
    LCD_Chr_Cp("r") ' r
    LCD_Chr_Cp(111) ' o

    Lcd_Cmd(LCD_SECOND_ROW)
    Lcd_Out(2, 6, "Elektronika")

    Delay_ms(1000)

    txt = "Elektronika"
    Lcd_Out(1, 6, txt)


end.

```


Hardware Connection

348

page



LCD 2X16

LCD8 (8-bit interface) Custom Library

mikroBasic for dsPIC30/33 and PIC24 provides a library for communication with LCDs (with HD44780 compliant controllers) through the 8-bit interface. An example of LCD connections is given on the schematic at the bottom of this page.

For creating a custom set of LCD characters use the LCD Custom Character Tool.

Note: mikroElektronika's development system based initialization routines can be found in the setup library files located in the Uses folder.


Note: Only the `Lcd8_Init` and `Lcd8_Config` routines use the RW pin (RW pin is configured as output and set to zero). If the user needs this pin for other purposes, it can be reconfigured after the `Lcd8_Init` or `Lcd8_Config` call.

Library Routines

```
Lcd8_Init
Lcd8_Config
Lcd8_Out
Lcd8_Out_Cp
Lcd8_Chrc
Lcd8_Chrc_Cp
Lcd8_Cmd
```

Lcd8_Init

350	page	Prototype <code>sub procedure Lcd8_Init(dim byref data_port as word, dim db7, db6, db5, db4, db3, db2, db1, db0 as word, dim byref ctrl_port as word, dim rs, ctrl_rw, enable as word)</code>
		Description Initializes LCD with custom pin settings. Parameters : - data_port: data port - db7: data bit 7 - db6: data bit 6 - db5: data bit 5 - db4: data bit 4 - db3: data bit 3 - db2: data bit 2 - db1: data bit 1 - db0: data bit 0 - ctrl_port: control port - rs: register select (data/instruction) signal pin - ctrl_rw: read/write signal pin - enable: enable signal pin
		Example <pre>' Init for EasydsPIC2 development system Lcd8_Init(PORTB, 7, 6, 5, 4, 3, 2, 1, 0, PORTD, 0, 1, 2) ' or just call the appropriate system based ' initialization routine Lcd8_Init_EasyDsPIC2()</pre>



Lcd8_Config

Prototype	<pre>sub procedure Lcd8_Config(dim byref data_portHi as word, dim db7, db6, db5, db4 as word, dim byref data_portLo as word, dim db3, db2, db1, db0 as word, dim byref ctrl_port as word, dim rs, ctrl_rw, enable as word)</pre>
Description	Initializes LCD with custom pin settings. LCD data lines can be configured on two MCU ports. Parameters : - data_portHi: MCU's port connected to LCD's D7..D4 data lines - db7: data bit 7 - db6: data bit 6 - db5: data bit 5 - db4: data bit 4 - data_portLo: MCU's port connected to LCD's D3..D0 data lines - db3: data bit 3 - db2: data bit 2 - db1: data bit 1 - db0: data bit 0 - ctrl_port: control port - rs: register select (data/instruction) signal pin - ctrl_rw: read/write signal pin - enable: enable signal pin
Example	<pre>' Init for EasydsPIC3 development system Lcd8_Config(PORTD, 3, 2, 1, 0,PORTB, 3, 2, 1, 0,PORTF, 0, 1, 4) ' or just call the appropriate system based ' initialization routine Lcd8_Init_EasyDsPIC3()</pre>

Lcd8_Out

Prototype	sub procedure Lcd8_Out(dim row, column as word, dim byref text as string[20])
Description	Prints text on LCD starting from the specified position. Both string variables and literals can be passed as a text. Parameters : - row: starting position row number - column: starting position column number - text: text to be written
Requires	The LCD module needs to be initialized. See the Lcd8_Init and Lcd8_Config routines.
Example	<i>' Write text "Hello!" on LCD starting from row 1, column 3:</i> Lcd8_Out(1, 3, "Hello!")

Lcd8_Out_Cp

Prototype	sub procedure Lcd8_Out_Cp(dim byref text as string[20])
Description	Prints text on LCD at current cursor position. Both string variables and literals can be passed as a text. Parameters : - text: text to be written
Requires	The LCD module needs to be initialized. See the Lcd8_Init and Lcd8_Config routines.
Example	<i>' Write text "Here!" at current cursor position:</i> Lcd8_Out_Cp("Here!")



Lcd8_Ch

Prototype	<code>sub procedure Lcd8_Ch(dim row, column, out_char as byte)</code>
Description	Prints character on LCD at the specified position. Both variables and literals can be passed as a character. Parameters : - row: writing position row number - column: writing position column number - out_char: character to be written
Requires	The LCD module needs to be initialized. See the Lcd8_Init and Lcd8_Config routines.
Example	<pre>' Write character "i" at row 2, column 3: Lcd8_Out(2, 3, "i")</pre>

Lcd8_Ch_Cp

Prototype	<code>sub procedure Lcd8_Ch_Cp(dim out_char as byte)</code>
Description	Prints character on LCD at current cursor position. Both variables and literals can be passed as a character. Parameters : - out_char: character to be written
Requires	The LCD module needs to be initialized. See the Lcd8_Init and Lcd8_Config routines.
Example	<pre>' Write character "e" at current cursor position: Lcd8_Ch_Cp("e")</pre>

Lcd8_Cmd

Prototype	<code>sub procedure Lcd8_Cmd(dim out_char as word)</code>
Description	Sends command to LCD. Parameters : - out_char: command to be sent Note: Predefined constants can be passed to the function, see Available LCD Commands.
Requires	The LCD module needs to be initialized. See the Lcd8_Init and Lcd8_Config routines.
Example	<pre>' Clear LCD display: Lcd8_Cmd(LCD_CLEAR)</pre>

Library Example

Here is an example of using the Lcd8 Custom Library.

```
program Lcd8Bit_Test


dim txt as string[ 15]

main:
    ADPCFG = $FFFF                ' PORTB to be digital
    Lcd8_Init(PORTB, 7, 6, 5, 4, 3, 2, 1, 0, PORTD, 0, 1, 2)
    Lcd8_Cmd(LCD_CURSOR_OFF)
    Lcd8_Cmd(LCD_FIRST_ROW)

    LCD8_Chrcp("m") ' m
    LCD8_Chrcp(105) ' i
    LCD8_Chrcp(107) ' k
    LCD8_Chrcp("r") ' r
    LCD8_Chrcp(111) ' o

    Lcd8_Cmd(LCD_SECOND_ROW)
    Lcd8_Out(2, 6, "Elektronika")
    Delay_ms(1000)
    txt = "Elektronika"
    Lcd8_Out(1, 6, txt)

end.
```




LCD Commands

LCD Command	Purpose
LCD_FIRST_ROW	Move cursor to 1st row
LCD_SECOND_ROW	Move cursor to 2nd row
LCD_THIRD_ROW	Move cursor to 3rd row
LCD_FOURTH_ROW	Move cursor to 4th row
LCD_CLEAR	Clear display
LCD_RETURN_HOME	Return cursor to home position, returns a shifted display to original position. Display data RAM is unaffected.
LCD_CURSOR_OFF	Turn off cursor
LCD_UNDERLINE_ON	Underline cursor on
LCD_BLINK_CURSOR_ON	Blink cursor on
LCD_MOVE_CURSOR_LEFT	Move cursor left without changing display data RAM
Lcd_Move_Cursor_Right	Move cursor right without changing display data RAM
LCD_TURN_ON	Turn LCD display on
LCD_TURN_OFF	Turn LCD display off
LCD_SHIFT_LEFT	Shift display left without changing display data RAM
LCD_SHIFT_RIGHT	Shift display right without changing display data RAM

Hardware Connection

356

page




LCD 2X16



Manchester Code Library

mikroBasic for dsPIC30/33 and PIC24 provides a library for handling Manchester coded signals. The Manchester code is a code in which data and clock signals are combined to form a single self-synchronizing data stream; each encoded bit contains a transition at the midpoint of a bit period, the direction of transition determines whether the bit is 0 or 1; the second half is the true bit value and the first half is the complement of the true bit value (as shown in the figure below).

Manchester RF_Send_Byte format



Bi-phase coding



Notes: The Manchester receive routines are blocking calls (`Man_Receive_Config`, `Man_Receive_Init` and `Man_Synchro`). This means that MCU will wait until the task has been performed (e.g. byte is received, synchronization achieved, etc).

Library Routines

```

Man_Receive_Config
Man_Receive_Init
Man_Receive
Man_Send_Config
Man_Send_Init
Man_Send
Man_Synchro


```

The following routines are for the internal use by the compiler only:

```
Manchester_0
Manchester_1
Manchester_Out
```

Man_Receive_Config

Prototype	sub function Man_Receive_Config(dim byref port as word , dim rxpin as word) as word
Returns	- 0 - if initialization and synchronization were successful. - 1 - upon unsuccessful synchronization.
Description	The function configures Receiver pin and performs synchronization procedure in order to retrieve baud rate out of incoming signal. Parameters : - port: Receiver port - rxpin: Receiver pin Note: In case of multiple persistent errors on reception, the user should call this routine once again or Man_Synchro routine to enable synchronization.
Example	<pre>' Configure Receiver on pin RD3: Man_Receive_Config(PORTD, 3)</pre>



Man_Receive_Init

Prototype	<code>sub function Man_Receive_Init(dim byref port as word) as word</code>
Returns	- 0 - if initialization and synchronization were successful. - 1 - upon unsuccessful synchronization
Description	The function configures Receiver pin as pin3 of the MCU's port. After that, the function performs synchronization procedure in order to retrieve baud rate out of incoming signal. Parameters : - port: Receiver port Note: In case of multiple persistent errors on reception, the user should call this routine once again or Man_Synchro routine to enable synchronization.
Example	<pre>' Configure Receiver on pin RD3: Man_Receive_Init(PORTD)</pre>

Man_Receive

Prototype	<code>sub function Man_Receive(dim byref error as word) as byte</code>
Returns	A byte read from the incoming signal.
Description	The function extracts one byte from incoming signal. Parameters : - error: error flag. If signal format does not match the expected, the error flag will be set to non-zero.
Requires	To use this function, the user must prepare the MCU for receiving. See Man_Receive_Config or Man_Receive_Init.
Example	<pre>dim data, error as word ... error = 0 data = 0 data = Man_Receive(error) if (error <> 0) then ' error handling end if</pre>

Man_Send_Config

Prototype	sub procedure Man_Send_Config(dim byref port as word , dim txpin as word)
Description	The function configures Transmitter pin. Parameters : - port: Transmitter port - txpin: Transmitter pin
Example	<i>' Configure Transmitter on pin RD0:</i> Man_Send_Config(PORTD, 0)

Man_Send_Init

Prototype	sub procedure Man_Send_Init(dim byref port as word)
Description	The function configures Transmitter pin as pin0 of the MCU's port. Parameters : - port: Transmitter port
Example	<i>' Configure Transmitter on pin RD0:</i> Man_Send_Init(PORTD)

Man_Send

Prototype	sub procedure Man_Send(dim data as byte)
Description	Sends one byte. Parameters : - data: data to be sent Note: Baud rate used is 500 bps.
Requires	To use this function, the user must prepare the MCU for sending. See Man_Send_Config or Man_Send_Init.
Example	dim msg as byte ... Man_Send(msg)



Man_Synchro

Prototype	<code>sub function Man_Synchro() as word</code>
Returns	- 0 - if synchronization was not successful. - Half of the manchester bit length, given in multiples of 10us upon successful synchronization.
Description	Measures half of the manchester bit length with 10us resolution.
Requires	To use this function, you must first prepare the MCU for receiving. See Man_Receive_Config or Man_Receive_Init.
Example	<pre>dim man__half_bit_len as word ... man__half_bit_len = Man_Synchro()</pre>

Library Example

The following code receives message in Manchester code:

```

program Manchester_Rcv

dim
    _error,
    ErrorCount,
    tmp as word

main:
    ADPCFG = 0xFFFF
    _error = 0
    ErrorCount = 0

    Lcd_Init_EasydsPIC4()
    Lcd_Out(1,1,"mikroManchester")
    Man_Receive_Config(PORTC, 13)
    while true
        Lcd_Cmd(LCD_FIRST_ROW)
        while true
            tmp = Man_Receive(_error)
            if (tmp = 0x0B) then
                break
            end if
            if (_error <> 0) then
                break
            end if
        wend

        while (tmp <> 0x0E)
            tmp = Man_Receive(_error)
            if (_error <> 0) then
                Lcd_Chrcp("?")
                ErrorCount = ErrorCount + 1
                if (ErrorCount > 20) then
                    'Man_Receive_Init(PORTD)
                    ' alternative:
                    tmp = Man_Synchro()
                    ErrorCount = 0
                end if
            else
                if (tmp <> 0x0E) then
                    Lcd_Chrcp(tmp)
                end if
            end if
            Delay_ms(25)
        wend
    wend

```

' Initialize LCD on EasydsPIC4

' Configure and synchronize receiver



' Wait for the start marker

' We got the starting sequence

' Exit so we do not loop forever

' Attempt byte receive

' Don't write the end marker on LCD



Multi Media Card Library

mikroBasic for dsPIC30/33 and PIC24 provides a library for handling data on MMC and SD memory cards using SPI interface.

Note: Routines for file handling can be used only with FAT16 file system.

Note: Library functions create and read files from the root directory only.

Note: Library functions populate both FAT1 and FAT2 tables when writing to files, but the file data is being read from the FAT1 table only; i.e. there is no recovery if the FAT1 table gets corrupted.

Note: If MMC/SD card has Master Boot Record (MBR), the library will work with the first available primary (logical) partition that has non-zero size. If MMC/SD card has Volume Boot Record (i.e. there is only one logical partition and no MBRs), the library works with entire card as a single partition. For more information on MBR, physical and logical drives, primary/secondary partitions and partition tables, please consult other resources, e.g. Wikipedia and similar.


Note: Before writing operation, make sure to not overwrite boot or FAT sector because it could make your card on PC or digital camera unreadable. Drive mapping tools, such as Winhex, can be of a great assistance.

Note: Library uses SPI module for communication. The user must initialize the appropriate SPI module before using the MMC Library. For MCUs with two SPI modules it is possible to initialize both of them and then switch by using the `Spi_Set_Active()` function. See the Spi Library functions.

The SPI module has to be initialized through the `Spi_Init_Advanced` routine with the following parameters:

- SPI Master
- 8bit mode
- secondary prescaler 1
- primary prescaler 64
- Slave Select disabled
- data sampled in the middle of data output time
- clock idle high
- Serial output data changes on transition from active clock state to idle clock state

Note: Once the MMC/SD card is initialized, the user can reinitialize SPI at higher speed. See the `Mmc_Init` and `Mmc_Fat_Init` routines.



Library Routines

Mmc_Init	Mmc_Fat_Read
Mmc_Read_Sector	Mmc_Fat_Rewrite
Mmc_Write_Sector	Mmc_Fat_Append
Mmc_Read_Cid	Mmc_Fat_Delete
Mmc_Read_Csd	Mmc_Fat_Write
Mmc_Fat_Init	Mmc_Fat_Set_File_Date
Mmc_Fat_QuickFormat	Mmc_Fat_Get_File_Date
Mmc_Fat_Assign	Mmc_Fat_Get_File_Size
Mmc_Fat_Reset	Mmc_Fat_Get_Swap_File

Mmc_Init


Prototype	sub function Mmc_Init(dim byref port as word , dim cspin as word) as word
Returns	- 0 - if MMC/SD card was detected and successfully initialized - 1 - otherwise
Description	Initializes MMC through hardware SPI interface. Parameters: - port: chip select signal port address. - cspin: chip select pin.
Requires	The appropriate hardware SPI module must be previously initialized. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	dim i as word ... <i>' Initialize the SPI module</i> Spi1_Init_Advanced(_SPI_MASTER, _SPI_8_BIT, _SPI_PRESCALE_SEC_1, _SPI_PRESCALE_PRI_64, _SPI_SS_DISABLE, _SPI_DATA_SAMPLE_MIDDLE, _SPI_CLK_IDLE_HIGH, _SPI_ACTIVE_2_IDLE) <i>' MMC initialization</i> i = Mmc_Init(PORTF, 0)

Mmc_Read_Sector

Prototype	sub function Mmc_Read_Sector(dim sector as longint, dim byref data as byte[512]) as word
Returns	- 0 - if reading was successful - 1 - if an error occurred
Description	The function reads one sector (512 bytes) from MMC card. Parameters: - sector: MMC/SD card sector to be read. - data: buffer of minimum 512 bytes in length for data storage.
Requires	MMC/SD card must be initialized. See Mmc_Init.
Example	<pre>' read sector 510 of the MMC/SD card dim error as word sectorNo as longint dataBuffer as byte[512] ... sectorNo = 510 error = Mmc_Read_Sector(sectorNo, dataBuffer)</pre>

Mmc_Write_Sector

Prototype	sub function Mmc_Write_Sector(dim sector as longint, dim byref data as byte[512]) as word
Returns	- 0 - if writing was successful - 1 - if there was an error in sending write command - 2 - if there was an error in writing (data rejected)
Description	The function writes 512 bytes of data to one MMC card sector. Parameters: - sector: MMC/SD card sector to be written to. - data: data to be written (buffer of minimum 512 bytes in length).
Requires	MMC/SD card must be initialized. See Mmc_Init.
Example	<pre>' write to sector 510 of the MMC/SD card dim error as word sectorNo as longint dataBuffer as byte[512] ... sectorNo = 510 error = Mmc_Write_Sector(sectorNo, dataBuffer)</pre>



Mmc_Read_Cid

Prototype	sub function Mmc_Read_Cid(dim byref data_cid as byte [2]) as word
Returns	- 0 - if CID register was read successfully - 1 - if there was an error while reading
Description	The function reads 16-byte CID register. Parameters: - data_cid: buffer of minimum 16 bytes in length for storing CID register content.
Requires	MMC/SD card must be initialized. See Mmc_Init.
Example	<pre>dim error as word dataBuffer as byte[512] ... error = Mmc_Read_Cid(dataBuffer)</pre>

Mmc_Read_Csd

Prototype	sub function Mmc_Read_Csd(dim byref data_csd as byte [16]) as word
Returns	- 0 - if CSD register was read successfully - 1 - if there was an error while reading
Description	The function reads 16-byte CSD register. Parameters: - data_csd: buffer of minimum 16 bytes in length for storing CSD register content.
Requires	MMC/SD card must be initialized. See Mmc_Init.
Example	<pre>dim error as word dataBuffer as byte[512] ... error = Mmc_Read_Csd(dataBuffer)</pre>

Mmc_Fat_Init

Prototype	sub function Mmc_Fat_Init(dim byref port as word, dim pin as word) as word
Returns	- 0 - if MMC/SD card was detected and successfully initialized - 1 - if FAT16 boot sector was not found - 255 - if MMC/SD card was not detected
Description	Initializes MMC/SD card, reads MMC/SD FAT16 boot sector and extracts necessary data needed by the library. Parameters: - port: chip select signal port address. - pin: chip select pin. Note: MMC/SD card has to be formatted to FAT16 file system.
Requires	The appropriate hardware SPI module must be previously initialized.
Example	<pre> ' Initialize the SPI module Spi1_Init_Advanced(_SPI_MASTER, _SPI_8_BIT, _SPI_PRESCALE_SEC_1, _SPI_PRESCALE_PRI_64, _SPI_SS_DISABLE, _SPI_DATA_SAMPLE_MIDDLE, _SPI_CLK_IDLE_HIGH, _SPI_ACTIVE_2_IDLE) ' Initialize MMC/SD card and MMC_FAT16 library globals if (Mmc_Fat_Init(PORTF, 0) = 0) then ' EasydsPIC4 board ' reinitialize spi at higher speed Spi1_Init_Advanced(_SPI_MASTER, _SPI_8_BIT, _SPI_PRESCALE_SEC_1, _SPI_PRESCALE_PRI_4, _SPI_SS_DISABLE, _SPI_DATA_SAMPLE_MIDDLE, _SPI_CLK_IDLE_HIGH, _SPI_ACTIVE_2_IDLE) ... end if </pre>



Mmc_Fat_QuickFormat


Prototype	<code>sub function Mmc_Fat_QuickFormat(dim byref port as word, dim pin as word, dim byref mmc_fat_label as string[11]) as word</code>
Returns	- 0 - if MMC/SD card was detected, successfully formatted and initialized - 1 - if FAT16 format was unseccessful - 255 - if MMC/SD card was not detected
Description	Formats to FAT16 and initializes MMC/SD card. Parameters: - port: chip select signal port address. - pin: chip select pin. - mmc_fat_label: volume label (11 characters in length). If less than 11 characters are provided, the label will be padded with spaces. If an empty string is passed, the volume will not be labeled. Note: This routine can be used instead or in conjunction with the Mmc_Fat_Init routine. Note: If MMC/SD card already contains a valid boot sector, it will remain unchanged (except volume label field) and only FAT and ROOT tables will be erased. Also, the new volume label will be set.
Requires	The appropriate hardware SPI module must be previously initialized.
Example	<pre>' Initialize the SPI module Spi1_Init_Advanced(_SPI_MASTER, _SPI_8_BIT, _SPI_PRESCALE_SEC_1, _SPI_PRESCALE_PRI_64, _SPI_SS_DISABLE, _SPI_DATA_SAMPLE_MIDDLE, _SPI_CLK_IDLE_HIGH, _SPI_ACTIVE_2_IDLE) ' Format and initialize MMC/SD card and MMC_FAT16 library globals Mmc_Fat_QuickFormat(PORTF, 0, "mikroE") ' Reinitialize the SPI module at higher speed ' (change primary prescaler). Spi1_Init_Advanced(_SPI_MASTER, _SPI_8_BIT, _SPI_PRESCALE_SEC_1, _SPI_PRESCALE_PRI_4, _SPI_SS_DISABLE, _SPI_DATA_SAMPLE_MIDDLE, _SPI_CLK_IDLE_HIGH, _SPI_ACTIVE_2_IDLE)</pre>

Mmc_Fat_Assign

370

page

Prototype	<code>sub function Mmc_Fat_Assign(dim byref filename as string[11] , dim file_cre_attr as byte) as word</code>																											
Returns	- 1 - if file already exists or file does not exist but a new file is created. - 0 - if file does not exist and no new file is created.																											
Description	Assigns file for file operations (read, write, delete...). All subsequent file operations will be applied on an assigned file. Parameters: - filename: name of the file that should be assigned for file operations. File name should be in DOS 8.3 (file_name.extension) format. The file name and extension will be automatically padded with spaces by the library if they have less than length required (i.e. "mikro.tx" -> "mikro .tx "), so the user does not have to take care of that. The file name and extension are case insensitive. The library will convert them to proper case automatically, so the user does not have to take care of that. Also, in order to keep backward compatibility with the first version of this library, file names can be entered as UPPERCASE string of 11 bytes in length with no dot character between file name and extension (i.e. "MIKROELETXT" -> MIKROELE.TXT). In this case last 3 characters of the string are considered to be file extension. - file_cre_attr: file creation and attributs flags. Each bit corresponds to the appropriate file attribut: <table><tr><th>BIT</th><th>MASK</th><th>Description</th></tr><tr><td>0</td><td>0x01</td><td>Read Only</td></tr><tr><td>1</td><td>0x02</td><td>Hidden</td></tr><tr><td>2</td><td>0x04</td><td>System</td></tr><tr><td>3</td><td>0x08</td><td>Volume Label</td></tr><tr><td>4</td><td>0x10</td><td>Subdirectory</td></tr><tr><td>5</td><td>0x20</td><td>Archive</td></tr><tr><td>6</td><td>0x40</td><td>Device (internal use only, never found on disk)</td></tr><tr><td>7</td><td>0x80</td><td>File creation flag. If the file does not exist and this flag is set, a new file with specified name will be created.</td></tr></table> Note: Long File Names (LFN) are not supported.	BIT	MASK	Description	0	0x01	Read Only	1	0x02	Hidden	2	0x04	System	3	0x08	Volume Label	4	0x10	Subdirectory	5	0x20	Archive	6	0x40	Device (internal use only, never found on disk)	7	0x80	File creation flag. If the file does not exist and this flag is set, a new file with specified name will be created.
BIT	MASK	Description																										
0	0x01	Read Only																										
1	0x02	Hidden																										
2	0x04	System																										
3	0x08	Volume Label																										
4	0x10	Subdirectory																										
5	0x20	Archive																										
6	0x40	Device (internal use only, never found on disk)																										
7	0x80	File creation flag. If the file does not exist and this flag is set, a new file with specified name will be created.																										
Requires	MMC/SD card and MMC library must be initialized for file operations. See Mmc_Fat_Init.																											
Example	<code>' create file with archive attribut if it does not already exist Mmc_Fat_Assign("MIKRO007.TXT", 0xA0)</code>																											



Mmc_Fat_Reset

Prototype	sub procedure Mmc_Fat_Reset(dim byref size as longint)
Description	Opens currently assigned file for reading. Parameters: - size: buffer to store file size to. After file has been open for reading, its size is returned through this parameter.
Requires	MMC/SD card and MMC library must be initialized for file operations. See Mmc_Fat_Init. The file must be previously assigned. See Mmc_Fat_Assign.
Example	<pre>dim size as longint ... Mmc_Fat_Reset(size)</pre>

Mmc_Fat_Read

Prototype	sub procedure Mmc_Fat_Read(dim byref bdata as byte)
Description	Reads a byte from the currently assigned file opened for reading. Upon function execution, file pointers will be set to the next character in the file. Parameters: - bdata: buffer to store read byte to. Upon this function execution read byte is returned through this parameter.
Requires	MMC/SD card and MMC library must be initialized for file operations. See Mmc_Fat_Init. The file must be previously assigned. See Mmc_Fat_Assign. The file must be opened for reading. See Mmc_Fat_Reset.
Example	<pre>dim character as byte ... Mmc_Fat_Read(character)</pre>

Mmc_Fat_Rewrite


Prototype	sub procedure Mmc_Fat_Rewrite()
Description	Opens the currently assigned file for writing. If the file is not empty its content will be erased.
Requires	MMC/SD card and MMC library must be initialized for file operations. See Mmc_Fat_Init. The file must be previously assigned. See Mmc_Fat_Assign.
Example	<i>' open file for writing</i> Mmc_Fat_Rewrite()

Mmc_Fat_Append

Prototype	sub procedure Mmc_Fat_Append()
Description	Opens the currently assigned file for appending. Upon this function execution file pointers will be positioned after the last byte in the file, so any subsequent file writing operation will start from there.
Requires	MMC/SD card and MMC library must be initialized for file operations. See Mmc_Fat_Init. The file must be previously assigned. See Mmc_Fat_Assign.
Example	<i>' open file for appending</i> Mmc_Fat_Append()

Mmc_Fat_Delete

Prototype	sub procedure Mmc_Fat_Delete()
Description	Deletes currently assigned file from MMC/SD card.
Requires	MMC/SD card and MMC library must be initialized for file operations. See Mmc_Fat_Init. The file must be previously assigned. See Mmc_Fat_Assign.
Example	<i>' delete current file</i> Mmc_Fat_Delete()



Mmc_Fat_Write

Prototype	sub procedure Mmc_Fat_Write(dim byref fdata as byte [12] , dim data_len as word)
Description	Writes requested number of bytes to the currently assigned file opened for writing. Parameters: - fdata: data to be written. - data_len: number of bytes to be written.
Requires	MMC/SD card and MMC library must be initialized for file operations. See Mmc_Fat_Init. The file must be previously assigned. See Mmc_Fat_Assign. The file must be opened for writing. See Mmc_Fat_Rewrite or Mmc_Fat_Append.
Example	<pre>dim file_contents as byte[42] ... Mmc_Fat_Write(file_contents, 42) ' write data to the assigned file</pre>

Mmc_Set_File_Date


Prototype	sub procedure Mmc_Fat_Set_File_Date(dim year as word , dim month as byte , dim day as byte , dim hours as byte , dim mins as byte , dim seconds as byte)
Description	Sets the date/time stamp. Any subsequent file writing operation will write this stamp to the currently assigned file's time/date attributs. Parameters: - year: year attribute. Valid values: 1980-2107 - month: month attribute. Valid values: 1-12 - day: day attribute. Valid values: 1-31 - hours: hours attribute. Valid values: 0-23 - mins: minutes attribute. Valid values: 0-59 - seconds: seconds attribute. Valid values: 0-59
Requires	MMC/SD card and MMC library must be initialized for file operations. See Mmc_Fat_Init. The file must be previously assigned. See Mmc_Fat_Assign. The file must be opened for writing. See Mmc_Fat_Rewrite or Mmc_Fat_Append.
Example	<pre>Mmc_Fat_Set_File_Date(2005, 9, 30, 17, 41, 0)</pre>

Mmc_Fat_Get_File_Date

Prototype	sub procedure Mmc_Fat_Get_File_Date(dim byref year as word , dim byref month as byte , dim byref day as byte , dim byref hours as byte , dim byref mins as byte)
Description	Reads time/date attributes of the currently assigned file. Parameters: - year: buffer to store year attribute to. Upon function execution year attribute is returned through this parameter. - month: buffer to store month attribute to. Upon function execution month attribute is returned through this parameter. - day: buffer to store day attribute to. Upon function execution day attribute is returned through this parameter. - hours: buffer to store hours attribute to. Upon function execution hours attribute is returned through this parameter. - mins: buffer to store minutes attribute to. Upon function execution minutes attribute is returned through this parameter.
Requires	MMC/SD card and MMC library must be initialized for file operations. See Mmc_Fat_Init. The file must be previously assigned. See Mmc_Fat_Assign.
Example	<pre> dim year as word month, day, hours, mins as byte ... Mmc_Fat_Get_File_Date(year, month, day, hours, mins) </pre>

Mmc_Fat_Get_File_Size

Prototype	sub function Mmc_Fat_Get_File_Size() as longint
Returns	Size of the currently assigned file in bytes.
Description	This function reads size of the currently assigned file in bytes.
Requires	MMC/SD card and MMC library must be initialized for file operations. See Mmc_Fat_Init. The file must be previously assigned. See Mmc_Fat_Assign.
Example	<pre> dim my_file_size as longint ... my_file_size = Mmc_Fat_Get_File_Size() </pre>




Mmc_Fat_Get_Swap_File

375

page

Prototype	sub function Mmc_Fat_Get_Swap_File(dim sectors_cnt as longint, dim byref filename as string[11] , dim file_attr as byte) as longint
Returns	- Number of the start sector for the newly created swap file, if there was enough free space on the MMC/SD card to create file of required size. - 0 - otherwise.
Description	This function is used to create a swap file of predefined name and size on the MMC/SD media. If a file with specified name already exists on the media, search for consecutive sectors will ignore sectors occupied by this file. Therefore, it is recommended to erase such file if it already exists before calling this function. If it is not erased and there is still enough space for a new swap file, this function will delete it after allocating new memory space for a new swap file. The purpose of the swap file is to make reading and writing to MMC/SD media as fast as possible, by using the Mmc_Read_Sector() and Mmc_Write_Sector() functions directly, without potentially damaging the FAT system. The swap file can be considered as a "window" on the media where the user can freely write/read data. Its main purpose in the mikroBasic's library is to be used for fast data acquisition; when the time-critical acquisition has finished, the data can be re-written into a "normal" file, and formatted in the most suitable way. Parameters: - sectors_cnt: number of consecutive sectors that user wants the swap file to have. - filename: name of the file that should be assigned for file operations. File name should be in DOS 8.3 (file_name.extension) format. The file name and extension will be automatically padded with spaces by the library if they have less than length required (i.e. "mikro.tx" -> "mikro .tx "), so the user does not have to take care of that. The file name and extension are case insensitive. The library will convert them to proper case automatically, so the user does not have to take care of that. Also, in order to keep backward compatibility with the first version of this library, file names can be entered as UPPERCASE string of 11 bytes in length with no dot character between file name and extension (i.e. "MIKROELETXT" -> MIKROELE.TXT). In this case the last 3 characters of the string are considered to be file extension. - file_attr: file creation and attributs flags. Each bit corresponds to the appropriate file attribut: ' continues on the next page ...

	<i>' continued from the previous page ...</i> <table><tr><th>BIT</th><th>MASK</th><th>Description</th></tr><tr><td>0</td><td>0x01</td><td>Read Only</td></tr><tr><td>1</td><td>0x02</td><td>Hidden</td></tr><tr><td>2</td><td>0x04</td><td>System</td></tr><tr><td>3</td><td>0x08</td><td>Volume Label</td></tr><tr><td>4</td><td>0x10</td><td>Subdirectory</td></tr><tr><td>5</td><td>0x20</td><td>Archive</td></tr><tr><td>6</td><td>0x40</td><td>Device (internal use only, never found on disk)</td></tr><tr><td>7</td><td>0x80</td><td>Not Used</td></tr></table> Note: Long File Names (LFN) are not supported.	BIT	MASK	Description	0	0x01	Read Only	1	0x02	Hidden	2	0x04	System	3	0x08	Volume Label	4	0x10	Subdirectory	5	0x20	Archive	6	0x40	Device (internal use only, never found on disk)	7	0x80	Not Used
BIT	MASK	Description																										
0	0x01	Read Only																										
1	0x02	Hidden																										
2	0x04	System																										
3	0x08	Volume Label																										
4	0x10	Subdirectory																										
5	0x20	Archive																										
6	0x40	Device (internal use only, never found on disk)																										
7	0x80	Not Used																										
Requires	MMC/SD card and MMC library must be initialized for file operations. See Mmc_Fat_Init.																											
Example	<i>' Try to create a swap file with archive attribute, whose size ' will be at least 1000 sectors. ' If it succeeds, it sends No. of start sector over USART</i> <pre>dim size as longint ... size = Mmc_Fat_Get_Swap_File(1000, "mikroE.txt", 0x20) if (size <> 0) then Usart_Write(0xAA) Usart_Write(Lo(size)) Usart_Write(Hi(size)) Usart_Write(Higher(size)) Usart_Write(Highest(size)) Usart_Write(0xAA) end if</pre>																											



Library Example

The following example demonstrates usage of the mmc and mmc_fat routines. Hardware configurations in this example are made for the EasydsPIC3 board and dsPIC30F4013.

```
program MMC_Fat16_Test

const
    SWAP_FILE_MSG as string[ 15] = "Swap file at: "

dim
    fat_txt as string[ 20]
    file_contents as string[ 50]

    filename as byte[ 14] ' File names

    loopP, loop2 as word
    character as byte
    i, size as longint

    Buffer as byte[ 512]

sub procedure Glob_Init
    fat_txt = "FAT16 not found"
    file_contents = "XX MMC/SD FAT16 library by Anton Rieckert" + Chr(10) + Chr(0)
    filename = "MIKRO00xTXT" ' File names
end sub

'I-I-I----- Writes string to USART
sub procedure I_Write_Str(dim byref ostr as byte[ 2] )
dim i as word
    i = 0
    while ostr[ i] <> 0
        Uart1_Write_Char(ostr[ i] )
        Inc(i)
    wend
end sub '~

' continues ...
```

```
' continued ...

'M-M-M----- Creates new file and writes some data to it
sub procedure M_Create_New_File
    filename[ 7] = "A"
    Mmc_Fat_Assign(filename, 0xA0)      ' Will not find file and then create file
    Mmc_Fat_Rewrite                     ' To clear file and start with new data
    for loopP = 1 to 99                 ' We want 5 files on the MMC card
        Uart1_Write_Char(".")
        file_contents[ 0] = (loopP div 10) + 48
        file_contents[ 1] = (loopP mod 10) + 48
        ' Uart1_Write_Text(file_contents)
        Mmc_Fat_Write(file_contents, 42) ' write data to the assigned file
    next loopP
end sub '~

'M-M-M----- Creates many new files and writes data to them
sub procedure M_Create_Multiple_Files
    'for loop2 = "B" to "Z"
    for loop2 = "B" to "Z"
        Uart1_Write_Char(loop2)          ' signal the progress
        filename[ 7] = loop2             ' set filename
        Mmc_Fat_Assign(filename, 0xA0)    ' find existing file or create a new one
        Mmc_Fat_Rewrite                   ' To clear file and start with new data
        for loopP = 1 to 44
            file_contents[ 0] = (loopP div 10) + 48
            file_contents[ 1] = (loopP mod 10) + 48
            Mmc_Fat_Write(file_contents, 42) ' write data to the assigned file
        next loopP
    next loop2
end sub '~

'M-M-M----- Opens an existing file and rewrites it
sub procedure M_Open_File_Rewrite
    filename[ 7] = "C"
    Mmc_Fat_Assign(filename, 0)
    Mmc_Fat_Rewrite
    for loopP = 1 to 55
        file_contents[ 0] = loopP div 10 + 64
        file_contents[ 1] = loopP mod 10 + 64
        Mmc_Fat_Write(file_contents, 42) ' write data to the assigned file
    next loopP
end sub '~

' continues ...
```

' continued ...

'M-M-M----- Opens an existing file and appends data to it
' (and alters the date/time stamp)

```
sub procedure M_Open_File_Append
  filename[ 7] = "B"
  Mmc_Fat_Assign(filename, 0)
  Mmc_Fat_Set_File_Date(2005,6,21,10,35,0)
  Mmc_Fat_Append ' Prepare file for append
  Mmc_Fat_Write(" for mikroElektronika 2005\n", 27)' Write data to assigned file
end sub '~
```

'M-M-M----- Opens an existing file, reads data from it and puts it to USART

```
sub procedure M_Open_File_Read
  filename[ 7] = "B"
  Mmc_Fat_Assign(filename, 0)
  Mmc_Fat_Reset(size) ' To read file, procedure returns size of file
  for i = 1 to size
    ' Mmc_Fat_Read(caracter)
    Mmc_Fat_Read(caracter)
    Uart1_Write_Char(caracter) ' Write data to USART
  next i
end sub '~
```

'M-M-M----- Deletes a file. If file doesn't exist, it will first be created
' and then deleted.

```
sub procedure M_Delete_File
  filename[ 7] = "F"
  Mmc_Fat_Assign(filename, 0)
  Mmc_Fat_Delete
end sub '~
```

' continues ...


```
' continued ...

'M-M-M----- Tests whether file exists, and if so sends its creation date
'               and file size via USART
sub procedure M_Test_File_Exist(dim fLetter as byte)
dim
    fsize as longint
    year as word
    monthH, day, hourR, minuteE as byte
    outstr as byte[ 12]

    filename[ 7] = fLetter
    if (Mmc_Fat_Assign(filename, 0) <> 0) then
        '--- file has been found - get its date
        Mmc_Fat_Get_File_Date(year, monthH, day, hourR, minuteE)
        WordToStr(year, outstr)
        I_Write_Str(outstr)
        WordToStr(monthH, outstr)
        I_Write_Str(outstr)
        WordToStr(day, outstr)
        I_Write_Str(outstr)
        WordToStr(hourR, outstr)
        I_Write_Str(outstr)
        WordToStr(minuteE, outstr)
        I_Write_Str(outstr)
        '--- get file size
        fsize = Mmc_Fat_Get_File_Size
        LongIntToStr(longint(fsize), outstr)
        I_Write_Str(outstr)
    else
        '--- file was not found - signal it
        Uart1_Write_Char(0x55)
        Delay_ms(1000)
        Uart1_Write_Char(0x55)
    end if
end sub '~

' continues ...
```

```
' continued ...

sub procedure M_Create_Swap_File
  dim i as word
  for i=0 to 511
    Buffer[i] = i
  next i

  size = Mmc_Fat_Get_Swap_File(5000, "mikroE.txt", 0x20)
  ' see help on this function for details

  if (size <> 0) then
    LongIntToStr(size, fat_txt)
    Uart1_Write_Text(fat_txt)

    for i=0 to 4999
      Mmc_Write_Sector(size, Buffer)
      Inc(size)
      Uart1_Write_Char(".")
    next i
  end if

main:
  '--- Main. Uncomment the function(s) to test the desired operation(s)
  Glob_Init
  '--- prepare PORTD for signalling
  PORTD = 0
  TRISD = 0
  ADPCFG = 0xFFFF
  '--- set up USART for the file read
  Uart1_Init(19200)
  U1MODE.10 = 1 ' clear the way for the SPI
  '--- init the FAT library
  Spil_Init_Advanced(_SPI_MASTER, _SPI_8_BIT, _SPI_PRESCALE_SEC_1,
_SPI_PRESCALE_PRI_64, _SPI_SS_DISABLE, _SPI_DATA_SAMPLE_MIDDLE,
_SPI_CLK_IDLE_HIGH, _SPI_ACTIVE_2_IDLE)

  '--- (primary prescale = 64:1), secondary prescale = 1:1
  ' use fat16 quick format instead of init routine if a format is needed

  if (Mmc_Fat_Init(PORTF, 0) = 0) then ' EasydsPIC4 board
    Spil_Init_Advanced(_SPI_MASTER, _SPI_8_BIT, _SPI_PRESCALE_SEC_1,
_SPI_PRESCALE_PRI_4, _SPI_SS_DISABLE, _SPI_DATA_SAMPLE_MIDDLE,
_SPI_CLK_IDLE_HIGH, _SPI_ACTIVE_2_IDLE)

    '--- Test start
    PORTD = 0x0005

' continues ...
```

' continued ...

382

page

```
'--- Test routines. Uncomment them one-by-one to test certain features
M_Create_New_File
M_Create_Multiple_Files
Uart1_Write_Char(10)



M_Open_File_Rewrite
M_Open_File_Append
M_Delete_File
M_Create_Swap_File
Uart1_Write_Char(10)

M_Open_File_Read
Uart1_Write_Char(10)
M_Test_File_Exist("F")           ' this file will not exist here
Uart1_Write_Char(10)
M_Test_File_Exist("B")           ' this file will exist here
Uart1_Write_Char(10)
else
    I_Write_Str(fat_txt)
end if
'--- Test termination
PORTD = 0xFFFF
end.
```

Hardware Connection

383

page



OneWire Library

The OneWire library provides routines for communication via the Dallas OneWire protocol, e.g. with DS18x20 digital thermometer. OneWire is a Master/Slave protocol, and all communication cabling required is a single wire. OneWire enabled devices should have open collector drivers (with single pull-up resistor) on the shared data line.

Slave devices on the OneWire bus can even get their power supply from data line. For detailed schematic see device datasheet.

Some basic characteristics of this protocol are:


- single master system,
- low cost,
- low transfer rates (up to 16 kbps),
- fairly long distances (up to 300 meters),
- small data transfer packages.

Each OneWire device has also a unique 64-bit registration number (8-bit device type, 48-bit serial number and 8-bit CRC), so multiple slaves can co-exist on the same bus.

Note: Oscillator frequency F_{osc} needs to be at least 4MHz in order to use the routines with Dallas digital thermometers.

Library Routines

```
Ow_Reset  
Ow_Read  
Ow_Write
```



Ow_Reset

Prototype	<code>sub function Ow_Reset(dim byref port as word, dim pin as word) as word</code>
Returns	- 0 if the device is present - 1 if the device is not present
Description	Issues OneWire reset signal for DS18x20. Parameters : - port: OneWire bus port - pin: OneWire bus pin
Requires	Devices compliant with the Dallas OneWire protocol.
Example	<pre>' Issue Reset signal on One-Wire Bus connected to pin RF6 Ow_Reset(PORTF, 6)</pre>

Ow_Read

Prototype	<code>sub function Ow_Read(dim byref port as word, dim pin as word) as byte</code>
Returns	Data read from an external device over the OneWire bus.
Description	Reads one byte of data via the OneWire bus. Parameters : - port: OneWire bus port - pin: OneWire bus pin
Requires	Devices compliant with the Dallas OneWire protocol.
Example	<pre>' Read a byte from the One-Wire Bus connected to pin RF6 dim read_data as byte ... read_data = Ow_Read(PORTF, 6)</pre>

Ow_Write

Prototype	sub procedure Ow_Write(dim byref port as word , dim pin, par as word)
Description	Writes one byte of data via the OneWire bus. Parameters : - port: OneWire bus port - pin: OneWire bus pin - par: data to be written
Requires	Devices compliant with the Dallas OneWire protocol.
Example	<i>' Send a byte to the One-Wire Bus connected to pin RF6</i> Ow_Write(PORTF, 6, 0xCC)

Library Example

This example demonstrates one-wire communication with temperature sensor DS1820 connected to RF6 pin. After reset, dsPIC obtains temperature from sensor and prints it on LCD.

program OneWire

```
' Set TEMP_RESOLUTION to the corresponding resolution of your DS18x20 sensors
' 18S20as 9 (default setting can be 9,10,11,or 12)
' 18B20as 12
```

```
const TEMP_RESOLUTION as byte = 12
```

```
dim
```

```
  j as byte
  temp as word
  text as string[ 8]           ' "000.0000"
```

```
sub procedure Read_Temperature()
```

```
  Ow_Reset(PORTF,6)           ' Onewire reset signal
  Ow_Write(PORTF,6,0xCC)       ' Issue command SKIP_ROM
  Ow_Write(PORTF,6,0x44)       ' Issue command CONVERT_T
  Delay_us(120)
```

```
  Ow_Reset(PORTF,6)
  Ow_Write(PORTF,6,0xCC)       ' Issue command SKIP_ROM
  Ow_Write(PORTF,6,0xBE)       ' Issue command READ_SCRATCHPAD
  Delay_ms(400)
```

```
  j      = OW_Read(PORTF,6)     ' Get temperature LSB
  temp   = OW_Read(PORTF,6)     ' Get temperature MSB
  temp   = temp << 8
  temp   = temp + j             ' Form the 2byte variable
```

```
end sub
```

```
sub procedure Write_Temp(dim temp2write as word)
```

```
  const
    RES_SHIFT as byte = TEMP_RESOLUTION - 8
```

```
  dim
    temp_whole as byte
    temp_fraction as word
```

```
  if ((temp and 0x8000) > 0) then
    text[ 0] = "-"
    temp2write = (not temp2write) + 1
  end if
```

```
' continues...
```



```
' continued...

temp_whole = temp2write >> RES_SHIFT
if (temp_whole div 100) then
    text[ 0] = temp_whole div 100  + 48
end if

text[ 1] =(temp_whole div 10) mod 10 + 48
text[ 2] = temp_whole mod 10 + 48

temp_fraction = temp2write << (4-RES_SHIFT)
temp_fraction = temp_fraction and 0x000F
temp_fraction = temp_fraction * 625
text[ 4] =  temp_fraction div 1000 + 48
text[ 5] = (temp_fraction div 100) mod 10 + 48
text[ 6] = (temp_fraction div 10)  mod 10 + 48
text[ 7] =  temp_fraction mod 10 + 48

    Lcd_Out(2,1,text)
end sub

' ----Main----
main:

    text    = "000.0000"
    ADPCFG = 0xFFFF


    Lcd_Init_dsPICPro3()
    Lcd_Cmd(LCD_CLEAR)
    Lcd_Cmd(LCD_CURSOR_OFF)
    Lcd_Out(1,1,"temperature")

'--- main loop
while TRUE
    Read_Temperature()
    Write_Temp(temp)
    Delay_ms(1000)
wend
end.
```

Hardware Connection

389

page



Port Expander Library


mikroBasic for dsPIC30/33 and PIC24 provides a library for communication with the Microchip's Port Expander MCP23S17 via SPI interface. Connections of the dsPIC30/33 and PIC24 MCU and MCP23S17 is given on the schematic at the bottom of this page.

Note: Library uses the SPI module for communication. The user must initialize the appropriate SPI module before using the Port Expander Library. For MCUs with two SPI modules it is possible to initialize both of them and then switch by using the `Spi_Set_Active()` function. See the Spi Library functions.

Note: Library does not use Port Expander interrupts.

Library Routines

```
Expander_Init  
Expander_Read_Byte  
Expander_Write_Byte  
Expander_Read_PortA  
Expander_Read_PortB  
Expander_Read_PortAB  
Expander_Write_PortA  
Expander_Write_PortB  
Expander_Write_PortAB  
Expander_Set_DirectionPortA  
Expander_Set_DirectionPortB  
Expander_Set_DirectionPortAB  
Expander_Set_PullUpsPortA  
Expander_Set_PullUpsPortB  
Expander_Set_PullUpsPortAB
```



Expander_Init

Prototype	<code>sub procedure Expander_Init (dim ModuleAddress as byte, dim byref RstPort as word, dim RstPin as word, dim byref CSPort as word, dim CSPin as word)</code>
Description	Initializes Port Expander using SPI communication. Port Expander module settings : - hardware addressing enabled - automatic address pointer incrementing disabled (byte mode) - BANK_0 register addressing - slew rate enabled Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - rstport: Port Expander's reset signal port address - rstpin: Port Expander's reset signal pin - csport: Port Expander's chip select signal port address - cspin: Port Expander's chip select signal pin
Requires	The SPI module needs to be initialized. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre>' initialize the SPI1 module and Port Expander Spi1_Init() Expander_Init(0, PORTF, 0, PORTF, 1)</pre>

Expander_Read_Byte

Prototype	sub function Expander_Read_Byte(dim ModuleAddress, RegAddress as byte) as byte
Returns	Byte read.
Description	The function reads byte from Port Expander. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - RegAddress: Port Expander's internal register address
Requires	Port Expander must be initialized. See Expander_Init.
Example	<pre>' Read a byte from Port Expander's register dim read_data as byte ... read_data = Expander_Read_Byte(0,1)</pre>

Expander_Write_Byte

Prototype	sub procedure Expander_Write_Byte(dim ModuleAddress, RegAddress, Data as byte)
Returns	Nothing.
Description	Routine writes a byte to Port Expander. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - RegAddress: Port Expander's internal register address - Data: data to be written
Requires	Port Expander must be initialized. See Expander_Init.
Example	<pre>' Write a byte to the Port Expander's register Expander_Write_Byte(0,1,\$FF)</pre>




Expander_Read_PortA

Prototype	<code>sub function Expander_Read_PortA(dim ModuleAddress as byte) as byte</code>
Returns	Byte read.
Description	The function reads byte from Port Expander's PortA. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page
Requires	Port Expander must be initialized. See Expander_Init. Port Expander's PortA should be configured as input. See the Expander_Set_DirectionPortA and Expander_Set_DirectionPortAB routines.
Example	<pre>' Read a byte from Port Expander's PORTA dim read_data as byte ... Expander_Set_DirectionPortA(0,\$FF) ' set expander's porta to be input ... read_data = Expander_Read_PortA(0)</pre>

Expander_Read_PortB

Prototype	sub function Expander_Read_PortB(dim ModuleAddress as byte) as byte
Returns	Byte read.
Description	The function reads byte from Port Expander's PortB. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page
Requires	Port Expander must be initialized. See Expander_Init. Port Expander's PortB should be configured as input. See the Expander_Set_DirectionPortB and Expander_Set_DirectionPortAB routines.
Example	<pre>' Read a byte from Port Expander's PORTB dim read_data as byte ... Expander_Set_DirectionPortB(0,\$FF) ' set expander's portb to be input ... read_data = Expander_Read_PortB(0)</pre>




Expander_Read_PortAB

Prototype	<code>sub function Expander_Read_PortAB(dim ModuleAddress as byte) as word</code>
Returns	Word read.
Description	The function reads word from Port Expander's ports. PortA readings are in the higher byte of the result. PortB readings are in the lower byte of the result. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page
Requires	Port Expander must be initialized. See Expander_Init. Port Expander's PortA and PortB should be configured as inputs. See the Expander_Set_DirectionPortA, Expander_Set_DirectionPortB and Expander_Set_DirectionPortAB routines.
Example	<pre>' Read a byte from Port Expander's PORTA and PORTB dim read_data as word ... Expander_Set_DirectionPortAB(0,\$FFFF) ' set expander's porta and portb to be input ... read_data s= Expander_Read_PortAB(0)</pre>

Expander_Write_PortA

Prototype	sub procedure Expander_Write_PortA(dim ModuleAddress, Data as byte)
Returns	Nothing.
Description	The function writes byte to Port Expander's PortA. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - Data: data to be written
Requires	Port Expander must be initialized. See Expander_Init. Port Expander's PortA should be configured as output. See the Expander_Set_DirectionPortA and Expander_Set_DirectionPortAB routines.
Example	<pre>' Write a byte to Port Expander's PORTA ... Expander_Set_DirectionPortA(0,\$00) ' set expander's porta to be output ... Expander_Write_PortA(0, \$AA)</pre>




Expander_Write_PortB

Prototype	<code>sub procedure Expander_Write_PortB(dim ModuleAddress, Data as byte)</code>
Returns	Nothing.
Description	The function writes byte to Port Expander's PortB. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - Data: data to be written
Requires	Port Expander must be initialized. See Expander_Init. Port Expander's PortB should be configured as output. See the Expander_Set_DirectionPortB and Expander_Set_DirectionPortAB routines.
Example	<pre>' Write a byte to Port Expander's PORTB ... Expander_Set_DirectionPortB(0,\$00) ' set expander's portb to be output ... Expander_Write_PortB(0,\$55)</pre>

Expander_Write_PortAB

Prototype	sub procedure Expander_Write_PortAB(dim ModuleAddress as byte , dim Data as word)
Returns	Nothing.
Description	The function writes word to Port Expander's ports. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - Data: data to be written. Data to be written to PortA are passed in Data's higher byte. Data to be written to PortB are passed in Data's lower byte
Requires	Port Expander must be initialized. See Expander_Init. Port Expander's PortA and PortB should be configured as outputs. See the Expander_Set_DirectionPortA, Expander_Set_DirectionPortB and Expander_Set_DirectionPortAB routines.
Example	<pre>' Write a byte to Port Expander's PORTA and PORTB ... Expander_Set_DirectionPortAB(0, \$0000) ' set expander's porta and portb to be output ... Expander_Write_PortAB(0, \$AA55)</pre>



Expander_Set_DirectionPortA

399

page

Prototype	sub procedure Expander_Set_DirectionPortA(dim ModuleAddress, Data as byte)
Description	The function sets Port Expander's PortA direction. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - Data: data to be written to the PortA direction register. Each bit corresponds to the appropriate pin of the PortA register. Set bit configures corresponding pin as input. Cleared bit configures corresponding pin as output.
Requires	Port Expander must be initialized. See Expander_Init.
Example	<i>' Set Port Expander's PORTA to be output</i> Expander_Set_DirectionPortA(0,\$00)

Expander_Set_DirectionPortB


Prototype	sub procedure Expander_Set_DirectionPortB(dim ModuleAddress, Data as byte)
Description	The function sets Port Expander's PortB direction. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - Data: data to be written to the PortB direction register. Each bit corresponds to the appropriate pin of the PortB register. Set bit configures corresponding pin as input. Cleared bit configures corresponding pin as output.
Requires	Port Expander must be initialized. See Expander_Init.
Example	<i>' Set Port Expander's PORTB to be input</i> Expander_Set_DirectionPortB(0,\$FF)

Expander_Set_DirectionPortAB

Prototype	sub procedure Expander_Set_DirectionPortAB(dim ModuleAddress, Direction as word)
Description	The function sets Port Expander's PortA and PortB direction. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - Direction: data to be written to direction registers. Data to be written to the PortA direction register are passed in Direction's higher byte. Data to be written to the PortB direction register are passed in Direction's lower byte. Each bit corresponds to the appropriate pin of the PortA/PortB register. Set bit configures corresponding pin as input. Cleared bit configures corresponding pin as output.
Requires	Port Expander must be initialized. See Expander_Init.
Example	<i>' Set Port Expander's PORTA to be output and PORTB to be input</i> Expander_Set_DirectionPortAB(0,\$00FF)

Expander_Set_PullUpsPortA

Prototype	sub procedure Expander_Set_PullUpsPortA(dim ModuleAddress, Data as byte)
Description	The function sets Port Expander's PortA pull up/down resistors. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - Data: data for choosing pull up/down resistors configuration. Each bit corresponds to the appropriate pin of the PortA register. Set bit enables pull-up for corresponding pin.
Requires	Port Expander must be initialized. See Expander_Init.
Example	<i>' Set Port Expander's PORTA pull-up resistors</i> Expander_Set_PullUpsPortA(0, \$FF)



Expander_Set_PullUpsPortB

Prototype	<code>sub procedure Expander_Set_PullUpsPortB(dim ModuleAddress, Data as byte)</code>
Description	The function sets Port Expander's PortB pull up/down resistors. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - Data: data for choosing pull up/down resistors configuration. Each bit corresponds to the appropriate pin of the PortB register. Set bit enables pull-up for corresponding pin.
Requires	Port Expander must be initialized. See Expander_Init.
Example	<pre>' Set Port Expander's PORTB pull-up resistors Expander_Set_PullUpsPortB(0, \$FF)</pre>

Expander_Set_PullUpsPortAB

Prototype	<code>sub procedure Expander_Set_PullUpsPortAB(dim ModuleAddress as byte, dim PullUps as word)</code>
Description	The function sets Port Expander's PortA and PortB pull up/down resistors. Parameters : - ModuleAddress: Port Expander hardware address, see schematic at the bottom of this page - PullUps: data for choosing pull up/down resistors configuration. PortA pull up/down resistors configuration is passed in PullUps's higher byte. PortB pull up/down resistors configuration is passed in PullUps's lower byte. Each bit corresponds to the appropriate pin of the PortA/PortB register. Set bit enables pull-up for corresponding pin.
Requires	Port Expander must be initialized. See Expander_Init.
Example	<pre>' Set Port Expander's PORTA and PORTB pull-up resistors Expander_Set_PullUpsPortAB(0, \$FFFF)</pre>

Library Example

The example demonstrates how to communicate with Port Expander MCP23S17. Note that Port Expander pins A2 A1 A0 are connected to GND so Port Expander Hardware Address is 0.

```
program PortExpander

dim i as byte

main:
    ADPCFG = 0xFFFF           ' all pins digital
    TRISB  = 0x00             ' PORTB output
    PORTB  = 0xFF

    ' for faster spi communication use Spi_Init_Advanced routine
    SPI_init                    ' initialize SPI
    Delay_ms(200)
    Expander_Init(0, PORTF, 0, PORTB, 8)      ' initialize port expander
    ' on EASYdsPIC4 board RST pin is connected to Vcc
    ' any port/pin can be passed as rstport and rstpin parameters
    ' this pin is used only in Expander_Init function.
    ' This pin can be reassigned later in the code.

    Expander_Set_DirectionPortA(0, 0)        ' set expander's porta to be output


    Expander_Set_DirectionPortB(0, 0xFF)     ' set expander's porta to be input
    Expander_Set_PullUpsPortB(0, 0xFF)
    ' set pull ups to all of the expander's portb pins

    i = 0
    while true
        Expander_Write_PortA(0, i) ' write i to expander's porta
        i = i + 1
        PORTB = Expander_Read_PortB(0)
        ' read expander's portb and write it to dsPIC's LATB
        Delay_ms(20)
    wend
end.
```

Hardware Connection

403

page



PS/2 Library

mikroBasic for dsPIC30/33 and PIC24 provides a library for communication with the common PS/2 keyboard.

Note: The library does not utilize interrupts for data retrieval, and requires the oscillator clock to be at least 6MHz.

Note: The pins to which a PS/2 keyboard is attached should be connected to the pull-up resistors.


Note: Although PS/2 is a two-way communication bus, this library does not provide MCU-to-keyboard communication; e.g. pressing the Caps Lock key will not turn on the Caps Lock LED.

Library Routines

Ps2_Init
Ps2_Config
Ps2_Key_Read

Ps2_Init

Prototype	sub procedure Ps2_Init(dim byref port as word)
Description	Initializes MCU for work with the PS/2 keyboard with default pin settings (pin 13 is connected to Data line and pin 14 is connected to Clock line). Parameters : - port: MCU's port initialized for communication with keyboard
Requires	Both Data and Clock lines need to be in the pull-up mode.
Example	<pre>' Initialize PORTC (with default pin settings) ' for work with the PS/2 keyboard Ps2_Init(PORTC)</pre>



Ps2_Config

Prototype	<code>sub procedure Ps2_Config(dim byref port as word, dim clkpin as word, dim datapin as word)</code>
Description	Initializes the MCU for work with the PS/2 keyboard with custom pin settings. Parameters : - port: MCU's port initialized for communication with keyboard - clkpin: clock signal pin - datapin: data signal pin
Requires	Both Data and Clock lines need to be in the pull-up mode.
Example	<pre>' Initialize PORTB for work with the PS/2 keyboard. ' Pin RB2 is connected to Clock signal. ' Pin RB3 is connected to Data signal. Ps2_Config(PORTB, 2, 3)</pre>

Ps2_Key_Read

Prototype	sub function Ps2_Key_Read(dim byref value as word , dim byref special as word , dim byref pressed as word) as word
Returns	- 1 if reading of a key from the keyboard was successful - 0 if no key was pressed
Description	The function retrieves information on key pressed. Parameters : - value: holds the value of the key pressed. For characters, numerals, punctuation marks, and space value will store the appropriate ASCII code. Routine “recognizes” the function of Shift and Caps Lock, and behaves appropriately. For special function keys see the Special Function Keys Table. - special: is a flag for special function keys (F1, Enter, Esc, etc). If key pressed is one of them, special will be set to 1, otherwise it will be set to 0. - pressed: is set to 1 if the key is pressed, and 0 if it is released.
Requires	PS/2 keyboard needs to be initialized. See the Ps2_Init and Ps2_Config routines.
Example	<pre> dim value, special, pressed as word ... ' Press Enter to continue: do { if (Ps2_Key_Read(value, special, pressed)) then if ((value = 13) and (special = 1)) then break end if end if loop until (0=1) </pre>

Special Function Keys

Key	Value returned
F1	1
F2	2
F3	3
F4	4
F5	5
F6	6
F7	7
F8	8
F9	9
F10	10
F11	11
F12	12
ENTER	13
PAGE UP	14
PAGE DOWN	15
BACKSPACE	16
INSERT	17

Key	Value returned
DELETE	18
WINDOWS	19
CTRL	20
SHIFT	21
ALT	22
PRINT SCREEN	23
PAUSE	24
CAPS LOCK	25
END	26
HOME	27
SCROLL LOCK	28
NUM LOCK	29
LEFT ARROW	30
RIGHT ARROW	31
UP ARROW	32
DOWN ARROW	33
ESCAPE	34
TAB	35

Library Example

The following example reads values of keys pressed on PS/2 keyboard and sends them via UART1.

```

program ps2_test

dim
  keydata, special, down as word

main:
  ADPCFG=$FFFF
  keydata = 0
  special = 0
  down    = 0

  Ps2_Config(PORTC, 14, 13)
  Uart1_Init(9600)

  Uart1_Write_Text("You can type now!") ' Ready
  while TRUE
    if Ps2_Key_Read(keydata, special, down) <> 0 then
      if ((down<>0) and (keydata = 16)) <> 0 then
        Uart1_Write_Char(0x08)
      else
        if ((down<>0) and (keydata = 13)) <> 0 then
          ' Enter
          Uart1_Write_Char(13)
          Uart1_Write_Char(10)
        else
          if ((down<>0) and (special=0) and (keydata<>0)) <> 0 then
            Uart1_Write_Char(keydata)
          end if
        end if
      end if
    end if
    Delay_ms(1) ' debounce
  wend
end.

```



PWM Library

The CCP module is available with a number of dsPIC30/33 and PIC24 MCUs. mikroBasic for dsPIC30/33 and PIC24 provides a library which simplifies using of the PWM HW Module.

Note: PWM module uses either Timer2 or Timer3 module.

Library Routines

Pwm_Init
Pwm_Set_Duty
Pwm_Start
Pwm_Stop

Pwm_Init


Prototype	sub function Pwm_Init(dim freq_hz as longint , dim enable_channel_x, timer_prescale, use_timer_x as word) as word
Returns	- 0xFFFF - if timer settings are not valid - Calculated timer period, otherwise
Description	Initializes the PWM module with duty ratio 0. Parameters : - freq_hz: PWM frequency in Hz (refer to device datasheet for correct values in respect with Fosc) - enable_channel_x: number of PWM channel to be initialized. Refer to MCU's datasheet for available PWM channels - timer_prescale: timer prescaler parameter. Valid values: 1, 8, 64, and 256 - use_timer_x: timer to be used with the PWM module. Valid values: 2 (Timer2) and 3 (Timer3) Note: number of available PWM channels depends on MCU. Refer to MCU datasheet for details.
Example	<pre>' Initializes the PWM module at 5KHz, channel 1, ' no clock prescale, timer2 : dim pwm_period1 as word ... pwm_period1 = Pwm_Init(5000, 1, 0, 2)</pre>

Pwm_Set_Duty

Prototype	sub procedure Pwm_Set_Duty(dim duty, channel as word)
Description	The function changes PWM duty ratio. Parameters : - duty: PWM duty ratio. Valid values: 0 to timer period returned by the Pwm_Init function. - channel: number of PWM channel to change duty to. Note: number of available PWM channels depends on MCU. Refer to MCU datasheet for details.
Requires	MCU must have the HW PWM Module. PWM channel must be properly initialized. See the Pwm_Init routine.
Example	<pre>' Set channel 1 duty ratio to 50%: dim pwm_period1 as word ... Pwm_Set_Duty(pwm_period1 div 2, 1)</pre>

Pwm_Start

Prototype	sub procedure Pwm_Start(dim enable_channel_x as byte)
Description	Starts PWM at requested channel . Parameters : - enable_channel_x: number of PWM channel Note: number of available PWM channels depends on MCU. Refer to MCU datasheet for details.
Requires	MCU must have the HW PWM Module. PWM channel must be properly configured. See the Pwm_Init and Pwm_Set_Duty routines.
Example	<pre>' start PWM at channel 1 Pwm_Start(1)</pre>



Pwm_Stop

Prototype	<code>sub procedure Pwm_Stop(dim disable_channel_x as byte)</code>
Description	Stops PWM at requested channel. Parameters : - <code>disable_channel_x</code>: number of PWM channel Note: number of available PWM channels depends on MCU. Refer to MCU datasheet for details.
Requires	MCU must have the HW PWM Module.
Example	<pre>' stop PWM at channel 1 Pwm_Stop(1)</pre>

Library Example

The example changes PWM duty ratio on channels 1 and 2 continuously. If LEDs are connected to channels 1 and 2, a gradual change of emitted light will be noticeable.

```
program PWM_Test

dim pwm_period1, pwm_period2, i1, i2 as word

main:

    i1 = 0
    i2 = 0

    pwm_period1 = Pwm_Init(5000, 1, 1, 2)
    pwm_period2 = Pwm_Init(10000, 2, 1, 3)


    Pwm_Start(1)
    Pwm_Start(2)

    while (true)
        Pwm_Set_Duty(i1, 1)
        Pwm_Set_Duty(i2, 2)
        if (i1 = pwm_period1) then
            i1 = 0
        end if
        if (i2 = pwm_period2) then
            i2 = 0
        end if
        Inc(i1)
        Inc(i2)
        Delay_ms(1)
    wend
end.
```

Hardware Connection

413

page




PWM Motor Library

The PWM Motor Control module is available with a number of dsPIC30/33 MCUs. mikroBasic for dsPIC30/33 and PIC24 provides a library which simplifies using the PWM Motor Control module.

Library Routines

```
Pwm_Mc_Init  
Pwm_Mc_Set_Duty  
Pwm_Mc_Start  
Pwm_Mc_Stop
```



Pwm_Mc_Init

Prototype	sub function Pwm_Mc_Init(dim freq_hz, pair_output_mode, enable_output_x, clock_prescale_output_postscale as word) as word
Returns	Calculated timer period.
Description	Initializes the Motor Control PWM module with duty ratio 0. The function calculates timer period, writes it to the MCU's PTPER register and returns it as the function result. Parameters : - freq_hz: PWM frequency in Hz (refer to device datasheet for correct values in respect with Fosc) - pair_output_mode: output mode for output pin pairs: 1 = independent, 0 = complementary. if bit_0 is equal to 1 then PWM channels PWM1L and PWM1H will be independent, if bit_1 is equal to 0 then PWM channels PWM2L and PWM2H will be complementary ... - enable_output_x: bits <7..0> are enabling corresponding PWM channels [PWM4H.PWM3H.PWM2H.PWM1H.PWM4L.PWM3L.PWM2L.PWM1L]. If bit value is equal to 0 then corresponding PWM channel is disabled (pin is standard I/O). If bit value is equal to 1 then corresponding PWM channel is enabled (pin is PWM output). For detailed explanation consult the "Motor Control PWM Module" section in device datasheet - clock_prescale_output_postscale: PWM clock prescaler/postscaler settings. Values <0..3> <0..15> correspond to prescaler/postscaler < 1:1, 1:4, 1:16, 1:64> <1:1, 1:2, ..., 1:16> Note: number of available PWM channels depends on MCU. Refer to MCU datasheet for details.
Requires	The dsPIC30/33 MCU must have the Motor Control PWM module.
Example	<pre>' Initializes the PWM module at 5KHz, complementary pin-pair ' output, output enabled on pins 41..11, no clock prescale and no ' clock postscale: dim duty_50 as word ... duty_50 = Pwm_Mc_Init(5000, 1, \$0F, 0)</pre>

Pwm_Mc_Set_Duty

Prototype	sub procedure Pwm_Mc_Set_Duty(dim duty, channel as word)
Description	The function changes PWM duty ratio. Parameters : - duty: PWM duty ratio. Valid values: 0 to timer period returned by the Pwm_Mc_Init function. - channel: number of PWM channel to change duty to. Note: number of available PWM channels depends on MCU. Refer to MCU datasheet for details.
Requires	The dsPIC30/33 MCU must have the Motor Control PWM module. The PWM module needs to be initialized. See the Pwm_Mc_Init function.
Example	<pre>' Set duty ratio to 50% at channel 1: Pwm_Mc_Init(5000,1,\$F,0) ... Pwm_Mc_Set_Duty(32767, 1)</pre>



Pwm_Mc_Start

Prototype	<code>sub procedure Pwm_Mc_Start()</code>
Description	Starts the Motor Control PWM module (channels initialized in the Pwm_Mc_Init function). Note: number of available PWM channels depends on MCU. Refer to MCU datasheet for details.
Requires	The dsPIC30/33 MCU must have the Motor Control PWM module. The PWM module needs to be initialized. See the Pwm_Mc_Init function.
Example	<pre>' start the Motor Control PWM module Pwm_Mc_Start()</pre>

Pwm_Mc_Stop

Prototype	<code>sub procedure Pwm_Mc_Stop()</code>
Description	Stops the Motor Control PWM module.
Requires	The dsPIC30/33 MCU must have the Motor Control PWM module.
Example	<pre>' stop the Motor Control PWM module Pwm_Mc_Stop()</pre>

Library Example

This is a simple example on usage of the PWM library for dsPIC MCUs. Upon reset, PWM module is set up to 50% duty ratio. Then, this ratio is being decreased to zero, and then restored up to approx. 100%, in an infinite loop. The ratio decrease can be observed by turning the PWM output LED on or in digital form on PORTB.

```
program MC_PWM_Test


dim i, duty_50 as word

main:
    ADPCFG = 0xFFFF
    TRISE  = 0
    PORTB  = 0xAAAA
    TRISB   = 0
    Delay_ms(1000)

    duty_50 = Pwm_Mc_Init(5000,1,0x01,0) ' Pwm_Mc_Init returns 50% of the duty
    i = duty_50
    Pwm_Mc_Set_Duty(i, 1)
    Pwm_Mc_Start()

    while true
        i = i - 1
        Pwm_Mc_Set_Duty(i,1)
        Delay_ms(1)
        if (i = 0) then                                ' Do not allow the overflow
            i = duty_50 * 2 - 1
        end if
        PORTB = i
    wend
end.
```

Hardware Connection



RS-485 Library

RS-485 is a multipoint communication which allows multiple devices to be connected to a single bus. mikroBasic for dsPIC30/33 and PIC24 provides a set of library routines for comfortable work with RS485 system using Master/Slave architecture. Master and Slave devices interchange packets of information. Each of these packets contains synchronization bytes, CRC byte, address byte and the data. Each Slave has unique address and receives only packets addressed to it. The Slave can never initiate communication.

It is the user's responsibility to ensure that only one device transmits via 485 bus at a time.


The RS-485 routines require the UART module. Pins of UART need to be attached to RS-485 interface transceiver, such as LTC485 or similar (see schematic at the bottom of this page).

Library constants: START byte value = 150. STOP byte value = 169. Address 50 is the broadcast address for all Slaves (packets containing address 50 will be received by all Slaves except the Slaves with addresses 150 and 169).

Note: The library uses the UART module for communication. The user must initialize the appropriate UART module before using the RS-485 Library. For MCUs with two UART modules it is possible to initialize both of them and then switch by using the `Uart_Set_Active` function. See the Uart Library functions.

Library Routines

```
RS485Master_Init  
RS485Master_Receive  
RS485Master_Send  
RS485Slave_Init  
RS485Slave_Receive  
RS485Slave_Send
```



RS485Master_Init

421

page

Prototype	sub procedure Rs485master_Init(dim byref port as word , dim pin as word)
Description	Initializes MCU as a Master for RS-485 communication. Parameters : - port: RE/DE port address - pin: RE/DE pin. This pin is connected to RE/DE input of RS-485 transceiver(see schematic at the bottom of this page). RE/DE signal controls RS-485 transceiver operation mode. Valid values: 1 (for transmitting) and 0 (for receiving)
Requires	UART HW module needs to be initialized. See the Uart1_Init, Uart2_Init and Uart_Init routines.
Example	<pre>' initialize UART module Uart1_Init(9600) ' initialize mcu as a Master for RS-485 communication Rs485master_Init(PORTF, 4)</pre>

RS485Master_Receive


Prototype	sub procedure Rs485master_Receive(dim byref data as byte [10])
Description	Receives messages from Slaves. Messages are multi-byte, so this routine must be called for each byte received. Parameters : - data: 7 byte buffer for storing received data. Data will be stored in the following manner: - data[0..2] : message content - data[3] : number of message bytes received, 1–3 - data[4] : is set to 255 when message is received - data[5] : is set to 255 if error has occurred - data[6] : address of the Slave which sent the message The function automatically adjusts data[4] and data[5] upon every received message. These flags need to be cleared by software.
Requires	MCU must be initialized as a Master for RS-485 communication. See RS485Master_Init.
Example	<pre>dim msg as byte[8] ... RS485Master_Receive(msg)</pre>

RS485Master_Send

Prototype	sub procedure Rs485master_Send(dim byref data as byte [1] , dim datalen as byte , dim address as byte)
Description	Sends message to Slave(s). Message format can be found at the bottom of this page. Parameters : - data: data to be sent - datalen: number of bytes for transmission. Valid values: 0 to 3. - address: Slave(s) address
Requires	MCU must be initialized as a Master for RS-485 communication. See RS485Master_Init. It is the user's responsibility to ensure (by protocol) that only one device sends data via 485 bus at a time.
Example	<pre>dim msg as byte[8] ... ' send 3 bytes of data to slave with address 0x12 Rs485Master_Send(msg, 3, 0x12)</pre>

RS485Slave_Init

Prototype	sub procedure Rs485slave_Init(dim byref port as word , dim pin as word , dim address as byte)
Description	Initializes MCU as a Slave for RS-485 communication. Parameters : - port: RE/DE port address - pin: RE/DE pin. This pin is connected to RE/DE input of RS-485 transceiver (see schematic at the bottom of this page). RE/DE signal controls RS-485 transceiver operation mode. Valid values: 1 (for transmitting) and 0 (for receiving) - address: Slave address
Requires	UART HW module needs to be initialized. See Uart_Init.
Example	Initialize MCU as a Slave with address 160: <pre>' intialize mcu as a Slave for RS-485 communication ' with address 160 Rs485slave_Init(PORTF, 4, 160)</pre>



RS485Slave_Receive

Prototype	<code>sub procedure Rs485Slave_Receive(dim byref data as byte[10])</code>
Description	Receives messages from Master. If Slave address and Message address field don't match then the message will be discarded. Messages are multi-byte, so this routine must be called for each byte received. Parameters : - data: 6 byte buffer for storing received data. Data will be stored in the following manner: data[0..2] : message content data[3] : number of message bytes received, 1–3 data[4] : is set to 255 when message is received data[5] : is set to 255 if error has occurred The function automatically adjusts data[4] and data[5] upon every received message. These flags need to be cleared by software.
Requires	MCU must be initialized as a Slave for RS-485 communication. See RS485Slave_Init.
Example	<pre>dim msg as byte[8] ... RS485Slave_Read(msg)</pre>

RS485Slave_Send

Prototype	<code>sub procedure Rs485slave_Send(dim byref data as byte[1] , dim datalen as byte)</code>
Description	Sends message to Master. Message format can be found at the bottom of this page. Parameters : - data: data to be sent - datalen: number of bytes for transmission. Valid values: 0 to 3.
Requires	MCU must be initialized as a Slave for RS-485 communication. See RS485Slave_Init. It is the user's responsibility to ensure (by protocol) that only one device sends data via 485 bus at a time.
Example	<pre>dim msg as byte[8] ... ' send 2 bytes of data to the master RS485Slave_Send(msg, 2)</pre>

Message format and CRC calculations

Q: How is CRC checksum calculated on RS485 master side?

```
const START_BYTE as byte = 0x96 ' 10010110
const STOP_BYTE  as byte = 0xA9 ' 10101001
```

PACKAGE:

START_BYTE 0x96

ADDRESS

DATALEN

[DATA1] ' if exists

[DATA2] ' if exists

[DATA3] ' if exists

CRC

STOP_BYTE 0xA9

DATALEN bits:

bit7 = 1 MASTER SENDS

0 SLAVE SENDS

bit6 = 1 ADDRESS WAS XORed with 1, IT WAS EQUAL TO START_BYTE or STOP_BYTE

0 ADDRESS UNCHANGED

bit5 = 0 FIXED

bit4 = 1 DATA3 (if exists) WAS XORed with 1, IT WAS EQUAL TO START_BYTE or STOP_BYTE

0 DATA3 (if exists) UNCHANGED

bit3 = 1 DATA2 (if exists) WAS XORed with 1, IT WAS EQUAL TO START_BYTE or STOP_BYTE

0 DATA2 (if exists) UNCHANGED

bit2 = 1 DATA1 (if exists) WAS XORed with 1, IT WAS EQUAL TO START_BYTE or STOP_BYTE

0 DATA1 (if exists) UNCHANGED

bit1bit0 = 0 to 3 NUMBER OF DATA BYTES SEND

CRC generation :

crc_send = datalen **xor** address

crc_send = crc_send **xor** data[0] ' if exists

crc_send = crc_send **xor** data[1] ' if exists

crc_send = crc_send **xor** data[2] ' if exists


crc_send = crc_send **not** crc_send

if ((crc_send = START_BYTE) **or** (crc_send = STOP_BYTE)) **then**

 crc_send = crc_send + 1

end if

NOTE: DATALEN<4..0> can not take the START_BYTE<4..0> or STOP_BYTE<4..0> values.



Library Example

The example demonstrates working with the dsPIC as a Master node in RS-485 communication. Master sends message to Slave with address 160 and waits for a response. After the response is received, the first byte of received data is incremented and sent back to the Slave. The received data is displayed on PORTB while error on receiving (0xAA) and number of consecutive unsuccessful retries are displayed on PORTD. Hardware configurations in this example are made for the EasydsPIC3 board and dsPIC30F4013.

```

program rs485Transmitter

dim dat as byte[ 10]           ' buffer for receving/sending messages
    i,j as integer
    cnt as longint
'----- Interrupt routine
sub procedure interrupt_uart() org 0x26
    Rs485master_Receive(dat)
    ' IFS0bits.U1RXIF = 0;
    IFS0.9 = 0                    ' ensure interrupt not pending
end sub

main:
    cnt      = 0
    ADPCFG   = 0xFFFF
    PORTD    = 0
    TRISD    = 0
    PORTB    = 0
    TRISB    = 0
    Uart1_Init(9600)
    Rs485master_Init(PORTF, 4)    ' intialize mcu as master
    dat[ 0]  = 0xAa
    dat[ 1]  = 0xF0
    dat[ 2]  = 0x0F
    dat[ 5]  = 0
    dat[ 6]  = 0
    Rs485master_Send(dat, 1, 160)
    dat[ 4]  = 0                  ' ensure that message received flag is 0
    dat[ 5]  = 0                  ' ensure that error flag is 0
    ' U1STAbits.URXISEL = 0;
    U1STA.6 = 0
    ' INTCON1bits.NSTDIS = 1;
    INTCON1.15 = 1                ' no nesting of interrupts
    ' IFS0bits.U1RXIF = 0;
    IFS0.9 = 0                    ' ensure interrupt not pending
    ' IEC0bits.U1RXIE = 1;
    IEC0.9 = 1                    ' enable intterrupt

    ' continues...

```

' continued...

426

page

```

while true

    cnt = cnt + 1
    if dat[ 5] <> 0 then
        PORTD = 0xAA
    end if
    if dat[ 4] <> 0 then

        cnt      = 0
        dat[ 4]  = 0
        j = dat[ 3]
        for i = 1 to j
            PORTB = dat[ i-1]
        next i
        dat[ 0] = dat[ 0] + 1
        Delay_ms(10)
        Rs485master_Send(dat, 1, 160)
    end if
    if (cnt > 100000) then

        PORTD = PORTD + 1

        cnt = 0
        Rs485master_Send(dat, 1, 160)
        if(PORTD > 10) then
            PORTD = 0
            Rs485master_Send(dat, 1, 50)
        end if
    end if
wend
end.

```

' upon completed valid message receiving
' data[4] is set to 255

' if error detected, signal it by
' setting PORTD to 0xAA

' if message received successfully
' clear message received flag


' show data on PORTB
' increment received dat[0]
' and send it to slave

' if in 100000 poll-cycles the answer
was not detected, signal
failure of send-message
if sending failed 10 times
send message on broadcast address

Hardware Connection

427

page



Software I2C Library

mikroBasic for dsPIC30/33 and PIC24 provides routines for implementing Software I²C communication. These routines are hardware independent and can be used with any MCU. The Software I²C library enables you to use MCU as Master in I²C communication. Multi-master mode is not supported.

Note: This library implements time-based activities, so interrupts need to be disabled when using Software I²C.

Note: All I²C Library functions are blocking-call functions (they are waiting for I²C clock line to become logical one).


Library Routines

```
Soft_I2C_Init
Soft_I2C_Start
Soft_I2C_Read
Soft_I2C_Write
Soft_I2C_Stop
```

Note: Every hardware I²C library function has its own counterpart in this software library, except I2C_Repeated_Start. Soft_I2C_Start is used instead of I2C_Repeated_Start.

Soft_I2C_Init

Prototype	sub procedure Soft_I2C_Init(dim byref portOut as word , dim sda, clk as word)
Description	Configures the software I ² C module. Parameters : - portOut: software I ² C port address - sda: serial data line pin - clk: serial clock line pin
Example	<pre>' Initialize Software I2C communication on pins RB1(sda) ' and RB2(clk) Soft_I2C_Init(PORTB, 1, 2)</pre>



Soft_I2C_Start

Prototype	<code>sub procedure Soft_I2C_Start()</code>
Description	Determines if the I ² C bus is free and issues START signal.
Requires	Software I ² C must be configured before using this function. See the Soft_I2C_Init routine.
Example	<pre>' Issue START signal Soft_I2C_Start()</pre>

Soft_I2C_Read


Prototype	<code>sub function Soft_I2C_Read(dim ack as word) as byte</code>
Returns	One byte from the Slave.
Description	Reads one byte from the slave. Parameters : - ack: acknowledge signal parameter. If the ack==0 not acknowledge signal will be sent after reading, otherwise the acknowledge signal will be sent.
Requires	Soft I ² C must be configured before using this function. See the Soft_I2C_Init routine. Also, START signal needs to be issued in order to use this function. See the Soft_I2C_Start routine.
Example	<pre>dim take as byte ... ' Read data and send the not_acknowledge signal take = Soft_I2C_Read(0)</pre>

Soft_I2C_Write

Prototype	sub function Soft_I2C_Write(dim Data as byte) as byte
Returns	- 0 if there were no errors. - 1 if write collision was detected on the I ² C bus.
Description	Sends data byte via the I ² C bus. Parameters : - Data: data to be sent
Requires	Soft I ² C must be configured before using this function. See the Soft_I2C_Init routine. Also, START signal needs to be issued in order to use this function. See the Soft_I2C_Start routine.
Example	dim data, error as byte ... error = Soft_I2C_Write(data) error = Soft_I2C_Write(\$A3)

Soft_I2C_Stop

Prototype	sub procedure Soft_I2C_Stop()
Description	Issues STOP signal.
Requires	Soft I ² C must be configured before using this function. See the Soft_I2C_Init routine.
Example	<i>' Issue STOP signal</i> Soft_I2C_Stop()



Library Example

The example demonstrates use of the Software I²C Library. The dsPIC30/33 or PIC24 MCU is connected (SCL, SDA pins) to PCF8583 RTC (real-time clock).

```
program Soft_RTC_WriteRead
```

```
dim sec, minN, hr, day, mn, year as word
    txt as string[ 15]
    tmp as char[ 5]
```

```
sub procedure Set_Time(dim byref sec, minN, hr, day, mn, year as byte)
    ' from real TIME to VARIABLE
```

```
    sec = ((sec div 10) << 4) or (sec mod 10)
    minN = ((minN div 10) << 4) or (minN mod 10)
    hr = ((hr div 10) << 4) or (hr mod 10)
    day = ((day div 10) << 4) or (day mod 10)
    mn = ((mn div 10) << 4) or (mn mod 10)
```

```
    year = year-2005
    year = year << 6
    day = day or year
```

```
end sub
```

```
    ' Reads time and date information from RTC (PCF8583)
```

```
sub procedure Read_Time(dim byref sec, minN, hr, day, mn, year as word)
```

```
    year = 0
    Soft_I2C_Start()
    Soft_I2C_Write($A0)
    Soft_I2C_Write(2)
    Soft_I2C_Start()
    Soft_I2C_Write($A1)
    sec = Soft_I2C_Read(1)
    minN = Soft_I2C_Read(1)
    hr = Soft_I2C_Read(1)
    day = Soft_I2C_Read(1)
    mn = Soft_I2C_Read(0)
    Soft_I2C_Stop()
```

```
end sub
```

```
    ' continues ...
```

```
' continued ...

sub procedure Write_Time_And_Date(dim sec, minN, hr, day, mn as byte)
    Soft_I2C_Start()           ' Issue start signal
    Soft_I2C_Write($A0)        ' Address PCF8583
    Soft_I2C_Write(0)          ' Start from word at address 0 (configuration word)
    Soft_I2C_Write($80)        ' Write $80 to config. (pause counter...)
    Soft_I2C_Write(0)          ' Write 0 to hundreds of seconds word
    Soft_I2C_Write(sec)        ' Write seconds
    Soft_I2C_Write(minN)       ' Write minutes
    Soft_I2C_Write(hr)         ' Write hours
    Soft_I2C_Write(day)        ' Write year/date
    Soft_I2C_Write(mn)         ' Write weekday/month
    Soft_I2C_Stop()            ' issue stop signal

    Soft_I2C_Start()           ' Issue start signal
    Soft_I2C_Write($A0)        ' Address PCF8530
    Soft_I2C_Write(0)          ' Start from word at address 0
    Soft_I2C_Write(0)          ' Write 0 to config. word (enable counting)
    Soft_I2C_Stop()            ' Issue sop signal
end sub

main:

' Here you can set the date and time to write to RTC

sec = 0      ' seconds
minN = 40    ' minutes
hr = 10      ' hours
day = 26     ' day
mn = 8       ' month
year = 2006  ' year

ADPCFG = $FFFF

Glcd_Init_EasydsPIC4()
Glcd_Fill(0)

Soft_I2C_Init(PORTB, 12, 11)
Glcd_Set_Font(@FontSystem5x8,5,8,32)
Glcd_Write_Text("Time :",10,0,1)
Glcd_Write_Text("      :      ",10,1,1)
Glcd_Write_Text("Date :",10,3,1)
Glcd_Write_Text("  Software I2C",10,7,1)

Set_Time(sec, minN, hr, day, mn, year)

Write_Time_And_Date(sec, minN, hr, day, mn)

' continues ...
```

' continued ...

```

while true
  Read_Time(sec, minN, hr, day, mn, year)
  sec = ((sec and $F0) >> 4)*10 + (sec and $0F)
  minN = ((minN and $F0) >> 4)*10 + (minN and $0F)
  hr = ((hr and $F0) >> 4)*10 + (hr and $0F)
  year = ((day and $C0) >> 6
  day = ((day and $30) >> 4)*10 + (day and $0F)
  mn = ((mn and $10) >> 4)*10 + (mn and $0F)

  year = year + 2005

  select case mn
    case 1  txt = "Jan"
    case 2  txt = "Feb"
    case 3  txt = "Mar"
    case 4  txt = "Apr"
    case 5  txt = "May"
    case 6  txt = "Jun"
    case 7  txt = "Jul"
    case 8  txt = "Aug"
    case 9  txt = "Sep"
    case 10 txt = "Oct"
    case 11 txt = "Nov"
    case 12 txt = "Dec"
    case else
      txt = "unknown"
  end select

  Glcd_Write_Text(txt, 45, 4, 1)

  WordToStr(sec, tmp)
  Glcd_Write_Text(tmp, 80, 1, 1)

  WordToStr(minN, tmp)
  Glcd_Write_Text(tmp, 45, 1, 1)

  WordToStr(hr, tmp)
  Glcd_Write_Text(tmp, 10, 1, 1)

  WordToStr(day, tmp)
  Glcd_Write_Text(tmp, 10, 4, 1)

  WordToStr(year, tmp)
  Glcd_Write_Text(tmp, 70, 4, 1)

  Delay_ms(200)
wend
end.

```

Software SPI Library

mikroBasic for dsPIC30/33 and PIC24 provides routines for implementing Software SPI communication. These routines are hardware independent and can be used with any MCU. The Software SPI Library provides easy communication with other devices via SPI: A/D converters, D/A converters, MAX7219, LTC1290, etc.

The library configures SPI to the master mode, clock = 20kHz, data sampled at the middle of interval, clock idle state low and data transmitted at low to high edge.


Note: The Software SPI library implements time-based activities, so interrupts need to be disabled when using it.

Library Routines

```
Soft_Spi_Config
Soft_Spi_Init
Soft_Spi_Read
Soft_Spi_Write
```

Soft_Spi_Config

Prototype	sub procedure Soft_Spi_Config(dim byref port as word , dim SDI, SDO, SCK as word)
Description	Configures and initializes the software SPI module. Parameters : - portOut: software SPI port address - SDI: serial data input line pin - SDO: serial data output line pin - SCK: serial clock line pin
Example	<pre>' Initialize Software SPI communication on pins RB4(SDI), ' RB5(SDO) and RB3(SCK) Soft_Spi_Config(PORTB, 4, 5, 3)</pre>



Soft_Spi_Init

Prototype	sub procedure Soft_Spi_Init(dim byref port as word)
Description	Configures and initializes the software SPI module. Parameters : - port: software SPI port address SPI pinout is fixed to : SDI=pin4, SDO=pin5 and SCK=pin3.
Example	<i>' Initialize Software SPI communication on PORTB with default ' pinout(pin4(SDI), pin5(SDO) and pin3(SCK)) Soft_Spi_Init(PORTB)</i>

Soft_Spi_Read

Prototype	sub function Soft_Spi_Read(dim data as byte) as byte
Returns	Byte received via the SPI bus.
Description	This routine performs 3 operations simultaneously. It provides clock for the Software SPI bus, reads a byte and sends a byte. Parameters : - data: data to be sent.
Requires	Soft SPI must be initialized before using this function. See the Soft_Spi_Config and Soft_Spi_Init routines.
Example	dim data_read, data_send as byte ... <i>' Read a byte and assign it to data_read variable ' (data_send byte will be sent via SPI during the Read operation) data_read = Soft_Spi_Read(data_send)</i>

Soft_Spi_Write

Prototype	sub procedure Soft_Spi_Write(dim data as byte)
Description	This routine sends one byte via the Software SPI bus. Parameters : - data: data to be sent.
Requires	Soft SPI must be initialized before using this function. See the Soft_Spi_Config and Soft_Spi_Init routines.
Example	<i>' Write a byte to the Soft SPI bus</i> Soft_Spi_Write(\$AA)

Library Example

This code demonstrates using library routines for SPI communication. The project shows how to drive the DAC MCP 4921 (Microchip) via the software SPI library.

```

program Soft_spi_test
const CS_PIN = 0                                ' DAC CS pin
dim value as word
sub procedure InitMain()
    ADPCFG = 0xFFFF
    TRISF.CS_PIN = 0                             ' CS pin
    LATF.CS_PIN = 1                               ' Set CS to inactive
    Soft_Spi_Config(PORTF, 4, 5, 3)
end sub
' DAC increments (0..4095) --> output voltage (0..Vref)
sub procedure DAC_Output(dim valueDAC as word)
    LATF.CS_PIN = 0                               ' CS enable for DAC
    Soft_SPI_Write(0x30 or ((valueDAC >> 8) and 0x0F))
    ' Prepare hi-byte for transfer
    ' It's a 12-bit number, so only
    ' lower nibble of high byte is used
    Soft_SPI_Write(valueDAC) ' Prepare lo-byte for transfer
    LATF.CS_PIN = 1                               ' CS disable for DAC
end sub

main:
    InitMain()
    while true
        value = 1
        while value < $FFF
            DAC_Output(value)
            Delay_ms(5)
            value = value+1
        wend
    wend ' the output in the mid-range
end.

```

Software UART Library

mikroBasic for dsPIC30/33 and PIC24 provides routines for implementing Software UART communication. These routines are hardware independent and can be used with any MCU. The Software UART Library provides easy communication with other devices via the RS232 protocol.

Note: The Software UART library implements time-based activities, so interrupts need to be disabled when using it.

Library Routines

Soft_Uart_Init
Soft_Uart_Read
Soft_Uart_Write

Soft_Uart_Init

Prototype	sub procedure Soft_Uart_Init(dim byref port as word , dim rx, tx as word , dim baud_rate as longint , dim inverted as word)
Description	Configures and initializes the software UART module. Parameters : - port: software UART port address - rx: receiver pin - tx: transmitter pin - baud_rate: requested baudrate. Maximum baud rate depends on the MCU's clock and working conditions - inverted: if set to non-zero value, indicates inverted logic on output.
Example	<pre>' Initialize Software UART communication on pins RB1(Rx), ' RB2(Tx), at 9600 bps Soft_Uart_Init(PORTB, 1, 2, 9600, 0)</pre>

Soft_Uart_Read

Prototype	sub function Soft_Uart_Read(dim byref error as word) as byte
Returns	Byte received via UART.
Description	The function receives a byte via software UART. This is a blocking function call (waits for the start bit). Parameters : - error: error parameter will be zero if the transfer was successful.
Requires	Software UART must be initialized before using this function. See the Soft_Uart_Init routine.
Example	<pre> dim data as byte error as word ... ' wait until data is received do data = Soft_Uart_Read(error) loop until (error = 0) </pre>

Soft_Uart_Write

Prototype	sub procedure Soft_Uart_Write(dim data as byte)
Description	This routine sends one byte via the Software UART bus. Parameters : - data: data to be sent.
Requires	Software UART must be initialized before using this function. See the Soft_Uart_Init routine. Be aware that during transmission, software UART is incapable of receiving data – data transfer protocol must be set in such a way to prevent loss of information.
Example	<pre> dim some_byte as byte ... some_byte = \$0A ' Write a byte via Soft Uart Soft_Uart_Write(some_byte) </pre>

Library Example

The example demonstrates a simple data exchange via software UART. When the MCU receives data, it immediately sends it back. If dsPIC is connected to the PC, you can test the example from the mikroBasic terminal for RS-232 communication, menu item **Tools > USART Terminal**.

```
program Soft_Uart_Example

dim rx, _err as word

main:
    ADPCFG = $FFFF
    Soft_Uart_Init(PORTF, 2, 3, 9600, 0)
    while true
        rx = Soft_Uart_Read(_err)
        Soft_Uart_Write(rx)
    wend
end.
```

Sound Library

mikroBasic for dsPIC30/33 and PIC24 provides a Sound Library to supply users with routines necessary for sound signalization in their applications. Sound generation needs additional hardware, such as piezo-speaker (example of piezo-speaker interface is given on the schematic at the bottom of this page).

Library Routines

Sound_Init
Sound_Play

Sound_Init

Prototype	sub procedure Sound_Init(dim byref snd_port, snd_pin as word)
Description	Configures the appropriate MCU pin for sound generation. Parameters : - snd_port: sound output port address - snd_pin: sound output pin
Example	<i>' Initialize the pin RB2 for playing sound</i> Sound_Init(PORTB, 2)

Sound_Play

Prototype	sub procedure Sound_Play(dim freq_in_hz, duration_ms as word)
Description	Generates the square wave signal on the appropriate pin. Parameters : - freq_in_hz: signal frequency in Hertz (Hz) - duration_ms: signal duration in milliseconds (ms)
Example	<i>' Play sound of 1KHz in duration of 100ms</i> Sound_Play(1000, 100)

Library Example

The example is a simple demonstration of how to use sound library for playing tones on a piezo speaker. The code can be used with any MCU that has PORTB. Sound frequencies in this example are generated by reading the buttons on PORTB.

441

page


```

program sound
main:
    ' initialize sound lib
    Sound_Init(PORTB, 3);

    ' three beeps
    Sound_Play(1000, 500)
    delay_ms(50)
    Sound_Play(1000, 500)
    delay_ms(50)
    Sound_Play(1000, 500)
    delay_ms(50)
    Sound_Play(1200, 500) ' frequency is 1200 Hz and duration is 500ms
end.

```

Hardware Connection



SPI Library

The SPI module is available with all dsPIC30/33 and PIC24 MCUs. mikroBasic for dsPIC30/33 and PIC24 provides a library for initializing the Slave mode and initializing and comfortable work with the Master mode. The dsPIC30/33 and PIC24 can easily communicate with other devices via SPI: A/D converters, D/A converters, MAX7219, LTC1290, etc.


Note: For the dsPIC30/33 and PIC24 MCUs with the multiple SPI modules there are SPI1 (supports SPI1 module), SPI2 (supports SPI2 module) and SPI (supports both SPI modules) libraries. Switching between the SPI modules in the SPI library is done by the Spi_Set_Active function (both SPI modules have to be previously initialized).

Library Routines

Spi1_Init
Spi1_Init_Advanced
Spi1_Data_Ready
Spi1_Read
Spi1_Write
Spi1_Stop
SPI1_TxBuffer_Empty

Spi_Init
Spi_Init_Advanced
Spi_Data_Ready
Spi_Read
Spi_Write
Spi_Stop
SPI_TxBuffer_Empty

Spi2_Init
Spi2_Init_Advanced
Spi2_Data_Ready
Spi2_Read
Spi2_Write
Spi2_Stop
SPI2_TxBuffer_Empty




Spi1_Init

Prototype	<code>sub procedure Spi1_Init()</code>
Description	Configures and initializes the SPI1 module with default settings. Default settings: - Master mode - 8-bit data mode - secondary prescaler 1:1 - primary prescaler 64:1 - Slave Select disabled - input data sampled in the middle of interval - clock idle state low - Serial output data changes on transition from active clock state to idle clock state
Requires	MCU must have the SPI1 module.
Example	<pre>' Initialize the SPI1 module with default settings Spi1_Init()</pre>

Spi1_Init_Advanced

Prototype	<pre> sub procedure Spi1_Init_Advanced(dim master_mode, mode16, sec_prescaler, pri_prescaler, slave_select, data_sample, clock_idle, edge as word) </pre>
Description	Configures and initializes the SPI1 module. The <code>master_mode</code> parameter determines the working mode for SPI1. It can have the following values: <pre> '--- Master/Slave mode, SPI1CON1<5> const _SPI_MASTER = \$0020, ' Master mode const _SPI_SLAVE = \$0000, ' Slave mode </pre> The parameter <code>mode16</code> determines the data length mode, which can be 8-bits (per transitions cycle) or 16-bits. It is being configured as follows: <pre> '--- data length select, SPI1CON1<10> const _SPI_16_BIT = \$0400, ' 16-bit mode const _SPI_8_BIT = \$0000, ' 8-bit mode </pre> The parameter <code>sec_prescaler</code> determines the value of the secondary SPI clock prescaler. This parameter is used only in the Master Mode. Valid settings are: <pre> '--- secondary prescale (Master mode), SPI1CON1<4:2> const _SPI_PRESCALE_SEC_1 = \$001C, ' secondary prescale 1:1 const _SPI_PRESCALE_SEC_2 = \$0018, ' secondary prescale 2:1 const _SPI_PRESCALE_SEC_3 = \$0014, ' secondary prescale 3:1 const _SPI_PRESCALE_SEC_4 = \$0010, ' secondary prescale 4:1 const _SPI_PRESCALE_SEC_5 = \$000C, ' secondary prescale 5:1 const _SPI_PRESCALE_SEC_6 = \$0008, ' secondary prescale 6:1 const _SPI_PRESCALE_SEC_7 = \$0004, ' secondary prescale 7:1 const _SPI_PRESCALE_SEC_8 = \$0000, ' secondary prescale 8:1 ' you can also use the following set of constants which are kept ' for the sake of backward compatibility const _SPI_PRESCALE_1 = \$001C ' value for prescale 1:1 const _SPI_PRESCALE_2 = \$0018 ' value for prescale 2:1 const _SPI_PRESCALE_3 = \$0014 ' value for prescale 3:1 const _SPI_PRESCALE_4 = \$0010 ' value for prescale 4:1 const _SPI_PRESCALE_5 = \$000C ' value for prescale 5:1 const _SPI_PRESCALE_6 = \$0008 ' value for prescale 6:1 const _SPI_PRESCALE_7 = \$0004 ' value for prescale 7:1 const _SPI_PRESCALE_8 = \$0000 ' value for prescale 8:1 ' continues ... </pre>



Description
(continued)

' continued ...

The parameter `pri_prescaler` determines the value of the **primary** SPI clock prescaler. This parameter is used only in the Master Mode. Valid settings are:

```
'--- primary prescale (Master mode), SPI1CON1<1:0>  
const _SPI_PRESCALE_PRI_1      = $0003,  ' primary prescale 1:1  
const _SPI_PRESCALE_PRI_4      = $0002,  ' primary prescale 4:1  
const _SPI_PRESCALE_PRI_16     = $0001,  ' primary prescale 16:1  
const _SPI_PRESCALE_PRI_64     = $0000,  ' primary prescale 64:1
```

*' you can also use the following set of constants which are kept
' for the sake of backward compatibility*

```
const _SPI_FCY_DIV1      = $0003  ' value for Fcy_div 1:1  
const _SPI_FCY_DIV4      = $0002  ' value for Fcy_div 4:1  
const _SPI_FCY_DIV16     = $0001  ' value for Fcy_div 16:1  
const _SPI_FCY_DIV64     = $0000  ' value for Fcy_div 64:1
```

The parameter `slave_select` determines whether the Slave Select (SS) pin is used in communication. This parameter is valid in the Slave Mode only. It can be:

```
'--- Slave select enable bit (Slave Mode), SPI1CON1<7>  
const _SPI_SS_ENABLE  = $0080,  ' SS used for the Slave mode  
const _SPI_SS_DISABLE = $0000,  ' SS not used for the Slave mode
```

The parameter `data_sample` determines the sample moment (phase) of input data. It can be:

```
'--- SPI data input sample phase, SPI1CON1<9>  
const _SPI_DATA_SAMPLE_MIDDLE = $0000,  
' data sampled in the middle of data output time  
const _SPI_DATA_SAMPLE_END    = $2000,  
' data sampled at end of data output time
```


The parameter `clock_idle` determines the behaviour of the SPI clock (CLK) line in IDLE phase:

```
'--- Clock Polarity Select bit, SPI1CON1<6>  
const _SPI_CLK_IDLE_LOW      = $0000,  ' IDLE state is Lo,  
' ACTIVE state is Hi  
const _SPI_CLK_IDLE_HIGH     = $0040,  ' IDLE state is Hi,  
' ACTIVE state is Lo  
  
' continues...
```

Description (continued)	<i>' continued..</i> The parameter <code>edge</code> determines on which clock edge the data is considered to be valid. Possible settings are: <pre> ' Clock EDGE select bit (where output data is valid), SPI1CON1<8> const _SPI_ACTIVE_2_IDLE = \$0000, ' data is valid on ' ACTIVE-to-IDLE transition ' (data changes on IDLE-to-ACTIVE transition) const _SPI_IDLE_2_ACTIVE = \$0100; ' data is valid on IDLE-to-ACTIVE transition ' (data changes on ACTIVE-to-IDLE transition) </pre>
Requires	MCU must have the SPI1 module.
Example	<pre> ' Set SPI1 to the Master Mode, data length is 16-bit, clock = Fcy ' (no clock scaling), data sampled in the middle of interval, ' clock IDLE state high and data transmitted at low to high clock ' edge: Spi1_Init_Advanced(_SPI_MASTER, _SPI_16_BIT, _SPI_PRESCALE_SEC_1, _SPI_PRESCALE_PRI_1, SPI_SS_DISABLE, _SPI_DATA_SAMPLE_MIDDLE, _SPI_CLK_IDLE_HIGH, _SPI_ACTIVE_2_IDLE) </pre>

Spi1_Read

Prototype	sub function Spi1_Read(dim data_out as word) as word
Returns	Received data.
Description	Reads one word or byte (depending on mode set by init routines) from the SPI bus. Parameters : - data_out: dummy data for clock generation (see device Datasheet for SPI module implementation details)
Requires	MCU must have the SPI1 module. SPI1 must be initialized before using this function. See the Spi1_Init_Advanced and Spi1_Init routines.
Example	<pre> ' read a byte from the SPI bus dim take, buffer as byte ... take = Spi1_Read(buffer) </pre>



Spi1_Write

447

page

Prototype	sub procedure Spi1_Write(dim data_out as word)
Description	Writes one word or byte (depending on mode set by init routines) via the SPI bus. Parameters : - data_out: data to be sent
Requires	MCU must have the SPI1 module. SPI1 must be initialized before using this function. See the Spi1_Init_Advanced and Spi1_Init routines.
Example	<i>' write a byte to the SPI bus</i> dim buffer as byte ... Spi1_Write(buffer)

Spi2_Init

Prototype	sub procedure Spi2_Init()
Description	Configures and initializes the SPI2 module with default settings. Default settings: - Master mode - 8-bit data mode - Serial output data changes on transition from active clock state to Idle clock state secondary prescaler 1:1 - primary prescaler 64:1 - Slave Select disabled - input data sampled in the middle of interval - clock idle state low - Serial output data changes on transition from active clock state to idle clock state
Requires	MCU must have the SPI2 module.
Example	<i>' Initialize the SPI2 module with default settings</i> Spi2_Init()

Spi2_Init_Advanced

448

page

Prototype	<pre>sub procedure Spi2_Init_Advanced(dim master_mode, mode16, sec_prescaler, pri_prescaler, slave_select, data_sample, clock_idle, edge as word)</pre>
Description	Configures and initializes the SPI2 module. The <code>master_mode</code> parameter determines the working mode for SPI2. It can have the following values: <pre>'--- Master/Slave mode, SPI2CON1<5> const _SPI_MASTER = \$0020, ' Master mode const _SPI_SLAVE = \$0000, ' Slave mode</pre> The parameter <code>mode16</code> determines the data length mode, which can be 8-bits (per transitions cycle) or 16-bits. It is being configured as follows: <pre>'--- data length select, SPI2CON1<10> const _SPI_16_BIT = \$0400, ' 16-bit mode const _SPI_8_BIT = \$0000, ' 8-bit mode</pre> The parameter <code>sec_prescaler</code> determines the value of the secondary SPI clock prescaler. This parameter is used only in the Master Mode. Valid settings are: <pre>'--- secondary prescale (Master mode), SPI2CON1<4:2> const _SPI_PRESCALE_SEC_1 = \$001C, ' secondary prescale 1:1 const _SPI_PRESCALE_SEC_2 = \$0018, ' secondary prescale 2:1 const _SPI_PRESCALE_SEC_3 = \$0014, ' secondary prescale 3:1 const _SPI_PRESCALE_SEC_4 = \$0010, ' secondary prescale 4:1 const _SPI_PRESCALE_SEC_5 = \$000C, ' secondary prescale 5:1 const _SPI_PRESCALE_SEC_6 = \$0008, ' secondary prescale 6:1 const _SPI_PRESCALE_SEC_7 = \$0004, ' secondary prescale 7:1 const _SPI_PRESCALE_SEC_8 = \$0000, ' secondary prescale 8:1 ' you can also use the following set of constants which are kept ' for the sake of backward compatibility const _SPI_PRESCALE_1 = \$001C ' value for prescale 1:1 const _SPI_PRESCALE_2 = \$0018 ' value for prescale 2:1 const _SPI_PRESCALE_3 = \$0014 ' value for prescale 3:1 const _SPI_PRESCALE_4 = \$0010 ' value for prescale 4:1 const _SPI_PRESCALE_5 = \$000C ' value for prescale 5:1 const _SPI_PRESCALE_6 = \$0008 ' value for prescale 6:1 const _SPI_PRESCALE_7 = \$0004 ' value for prescale 7:1 const _SPI_PRESCALE_8 = \$0000 ' value for prescale 8:1 ' continues ...</pre>

Description
(continued)

' continued ...

The parameter `pri_prescaler` determines the value of the **primary** SPI clock prescaler. This parameter is used only in the Master Mode. Valid settings are:

```
'--- primary prescale (Master mode), SPI2CON1<1:0>  
const _SPI_PRESCALE_PRI_1      = $0003, ' primary prescale 1:1  
const _SPI_PRESCALE_PRI_4      = $0002, ' primary prescale 4:1  
const _SPI_PRESCALE_PRI_16     = $0001, ' primary prescale 16:1  
const _SPI_PRESCALE_PRI_64     = $0000, ' primary prescale 64:1
```

*' you can also use the following set of constants which are kept
' for the sake of backward compatibility*

```
const _SPI_FCY_DIV1      = $0003; ' value for Fcy_div 1:1  
const _SPI_FCY_DIV4      = $0002; ' value for Fcy_div 4:1  
const _SPI_FCY_DIV16     = $0001; ' value for Fcy_div 16:1  
const _SPI_FCY_DIV64     = $0000; ' value for Fcy_div 64:1
```

The parameter `slave_select` determines whether the Slave Select (SS) pin is used in communication. This parameter is valid in the Slave Mode only. It can be:

```
'--- Slave select enable bit (Slave Mode), SPI2CON1<7>  
const _SPI_SS_ENABLE      = $0080, ' SS used for the Slave mode  
const _SPI_SS_DISABLE    = $0000, ' SS not used for the Slave mode
```

The parameter `data_sample` determines the sample moment (phase) of input data. It can be:

```
'--- SPI data input sample phase, SPI2CON1<9>  
const _SPI_DATA_SAMPLE_MIDDLE = $0000,  
' data sampled in the middle of data output time
```

```
const _SPI_DATA_SAMPLE_END    = $2000,  
' data sampled at end of data output time
```

The parameter `clock_idle` determines the behaviour of the SPI clock (CLK) line in IDLE phase:

```
'--- Clock Polarity Select bit, SPI2CON1<6>  
const _SPI_CLK_IDLE_LOW      = $0000,  
' IDLE state is Lo, ACTIVE state is Hi
```


```
const _SPI_CLK_IDLE_HIGH     = $0040,  
' IDLE state is Hi, ACTIVE state is Lo
```

' continues...

Description (continued)	<i>' continued..</i> The parameter <code>edge</code> determines on which clock edge data is considered to be valid. Possible settings are: <pre> <i>' Clock EDGE select bit (where output data is valid), SPI2CON1<8></i> const _SPI_ACTIVE_2_IDLE = \$0000, <i>' data is valid on ACTIVE-to-IDLE transition</i> <i>' (data changes on IDLE-to-ACTIVE transition)</i> const _SPI_IDLE_2_ACTIVE = \$0100; <i>' data is valid on IDLE-to-ACTIVE transition</i> <i>' (data changes on ACTIVE-to-IDLE transition)</i> </pre>
Requires	MCU must have the SPI2 module.
Example	<pre> Spi2_Init_Advanced(_SPI_MASTER, _SPI_8_BIT, _SPI_PRESCALE_SEC_1, _SPI_PRESCALE_PRI_64, _SPI_SS_DISABLE, _SPI_DATA_SAMPLE_MIDDLE, _SPI_CLK_IDLE_HIGH, _SPI_ACTIVE_2_IDLE) </pre>

Spi2_Read

Prototype	sub function Spi2_Read(dim data_out as word) as word
Returns	Returns the received data.
Description	Reads one word or byte (depending on mode set by init routines) from the SPI bus. Parameters : - <code>data_out</code>: dummy data for clock generation (see device Datasheet for SPI module implementation details).
Requires	MCU must have the SPI2 module. SPI2 must be initialized before using this function. See the Spi2_Init_Advanced and Spi2_Init routines.
Example	<pre> <i>' read a byte from the SPI bus</i> dim take, buffer as byte ... take = Spi2_Read(buffer) </pre>



Spi2_Write

Prototype	sub procedure Spi2_Write(dim data_out as word)
Description	Writes one word or byte (depending on mode set by init routines) via the SPI bus. Parameters : - data_out: data to be sent
Requires	MCU must have the SPI2 module. SPI2 must be initialized before using this function. See the Spi2_Init_Advanced and Spi2_Init routines.
Example	<i>' write a byte to the SPI bus</i> dim buffer as byte ... Spi2_Write(buffer)

Spi_Init

Prototype	sub procedure Spi_Init()
Description	Configures and initializes the SPI1 module with default settings. Default settings: - Master mode - 8-bit data mode - secondary prescaler 1:1 - primary prescaler 64:1 - Slave Select disabled - input data sampled in the middle of interval - clock idle state low - Serial output data changes on transition from active clock state to idle clock state
Requires	MCU must have the SPI1 module.
Example	<i>' Initialize the SPI1 module with default settings</i> Spi_Init()

Spi_Init_Advanced

452

page

Prototype	<pre>sub procedure Spi_Init_Advanced(dim master_mode, mode16, sec_prescaler, pri_prescaler, slave_select, data_sample, clock_idle, edge as word)</pre>
Description	Configures and initializes the SPI1 module. The <code>master_mode</code> parameter determines the working mode for SPI1. It can have the following values: <pre>'--- Master/Slave mode, SPI1CON1<5> const _SPI_MASTER = \$0020, ' Master mode const _SPI_SLAVE = \$0000, ' Slave mode</pre> The parameter <code>mode16</code> determines the data length mode, which can be 8-bits (per transactions cycle) or 16-bits. It is being configured as follows: <pre>'--- data length select, SPI1CON1<10> const _SPI_16_BIT = \$0400, ' 16-bit mode const _SPI_8_BIT = \$0000, ' 8-bit mode</pre> The parameter <code>sec_prescaler</code> determines the value of the secondary SPI clock prescaler. This parameter is used only in the Master Mode. Valid settings are: <pre>'--- secondary prescale (Master mode), SPI1CON1<4:2> const _SPI_PRESCALE_SEC_1 = \$001C, ' secondary prescale 1:1 const _SPI_PRESCALE_SEC_2 = \$0018, ' secondary prescale 2:1 const _SPI_PRESCALE_SEC_3 = \$0014, ' secondary prescale 3:1 const _SPI_PRESCALE_SEC_4 = \$0010, ' secondary prescale 4:1 const _SPI_PRESCALE_SEC_5 = \$000C, ' secondary prescale 5:1 const _SPI_PRESCALE_SEC_6 = \$0008, ' secondary prescale 6:1 const _SPI_PRESCALE_SEC_7 = \$0004, ' secondary prescale 7:1 const _SPI_PRESCALE_SEC_8 = \$0000, ' secondary prescale 8:1</pre> ' you can also use the following set of constants which are kept ' for the sake of backward compatibility <pre>const _SPI_PRESCALE_1 = \$001C ' value for prescale 1:1 const _SPI_PRESCALE_2 = \$0018 ' value for prescale 2:1 const _SPI_PRESCALE_3 = \$0014 ' value for prescale 3:1 const _SPI_PRESCALE_4 = \$0010 ' value for prescale 4:1 const _SPI_PRESCALE_5 = \$000C ' value for prescale 5:1 const _SPI_PRESCALE_6 = \$0008 ' value for prescale 6:1 const _SPI_PRESCALE_7 = \$0004 ' value for prescale 7:1 const _SPI_PRESCALE_8 = \$0000 ' value for prescale 8:1</pre> ' continues ...

Description
(continued)

' continued ...

The parameter `pri_prescaler` determines the value of the **primary** SPI clock prescaler. This parameter is used only in the Master Mode. Valid settings are:

```
'--- primary prescale (Master mode), SPI1CON1<1:0>
const _SPI_PRESCALE_PRI_1      = $0003, ' primary prescale 1:1
const _SPI_PRESCALE_PRI_4      = $0002, ' primary prescale 4:1
const _SPI_PRESCALE_PRI_16     = $0001, ' primary prescale 16:1
const _SPI_PRESCALE_PRI_64     = $0000, ' primary prescale 64:1
```

*' you can also use the following set of constants which are kept
' for the sake of backward compatibility*

```
const _SPI_FCY_DIV1           = $0003; ' value for Fcy_div 1:1
const _SPI_FCY_DIV4           = $0002; ' value for Fcy_div 4:1
const _SPI_FCY_DIV16          = $0001; ' value for Fcy_div 16:1
const _SPI_FCY_DIV64          = $0000; ' value for Fcy_div 64:1
```

The parameter `slave_select` determines whether the Slave Select (SS) pin is used in communication. This parameter is valid in the Slave Mode only. It can be:

```
'--- Slave select enable bit (Slave Mode), SPI1CON1<7>
const _SPI_SS_ENABLE          = $0080, ' SS used for the Slave mode
const _SPI_SS_DISABLE         = $0000, ' SS not used for the Slave mode
```

The parameter `data_sample` determines the sample moment (phase) of input data. It can be:

```
'--- SPI data input sample phase, SPI1CON1<9>
const _SPI_DATA_SAMPLE_MIDDLE = $0000,
' data sampled in the middle of data output time

const _SPI_DATA_SAMPLE_END     = $2000,
' data sampled at end of data output time
```

The parameter `clock_idle` determines the behaviour of the SPI clock (CLK) line in IDLE phase:

```
'--- Clock Polarity Select bit, SPI1CON1<6>
const _SPI_CLK_IDLE_LOW       = $0000,
' IDLE state is Lo, ACTIVE state is Hi


const _SPI_CLK_IDLE_HIGH      = $0040,
' IDLE state is Hi, ACTIVE state is Lo

' continues...
```

Description (continued)	<i>' continued..</i> The parameter <code>edge</code> determines on which clock edge data is considered to be valid. Possible settings are: <pre> ' Clock EDGE select bit (where output data is valid), SPI1CON1<8> const _SPI_ACTIVE_2_IDLE = \$0000, ' data is valid on ACTIVE-to-IDLE transition ' (data changes on IDLE-to-ACTIVE transition) const _SPI_IDLE_2_ACTIVE = \$0100; ' data is valid on IDLE-to-ACTIVE transition ' (data changes on ACTIVE-to-IDLE transition) </pre>
Requires	MCU must have the SPI1 module.
Example	<pre> ' Set SPI1 to the Master Mode, data length is 16-bit, clock = Fcy ' (no clock scaling), data sampled in the middle of interval, ' clock IDLE state high and data transmitted at low to high clock ' edge: Spi_Init_Advanced(_SPI_MASTER, _SPI_16_BIT, _SPI_PRESCALE_SEC_1, _SPI_PRESCALE_PRI_1, SPI_SS_DISABLE, _SPI_DATA_SAMPLE_MIDDLE, _SPI_CLK_IDLE_HIGH, _SPI_ACTIVE_2_IDLE) </pre>

Spi_Read

Prototype	sub function Spi_Read(dim data_out as word) as word
Returns	Received data.
Description	Reads one word or byte (depending on mode set by init routines) from the SPI bus. Parameters : - data_out: dummy data for clock generation (see device Datasheet for SPI modules implementation details) Note: if MCU has 2 SPI modules, active module will be used. See the Spi_Set_Active routine.
Requires	Routine requires at least one SPI module. Used SPI module must be initialized before using this function. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre> ' read a byte from the SPI bus dim take, buffer as byte ... take = Spi_Read(buffer) </pre>



Spi_Write

Prototype	sub procedure Spi_Write(dim data_out as word)
Description	Writes one word or byte (depending on mode set by init routines) via the SPI bus. Parameters : - data_out: data to be sent Note: if MCU has 2 SPI modules, active module will be used. See the Spi_Set_Active routine.
Requires	Routine requires at least one SPI module. Used SPI module must be initialized before using this function. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre>' write a byte to the SPI bus dim buffer as byte ... Spi_Write(buffer)</pre>

Spi_Set_Active

Prototype	sub procedure Spi_Set_Active(dim SpiNo as byte)
Description	Sets the active SPI module which will be used by the Spi_Read and Spi_Write routines. Parameters : - SpiNo: module number. Valid values: 1 (for SPI1) and 2 (for SPI2)
Requires	Routine is available only for MCUs with two SPI modules. Used SPI module must be initialized before using this function. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre>Spi_Set_Active(2) ' Sets the SPI2 module active</pre>

Library Example

The code demonstrates how to use SPI library functions for communication between the SPI2 module of the MCU and MCP4921 DAC chip

```
program SPITest
const   LOAD_PIN      = 2   ' DAC load pin
const   CS_PIN        = 1   ' DAC CS pin


dim value as word

sub procedure InitMain()
    TRISC.LOAD_PIN = 0           ' LOAD pin
    TRISC.CS_PIN   = 0           ' CS pin
    LATC.CS_PIN    = 1           ' Set CS to inactive
    LATC.LOAD_PIN  = 0           ' Set LOAD to inactive
    Spi2_Init_Advanced(_SPI_MASTER, _SPI_16_BIT, _SPI_PRESCALE_SEC_1,
        _SPI_PRESCALE_PRI_1, _SPI_SS_DISABLE, _SPI_DATA_SAMPLE_MIDDLE,
        _SPI_CLK_IDLE_HIGH, _SPI_ACTIVE_2_IDLE) ' Init SPI
end sub

' DAC increments (0..4095) --> output voltage (0..Vref)
sub procedure DAC_Output(dim valueDAC as word)
    while (SPI2STAT.1 = 1) ' wait for SPI module to finish, if doing something
        nop
    wend
    LATC.CS_PIN = 0           ' CS enable for DAC
    SPI2BUF = 0x3000 or valueDAC
    ' Write CurrentValue to DAC (0x3 is required by DAC)
    while (SPI2STAT.1 = 1) ' Wait for SPI module to finish write
        nop
    wend

    LATC.CS_PIN = 1           ' CS disable for DAC
end sub

main:
    InitMain()
    while true
        value = 1
        while value < $FFF
            DAC_Output(value)
            Delay_ms(5)
            value = value+1
        wend
    wend ' the output in the mid-range
end.
```



SPI Ethernet Library

The ENC28J60 is a stand-alone Ethernet controller with an industry standard Serial Peripheral Interface (SPI™). It is designed to serve as an Ethernet network interface for any controller equipped with SPI.

The ENC28J60 meets all IEEE 802.3 specifications. It incorporates a number of packet filtering schemes to limit incoming packets. It also provides an internal DMA module for fast data throughput and hardware assisted IP checksum calculations. Communication with the host controller is implemented via two interrupt pins and SPI, with data rates of up to 10 Mb/s. Two ENC28J60 pins are dedicated for LED link and network activity indication.


This library is designed to simplify handling of the underlying hardware (ENC28J60). It works with any dsPIC30/33 and PIC24 with integrated SPI and more than 4 Kb ROM. 32 to 40 MHz clock is recommended to get from 8 to 10 MHz SPI clock, otherwise the dsPIC30/33 and PIC24 should be clocked by ENC clock output due to ENC silicone bug in the SPI hardware. If you try lower dsPIC30/33 and PIC24 clock speed, there might be a board hang or some requests might be missed.

Note: For advanced users there is a header file (`enc28j60_libprivate.dbas`) in the Uses folder of the compiler with detailed description of all functions which are implemented in the SPI Ethernet Library.

Note: The Library uses the SPI module for communication. The user must initialize the appropriate SPI module before using the SPI Ethernet Library. For MCUs with two SPI modules it is possible to initialize both of them and then switch by using the `Spi_Set_Active()` function. See the Spi Library functions.

Library Routines

```
SPI_Ethernet_Init  
SPI_Ethernet_doPacket  
SPI_Ethernet_putByte  
SPI_Ethernet_getByte  
SPI_Ethernet_UserTCP  
SPI_Ethernet_UserUDP
```



SPI_Ethernet_Init

459

page

Prototype	sub procedure SPI_Ethernet_Init(dim byref resetPort as word , dim resetBit as word , dim byref CSportPtr as word , dim CSbit as word , dim byref mac as byte [6] , dim byref ip as byte [4] , dim fullDuplex as byte)
Description	This function initializes ENC controller. This function is split into 2 parts in order to help linker when coming short of memory. Parameters: - resetPort: reset signal port address - resetBit: reset signal pin - CSportPtr: chip select signal port address - CSbit: chip select signal pin - mac: 6 char array containing MAC address - ip: 4 char array containing IP address - fullDuplex: communication mode parameter. Valid values: SPI_Ethernet_HALFDUPLEX and SPI_Ethernet_FULLDUPLEX
Requires	The SPI module needs to be initialized. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre>Spi1_Init() SPI_Ethernet_Init(PORTF, 0, PORTF, 1, myMacAddr, myIpAddr, SPI_Ethernet_FULLDUPLEX)</pre>

SPI_Ethernet_doPacket


Prototype	sub procedure SPI_Ethernet_doPacket()
Description	The function checks if a packet has been received. If it has, the function processes it in the following manner: - reply to ARP & ICMP echo requests automatically - upon TCP request the SPI_Ethernet_UserTCP function is called for further processing - upon UDP request the SPI_Ethernet_UserUDP function is called for further processing Note: SPI_Ethernet_doPacket must be called as often as possible in user code.
Requires	Ethernet module has to be initialized . See SPI_Ethernet_Init.
Example	<pre>SPI_Ethernet_doPacket()</pre>

SPI_Ethernet_putByte

Prototype	sub procedure SPI_Ethernet_putByte(dim v as byte)
Description	Stores one byte to address pointed by the ENC28J60 write pointer (EWRPT). Parameters: - v: value to store
Requires	Ethernet module has to be initialized . See SPI_Ethernet_Init.
Example	dim data as byte ... SPI_Ethernet_putByte(data)

SPI_Ethernet_getByte

Prototype	sub function SPI_Ethernet_getByte() as byte
Returns	Byte read from ENC28J60 memory.
Description	Gets byte from address pointed by the ENC28J60 read pointer (ERDPT).
Requires	Ethernet module has to be initialized . See SPI_Ethernet_Init.
Example	dim buffer as byte buffer = SPI_Ethernet_getByte()



SPI_Ethernet_UserTCP

461

page

Prototype	sub function SPI_Ethernet_UserTCP(dim byref remoteHost as byte [4], dim remotePort, localPort, reqLength as word) as word
Returns	- 0 - if there should not be a reply to the request. - Length of TCP/HTTP reply data field, otherwise
Description	This function is internally called by the library. The user accesses to the TCP/HTTP request by successive calls to SPI_Ethernet_getByte(). The user puts data in the transmit buffer by successive calls to SPI_Ethernet_putByte(). The function must return the length in bytes of the TCP/HTTP reply, or 0 if there is nothing to transmit. If there is no need to reply to the TCP/HTTP requests, just define this function with return(0) as a single statement. Parameters: - remoteHost: client's IP address - remotePort: client's TCP port - localPort: port to which the request is sent - reqLength: TCP/HTTP request data field length Note: The function source code is provided with appropriate example projects. The code should be adjusted by the user to achieve desired reply.
Requires	Ethernet module has to be initialized . See SPI_Ethernet_Init.
Example	This function is internally called by the library.

SPI_Ethernet_UserUDP

Prototype	sub function SPI_Ethernet_UserUDP(dim byref remoteHost as byte [4] , dim remotePort, destPort, reqLength as word) as word
Returns	Length of UDP reply data field, or 0 if the library should not reply to the request.
Description	This function is internally called by the library. The user accesses to the UDP request by successive calls to SPI_Ethernet_getByte(). The user puts data in the transmit buffer by successive calls to SPI_Ethernet_putByte(). The function must return the length in bytes of the UDP reply, or 0 if nothing to transmit. If you don't need to reply to the UDP requests, just define this function with a return(0) as single statement. Parameters: - remoteHost: client's IP address - remotePort: client's port - destPort: port to which the request is sent - reqLength: UDP request data field length Note: The function source code is provided with appropriate example projects. The code should be adjusted by the user to achieve desired reply.
Requires	Ethernet module has to be initialized . See SPI_Ethernet_Init.
Example	This function is internally called by the library.

Library Example

The following example is a simple demonstration of the SPI Ethernet Library. IP address 192.168.20.60 is assigned to the MCU+ENC28J60 server. The server will respond to ping, the TCP and UDP requests if connected to a local area network. Hardware configurations in this example are made for the dsPICPRO2 board and dsPIC30F6014A.

```
program enc_ethernet

include enc_utils ' this is where you should write implementation for UDP and HTTP

'*****
'* RAM variables
'*
dim myMacAddr    as byte[ 6]    ' my MAC address
    myIpAddr      as byte[ 4]    ' my IP address

main:
    ADPCFG = 0xFBFF              ' ADC convertors will be used (channel10)

    PORTB = 0
    TRISB = 0xFFFF              ' set PORTB as input for buttons

    PORTD = 0x00
    TRISD = 0                    ' set PORTD as output

    httpCounter = 0

    myMacAddr[ 0] = 0x00
    myMacAddr[ 1] = 0x14
    myMacAddr[ 2] = 0xA5
    myMacAddr[ 3] = 0x76
    myMacAddr[ 4] = 0x19
    myMacAddr[ 5] = 0x3F

    myIpAddr[ 0] = 192
    myIpAddr[ 1] = 168
    myIpAddr[ 2] = 20
    myIpAddr[ 3] = 60

' continues...
```

```
' continued...

'*
'* starts ENC28J60 with :
'* reset bit on RF0
'* CS bit on RF1
'* my MAC & IP address
'* full duplex
'*

' for faster spi communication use Spi_Init_Advanced routine
Spi2_Init()
Spi_Ethernet_Init(PORTG, 13, PORTG, 12, myMacAddr, myIpAddr, SPI_Ethernet_FULLDU-
PLEX)
while true                                ' do forever
    Spi_Ethernet_doPacket()                ' process incoming Ethernet packets

    '*
    '* add your stuff here if needed
    '* ENC28J60_doPacket() must be called as often as possible
    '* otherwise packets could be lost
    '*
wend
end.
```

465

page

SPI Graphic LCD Library

mikroBasic for dsPIC30/33 and PIC24 provides a library for operating Graphic LCD 128x64 (with the commonly used Samsung KS108/KS107 controller) via SPI interface. For creating a custom set of GLCD images use the GLCD Bitmap Editor Tool.

Note: When using this library with the dsPIC33 and PIC24 family MCUs be aware of their voltage incompatibility with a certain number of Samsung KS0108 based GLCD modules. So, additional external power supply for these modules may be required.

Note: The library uses the SPI module for communication. The user must initialize the appropriate SPI module before using the SPI GLCD Library. For MCUs with two SPI modules it is possible to initialize both of them and then switch by using the `Spi_Set_Active()` function. See the Spi Library functions.

Note: This Library is designed to work with the mikroElektronika's Serial LCD/GLCD Adapter Board pinout, see schematic at the bottom of this page for details.


Library Routines

Basic routines:

```
SPI_Glcd_Config  
Spi_Glcd_Init  
Spi_Glcd_Set_Side  
Spi_Glcd_Set_Page  
Spi_Glcd_Set_X  
Spi_Glcd_Read_Data  
Spi_Glcd_Write_Data
```

Advanced routines:

```
Spi_Glcd_Fill  
Spi_Glcd_Dot  
Spi_Glcd_Line  
Spi_Glcd_V_Line  
Spi_Glcd_H_Line  
Spi_Glcd_Rectangle  
Spi_Glcd_Box  
Spi_Glcd_Circle  
Spi_Glcd_Set_Font  
Spi_Glcd_Write_Char  
Spi_Glcd_Write_Text  
Spi_Glcd_Image
```



Spi_Glcd_Config

467

page

Prototype	sub procedure Spi_Glcd_Config(dim DeviceAddress as byte, dim byref RstPort as word, dim RstPin as word, dim byref CSPort as word, dim CSPin as word)
Description	Initializes the GLCD module via SPI interface. Parameters : - DeviceAddress: spi expander hardware address, see schematic at the bottom of this page - RstPort: reset signal port address - RstPin: reset signal pin - CSPort: chip select signal port address - CSPin: chip select signal pin
Requires	The SPI module needs to be initialized. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre>' initialize the SPI1 module and GLCD module Spi_Init() Spi_Glcd_Config(0, PORTF, 0, PORTF, 1)</pre>

Spi_Glcd_Init


Prototype	sub procedure Spi_Glcd_Init()
Description	Initializes the GLCD module via SPI interface with the DeviceAddress=0, reset signal connected to the RF0 pin and the chip select signal connected to the RF1 pin. Note: The Spi_Glcd_Init() routine can be changed by the user. Source code is located in the setup library file in the Uses folder.
Requires	The SPI module needs to be initialized. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre>' initialize the SPI1 module and GLCD module Spi_Init() Spi_Glcd_Init()</pre>

Spi_Glcd_Set_Side

Prototype	sub procedure Spi_Glcd_Set_Side(dim x_pos as byte)
Description	Selects GLCD side. Refer to the GLCD datasheet for detail explanation. Parameters : - x_pos: position on x-axis. Valid values: 0..127 The parameter x_pos specifies the GLCD side: values from 0 to 63 specify the left side, values from 64 to 127 specify the right side. Note: For side, x axis and page layout explanation, see schematic at the bottom of this page.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	The following two lines are equivalent, and both of them select the left side of GLCD: <pre>SPI_Glcd_Set_Side(0) Spi_Glcd_Set_Side(10)</pre>

Spi_Glcd_Set_Page

Prototype	sub procedure Spi_Glcd_Set_Page(dim page as byte)
Description	Selects page of GLCD. Parameters : - page: page number. Valid values: 0..7 Note: For side, x axis and page layout explanation, see schematic at the bottom of this page.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	Spi_Glcd_Set_Page(5)



Spi_Glcd_Set_X

Prototype	sub procedure Spi_Glcd_Set_X(dim x_pos as byte)
Description	Sets x-axis position to x_pos dots from the left border of GLCD within the selected side. Parameters : - x_pos: position on x-axis. Valid values: 0..63 Note: For side, x axis and page layout explanation, see schematic at the bottom of this page.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	Spi_Glcd_Set_X(25)

Spi_Glcd_Read_Data


Prototype	sub function Spi_Glcd_Read_Data() as byte
Returns	One byte from GLCD memory.
Description	Reads data from the current location of GLCD memory and moves to the next location.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines. GLCD side, x-axis position and page should be set first. See the functions Spi_Glcd_Set_Side, Spi_Glcd_Set_X, and Spi_Glcd_Set_Page.
Example	dim data as byte ... data = Spi_Glcd_Read_Data()

Spi_Glcd_Write_Data

Prototype	sub procedure Spi_Glcd_Write_Data(dim data as byte)
Description	Writes one byte to the current location in GLCD memory and moves to the next location. Parameters : - data: data to be written.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines. GLCD side, x-axis position and page should be set first. See the functions Spi_Glcd_Set_Side, Spi_Glcd_Set_X, and Spi_Glcd_Set_Page.
Example	dim data as byte ... Spi_Glcd_Write_Data(data)

Spi_Glcd_Fill

Prototype	sub procedure Spi_Glcd_Fill(dim pattern as byte)
Description	Fills GLCD memory with byte pattern. Parameters : - pattern: byte to fill GLCD memory with To clear the GLCD screen, use Spi_Glcd_FillGlcd_Fill(0). To fill the screen completely, use Spi_Glcd_Fill(0xFF).
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	<i>' Clear screen</i> Spi_Glcd_Fill(0)



Spi_Glcd_Dot

471

page

Prototype	sub procedure Spi_Glcd_Dot(dim x_pos, y_pos, color as byte)
Description	Draws a dot on GLCD at coordinates (x_pos, y_pos). Parameters : - x_pos: x position. Valid values: 0..127 - y_pos: y position. Valid values: 0..63 - color: color parameter. Valid values: 0..2 The parameter color determines the dot state: 0 clears dot, 1 puts a dot, and 2 inverts dot state. Note: For x and y axis layout explanation, see schematic at the bottom of this page.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	<pre>' Invert the dot in the upper left corner Spi_Glcd_Dot(0, 0, 2)</pre>

Spi_Glcd_Line


Prototype	sub procedure SPI_Glcd_Line(dim x_start, y_start, x_end, y_end as integer, dim color as byte)
Description	Draws a line on GLCD. Parameters : - x_start: x coordinate of the line start. Valid values: 0..127 - y_start: y coordinate of the line start. Valid values: 0..63 - x_end: x coordinate of the line end. Valid values: 0..127 - y_end: y coordinate of the line end. Valid values: 0..63 - color: color parameter. Valid values: 0..2 Parameter color determines the line color: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	<pre>' Draw a line between dots (0,0) and (20,30) Spi_Glcd_Line(0, 0, 20, 30, 1)</pre>

Spi_Glcd_V_Line

Prototype	sub procedure Spi_Glcd_V_Line(dim y_start, y_end, x_pos, color as byte)
Description	Draws a vertical line on GLCD. Parameters : - y_start: y coordinate of the line start. Valid values: 0..63 - y_end: y coordinate of the line end. Valid values: 0..63 - x_pos: x coordinate of vertical line. Valid values: 0..127 - color: color parameter. Valid values: 0..2 The parameter color determines the line color: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	<pre>' Draw a vertical line between dots (10,5) and (10,25) Spi_Glcd_V_Line(5, 25, 10, 1)</pre>

Spi_Glcd_H_Line

Prototype	sub procedure Spi_Glcd_H_Line(dim x_start, x_end, y_pos, color as byte)
Description	Draws a horizontal line on GLCD. Parameters : - x_start: x coordinate of the line start. Valid values: 0..127 - x_end: x coordinate of the line end. Valid values: 0..127 - y_pos: y coordinate of horizontal line. Valid values: 0..63 - color: color parameter. Valid values: 0..2 The parameter color determines the line color: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized for SPI communication, see SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	<pre>' Draw a horizontal line between dots (10,20) and (50,20) Spi_Glcd_H_Line(10, 50, 20, 1)</pre>



Spi_Glcd_Rectangle

473

page


Prototype	sub procedure SPI_Glcd_Rectangle(dim x_upper_left, y_upper_left, x_bottom_right, y_bottom_right, color as byte)
Description	Draws a rectangle on GLCD. Parameters : - x_upper_left: x coordinate of the upper left rectangle corner. Valid values: 0..127 - y_upper_left: y coordinate of the upper left rectangle corner. Valid values: 0..63 - x_bottom_right: x coordinate of the lower right rectangle corner. Valid values: 0..127 - y_bottom_right: y coordinate of the lower right rectangle corner. Valid values: 0..63 - color: color parameter. Valid values: 0..2 The parameter color determines the color of the rectangle border: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized for SPI communication, see SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	<i>' Draw a rectangle between dots (5,5) and (40,40)</i> Spi_Glcd_Rectangle(5, 5, 40, 40, 1)

Spi_Glcd_Box

Prototype	sub procedure Spi_Glcd_Box(dim x1, y1, x2, y2, color as byte)
Description	Draws a box on GLCD. Parameters : - x_upper_left: x coordinate of the upper left box corner. Valid values: 0..127 - y_upper_left: y coordinate of the upper left box corner. Valid values: 0..63 - x_bottom_right: x coordinate of the lower right box corner. Valid values: 0..127 - y_bottom_right: y coordinate of the lower right box corner. Valid values: 0..63 - color: color parameter. Valid values: 0..2 The parameter color determines the color of the box fill: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	<i>' Draw a box between dots (5,15) and (20,40)</i> Spi_Glcd_Box(5, 15, 20, 40, 1)

Spi_Glcd_Circle

Prototype	sub procedure SPI_Glcd_Circle(dim x_center, y_center, radius as integer, dim color as byte)
Description	Draws a circle on GLCD. Parameters : - x_center: x coordinate of the circle center. Valid values: 0..127 - y_center: y coordinate of the circle center. Valid values: 0..63 - radius: radius size - color: color parameter. Valid values: 0..2 The parameter color determines the color of the circle line: 0 white, 1 black, and 2 inverts each dot.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	<pre>' Draw a circle with center in (50,50) and radius=10 Spi_Glcd_Circle(50, 50, 10, 1)</pre>




Spi_Glcd_Set_Font

Prototype	sub procedure Spi_Glcd_Set_Font(dim activeFont as LongInt, dim aFontWidth, aFontHeight as byte, dim aFontOffs as word)
Description	Sets font that will be used with the Spi_Glcd_Write_Char and Spi_Glcd_Write_Text routines. Parameters : - activeFont: font address. Font needs to be formatted as an array of bytes - aFontWidth: width of the font characters in dots. - aFontHeight: height of the font characters in dots. - aFontOffs: number that represents difference between the mikroBasic character set and regular ASCII set (eg. if 'A' is 65 in ASCII character, and 'A' is 45 in the mikroBasic character set, aFontOffs is 20). Demo fonts supplied with the library have an offset of 32, which means that they start with space. The user can use fonts given in the file “__Lib_Glcd_Fonts.dbas” file located in the Uses\Consts folder or create his/her own fonts.
Requires	GLCD needs to be initialized for SPI communication, see the Spi_Glcd_Config and Spi_Glcd_Init routines.
Example	<i>' Use the custom 5x7 font "myfont" which starts with space (32):</i> Spi_Glcd_Set_Font(@myfont, 5, 7, 32)

Spi_Glcd_Write_Char

Prototype	sub procedure SPI_Glcd_Write_Char(dim chr1, x_pos, page_num, color as byte)
Description	Prints character on GLCD. Parameters : - chr1: character to be written - x_pos: character starting position on x-axis. Valid values: 0..(127-FontWidth) - page_num: the number of the page on which character will be written. Valid values: 0..7 - color: color parameter. Valid values: 0..2 The parameter color determines the color of the character: 0 white, 1 black, and 2 inverts each dot. Note: For x axis and page layout explanation see schematic at the bottom of this page.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines. Use Spi_Glcd_Set_Font to specify the font for display; if no font is specified, then the default 5x8 font supplied with the library will be used.
Example	<i>' Write character 'C' on the position 10 inside the page 2:</i> <pre>Spi_Glcd_Write_Char('C', 10, 2, 1)</pre>



Spi_Glcd_Write_Text

477

page

Prototype	sub procedure SPI_Glcd_Write_Text(dim byref text as char [40] , dim x_pos, page_num, color as byte)
Description	Prints text on GLCD. Parameters : - text: text to be written - x_pos: text starting position on x-axis. - page_num: the number of the page on which text will be written. Valid values: 0..7 - color: color parameter. Valid values: 0..2 The parameter color determines the color of the text: 0 white, 1 black, and 2 inverts each dot. Note: For x axis and page layout explanation, see schematic at the bottom of this page.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines. Use Spi_Glcd_Set_Font to specify the font for display; if no font is specified, then the default 5x8 font supplied with the library will be used.
Example	<i>' Write text "Hello world!" on the position 10 inside the page 2:</i> Spi_Glcd_Write_Text("Hello world!", 10, 2, 1)

Spi_Glcd_Image

Prototype	sub procedure SPI_Glcd_Image(dim byref constimage as byte)
Description	Displays bitmap on GLCD. Parameters : - image: image to be displayed. Bitmap array can be located in both code and RAM (due to the mikroBasic for dsPIC30/33 and PIC24 pointer to const and pointer to RAM equivalency). Use the mikroBasic's integrated GLCD Bitmap Editor (menu option Tools > GLCD Bitmap Editor) to convert image to a constant array suitable for displaying on GLCD.
Requires	GLCD needs to be initialized for SPI communication, see the SPI_Glcd_Config and Spi_Glcd_Init routines.
Example	Spi_Glcd_Image(my_image)

Library Example

The example demonstrates how to communicate to KS0108 GLCD via SPI module, using serial to parallel convertor MCP23S17.

```
program SerialGLCD

include __Lib_Glcd_Images

dim
    ii as byte
    jj as word
    someText as string[ 20]

sub procedure delay2S
    delay_ms(2000)
end sub

main:
    ADPCFG = 0xFFFF

    ' for faster spi communication use Spi_Init_Advanced routine
    Spi1_Init()
    Spi_Glcd_Init()
    Spi_Glcd_Fill(0xAA)
    delay2S

    while TRUE
        Spi_Glcd_Fill(0x00)
        Spi_Glcd_Image( truck_bmp )
        delay2S


        for jj = 1 to 40
            Spi_Glcd_Dot(jj,jj,1)
        next jj

        delay2S

        Spi_Glcd_Fill(0x00)
        Spi_Glcd_Line(120, 1, 5,60, 1)
        delay2S
        Spi_Glcd_Line(12, 42, 5,60, 1)
        delay2S

        Spi_Glcd_Rectangle(12, 20, 93,57, 1)
        delay2S

        ' continues...
```



```
' continues...

Spi_Glcd_Line(120, 12, 12,60, 1)
delay2S

Spi_Glcd_H_Line(5, 15, 6, 1)
Spi_Glcd_Line(0, 12, 120, 60, 1)
Spi_Glcd_V_Line(7, 63, 127, 1)
delay2S

for ii = 1 to 10
    Spi_Glcd_Circle(63, 32, 3*ii, 1)
next ii


delay2S
Spi_Glcd_Box(12, 20, 70, 57, 2)
delay2S

Spi_Glcd_Fill(0x00)

Spi_Glcd_Set_Font(@System3x6, 3, 6, 32)
someText = "SMALL FONT: 3X6"
Spi_Glcd_Write_Text(someText, 20, 5, 1)

Spi_Glcd_Set_Font(@FontSystem5x8, 5, 8, 32)
someText = "Large Font 5x8"
Spi_Glcd_Write_Text(someText, 3, 4, 1)
delay2S
wend
end.
```

Hardware Connection



SPI LCD Library (4-bit interface)

mikroBasic for dsPIC30/33 and PIC24 provides a library for communication with LCD (with HD44780 compliant controllers) in 4-bit mode via SPI interface.

For creating a custom set of LCD characters use the LCD Custom Character Tool.

Note: When using this library with the dsPIC33 and PIC24 family MCUs be aware of their voltage incompatibility with a certain number of the LCD modules. So, additional external power supply for these modules may be required.

Note: The library uses the SPI module for communication. The user must initialize the appropriate SPI module before using the SPI LCD Library. For MCUs with two SPI modules it is possible to initialize both of them and then switch by using the `Spi_Set_Active()` function. See the Spi Library functions.

Note: This Library is designed to work with the mikroElektronika's Serial LCD Adapter Board pinout. See schematic at the bottom of this page for details.

Library Routines


```
Spi_Lcd_Config
Spi_Lcd_Init
Spi_Lcd_Out
Spi_Lcd_Out_Cp
Spi_Lcd_Chr
Spi_Lcd_Chr_Cp
Spi_Lcd_Cmd
```

Spi_Lcd_Config

Prototype	sub procedure Spi_Lcd_Config(dim DeviceAddress as byte, dim byref rstport as word, dim rstpin as word, dim byref csport as word, dim cspin as word)
Description	Initializes the LCD module via SPI interface. Parameters : - DeviceAddress: spi expander hardware address, see schematic at the bottom of this page - rstport: reset signal port address - rstpin: reset signal pin - csport: chip select signal port address - cspin: chip select signal pin
Requires	The SPI module needs to be initialized. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre>' initialize the SPI1 module and LCD module Spi_Init() Spi_Lcd_Config(0, PORTE, 0, PORTE, 1)</pre>

Spi_Lcd_Init

Prototype	sub procedure Spi_Lcd_Init()
Description	Initializes the LCD module via SPI interface with the DeviceAddress=0, reset signal connected to the RF0 pin and the chip select signal connected to the RF1 pin. Note: The Spi_Lcd_Init() routine can be changed by the user. Source code is located in the setup library file in the Uses folder.
Requires	The SPI module needs to be initialized. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre>' initialize the SPI1 module and LCD module Spi_Init() Spi_Lcd_Init()</pre>



Spi_Lcd_Out

Prototype	sub procedure Spi_Lcd_Out(dim row, column as byte, dim byref text as string[20])
Description	Prints text on the LCD starting from specified position. Both string variables and literals can be passed as a text. Parameters : - row: starting position row number - column: starting position column number - text: text to be written
Requires	LCD needs to be initialized for SPI communication, see the Spi_Lcd_Config and Spi_Lcd_Init routines.
Example	<i>' Write text "Hello!" on LCD starting from row 1, column 3:</i> Spi_Lcd_Out(1, 3, "Hello!")

Spi_Lcd_Out_Cp


Prototype	sub procedure Spi_Lcd_Out_CP(dim byref text as string[40])
Description	Prints text on the LCD at current cursor position. Both string variables and literals can be passed as a text. Parameters : - text: text to be written
Requires	LCD needs to be initialized for SPI communication, see the Spi_Lcd_Config and Spi_Lcd_Init routines.
Example	<i>' Write text "Here!" at current cursor position:</i> Spi_Lcd_Out_CP("Here!")

Spi_Lcd_Chrr

Prototype	sub procedure Spi_Lcd_Chrr(dim Row, Column, Out_Char as byte)
Description	Prints character on LCD at specified position. Both variables and literals can be passed as character. Parameters : - Row: writing position row number - Column: writing position column number - Out_Char: character to be written
Requires	LCD needs to be initialized for SPI communication, see the Spi_Lcd_Config and Spi_Lcd_Init routines.
Example	<i>' Write character "i" at row 2, column 3:</i> Spi_Lcd_Chrr(2, 3, "i")

Spi_Lcd_Chrr_Cp

Prototype	sub procedure Spi_Lcd_Chrr_CP(dim Out_Char as byte)
Description	Prints character on LCD at current cursor position. Both variables and literals can be passed as character. Parameters : - Out_Char: character to be written
Requires	LCD needs to be initialized for SPI communication, see the Spi_Lcd_Config and Spi_Lcd_Init routines.
Example	<i>' Write character "e" at current cursor position:</i> Spi_Lcd_Chrr_Cp("e")



Spi_Lcd_Cmd

Prototype	<code>sub procedure Spi_Lcd_Cmd(dim out_char as byte)</code>
Description	Sends command to LCD. Parameters : - out_char: command to be sent Note: Predefined constants can be passed to the function, see Available LCD Commands.
Requires	LCD needs to be initialized for SPI communication, see the Spi_Lcd_Config and Spi_Lcd_Init routines.
Example	<pre>' Clear LCD display: Spi_Lcd_Cmd(LCD_CLEAR)</pre>

Library Example (default pin settings)

Use Spi_Lcd_Init for default pin settings (see the first figure below).

```
program Spi_Lcd_demo

main:
' for faster spi communication use Spi_Init_Advanced routine
Spi_Init()           ' initialize SPI communication
Spi_Lcd_Init()       ' initialize lcd via SPI interface
Spi_Lcd_Cmd(Lcd_CLEAR) ' send command to LCD "clear display"
Spi_Lcd_Cmd(Lcd_CURSOR_OFF) ' send command cursor off
Spi_Lcd_Out(2, 1, "mikroElektronika") ' print txt to LCD, 2nd row, 1st column
Spi_Lcd_Out(1, 5, "mikroE")          ' print txt to LCD, 1st row, 5th column
Spi_Lcd_Out(3, 1, "mikroE")
' print txt to LCD, 3rd row, 1st column, for lcd's with more than two rows
Spi_Lcd_Out(4, 10, "mikroE")
' print txt to LCD, 4th row, 10th column, for lcd's with more than two rows
end.
```


LCD Commands

LCD Command	Purpose
LCD_FIRST_ROW	Move cursor to 1st row
LCD_SECOND_ROW	Move cursor to 2nd row
LCD_THIRD_ROW	Move cursor to 3rd row
LCD_FOURTH_ROW	Move cursor to 4th row
LCD_CLEAR	Clear display
LCD_RETURN_HOME	Return cursor to home position, returns a shifted display to original position. Display data RAM is unaffected.
LCD_CURSOR_OFF	Turn off cursor
LCD_UNDERLINE_ON	Underline cursor on
LCD_BLINK_CURSOR_ON	Blink cursor on
LCD_MOVE_CURSOR_LEFT	Move cursor left without changing display data RAM
Lcd_Move_Cursor_Right	Move cursor right without changing display data RAM
LCD_TURN_ON	Turn LCD display on
LCD_TURN_OFF	Turn LCD display off
LCD_SHIFT_LEFT	Shift display left without changing display data RAM
LCD_SHIFT_RIGHT	Shift display right without changing display data RAM

Hardware Connection

487

page



SPI LCD8 (8-bit interface) Library

mikroBasic for dsPIC30/33 and PIC24 provides a library for communication with LCD (with HD44780 compliant controllers) in 8-bit mode via SPI interface.

For creating a custom set of LCD characters use the LCD Custom Character Tool.


Note: When using this library with the dsPIC33 and PIC24 family MCUs be aware of their voltage incompatibility with a certain number of LCD modules. So, additional external power supply for these modules may be required.

Note: Library uses the SPI module for communication. The user must initialize the appropriate SPI module before using the SPI LCD Library. For MCUs with two SPI modules it is possible to initialize both of them and then switch by using the `Spi_Set_Active()` function. See the Spi Library functions.

Note: This Library is designed to work with mikroElektronika's Serial LCD/GLCD Adapter Board pinout, see schematic at the bottom of this page for details.

Library Routines

```
Spi_Lcd8_Config  
Spi_Lcd8_Init  
Spi_Lcd8_Out  
Spi_Lcd8_Out_Cp  
Spi_Lcd8_Chrc  
Spi_Lcd8_Chrc_Cp  
Spi_Lcd8_Cmd
```



Spi_Lcd8_Config

Prototype	sub procedure Spi_LCD8_Config(dim DeviceAddress as byte, dim byref rstport as word, dim rstpin as word, dim byref csport as word, dim cspin as word)
Description	Initializes the LCD module via SPI interface. Parameters : - DeviceAddress: spi expander hardware address, see schematic at the bottom of this page - rstport: reset signal port address - rstpin: reset signal pin - csport: chip select signal port address - cspin: chip select signal pin
Requires	The SPI module needs to be initialized. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre>' initialize the SPI1 module and ' LCD module in 8-bit mode Spi_Init() Spi_Lcd8_Config(0, PORTE, 0, PORTE, 1)</pre>

Spi_Lcd8_Init


Prototype	sub procedure Spi_Lcd8_Init()
Description	Initializes the LCD module via SPI interface with the DeviceAddress=0, reset signal connected to the RF0 pin and the chip select signal connected to the RF1 pin. Note: Spi_Lcd8_Init() routine can be changed by the user. Source code is located in setup library file in the Uses folder.
Requires	The SPI module needs to be initialized. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre>' Initialize the SPI1 module and LCD module in 8-bit mode Spi_Init() Spi_Lcd8_Init()</pre>

Spi_Lcd8_Out

Prototype	sub procedure Spi_LCD8_Out(dim row, column as byte, dim byref text as string[20])
Description	Prints text on LCD starting from specified position. Both string variables and literals can be passed as a text. Parameters : - row: starting position row number - column: starting position column number - text: text to be written
Requires	LCD needs to be initialized for SPI communication, see the Spi_Lcd8_Config and Spi_Lcd8_Init routines.
Example	<i>' Write text "Hello!" on LCD starting from row 1, column 3:</i> Spi_Lcd8_Out(1, 3, "Hello!")

Spi_Lcd8_Out_Cp

Prototype	sub procedure Spi_LCD8_Out_CP(dim byref text as string[20])
Description	Prints text on LCD at current cursor position. Both string variables and literals can be passed as a text. Parameters : - text: text to be written
Requires	LCD needs to be initialized for SPI communication, see the Spi_Lcd8_Config and Spi_Lcd8_Init routines.
Example	<i>' Write text "Here!" at current cursor position:</i> Spi_Lcd8_Out_Cp("Here!")



Spi_Lcd8_Chkr

Prototype	sub procedure Spi_LCD8_Chkr(dim row, column, out_char as byte)
Description	Prints character on LCD at specified position. Both variables and literals can be passed as character. Parameters : - row: writing position row number - column: writing position column number - out_char: character to be written
Requires	LCD needs to be initialized for SPI communication, see the Spi_Lcd8_Config and Spi_Lcd8_Init routines.
Example	<i>' Write character "i" at row 2, column 3:</i> Spi_Lcd8_Chkr(2, 3, "i")

Spi_Lcd8_Chkr_Cp

Prototype	sub procedure Spi_LCD8_Chkr_CP(dim out_char as byte)
Description	Prints character on LCD at current cursor position. Both variables and literals can be passed as character. Parameters : - out_char: character to be written
Requires	LCD needs to be initialized for SPI communication, see the Spi_Lcd8_Config and Spi_Lcd8_Init routines.
Example	<i>' Write character "e" at current cursor position:</i> Spi_Lcd8_Chkr_Cp("e")

Spi_Lcd8_Cmd

Prototype	sub procedure Spi_LCD8_Cmd(dim out_char as byte)
Description	Sends command to LCD. Parameters : - out_char: command to be sent Note: Predefined constants can be passed to the function, see Available LCD Commands.
Requires	LCD needs to be initialized for SPI communication, see the Spi_Lcd8_Config and Spi_Lcd8_Init routines.
Example	<pre>' Clear LCD display: Spi_Lcd8_Cmd(LCD_CLEAR)</pre>


Library Example (default pin settings)

program SpiLcd8

main:

```
' for faster spi communication use Spi_Init_Advanced routine
Spi1_Init()                ' initialize SPI communication
Spi_Lcd8_Init()            ' initialize lcd via SPI interface
Spi_Lcd8_Cmd(LCD_CLEAR)    ' Clear display
Spi_Lcd8_Cmd(LCD_CURSOR_OFF) ' Turn cursor OFF
Spi_Lcd8_Out(1, 5, "mikroE") ' Write Txt to LCD
Spi_Lcd8_Out(2, 1, "mikroElektronika") ' Write Txt to LCD
Spi_Lcd8_Out(3, 1, "mikroE") ' Write Txt to LCD
Spi_Lcd8_Out(4, 10, "mikroE") ' Write Txt to LCD
```

end.




LCD Commands

LCD Command	Purpose
LCD_FIRST_ROW	Move cursor to 1st row
LCD_SECOND_ROW	Move cursor to 2nd row
LCD_THIRD_ROW	Move cursor to 3rd row
LCD_FOURTH_ROW	Move cursor to 4th row
LCD_CLEAR	Clear display
LCD_RETURN_HOME	Return cursor to home position, returns a shifted display to original position. Display data RAM is unaffected.
LCD_CURSOR_OFF	Turn off cursor
LCD_UNDERLINE_ON	Underline cursor on
LCD_BLINK_CURSOR_ON	Blink cursor on
LCD_MOVE_CURSOR_LEFT	Move cursor left without changing display data RAM
Lcd_Move_Cursor_Right	Move cursor right without changing display data RAM
LCD_TURN_ON	Turn LCD display on
LCD_TURN_OFF	Turn LCD display off
LCD_SHIFT_LEFT	Shift display left without changing display data RAM
LCD_SHIFT_RIGHT	Shift display right without changing display data RAM

Hardware Connection

494

page



SPI T6963C Graphic LCD Library

mikroBasic for dsPIC30/33 and PIC24 provides a library for working with GLCDs based on TOSHIBA T6963C controller via SPI interface. The Toshiba T6963C is a very popular LCD controller for the use in small graphics modules. It is capable of controlling displays with a resolution up to 240x128. Because of its low power and small outline it is most suitable for mobile applications such as PDAs, MP3 players or mobile measurement equipment. Although this controller is small, it has a capability of displaying and merging text and graphics and it manages all interfacing signals to the displays Row and Column drivers.

For creating a custom set of GLCD images use the GLCD Bitmap Editor Tool.

Note: When using this library with the dsPIC33 and PIC24 family MCUs be aware of their voltage incompatibility with a certain number of T6963C based GLCD modules. So, additional external power supply for these modules may be required.

Note: GLCD size based initialization routines can be found in setup library files located in the Uses folder. The user must make sure that used MCU has appropriate ports and pins. If this is not the case the, user should adjust initialization routines.

Note: The library uses the SPI module for communication. The user must initialize the appropriate SPI module before using the Spi T6963C GLCD Library. For MCUs with two SPI modules it is possible to initialize both of them and then switch by using the Spi_Set_Active() function. See the Spi Library functions.

Note: This Library is designed to work with mikroElektronika's Serial GLCD 240x128 and 240x64 Adapter Boards pinout, see schematic at the bottom of this page for details.

Note: Some mikroElektronika's adapter boards have pinout different from T6369C datasheets. Appropriate relations between these labels are given in the table below:

Adapter Board	T6369C datasheet
RS	C/D
R/W	/RD
E	/WR

Library Routines

<code>Spi_T6963C_Init</code>	<code>Spi_T6963C_SetGrPanel</code>
<code>Spi_T6963C_WriteData</code>	<code>Spi_T6963C_SetTxtPanel</code>
<code>Spi_T6963C_WriteCommand</code>	<code>Spi_T6963C_PanelFill</code>
<code>Spi_T6963C_SetPtr</code>	<code>Spi_T6963C_GrFill</code>
<code>Spi_T6963C_WaitReady</code>	<code>Spi_T6963C_TxtFill</code>
<code>Spi_T6963C_Fill</code>	<code>Spi_T6963C_Cursor_Height</code>
<code>Spi_T6963C_Dot</code>	<code>Spi_T6963C_Graphics</code>
<code>Spi_T6963C_Write_Char</code>	<code>Spi_T6963C_Text</code>
<code>Spi_T6963C_Write_Text</code>	<code>Spi_T6963C_Cursor</code>
<code>Spi_T6963C_Line</code>	<code>Spi_T6963C_Cursor_Blink</code>
<code>Spi_T6963C_Rectangle</code>	
<code>Spi_T6963C_Box</code>	
<code>Spi_T6963C_Circle</code>	
<code>Spi_T6963C_Image</code>	
<code>Spi_T6963C_Sprite</code>	
<code>Spi_T6963C_Set_Cursor</code>	
<code>Spi_T6963C_ClearBit</code>	
<code>Spi_T6963C_SetBit</code>	
<code>Spi_T6963C_NegBit</code>	
<code>Spi_T6963C_DisplayGrPanel</code>	
<code>Spi_T6963C_DisplayTxtPanel</code>	



Spi_T6963C_Init

Prototype	<pre>sub procedure Spi_T6963C_Init(dim width, height, fntW as word, dim DeviceAddress as byte, dim byref rstport as word, dim rstpin as word, dim byref csport as word, dim cspin as word, dim wr, rd, cd, rst as byte)</pre>						
Description	Initializes the Graphic Lcd controller. Parameters : - width: width of the GLCD panel - height: height of the GLCD panel - fntW: font width - DeviceAddress: spi expander hardware address, see schematic at the bottom of this page - rstport: port expander's reset signal port address - rstpin: port expander's reset signal pin - csport: port expander's chip select signal port address - cspin: port expander's chip select signal pin - wr: write signal pin on GLCD control port - rd: read signal pin on GLCD control port - cd: cd signal pin on GLCD control port - rst: rst signal pin on GLCD control port Display RAM organization: The library cuts RAM into panels : a complete panel is one graphics panel followed by a text panel (see schematic below). <table><tr><td>GRAPHICS PANEL #0</td><td rowspan="2">PANEL 0</td></tr><tr><td>TEXT PANEL #0</td></tr><tr><td>GRAPHICS PANEL #1</td><td rowspan="2">PANEL 1</td></tr><tr><td>TEXT PANEL #2</td></tr></table> <i>' continues on the next page ...</i>	GRAPHICS PANEL #0	PANEL 0	TEXT PANEL #0	GRAPHICS PANEL #1	PANEL 1	TEXT PANEL #2
GRAPHICS PANEL #0	PANEL 0						
TEXT PANEL #0							
GRAPHICS PANEL #1	PANEL 1						
TEXT PANEL #2							


' continued from the previous page ...	
Requires	The SPI module needs to be initialized. See the Spi1_Init, Spi1_Init_Advanced, Spi2_Init, Spi2_Init_Advanced, Spi_Init and Spi_Init_Advanced routines.
Example	<pre> Spi1_Init() Spi_T6963C_Init(240, 64, 8, PORTF, 0, PORTF, 1, 0, 1, 3, 4, 0) ' init display for 240 pixel width and 64 pixel height ' 8 bits character width ' reset pin on PORTB.1 ' chip select pin on PORTB.0 ' bit 0 is !WR ' bit 1 is !RD ' bit 3 is !CD ' bit 4 is RST ' chip enable, reverse on, 8x8 font internally set in library ' device address is 0 </pre>

Spi_T6963C_writeData

Prototype	sub procedure Spi_T6963C_WriteData(dim data as byte)
Description	Writes data to T6963C controller via SPI interface. Parameters : - data: data to be written
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	Spi_T6963C_WriteData(AddrL)

Spi_T6963C_writeCommand

Prototype	sub procedure Spi_T6963C_WriteCommand(dim data as byte)
Description	Writes command to T6963C controller via SPI interface. Parameters : - data: command to be written
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	Spi_T6963C_WriteCommand(T6963C_CURSOR_POINTER_SET)



Spi_T6963C_setPtr

Prototype	<code>sub procedure Spi_T6963C_SetPtr(dim p as word, dim c as byte)</code>
Description	Sets the memory pointer p for command c. Parameters : - p: address where command should be written - c: command to be written
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<code>Spi_T6963C_SetPtr(T6963C_grHomeAddr + start, T6963C_ADDRESS_POINTER_SET)</code>

Spi_T6963C_waitReady


Prototype	<code>sub procedure Spi_T6963C_WaitReady()</code>
Description	Pools the status byte, and loops until Toshiba GLCD module is ready.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<code>Spi_T6963C_WaitReady()</code>

Spi_T6963C_fill

Prototype	<code>sub procedure Spi_T6963C_Fill(dim v as byte, dim start, len as word)</code>
Description	Fills controller memory block with given byte. Parameters : - v: byte to be written - start: starting address of the memory block - len: length of the memory block in bytes
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<code>Spi_T6963C_Fill(0x33, 0x00FF, 0x000F)</code>

Spi_T6963C_dot

Prototype	sub procedure Spi_T6963C_Dot(dim x, y as integer , dim color as byte)
Description	Draws a dot in the current graphic panel of GLCD at coordinates (x, y). Parameters : - x: dot position on x-axis - y: dot position on y-axis - color: color parameter. Valid values: T6963C_BLACK and T6963C_WHITE
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	Spi_T6963C_Dot(x0, y0, T6963C_BLACK)




Spi_T6963C_write_char

Prototype	<code>sub procedure Spi_T6963C_Write_Char(dim c, x, y, mode as byte)</code>
Description	Writes a char in the current text panel of GLCD at coordinates (x, y). Parameters : - c: char to be written - x: char position on x-axis - y: char position on y-axis - mode: mode parameter. Valid values: T6963C_ROM_MODE_OR, T6963C_ROM_MODE_XOR, T6963C_ROM_MODE_AND and T6963C_ROM_MODE_TEXT Mode parameter explanation: - OR Mode: In the OR-Mode, text and graphics can be displayed and the data is logically “OR-ed”. This is the most common way of combining text and graphics, for example labels on buttons. - XOR-Mode: In this mode, the text and graphics data are combined via the logical “exclusive OR”. This can be useful to display text in negative mode, i.e. white text on black background. - AND-Mode: The text and graphic data shown on display are combined via the logical “AND function”. - TEXT-Mode: This option is only available when displaying just a text. The Text Attribute values are stored in the graphic area of display memory. For more details see the T6963C datasheet.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<code>Spi_T6963C_Write_Char("A", 22, 23, T6963C_ROM_MODE_AND)</code>

Spi_T6963C_write_text

Prototype	sub procedure Spi_T6963C_Write_Text(dim byref str as byte [10] , dim x, y, mode as byte)
Description	Writes text in the current text panel of GLCD at coordinates (x, y). Parameters : - str: text to be written - x: text position on x-axis - y: text position on y-axis - mode: mode parameter. Valid values: T6963C_ROM_MODE_OR, T6963C_ROM_MODE_XOR, T6963C_ROM_MODE_AND and T6963C_ROM_MODE_TEXT Mode parameter explanation: - OR Mode: In the OR-Mode, text and graphics can be displayed and the data is logically “OR-ed”. This is the most common way of combining text and graphics for example labels on buttons. - XOR-Mode: In this mode, the text and graphics data are combined via the logical “exclusive OR”. This can be useful to display text in negative mode, i.e. white text on black background. - AND-Mode: The text and graphic data shown on the display are combined via the logical “AND function”. - TEXT-Mode: This option is only available when displaying just a text. The Text Attribute values are stored in the graphic area of display memory. For more details see the T6963C datasheet.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	Spi_T6963C_Write_Text("GLCD LIBRARY DEMO, WELCOME !", 0, 0, T6963C_ROM_MODE_XOR)



Spi_T6963C_line

Prototype	sub procedure Spi_T6963C_Line(dim x0, y0, x1, y1 as integer , dim pcolor as byte)
Description	Draws a line from (x0, y0) to (x1, y1). Parameters : - x0: x coordinate of the line start - y0: y coordinate of the line end - x1: x coordinate of the line start - y1: y coordinate of the line end - pcolor: color parameter. Valid values: T6963C_BLACK and T6963C_WHITE
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	Spi_T6963C_Line(0, 0, 239, 127, T6963C_WHITE)

Spi_T6963C_rectangle

Prototype	sub procedure Spi_T6963C_Rectangle(dim x0, y0, x1, y1 as integer , dim pcolor as byte)
Description	Draws a rectangle on GLCD. Parameters : - x0: x coordinate of the upper left rectangle corner - y0: y coordinate of the upper left rectangle corner - x1: x coordinate of the lower right rectangle corner - y1: y coordinate of the lower right rectangle corner - pcolor: color parameter. Valid values: T6963C_BLACK and T6963C_WHITE
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	Spi_T6963C_Rectangle(20, 20, 219, 107, T6963C_WHITE)

Spi_T6963C_box

Prototype	sub procedure Spi_T6963C_Box(dim x0, y0, x1, y1 as integer , dim pcolor as byte)
Description	Draws a box on the GLCD Parameters : - x0: x coordinate of the upper left box corner - y0: y coordinate of the upper left box corner - x1: x coordinate of the lower right box corner - y1: y coordinate of the lower right box corner - pcolor: color parameter. Valid values: T6963C_BLACK and T6963C_WHITE
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	Spi_T6963C_Box(0, 119, 239, 127, T6963C_WHITE)

Spi_T6963C_circle

Prototype	sub procedure Spi_T6963C_Circle(dim x, y as integer , dim r as longint , dim pcolor as word)
Description	Draws a circle on the GLCD. Parameters : - x: x coordinate of the circle center - y: y coordinate of the circle center - r: radius size - pcolor: color parameter. Valid values: T6963C_BLACK and T6963C_WHITE
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	Spi_T6963C_Circle(120, 64, 110, T6963C_WHITE)



Spi_T6963C_image

Prototype	<code>sub procedure Spi_T6963C_Image(dim const pic as ^byte)</code>
Description	Displays bitmap on GLCD. Parameters : - <code>pic</code>: image to be displayed. Bitmap array can be located in both code and RAM (due to the mikroBasic for dsPIC30 pointer to const and pointer to RAM equivalency). Use the mikroBasic's integrated GLCD Bitmap Editor (menu option Tools > GLCD Bitmap Editor) to convert image to a constant array suitable for displaying on GLCD.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<code>Spi_T6963C_Image(my_image)</code>

Spi_T6963C_sprite

Prototype	<code>sub procedure Spi_T6963C_Sprite(dim px, py as byte, dim const pic as ^byte, dim sx, sy as byte)</code>
Description	Fills graphic rectangle area (px, py) to (px+sx, py+sy) with custom size picture. Parameters : - <code>px</code>: x coordinate of the upper left picture corner - <code>py</code>: y coordinate of the upper left picture corner - <code>pic</code>: picture to be displayed - <code>sx</code>: picture width - <code>sy</code>: picture height
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<code>Spi_T6963C_Sprite(76, 4, einstein, 88, 119) ' draw a sprite</code>

Spi_T6963C_set_cursor


Prototype	sub procedure Spi_T6963C_Set_Cursor(dim x, y as byte)
Description	Sets cursor to row x and column y. Parameters : - x: cursor position row number - y: cursor position column number
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	Spi_T6963C_Set_Cursor(cposx, cposy)

Spi_T6963C_clearBit

Prototype	sub procedure Spi_T6963C_ClearBit(dim b as byte)
Description	Clears control port bit(s). Parameters : - b: bit mask. The function will clear bit x on control port if bit x in bit mask is set to 1.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<i>' clear bits 0 and 1 on control port</i> Spi_T6963C_ClearBit(0x0003)

Spi_T6963C_setBit

Prototype	sub procedure Spi_T6963C_SetBit(dim b as byte)
Description	Sets control port bit(s). Parameters : - b: bit mask. The function will set bit x on control port if bit x in bit mask is set to 1.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<i>' set bits 0 and 1 on control port</i> Spi_T6963C_SetBit(0x0003)



Spi_T6963C_negBit

Prototype	sub procedure Spi_T6963C_NegBit(dim b as byte)
Description	Negates control port bit(s). Parameters : - b: bit mask. The function will negate bit x on control port if bit x in bit mask is set to 1.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<i>' negate bits 0 and 1 on control port</i> Spi_T6963C_NegBit(0x0003)

Spi_T6963C_displayGrPanel

Prototype	sub procedure Spi_T6963C_DisplayGrPanel(dim n as word)
Description	Display selected graphic panel. Parameters : - n: graphic panel number. Valid values: 0 and 1.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<i>' display graphic panel 1</i> Spi_T6963C_DisplayGrPanel(1)

Spi_T6963C_displayTxtPanel

Prototype	sub procedure Spi_T6963C_DisplayTxtPanel(dim n as word)
Description	Display selected text panel. Parameters : - n: text panel number. Valid values: 0 and 1.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<i>' display text panel 1</i> Spi_T6963C_DisplayTxtPanel(1)

Spi_T6963C_setGrPanel


Prototype	sub procedure Spi_T6963C_SetGrPanel (dim n as word)
Description	Compute start address for selected graphic panel and set appropriate internal pointers. All subsequent graphic operations will be preformed at this graphic panel. Parameters : - n: graphic panel number. Valid values: 0 and 1
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<pre>' set graphic panel 1 as current graphic panel. Spi_T6963C_SetGrPanel(1)</pre>

Spi_T6963C_setTxtPanel

Prototype	sub procedure Spi_T6963C_SetTxtPanel (dim n as word)
Description	Compute start address for selected text panel and set appropriate internal pointers. All subsequent text operations will be preformed at this text panel. Parameters : - n: text panel number. Valid values: 0 and 1.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<pre>' set text panel 1 as current text panel. Spi_T6963C_SetTxtPanel(1)</pre>

Spi_T6963C_panelFill

Prototype	sub procedure Spi_T6963C_PanelFill (dim v as word)
Description	Fill current panel in full (graphic+text) with appropriate value (0 to clear). Parameters : - v: value to fill panel with.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<pre>' clear current panel Spi_T6963C_PanelFill(0)</pre>



Spi_T6963C_grFill

509

page

Prototype	sub procedure Spi_T6963C_GrFill(dim v as word)
Description	Fill current graphic panel with appropriate value (0 to clear). Parameters : - v: value to fill graphic panel with.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<i>' clear current graphic panel</i> Spi_T6963C_GrFill(0)

Spi_T6963C_txtFill

Prototype	sub procedure Spi_T6963C_TxtFill(dim v as word)
Description	Fill current text panel with appropriate value (0 to clear). Parameters : - v: this value increased by 32 will be used to fill text panel.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<i>' clear current text panel</i> Spi_T6963C_TxtFill(0)

Spi_T6963C_cursor_height

Prototype	sub procedure Spi_T6963C_Cursor_Height(dim n as byte)
Description	Set cursor size. Parameters : - n: cursor height. Valid values: 0..7.
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	Spi_T6963C_Cursor_Height(7)

Spi_T6963C_graphics


Prototype	sub procedure Spi_T6963C_Graphics(dim n as word)
Description	Enable/disable graphic displaying. Parameters : - n: graphic enable/disable parameter. Valid values: 0 (disable graphic displaying) and 1 (enable graphic displaying).
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<pre>' enable graphic displaying Spi_T6963C_Graphics(1)</pre>

Spi_T6963C_text

Prototype	sub procedure Spi_T6963C_Text(dim n as word)
Description	Enable/disable text displaying. Parameters : - n: text enable/disable parameter. Valid values: 0 (disable text displaying) and 1 (enable text displaying).
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<pre>' enable text displaying Spi_T6963C_Text(1)</pre>

Spi_T6963C_cursor

Prototype	sub procedure Spi_T6963C_Cursor(dim n as word)
Description	Set cursor on/off. Parameters : - n: on/off parameter. Valid values: 0 (set cursor off) and 1 (set cursor on).
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<pre>' set cursor on Spi_T6963C_Cursor(1)</pre>



Spi_T6963C_cursor_blink

Prototype	<code>sub procedure Spi_T6963C_Cursor_Blink(dim n as word)</code>
Description	Enable/disable cursor blinking. Parameters : - n: cursor blinking enable/disable parameter. Valid values: 0 (disable cursor blinking) and 1 (enable cursor blinking).
Requires	Toshiba GLCD module needs to be initialized. See the Spi_T6963C_Init routine.
Example	<pre>' enable cursor blinking Spi_T6963C_Cursor_Blink(1)</pre>

Library Example

The following drawing demo tests advanced routines of the Spi T6963C GLCD library.

```
program Spi_T6963C_240x128

include __Lib_T6963CConst
include bitmap
include bitmap2

dim    panel as byte           '* current panel
      i as word               '* general purpose register
      curs as byte            '* cursor visibility
      cposx,
      cposy as word           '* cursor x-y position
      txtcols as byte         '* number of text colons

main:
    ADPCFG = 0xFFFF
    PORTB  = 0
    TRISB  = 0xFF

    ' continues ...
```

```
' continued ...

'* init display for 240 pixel width and 128 pixel height
'* 8 bits character width
'* data bus on MCP23S17 portB
'* control bus on MCP23S17 portA
'* bit 2 is !WR
'* bit 1 is !RD
'* bit 0 is !CD
'* bit 4 is RST
'* chip enable, reverse on, 8x8 font internaly set in library
' for faster spi communication use Spi_Init_Advanced routine
Spi1_Init()
Spi_T6963C_Init_240x128()
Spi_T6963C_panelFill(0)

'* enable both graphics and text display at the same time

Spi_T6963C_graphics(1)
Spi_T6963C_text(1)

panel = 0
i = 0
curs = 0
cposy = 0
cposx = 0
txtcols = 240 div 8      '* calculate number of text colomns
                        '* (grafic display width divided by font width)
'* text messages

Spi_T6963C_write_text(" GLCD LIBRARY DEMO, WELCOME !", 0, 0,
T6963C_ROM_MODE_XOR)
Spi_T6963C_write_text(" EINSTEIN WOULD HAVE LIKED mE", 0, 15,
T6963C_ROM_MODE_XOR)

'* cursor

Spi_T6963C_cursor_height(8)      '* 8 pixel height
Spi_T6963C_set_cursor(0, 0)      '* move cursor to top left
Spi_T6963C_cursor(0)             '* cursor off

'* draw rectangles

Spi_T6963C_rectangle(0, 0, 239, 127, T6963C_WHITE)
Spi_T6963C_rectangle(20, 20, 219, 107, T6963C_WHITE)
Spi_T6963C_rectangle(40, 40, 199, 87, T6963C_WHITE)
Spi_T6963C_rectangle(60, 60, 179, 67, T6963C_WHITE)

' continues ...
```

```
' continued ...

'* draw a cross

Spi_T6963C_line(0, 0, 239, 127, T6963C_WHITE)
Spi_T6963C_line(0, 127, 239, 0, T6963C_WHITE)

'* draw solid boxes

Spi_T6963C_box(0, 0, 239, 8, T6963C_WHITE)
Spi_T6963C_box(0, 119, 239, 127, T6963C_WHITE)

'* draw circles

Spi_T6963C_circle(120, 64, 10, T6963C_WHITE)
Spi_T6963C_circle(120, 64, 30, T6963C_WHITE)
Spi_T6963C_circle(120, 64, 50, T6963C_WHITE)
Spi_T6963C_circle(120, 64, 70, T6963C_WHITE)
Spi_T6963C_circle(120, 64, 90, T6963C_WHITE)
Spi_T6963C_circle(120, 64, 110, T6963C_WHITE)
Spi_T6963C_circle(120, 64, 130, T6963C_WHITE)

Spi_T6963C_sprite(76, 4, einstein, 88, 119)    '* draw a sprite

Spi_T6963C_setGrPanel(1)    '* select other graphic panel

Spi_T6963C_image(mikrobasic_glcd_bmp)
'* fill the graphic screen with a picture

while true
    '*
    '* if RB1 is pressed, toggle the display between graphic
    '* panel 0 and graphic 1
    '*
    if(PORTB.1 <> 0) then
        panel = panel + 1
        panel = panel and 1
        Spi_T6963C_displayGrPanel(panel)
        Delay_ms(300)

    '* if RB2 is pressed, display only graphic panel
    '*
    else
        if(PORTB.2 <> 0) then
            Spi_T6963C_graphics(1)
            Spi_T6963C_text(0)
            Delay_ms(300)


' continues ...
```

```
' continued ...
    else '* if RB3 is pressed, display only text panel
        if(PORTB.3 <> 0) then
            Spi_T6963C_graphics(0)
            Spi_T6963C_text(1)
            Delay_ms(300)
        else '* if RB4 is pressed, display text and graphic panels
            if(PORTB.4 <> 0) then
                Spi_T6963C_graphics(1)
                Spi_T6963C_text(1)
                Delay_ms(300)
            else '* if RB5 is pressed, change cursor
                if(PORTB.5 <> 0) then
                    curs = curs + 1
                    if(curs = 3) then
                        curs = 0
                    end if
                    select case curs
                        case 0
                            Spi_T6963C_cursor(0)

                        case 1
                            Spi_T6963C_cursor(1)
                            Spi_T6963C_cursor_blink(1)

                        case 2
                            Spi_T6963C_cursor(1)
                            Spi_T6963C_cursor_blink(0)
                    end select
                    Delay_ms(300)
                end if
            end if
        end if
    end if
    '* move cursor, even if not visible
    cposx = cposx + 1
    if(cposx = txtcols) then
        cposx = 0
        cposy = cposy + 1
        if(cposy = (128 div T6963C_CHARACTER_HEIGHT)) then
            '* if y end
            cposy = 0 '* grafic height (128) div character height
        end if
    end if
    Spi_T6963C_set_cursor(cposx, cposy)
    Delay_ms(100)
wend
end.
```

Hardware Connection



T6963C Graphic LCD Library

mikroBasic for dsPIC30/33 and PIC24 provides a library for working with GLCDs based on TOSHIBA T6963C controller. The Toshiba T6963C is a very popular LCD controller for the use in small graphics modules. It is capable of controlling displays with a resolution up to 240x128. Because of its low power and small outline it is most suitable for mobile applications such as PDAs, MP3 players or mobile measurement equipment. Although small, this controller has a capability of displaying and merging text and graphics and it manages all the interfacing signals to the displays Row and Column drivers.

For creating a custom set of GLCD images use the GLCD Bitmap Editor Tool.

Note: When using this library with the dsPIC33 and PIC24 family MCUs be aware of their voltage incompatibility with a certain number of T6963C based GLCD modules. So, additional external power supply for these modules may be required.

Note: ChipEnable(CE), FontSelect(FS) and Reverse(MD) have to be set to appropriate levels by the user outside of the T6963C_Init() function. See the Library Example code at the bottom of this page.

Note: GLCD size based initialization routines can be found in setup library files located in the Uses folder. The user must make sure that used MCU has appropriate ports and pins. If this is not the case the user should adjust initialization routines.

Note: Some mikroElektronika's adapter boards have pinout different from T6369C datasheets. Appropriate relations between these labels are given in the table below:

Adapter Board	T6369C datasheet
RS	C/D
R/W	/RD
E	/WR

Library Routines

517

page

T6963C_Init
 T6963C_WriteData
 T6963C_WriteCommand
 T6963C_SetPtr
 T6963C_WaitReady
 T6963C_Fill
 T6963C_Dot
 T6963C_Write_Char
 T6963C_Write_Text
 T6963C_Line
 T6963C_Rectangle
 T6963C_Box
 T6963C_Circle
 T6963C_Image
 T6963C_Sprite
 T6963C_Set_Cursor
 T6963C_ClearBit
 T6963C_SetBit
 T6963C_NegBit
 T6963C_DisplayGrPanel
 T6963C_DisplayTxtPanel
 T6963C_SetGrPanel
 T6963C_SetTxtPanel
 T6963C_PanelFill
 T6963C_GrFill
 T6963C_TxtFill
 T6963C_Cursor_Height
 T6963C_Graphics
 T6963C_Text
 T6963C_Cursor
 T6963C_Cursor_Blink

T6963C_Init

Prototype	<pre>sub procedure T6963C_Init(dim width, height, fntW as word, dim byref data as word, dim byref cntrl as word, dim wr, rd, cd, rst as word)</pre>						
Description	Initializes the Graphic Lcd controller. Parameters : - width: width of the GLCD panel - height: height of the GLCD panel - fntW: font width - data: data PORT - cntrl: control PORT - wr: write signal pin - rd: read signal pin - cd: command/data signal pin - rst: reset signal pin Display RAM organization: The library cuts the RAM into panels : a complete panel is one graphics panel followed by a text panel (see schematic below). <table border="1"> <tbody> <tr> <td>GRAPHICS PANEL #0</td><td rowspan="2">PANEL 0</td></tr> <tr> <td>TEXT PANEL #0</td></tr> <tr> <td>GRAPHICS PANEL #1</td><td rowspan="2">PANEL 1</td></tr> <tr> <td>TEXT PANEL #2</td></tr> </tbody> </table> <i>' continues on the next page ...</i>	GRAPHICS PANEL #0	PANEL 0	TEXT PANEL #0	GRAPHICS PANEL #1	PANEL 1	TEXT PANEL #2
GRAPHICS PANEL #0	PANEL 0						
TEXT PANEL #0							
GRAPHICS PANEL #1	PANEL 1						
TEXT PANEL #2							

' continued from the previous page ...	
Example	<pre>T6963C_Init(240, 128, 8, PORTF, PORTD, 2, 1, 0, 4) ' init display for 240 pixel width and 128 pixel height ' 8 bits character width ' data bus on PORTF ' control bus on PORTD ' bit 2 is !WR ' bit 1 is !RD ' bit 0 is !CD ' bit 4 is RST</pre>

T6963C_writeData

Prototype	sub procedure T6963C_WriteData(dim data as byte)
Description	Writes data to T6963C controller. Parameters : - data: data to be written
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_WriteData(AddrL)

T6963C_writeCommand

Prototype	sub procedure T6963C_WriteCommand(dim data as byte)
Description	Writes command to the T6963C controller. Parameters : - data: command to be written
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_WriteCommand(T6963C_CURSOR_POINTER_SET)

T6963C_setPtr

Prototype	sub procedure T6963C_SetPtr (dim p as word, dim c as byte)
Description	Sets the memory pointer p for command c. Parameters : - p: address where command should be written - c: command to be written
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_SetPtr(T6963C_grHomeAddr + start, T6963C_ADDRESS_POINTER_SET)

T6963C_waitReady

Prototype	sub procedure T6963C_WaitReady()
Description	Pools the status byte, and loops until Toshiba GLCD module is ready.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_WaitReady()

T6963C_fill

Prototype	sub procedure T6963C_Fill(dim v as byte, dim start, len as word)
Description	Fills controller memory block with given byte. Parameters : - v: byte to be written - start: starting address of the memory block - len: length of the memory block in bytes
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_Fill(0x33, 0x00FF, 0x000F)




T6963C_dot

Prototype	<code>sub procedure T6963C_Dot(dim x, y as integer, dim color as byte)</code>
Description	Draws a dot in the current graphic panel of GLCD at coordinates (x, y). Parameters : - x: dot position on x-axis - y: dot position on y-axis - color: color parameter. Valid values: T6963C_BLACK and T6963C_WHITE
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<code>T6963C_Dot(x0, y0, pcolor)</code>

T6963C_write_char

Prototype	sub procedure T6963C_Write_Char(dim c, x, y, mode as byte)
Description	Writes a char in the current text panel of GLCD at coordinates (x, y). Parameters : - c: char to be written - x: char position on x-axis - y: char position on y-axis - mode: mode parameter. Valid values: T6963C_ROM_MODE_OR, T6963C_ROM_MODE_XOR, T6963C_ROM_MODE_AND and T6963C_ROM_MODE_TEXT Mode parameter explanation: - OR Mode: In the OR-Mode, text and graphics can be displayed and the data is logically “OR-ed”. This is the most common way of combining text and graphics, for example labels on buttons. - XOR-Mode: In this mode, the text and graphics data are combined via the logical “exclusive OR”. This can be useful to display text in the negative mode, i.e. white text on black background. - AND-Mode: The text and graphic data shown on display are combined via the logical “AND function”. - TEXT-Mode: This option is only available when displaying just a text. The Text Attribute values are stored in the graphic area of display memory. For more details see the T6963C datasheet.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_Write_Char("A", 22, 23, AND)



T6963C_write_text


Prototype	<code>sub procedure T6963C_Write_Text(dim byref str as byte[10] , dim x, y, mode as byte)</code>
Description	Writes text in the current text panel of GLCD at coordinates (x, y). Parameters : - str: text to be written - x: text position on x-axis - y: text position on y-axis - mode: mode parameter. Valid values: T6963C_ROM_MODE_OR, T6963C_ROM_MODE_XOR, T6963C_ROM_MODE_AND and T6963C_ROM_MODE_TEXT Mode parameter explanation: - OR Mode: In the OR-Mode, text and graphics can be displayed and the data is logically “OR-ed”. This is the most common way of combining text and graphics, for example labels on buttons. - XOR-Mode: In this mode, the text and graphics data are combined via the logical “exclusive OR”. This can be useful to display text in the negative mode, i.e. white text on black background. - AND-Mode: The text and graphic data shown on display are combined via the logical “AND function”. - TEXT-Mode: This option is only available when displaying just a text. The Text Attribute values are stored in the graphic area of display memory. For more details see the T6963C datasheet.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<code>T6963C_Write_Text("GLCD LIBRARY DEMO, WELCOME !", 0, 0, T6963C_ROM_MODE_XOR)</code>

T6963C_line

Prototype	sub procedure T6963C_Line(dim x0, y0, x1, y1 as integer , dim pcolor as byte)
Description	Draws a line from (x0, y0) to (x1, y1). Parameters : - x0: x coordinate of the line start - y0: y coordinate of the line end - x1: x coordinate of the line start - y1: y coordinate of the line end - pcolor: color parameter. Valid values: T6963C_BLACK and T6963C_WHITE
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_Line(0, 0, 239, 127, T6963C_WHITE)

T6963C_rectangle

Prototype	sub procedure T6963C_Rectangle(dim x0, y0, x1, y1 as integer , dim pcolor as byte)
Description	Draws a rectangle on GLCD. Parameters : - x0: x coordinate of the upper left rectangle corner - y0: y coordinate of the upper left rectangle corner - x1: x coordinate of the lower right rectangle corner - y1: y coordinate of the lower right rectangle corner - pcolor: color parameter. Valid values: T6963C_BLACK and T6963C_WHITE
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_Rectangle(20, 20, 219, 107, T6963C_WHITE)



T6963C_box

525

page

Prototype	sub procedure T6963C_Box(dim x0, y0, x1, y1 as integer , dim pcolor as byte)
Description	Draws a box on GLCD Parameters : - x0: x coordinate of the upper left box corner - y0: y coordinate of the upper left box corner - x1: x coordinate of the lower right box corner - y1: y coordinate of the lower right box corner - pcolor: color parameter. Valid values: T6963C_BLACK and T6963C_WHITE
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_Box(0, 119, 239, 127, T6963C_WHITE)

T6963C_circle


Prototype	sub procedure T6963C_Circle(dim x, y as integer , dim r as longint , dim pcolor as word)
Description	Draws a circle on GLCD. Parameters : - x: x coordinate of the circle center - y: y coordinate of the circle center - r: radius size - pcolor: color parameter. Valid values: T6963C_BLACK and T6963C_WHITE
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_Circle(120, 64, 110, T6963C_WHITE)

T6963C_image

Prototype	sub procedure T6963C_Image(dim const pic as ^byte)
Description	Displays bitmap on GLCD. Parameters : - pic: image to be displayed. Bitmap array can be located in both code and RAM (due to the mikroBasic for dsPIC30 pointer to const and pointer to RAM equivalency). Use the mikroBasic's integrated GLCD Bitmap Editor (menu option Tools › GLCD Bitmap Editor) to convert image to a constant array suitable for displaying on GLCD.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_Image(my_image)

T6963C_sprite

Prototype	sub procedure T6963C_Sprite(dim px, py as byte , dim const pic as ^byte , dim sx, sy as byte)
Description	Fills graphic rectangle area (px, py) to (px+sx, py+sy) with custom size picture. Parameters : - px: x coordinate of the upper left picture corner - py: y coordinate of the upper left picture corner - pic: picture to be displayed - sx: picture width - sy: picture height
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_Sprite(76, 4, einstein, 88, 119) ' draw a sprite



T6963C_set_cursor

Prototype	sub procedure T6963C_Set_Cursor(dim x, y as byte)
Description	Sets cursor to row x and column y. Parameters : - x: cursor position row number - y: cursor position column number
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_Set_Cursor(cposx, cposy)

T6963C_clearBit

Prototype	sub procedure T6963C_ClearBit(dim b as word)
Description	Clears control port bit(s). Parameters : - b: bit mask. The function will clear bit x on control port if bit x in bit mask is set to 1.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<pre>' clear bits 0 and 1 on control port T6963C_ClearBit(0x0003)</pre>

T6963C_setBit

Prototype	sub procedure T6963C_SetBit(dim b as word)
Description	Sets control port bit(s). Parameters : - b: bit mask. The function will set bit x on control port if bit x in bit mask is set to 1.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<pre>' set bits 0 and 1 on control port T6963C_SetBit(0x0003)</pre>

T6963C_negBit


Prototype	sub procedure T6963C_NegBit (dim b as word)
Description	Negates control port bit(s). Parameters : - b: bit mask. The function will negate bit x on control port if bit x in bit mask is set to 1.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<pre>' negate bits 0 and 1 on control port T6963C_NegBit (0x0003)</pre>

T6963C_displayGrPanel

Prototype	sub procedure T6963C_DisplayGrPanel (dim n as word)
Description	Display selected graphic panel. Parameters : - n: graphic panel number. Valid values: 0 and 1.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<pre>' display graphic panel 1 T6963C_DisplayGrPanel (1)</pre>

T6963C_displayTxtPanel

Prototype	sub procedure T6963C_DisplayTxtPanel (dim n as word)
Description	Display selected text panel. Parameters : - n: text panel number. Valid values: 0 and 1.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<pre>' display text panel 1 T6963C_DisplayTxtPanel (1)</pre>



T6963C_setGrPanel

Prototype	sub procedure T6963C_SetGrPanel (dim n as word)
Description	Compute start address for selected graphic panel and set appropriate internal pointers. All subsequent graphic operations will be preformed at this graphic panel. Parameters : - n: graphic panel number. Valid values: 0 and 1.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<pre>' set graphic panel 1 as current graphic panel. T6963C_SetGrPanel(1)</pre>

T6963C_setTxtPanel

Prototype	sub procedure T6963C_SetTxtPanel (dim n as word)
Description	Compute start address for selected text panel and set appropriate internal pointers. All subsequent text operations will be preformed at this text panel. Parameters : - n: text panel number. Valid values: 0 and 1.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<pre>' set text panel 1 as current text panel. T6963C_SetTxtPanel(1)</pre>

T6963C_panelFill

Prototype	sub procedure T6963C_PanelFill (dim v as word)
Description	Fill current panel in full (graphic+text) with appropriate value (0 to clear). Parameters : - v: value to fill panel with.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<pre>' clear current panel T6963C_PanelFill(0)</pre>

T6963C_grFill


Prototype	sub procedure T6963C_GrFill(dim v as word)
Description	Fill current graphic panel with appropriate value (0 to clear). Parameters : - v: value to fill graphic panel with.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<i>' clear current graphic panel</i> T6963C_GrFill(0)

T6963C_txtFill

Prototype	sub procedure T6963C_TxtFill(dim v as word)
Description	Fill current text panel with appropriate value (0 to clear). Parameters : - v: this value increased by 32 will be used to fill text panel.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<i>' clear current text panel</i> T6963C_TxtFill(0)

T6963C_cursor_height

Prototype	sub procedure T6963C_Cursor_Height(dim n as word)
Description	Set cursor size. Parameters : - n: cursor height. Valid values: 0..7.
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	T6963C_Cursor_Height(7)



T6963C_graphics

Prototype	sub procedure T6963C_Graphics(dim n as word)
Description	Enable/disable graphic displaying. Parameters : - n: on/off parameter. Valid values: 0 (disable graphic displaying) and 1 (enable graphic displaying).
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<pre>' enable graphic displaying T6963C_Graphics(1)</pre>

T6963C_text

Prototype	sub procedure T6963C_Text(dim n as word)
Description	Enable/disable text displaying. Parameters : - n: on/off parameter. Valid values: 0 (disable text displaying) and 1 (enable text displaying).
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<pre>' enable text displaying T6963C_Text(1)</pre>

T6963C_cursor

Prototype	sub procedure T6963C_Cursor(dim n as word)
Description	Set cursor on/off. Parameters : - n: on/off parameter. Valid values: 0 (set cursor off) and 1 (set cursor on).
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<pre>' set cursor on T6963C_Cursor(1)</pre>

T6963C_cursor_blink

Prototype	sub procedure T6963C_Cursor_Blink(dim n as word)
Description	Enable/disable cursor blinking. Parameters : - n: on/off parameter. Valid values: 0 (disable cursor blinking) and 1 (enable cursor blinking).
Requires	Toshiba GLCD module needs to be initialized. See the T6963C_Init routine.
Example	<i>' enable cursor blinking</i> T6963C_Cursor_Blink(1)

Library Example

The following drawing demo tests advanced routines of T6963C GLCD library.

```
program T6963C

include __Lib_T6963CConst
include bitmap
include bitmap2

dim    panel as byte           ' current panel
        i as word              ' general purpose register
        curs as byte          ' cursor visibility
        cposx,
        cposy as word         ' cursor x-y position

main:
    ADPCFG = 0xFFFF
    PORTD  = 0
    TRISD  = 0xFF
    TRISB  = 0                ' portb is output only
    PORTB  = %00000000       ' chip enable, reverse on, 8x8 font

    T6963C_init_240x128()
    'T6963C_init(240, 128, 8, PORTB, PORTF, 2, 1, 0, 4)

    ' continues...
```

```
' continued...

    '* enable both graphics and text display at the same time

T6963C_graphics(1)
T6963C_text(1)

panel = 0
i = 0
curs = 0
cposy = 0
cposx = 0

    '* text messages

    T6963C_write_text(" GLCD LIBRARY DEMO, WELCOME !", 0, 0,
T6963C_ROM_MODE_XOR)
    T6963C_write_text(" EINSTEIN WOULD HAVE LIKED mE", 0, 15,
T6963C_ROM_MODE_XOR)

    '* cursor

T6963C_cursor_height(8)          ' 8 pixel height
T6963C_set_cursor(0, 0)          ' move cursor to top left
T6963C_cursor(0)                  ' cursor off

    '* draw rectangles

T6963C_rectangle(0, 0, 239, 127, T6963C_WHITE)
T6963C_rectangle(20, 20, 219, 107, T6963C_WHITE)
T6963C_rectangle(40, 40, 199, 87, T6963C_WHITE)
T6963C_rectangle(60, 60, 179, 67, T6963C_WHITE)

    '* draw a cross

T6963C_line(0, 0, 239, 127, T6963C_WHITE)
T6963C_line(0, 127, 239, 0, T6963C_WHITE)

    '* draw solid boxes

T6963C_box(0, 0, 239, 8, T6963C_WHITE)
T6963C_box(0, 119, 239, 127, T6963C_WHITE)

' continues...
```

```

' continued...

'*
'* draw circles
'*
T6963C_circle(120, 64, 10, T6963C_WHITE)
T6963C_circle(120, 64, 30, T6963C_WHITE)
T6963C_circle(120, 64, 50, T6963C_WHITE)
T6963C_circle(120, 64, 70, T6963C_WHITE)
T6963C_circle(120, 64, 90, T6963C_WHITE)
T6963C_circle(120, 64, 110, T6963C_WHITE)
T6963C_circle(120, 64, 130, T6963C_WHITE)

T6963C_sprite(76, 4, einstein, 88, 119) ' draw a sprite

T6963C_setGrPanel(1)          ' select other graphic panel

T6963C_image(mikrobasic_glcd_bmp)
' fill the graphic screen with a picture

while TRUE
  '* if RD0 is pressed, toggle the display
  '* between graphic panel 0 and graphic 1

  if(PORTD.0 <> 0) then
    panel = panel + 1
    panel = panel and 1
    T6963C_displayGrPanel(panel)
    Delay_ms(300)

  '* if RD1 is pressed, display only graphic panel

  else
    if(PORTD.1 <> 0) then
      T6963C_graphics(1)
      T6963C_text(0)
      Delay_ms(300)

  '* if RD2 is pressed, display only text panel

  else
    if(PORTD.2 <> 0) then
      T6963C_graphics(0)
      T6963C_text(1)
      Delay_ms(300)

' continues...

```

```
' continued...

**
** if RD3 is pressed, display text and graphic panels
**
    else
        if(PORTD.3 <> 0) then
            T6963C_graphics(1)
            T6963C_text(1)
            Delay_ms(300)

**
** if RD4 is pressed, change cursor
**
    else
        if(PORTD.4 <> 0) then
            curs = curs + 1
            if(curs = 3) then
                curs = 0
            end if
            select case curs
                case 0
                    T6963C_cursor(0)

                case 1
                    T6963C_cursor(1)
                    T6963C_cursor_blink(1)

                case 2
                    T6963C_cursor(1)
                    T6963C_cursor_blink(0)
            end select
            Delay_ms(300)
        end if
    end if
end if
end if
end if

' continues...
```

```
' continued...

'*
'* move cursor, even if not visible
'*

cposx = cposx + 1
if(cposx = T6963C_txtCols) then
    cposx = 0
    cposy = cposy + 1
    if(cposy = (T6963C_grHeight div T6963C_CHARACTER_HEIGHT)) then
        cposy = 0
    end if
end if
T6963C_set_cursor(cposx, cposy)
Delay_ms(100)
wend
end.
```

537

page




UART Library

The UART hardware module is available with a number of the dsPIC30/33 and PIC24 MCUs. mikroBasic for dsPIC30/33 and PIC24 UART Library provides comfortable work with the Asynchronous (full duplex) mode.

Note: For the dsPIC30/33 and PIC24 MCUs with the multiple UART modules there are the UART1 (supports UART1 module), UART2 (supports UART2 module) and UART (supports both UART modules) libraries. Switching between the UART modules in the UART library is done by the `Uart_Set_Active` function (both UART modules have to be previously initialized).

Library Routines

<code>Uart1_Init</code>	<code>Uart2_Init</code>
<code>Uart1_Init_Advanced</code>	<code>Uart2_Init_Advanced</code>
<code>Uart1_Data_Ready</code>	<code>Uart2_Data_Ready</code>
<code>Uart1_Read_Char</code>	<code>Uart2_Read_Char</code>
<code>Uart1_Read_Text</code>	<code>Uart2_Read_Text</code>
<code>Uart1_Write_Char</code>	<code>Uart2_Write_Char</code>
<code>Uart1_Write_Text</code>	<code>Uart2_Write_Text</code>
<code>Uart_Init</code>	
<code>Uart_Init_Advanced</code>	
<code>Uart_Data_Ready</code>	
<code>Uart_Read_Char</code>	
<code>Uart_Read_Text</code>	
<code>Uart_Write_Char</code>	
<code>Uart_Write_Text</code>	
<code>Uart_Set_Active</code>	




Uart1_Init

Prototype	<code>sub procedure Uart1_Init(dim baud_rate as longint)</code>
Description	Configures and initializes the UART1 module. The internal UART1 module module is set to: - continue operation in IDLE mode - default Tx and Rx pins - loopback mode disabled - 8-bit data, no parity - 1 STOP bit - transmitter enabled - generate interrupt on transmission end - interrupt on reception enabled - Address Detect mode disabled Parameters : - baud_rate: requested baud rate Refer to the device data sheet for baud rates allowed for specific Fosc. Note: For the dsPIC33 and pic24 MCUs, the compiler will choose at which speed the calculation is to be performed (high or low). This does not mean that it is the best choice for desired baud rate. If the baud rate error generated in this way is too big then the Uart1_Init_Advanced routine, which allows speed selection, should be used.
Requires	MCU with the UART1 module.
Example	<pre>' Initialize hardware UART and establish communication ' at 2400 bps Uart1_Init(2400)</pre>

Uart1_Init_Advanced

Prototype (dsPIC30)	sub procedure Uart1_Init_Advanced(dim baud_rate as longint, dim parity, stop_bits as word)
Prototype (dsPIC33 and pic24)	sub procedure Uart1_Init_Advanced(dim baud_rate as longint, dim parity, stop_bits as word, dim high_low_speed as word)
Description	Configures and initializes the UART1 module. Parameters : - baud_rate: requested baud rate - parity: parity and data selection parameter. Valid values: 6 : 9-bit data, no parity 4 : 8-bit data, odd parity 2 : 8-bit data, even parity 0 : 8-bit data, no parity - stop_bits: stop bit selection parameter. Valid values: 1 : 2 STOP bits 0 : 1 STOP bit - high_low_speed: high/low speed selection parameter. Available only for dsPIC33 and pic24 MCUs. Valid values: 0 : use low speed calculations 1 : use high speed calculations - other : let the compiler decide which speed (low or high) to use. This does not mean that it is the best choice for desired baud rate Refer to the device data sheet for baud rates allowed for specific <i>Fosc</i>.
Requires	MCU with the UART1 module.
Example	<pre>' dsPIC30 family example ' Initialize hardware UART and establish communication at ' 2400 bps, 8-bit data, even parity and 2 STOP bits Uart1_Init_Advanced(2400, 2, 1) ' dsPIC33 and pic24 family example ' Initialize hardware UART and establish communication at ' 2400 bps, 8-bit data, even parity, 2 STOP bits and high speed ' baud rate calculations Uart1_Init_Advanced(2400, 2, 1, 1)</pre>



Uart1_Data_Ready


Prototype	sub function Uart1_Data_Ready() as word
Returns	- 1 if data is ready for reading - 0 if there is no data in the receive register
Description	The function tests if the data in receive buffer is ready for reading.
Requires	MCU with the UART1 module. The UART1 module must be initialized before using this routine. See the Uart1_Init routine.
Example	<pre> dim receive as word ... ' read data if ready if (Uart1_Data_Ready() = 1) then receive = Uart1_Read_Char() ... </pre>

Uart1_Read_Char

Prototype	sub function Uart1_Read_Char() as word
Returns	Received byte.
Description	The function receives a byte via UART1. Use the Uart1_Data_Ready function to test if data is ready.
Requires	MCU with the UART1 module. The UART1 module must be initialized before using this routine. See the Uart1_Init routine.
Example	<pre> dim receive as word ... ' read data if ready if (Uart1_Data_Ready() = 1) then receive = Uart1_Read_Char() ... </pre>

Uart1_Read_Text

Prototype	sub procedure Uart1_Read_Text(dim byref output, delimiter as string [20])
Description	Procedure receives text via UART1. Received bytes are stored into output string until the delimiter sequence is received. The procedure will end when delimiter is received, otherwise the procedure will end after 20 recieved characters. Parameters : - output: buffer for storing received data - delimiter: delimiter string
Requires	MCU with the UART1 module. The UART1 module must be initialized before using this routine. See the Uart1_Init routine.
Example	<pre>' Read text until the sequence "OK" is received, ' and then send it back: Uart1_Init(9600) delim = "OK" while TRUE if Uart1_Data_Ready() = 1 then Uart1_Read_Text(txt, delim) Uart1_Write_Text(txt) end if wend</pre>



Uart1_Write_Char

Prototype	<code>sub procedure Uart1_Write_Char(dim data as word)</code>
Description	The function transmits a byte via the UART1 module. Parameters : - data: data to be sent
Requires	MCU with the UART1 module. The UART1 module must be initialized before using this routine. See the Uart1_Init routine.
Example	<pre>dim data as byte ... data = 0x1E Uart1_Write_Char(data)</pre>

Uart1_Write_Text

Prototype	<code>sub procedure Uart1_Write_Text(dim byref uart_text as string[20])</code>
Description	Procedure sends text via UART1. Parameters : - uart_text: text to be sent
Requires	MCU with the UART1 module. The UART1 module must be initialized before using this routine. See the Uart1_Init routine.
Example	<pre>Uart1_Write_Text("Hello world!") ' send message via UART</pre>

Uart2_Init

Prototype	sub procedure Uart2_Init(dim baud_rate as longint)
Description	Configures and initializes the UART2 module. The internal UART2 module module is set to: - continue operation in IDLE mode - default Tx and Rx pins - loopback mode disabled - 8-bit data, no parity - 1 STOP bit - transmitter enabled - generate interrupt on transmission end - interrupt on reception enabled - Address Detect mode disabled Parameters : - baud_rate: requested baud rate Refer to the device datasheet for baud rates allowed for specific <i>Fosc</i>. Note: For the dsPIC33 and pic24 MCUs, the compiler will choose at which speed the calculation is to be performed (high or low). This does not mean that it is the best choice for desired baud rate. If the baud rate error generated in this way is too big then the Uart2_Init_Advanced routine, which allows speed selection, should be used.
Requires	MCU with the UART2 module.
Example	<pre>' Initialize hardware UART and establish communication ' at 2400 bps Uart2_Init(2400)</pre>



Uart2_Init_Advanced


Prototype (dsPIC30)	sub procedure Uart2_Init_Advanced(dim baud_rate as longint, dim parity, stop_bits as word)
Prototype (dsPIC33 and pic24)	sub procedure Uart2_Init_Advanced(dim baud_rate as longint, dim parity, stop_bits as word, dim high_low_speed as word)
Description	Configures and initializes the UART2 module. Parameters : - baud_rate: requested baud rate - parity: parity and data selection parameter. Valid values: 6 : 9-bit data, no parity 4 : 8-bit data, odd parity 2 : 8-bit data, even parity 0 : 8-bit data, no parity - stop_bits: stop bit selection parameter. Valid values: 1 : 2 STOP bits 0 : 1 STOP bit - high_low_speed: high/low speed selection parameter. Available only for dsPIC33 and pic24 MCUs. Valid values: 0 : use low speed calculations 1 : use high speed calculations - other : let the compiler decide which speed (low or high) to use. This does not mean that it is the best choice for desired baud rate Refer to the device data sheet for baud rates allowed for specific <i>Fosc</i>.
Requires	MCU with the UART2 module.
Example	<pre>' dsPIC30 family example ' Initialize hardware UART and establish communication at ' 2400 bps, 8-bit data, even parity and 2 STOP bits Uart2_Init_Advanced(2400, 2, 1) ' dsPIC33 and pic24 family example ' Initialize hardware UART and establish communication at ' 2400 bps, 8-bit data, even parity, 2 STOP bits and high speed ' baud rate calculations Uart2_Init_Advanced(2400, 2, 1, 1)</pre>

Uart2_Data_Ready

Prototype	sub function Uart2_Data_Ready() as word
Returns	- 1 if data is ready for reading - 0 if there is no data in the receive register
Description	The function tests if data in receive buffer is ready for reading.
Requires	MCU with the UART2 module. The UART2 module must be initialized before using this routine. See the Uart2_Init routine.
Example	<pre> dim receive as word ... ' read data if ready if (Uart2_Data_Ready() = 1) then receive = Uart2_Read_Char() ... </pre>

Uart2_Read_Char

Prototype	sub function Uart2_Read_Char() as word
Returns	Received byte.
Description	The function receives a byte via UART2. Use the Uart2_Data_Ready function to test if data is ready.
Requires	MCU with the UART2 module. The UART2 module must be initialized before using this routine. See the Uart2_Init routine.
Example	<pre> dim receive as word ... ' read data if ready if (Uart2_Data_Ready() = 1) then receive = Uart2_Read_Char() ... </pre>



Uart2_Read_Text


Prototype	<code>sub procedure Uart2_Read_Text(dim byref output, delimiter as string[20])</code>
Description	Procedure receives text via UART2. Received bytes are stored into output string until the delimiter sequence is received. The procedure will end when delimiter is received, otherwise the procedure will end after 20 recieved characters. Parameters : - output: buffer for storing received data - delimiter: delimiter string
Requires	MCU with the UART2 module. The UART2 module must be initialized before using this routine. See the Uart2_Init routine.
Example	<pre>' Read text until the sequence "OK" is received, ' and then send it back: Uart2_Init(9600) delim = "OK" while TRUE if Uart2_Data_Ready() = 1 then Uart2_Read_Text(txt, delim) Uart2_Write_Text(txt) end if wend</pre>

Uart2_Write_Char

Prototype	sub procedure Uart2_Write_Char(dim data as word)
Description	The function transmits a byte via the UART2 module. Parameters : - data: data to be sent
Requires	MCU with the UART2 module. The UART2 module must be initialized before using this routine. See the Uart2_Init routine.
Example	dim data as byte ... data = 0x1E Uart2_Write_Char(data)

Uart2_Write_Text

Prototype	sub procedure Uart2_Write_Text(dim byref uart_text as string[20])
Description	Procedure sends text via UART2. Parameters : - uart_text: text to be sent
Requires	MCU with the UART2 module. The UART2 module must be initialized before using this routine. See the Uart2_Init routine.
Example	Uart2_Write_Text("Hello world!") ' send message via UART




Uart_Init

Prototype	<code>sub procedure Uart_Init(dim baud_rate as longint)</code>
Description	Configures and initializes the UART1 module. The internal UART1 module module is set to: - continue operation in IDLE mode - default Tx and Rx pins - loopback mode disabled - 8-bit data, no parity - 1 STOP bit - transmitter enabled - generate interrupt on transmission end - interrupt on reception enabled - Address Detect mode disabled Parameters : - <code>baud_rate</code>: requested baud rate Refer to the device data sheet for baud rates allowed for specific <i>Fosc</i>. Note: For the dsPIC33 and pic24 MCUs, the compiler will choose at which speed the calculation is to be performed (high or low). This does not mean that it is the best choice for desired baud rate. If the baud rate error generated in this way is too big then the <code>Uart_Init_Advanced</code> routine, which allows speed selection, should be used.
Requires	MCU with the UART1 module.
Example	<pre>' Initialize hardware UART1 and establish communication ' at 2400 bps Uart_Init(2400)</pre>

Uart_Init_Advanced

Prototype (dsPIC30)	sub procedure Uart_Init_Advanced(dim baud_rate as longint, dim parity, stop_bits as word)
Prototype (dsPIC33 and pic24)	sub procedure Uart_Init_Advanced(dim baud_rate as longint, dim parity, stop_bits as word, dim high_low_speed as word)
Description	Configures and initializes the UART1 module. Parameters : - baud_rate: requested baud rate - parity: parity and data selection parameter. Valid values: 6 : 9-bit data, no parity 4 : 8-bit data, odd parity 2 : 8-bit data, even parity 0 : 8-bit data, no parity - stop_bits: stop bit selection parameter. Valid values: 1 : 2 STOP bits 0 : 1 STOP bit - high_low_speed: high/low speed selection parameter. Available only for dsPIC33 and pic24 MCUs. Valid values: 0 : use low speed calculations 1 : use high speed calculations - other : let the compiler decide which speed (low or high) to use. This does not mean that it is the best choice for desired baud rate Refer to the device data sheet for baud rates allowed for specific <i>Fosc</i>.
Requires	MCU with the UART1 module.
Example	<pre>' dsPIC30 family example ' Initialize hardware UART and establish communication ' at 2400 bps, 8-bit data, even parity and 2 STOP bits Uart_Init_Advanced(2400, 2, 1) ' dsPIC33 and pic24 family example ' Initialize hardware UART and establish communication ' at 2400 bps, 8-bit data, even parity, 2 STOP bits and high ' speed baud rate calculations Uart_Init_Advanced(2400, 2, 1, 1)</pre>



Uart_Data_Ready

Prototype	sub function Uart_Data_Ready() as word
Returns	- 1 if data is ready for reading - 0 if there is no data in the receive register
Description	The function tests if data in receive buffer is ready for reading. Note: if MCU has 2 UART modules, active module will be used. See the Uart_Set_Active routine.
Requires	Routine requires at least one UART module. Used UART module must be initialized before using this function. See the Uart1_Init, Uart1_Init_Advanced, Uart2_Init, Uart2_Init_Advanced, Uart_Init and Uart_Init_Advanced routines.
Example	<pre>dim receive as word ... ' read data if ready if (Uart_Data_Ready()= 1) then receive = Uart_Read_Char()</pre>

Uart_Read_Char

Prototype	sub function Uart_Read_Char() as word
Returns	Received byte.
Description	The function receives a byte via active UART module. Use the Uart_Data_Ready function to test if data is ready.
Requires	Routine requires at least one UART module. For choosing the active module see the Uart_Set_Active routine. Used UART module must be initialized before using this function. See the Uart1_Init, Uart1_Init_Advanced, Uart2_Init, Uart2_Init_Advanced, Uart_Init and Uart_Init_Advanced routines.
Example	<pre>dim receive as word ... ' read data if ready if (Uart_Data_Ready() = 1) then receive = Uart_Read_Char()</pre>

Uart_Read_Text

Prototype	sub procedure Uart_Read_Text(dim byref output, delimiter as string [20])
Description	Procedure receives text via the active UART module. Received bytes are stored into output string until the delimiter sequence is received. The procedure will end when delimiter is received, otherwise the procedure will end after 20 received characters. Parameters : - output: buffer for storing received data - delimiter: delimiter string
Requires	Routine requires at least one UART module. For choosing the active module see the Uart_Set_Active routine. Used UART module must be initialized before using this function. See the Uart1_Init, Uart1_Init_Advanced, Uart2_Init, Uart2_Init_Advanced, Uart_Init and Uart_Init_Advanced routines.
Example	<pre>' Read text until the sequence "OK" is ' received, and then send it back: Uart_Init(9600) delim = "OK" while TRUE if Uart_Data_Ready() = 1 then Uart_Read_Text(txt, delim) Uart_Write_Text(txt) end if wend</pre>



Uart_Write_Char

Prototype	<code>sub procedure Uart_Write_Char(dim data as word)</code>
Description	The function transmits a byte via the active UART module. Parameters : - data: data to be sent
Requires	Routine requires at least one UART module. For choosing the active module see the Uart_Set_Active routine. Used UART module must be initialized before using this function. See the Uart1_Init, Uart1_Init_Advanced, Uart2_Init, Uart2_Init_Advanced, Uart_Init and Uart_Init_Advanced routines.
Example	<pre>dim data as byte ... data = 0x1E Uart_Write_Char(data)</pre>

Uart_Write_Text

Prototype	<code>sub procedure Uart_Write_Text(dim byref uart_text as string[20])</code>
Description	Procedure sends text via active UART module. Parameters : - uart_text: text to be sent
Requires	Routine requires at least one UART module. For choosing the active module see the Uart_Set_Active routine. Used UART module must be initialized before using this function. See the Uart1_Init, Uart1_Init_Advanced, Uart2_Init, Uart2_Init_Advanced, Uart_Init and Uart_Init_Advanced routines.
Example	<pre>Uart_Write_Text("Hello world!") ' send message via UART</pre>

Uart_Set_Active

Prototype	sub procedure Uart_Set_Active(dim UartNo as byte)
Description	Sets the active UART module which will be used by Uart_Data_Ready, Uart_Read_Char, Uart_Read_Text, Uart_Write_Char and Uart_Write_Text routines. Parameters : - UartNo: module number. Valid values: 1 (for UART1) and 2 (for UART2)
Requires	Routine is available only for MCUs with two UART modules. Used UART module must be initialized before using this function. See the Uart1_Init, Uart1_Init_Advanced, Uart2_Init, Uart2_Init_Advanced, Uart_Init and Uart_Init_Advanced routines.
Example	Uart_Set_Active(2) <i>'Sets the UART2 module active</i>

Library Example

The example demonstrates simple data exchange via UART. When the microcontroller receives data, it immediately sends it back. If dsPIC is connected to the PC (see the figure below), you can test the example from the mikroBasic's terminal for the RS-232 communication, menu item **Tools > USART Terminal**.

```
program Uart1_Test

dim rx1 as word

main:

    Uart1_Init(9600)

    while TRUE
        if Uart1_Data_Ready = 1 then
            rx1 = Uart1_Read_Char()
            Uart1_Write_Char(rx1)
        end if
    wend

end.
```

Here's a simple test for chips with 2 UART modules:

```
program Uart2_Test


dim rx2 as word

main:
    Uart2_Init(9600)
    while true
        if Uart2_Data_Ready = 1 then
            rx2=Uart2_Read_Char
            Uart2_Write_Char(rx2)
        end if
    wend
end.
```


Hardware Connection

556

page



Conversions Library

mikroBasic for dsPIC30/33 and PIC24 Conversions Library provides routines for numerals to strings and BCD/decimal conversions.

Library Routines

You can get text representation of numerical value by passing it to one of the following routines:

```
ByteToStr
ShortToStr
WordToStr
WordToStrWithZeros
IntToStr
LongintToStr
LongWordToStr
WordToHex
FloatToStr
StrToInt
StrToWord
```

The following functions convert decimal values to BCD and vice versa:


```
Dec2Bcd
Bcd2Dec16
Dec2Bcd16
```

ByteToStr

Prototype	sub procedure ByteToStr(dim input as byte, dim byref output as string[3])
Description	Converts input byte to a string. The output string is right justified and remaining positions on the left (if any) are filled with blanks. Parameters : - input: byte to be converted - output: destination string
Example	<pre> dim t as byte txt as string[3] ... t = 24 ByteToStr(t, txt) ' txt is " 24" (one blank here) </pre>

ShortToStr

Prototype	sub procedure ShortToStr(dim input as short, dim byref output as string[4])
Description	Converts input short (signed byte) number to a string. The output string is right justified and remaining positions on the left (if any) are filled with blanks. Parameters : - input: short number to be converted - output: destination string
Example	<pre> dim t as short txt as string[4] ... t = -24 ByteToStr(t, txt) ' txt is " -24" (one blank here) </pre>



WordToStr

Prototype	<code>sub procedure WordToStr(dim input as word, dim byref output as string[5])</code>
Description	Converts input word to a string. The output string is right justified and the remaining positions on the left (if any) are filled with blanks. Parameters : - input: word to be converted - output: destination string
Example	<pre>dim t as word txt as string[5] ... t = 437 WordToStr(t, txt) ' txt is " 437" (two blanks here)</pre>

WordToStrWithZeros

Prototype	<code>sub procedure WordToStrWithZeros(dim input as word, dim byref output as string[5])</code>
Description	Converts input word to a string. The output string is right justified and the remaining positions on the left (if any) are filled with zeros. Parameters : - input: word to be converted - output: destination string
Example	<pre>dim t as word txt as string[5] ... t = 437 WordToStrWithZeros(t, txt) ' txt is '00437'</pre>

IntToStr

Prototype	sub procedure IntToStr(dim input as integer, dim byref output as string[6])
Description	Converts input integer number to a string. The output string is right justified and the remaining positions on the left (if any) are filled with blanks. Parameters : - input: integer number to be converted - output: destination string
Example	<pre> dim input as integer txt as string[6] ... input = -4220 IntToStr(input, txt) ' txt is " -4220" </pre>

LongintToStr

Prototype	sub procedure LongintToStr(dim input as longint, dim byref output as string[11])
Description	Converts input longint number to a string. The output string is right justified and the remaining positions on the left (if any) are filled with blanks. Parameters : - input: longint number to be converted - output: destination string
Example	<pre> dim input as longint txt as string[11] ... input = -12345678 IntToStr(input, txt) ' txt is " -12345678" </pre>



LongWordToStr


Prototype	<code>sub procedure LongWordToStr(dim input as dword, dim byref output as string[10])</code>
Description	Converts input double word number to a string. The output string is right justified and the remaining positions on the left (if any) are filled with blanks. Parameters : - input: double word number to be converted - output: destination string
Example	<pre>dim input as longint txt as string[10] ... input = 12345678 IntToStr(input, txt) ' txt is " 12345678"</pre>

WordToHex

Prototype	<code>sub procedure WordToHex(dim input as word, dim byref output as string[4])</code>
Description	Converts input word to hexadecimal digits string. The output string is right justified and the remaining positions on the left (if any) are filled with blanks. Parameters : - input: word to be converted - output: destination string
Example	Here's an example which prints hex value of a word variable on LCD: <pre>dim input as word txt as string[4] ... input = 26 WordToHex(input, txt) ' txt is "001A"</pre>

FloatToStr

Prototype	sub function FloatToStr(dim fnum as real, dim byref str as string[20]) as byte
Returns	- 3 if input number is NaN - 2 if input number is -INF - 1 if input number is +INF - 0 if conversion was successful
Description	Converts a floating point number to a string. Parameters : - fnum: floating point number to be converted - str: destination string The output string is left justified and null terminated after the last digit. Note: Given floating point number will be truncated to 7 most significant digits before conversion.
Example	<pre> dim ff1, ff2, ff3 as real txt as string[20] ... ff1 = -374.2 ff2 = 123.456789 ff3 = 0.000001234 FloatToStr(ff1, txt) ' txt is "-374.2" FloatToStr(ff2, txt) ' txt is "123.4567" FloatToStr(ff3, txt) ' txt is "1.234e-6" </pre>



StrToInt

Prototype	sub function StrToInt(dim byref input as string[6]) as integer
Returns	Integer variable.
Description	Converts a string to an integer. Parameters : - input: string to be converted
Requires	Input string is assumed to be the correct representation of a number. The conversion will end with the first character which is not a decimal digit.
Example	<pre>dim ii as integer ... ii= StrToInt("-1234")</pre>

StrToWord


Prototype	sub function StrToWord(dim byref input as string[6]) as word
Returns	Word variable.
Description	Converts a string to word. Parameters : - input: string to be converted.
Requires	Input string is assumed to be the correct representation of a number. The conversion will end with the first character which is not a decimal digit.
Example	<pre>dim ww as word ... ww = StrToword("65432")</pre>

Dec2Bcd

Prototype	<code>sub function Dec2Bcd (dim decnum as byte) as byte</code>
Returns	Converted BCD value.
Description	Converts input number to its appropriate BCD representation. Parameters : - decnum: number to be converted
Example	<pre>dim a, b as byte ... a = 22 b = Dec2Bcd(a) ' b equals 34</pre>

Bcd2Dec16

Prototype	<code>sub function Bcd2Dec16 (dim bcdnum as word) as word</code>
Returns	Converted decimal value.
Description	Converts 16-bit BCD numeral to its decimal equivalent. Parameters : - bcdnum: 16-bit BCD numeral to be converted
Example	<pre>dim a, b as word ... a = 0x1234 ' a equals 4660 b = Bcd2Dec16(a) ' b equals 1234</pre>



Dec2Bcd16

Prototype	<code>sub function Dec2Bcd16 (dim decnum as word) as word</code>
Returns	Converted BCD value.
Description	Converts decimal value to its BCD equivalent. Parameters : - <code>decnum</code> decimal number to be converted
Example	<pre>dim a, b as word ... a = 2345 b = Dec2Bcd16(a) ' b equals 9029</pre>

Math Library


mikroBasic for dsPIC30/33 and PIC24 provides a set of library functions for floating point math handling. See also Predefined Globals and Constants for the list of predefined math constants.

Library Routines

acos
asin
atan
atan2
ceil
cos
cosh
exp
fabs
floor
frexp
ldexp
log
log10
modf
pow
sin
sinh
sqrt
tan
tanh

acos

Prototype	sub function <code>acos(dim x as real) as real</code>
Description	The function returns the arc cosine of parameter x; that is, the value whose cosine is x. The input parameter x must be between -1 and 1 (inclusive). The return value is in radians, between 0 and pi (inclusive).



asin

Prototype	<code>sub function asin(dim x as real) as real</code>
Description	The function returns the arc sine of parameter x; that is, the value whose sine is x. The input parameter x must be between -1 and 1 (inclusive). The return value is in radians, between $-\pi/2$ and $\pi/2$ (inclusive).

atan

Prototype	<code>sub function atan(dim arg as real) as real</code>
Description	The function computes the arc tangent of parameter arg; that is, the value whose tangent is arg. The return value is in radians, between $-\pi/2$ and $\pi/2$ (inclusive).

atan2

Prototype	<code>sub function atan2(dim y, x as real) as real</code>
Description	This is the two-argument arc tangent function. It is similar to computing the arc tangent of y/x , except that the signs of both arguments are used to determine the quadrant of the result and x is permitted to be zero. The return value is in radians, between $-\pi$ and π (inclusive).

ceil

Prototype	<code>sub function ceil(dim x as real) as real</code>
Description	The function returns value of parameter x rounded up to the next whole number.

cos

Prototype	<code>sub function cos(dim arg as real) as real</code>
Description	The function returns the cosine of arg in radians. The return value is from -1 to 1.

cosh


Prototype	<code>sub function cosh(dim x as real) as real</code>
Description	The function returns the hyperbolic cosine of x, defined mathematically as $(e^x + e^{-x})/2$. If the value of x is too large (if overflow occurs), the function fails.

exp

Prototype	<code>sub function exp(dim x as real) as real</code>
Description	The function returns the value of e — the base of natural logarithms — raised to the power x (i.e. e^x).

fabs

Prototype	<code>sub function fabs(dim dd as real) as real</code>
Description	The function returns the absolute (i.e. positive) value of dd.



floor

569

page

Prototype	<code>sub function floor(dim x as real) as real</code>
Description	The function returns the value of parameter x rounded down to the nearest integer.

frexp

Prototype	<code>sub function frexp(dim byref eptr as integer) as real</code>
Description	The function splits a floating-point value value into a normalized fraction and an integral power of 2. The return value is a normalized fraction and the integer exponent is stored in the object pointed to by eptr.

ldexp

Prototype	<code>sub function ldexp(dim value as real, newexp as integer) as real</code>
Description	The function returns the result of multiplying the floating-point number value by 2 raised to the power newexp (i.e. returns $\text{value} * 2^{\text{newexp}}$).

log

Prototype	<code>sub function log(dim x as real) as real</code>
Description	The function returns the natural logarithm of x (i.e. $\log_e(x)$).

log10

Prototype	<code>sub function log10(dim x as real) as real</code>
Description	Function returns the base-10 logarithm of x (i.e. $\log_{10}(x)$).

modf


Prototype	<code>sub function modf(dim val as real, dim byref iptr as real) as real</code>
Description	The function returns the signed fractional component of val , placing its whole number component into the variable pointed to by $iptr$.

pow

Prototype	<code>sub function pow(dim x, y as real) as real</code>
Description	The function returns the value of x raised to the power y (i.e. x^y). If x is negative, the function will automatically cast y into <code>longint</code> .

sin

Prototype	<code>sub function sin(dim arg as real) as real</code>
Description	The function returns the sine of arg in radians. The return value is from -1 to 1.



sinh

Prototype	<code>sub function sinh(dim x as real) as real</code>
Description	The function returns the hyperbolic sine of x, defined mathematically as $(e^x - e^{-x})/2$. If the value of x is too large (if overflow occurs), the function fails.

sqrt

Prototype	<code>sub function sqrt(dim x as real) as real</code>
Description	The function returns the non negative square root of x.

tan

Prototype	<code>sub function tan(dim x as real) as real</code>
Description	The function returns the tangent of x in radians. The return value spans the allowed range of floating point in mikroBasic for dsPIC30/33 and PIC24.

tanh

Prototype	<code>sub function tanh(dim x as real) as real</code>
Description	The function returns the hyperbolic tangent of x, defined mathematically as $\sinh(x)/\cosh(x)$.

Setjmp Library


The Setjmp library contains functions and types definitions for bypassing the normal function call and return discipline.

Library Routines

Setjmp
Longjmp

Setjmp

Prototype	sub function setjmp(dim byref env as word [4]) as integer
Returns	- 0 if the return is from direct invocation - nonzero value if the return is from a call to longjmp (this value will be set by the longjmp routine)
Description	This function saves calling position for a later use by longjmp. Parameters : - env: buffer suitable for holding information needed for restoring calling environment
Example	dim buf as word [4] ... Setjmp(buf)



Longjmp

Prototype	<code>sub procedure longjmp(dim byref env as word[4] , dim val as integer)</code>
Description	Restores calling environment saved in the env buffer by the most recent invocation of setjmp. If there has been no such invocation, or the function containing the invocation of setjmp has terminated in the interim, the behavior is undefined. Parameters : - env: buffer holding the information saved by the corresponding setjmp invocation - val: value to be returned by the corresponding setjmp function
Requires	Invocation of <code>longjmp</code> must occur before return from the function in which setjmp was called encounters.
Example	<pre>dim buf as word[4] ... Longjmp (buf, 2)</pre>

Library Example

Example demonstrates function cross calling using setjmp and longjmp functions. When called, Setjmp() saves its calling environment in its **buf** argument for later use by the Longjmp(). Longjmp(), on the other hand, restores the environment saved by the most recent invocation of the Setjmp() with the corresponding **buf** argument.

program Setjmp

```
dim buf as word[ 4]
' Note: Program flow diagrams are indexed according
' to the sequence of execution
```

```
sub procedure func33()
    Delay_ms(1000)
```

```
    nop
    longjmp(buf, 2)
    nop
```

end sub

```
sub procedure func()
    PORTB = 3
    if (setjmp(buf) = 2) then
        PORTB = 1
    else
        func33()
    end if
```

end sub

```
main:
    ADPCFG = 0xFFFF
```

```
    PORTB = 0
    TRISB = 0
```

nop

```
func()
```

```
    nop
    Delay_ms(1000)
    PORTB = 0xFFFF
```

end.

String Library

mikroBasic for dsPIC30/33 and PIC24 includes a library which automatizes string related tasks.

```
memchr
memcmp
memcpy
memmove
memset
strcat
strchr
strcmp
strcpy
strcspn
strlen
strncat
strncmp
strncpy
strpbrk
strrchr
strspn
strstr
```

Memchr

Prototype	sub function memchr(dim p as word, dim ch as byte, dim n as word) as word
Description	The function locates the first occurrence of the word ch in the initial n words of memory area starting at the address p. The function returns the offset of this occurrence from the memory address p or \$FFFF if ch was not found. For the parameter p you can use either a numerical value (literal/variable/constant) indicating memory address or a dereferenced value of an object, for example @mystring or @PORTB.

Memcmp

Prototype	sub function memcmp(dim p1, p2, n as word) as integer								
Description	The function returns a positive, negative, or zero value indicating the relationship of first n words of memory areas starting at addresses p1 and p2. This function compares two memory areas starting at addresses p1 and p2 for n words and returns a value indicating their relationship as follows: <table> <tr> <td>Value</td><td>Meaning</td></tr> <tr> <td>< 0</td><td>p1 "less than" p2</td></tr> <tr> <td>= 0</td><td>p1 "equal to" p2</td></tr> <tr> <td>> 0</td><td>p1 "greater than" p2</td></tr> </table> The value returned by the function is determined by the difference between the values of the first pair of words that differ in the strings being compared. For parameters p1 and p2 you can use either a numerical value (literal/variable/constant) indicating memory address or a dereferenced value of an object, for example @mystring or @PORTB.	Value	Meaning	< 0	p1 "less than" p2	= 0	p1 "equal to" p2	> 0	p1 "greater than" p2
Value	Meaning								
< 0	p1 "less than" p2								
= 0	p1 "equal to" p2								
> 0	p1 "greater than" p2								



Memcpy

Prototype	<code>sub procedure memcpy(dim p1, p2, nn as word)</code>
Description	The function copies nn words from the memory area starting at the address p2 to the memory area starting at p1. If these memory buffers overlap, the memcpy function cannot guarantee that words are copied before being overwritten. If these buffers do overlap, use the memmove function. For parameters p1 and p2 you can use either a numerical value (literal/variable/constant) indicating memory address or a dereferenced value of an object, for example @mystring or @PORTB.

Memmove

Prototype	<code>sub procedure memmove(dim p1, p2, nn as word)</code>
Description	The function copies nn words from the memory area starting at the address p2 to the memory area starting at p1. If these memory buffers overlap, the Memmove function ensures that the words in p2 are copied to p1 before being overwritten. For parameters p1 and p2 you can use either a numerical value (literal/variable/constant) indicating memory address or a dereferenced value of an object, for example @mystring or @PORTB.

Memset

Prototype	<code>sub procedure memset(dim p as word, dim character as byte, dim n as word)</code>
Description	The function fills the first n words in the memory area starting at the address p with the value of word character. For parameter p you can use either a numerical value (literal/variable/constant) indicating memory address or a dereferenced value of an object, for example @mystring or @PORTB.

Strcat


Prototype	<code>sub procedure strcat(dim byref s1, s2 as string[100])</code>
Description	The function appends the value of string s2 to string s1 and terminates s1 with a null character.

Strchr

Prototype	<code>sub function strchr(dim byref s as string[100] , dim ch as byte) as word</code>
Description	The function searches the string s for the first occurrence of the character ch. The null character terminating s is not included in the search. The function returns the position (index) of the first character ch found in s; if no matching character was found, the function returns \$FFFF.

Strcmp

Prototype	<code>sub function strcmp(dim byref s1, s2 as string[100]) as integer</code>								
Description	The function lexicographically compares the contents of the strings s1 and s2 and returns a value indicating their relationship: <table> <thead> <tr> <th>Value</th><th>Meaning</th></tr> </thead> <tbody> <tr> <td>< 0</td><td>s1 "less than" s2</td></tr> <tr> <td>= 0</td><td>s1 "equal to" s2</td></tr> <tr> <td>> 0</td><td>s1 "greater than" s2</td></tr> </tbody> </table> The value returned by the function is determined by the difference between the values of the first pair of words that differ in the strings being compared.	Value	Meaning	< 0	s1 "less than" s2	= 0	s1 "equal to" s2	> 0	s1 "greater than" s2
Value	Meaning								
< 0	s1 "less than" s2								
= 0	s1 "equal to" s2								
> 0	s1 "greater than" s2								



Strcpy

Prototype	<code>sub procedure strcpy(dim byref s1, s2 as string[100])</code>
Description	The function copies the value of the string s2 to the string s1 and appends a null character to the end of s1.

Strcspn

Prototype	<code>sub function strcspn(dim byref s1, s2 as string[100]) as word</code>
Description	The function searches the string s1 for any of the characters in the string s2. The function returns the index of the first character located in s1 that matches any character in s2. If the first character in s1 matches a character in s2, a value of 0 is returned. If there are no matching characters in s1, the length of the string is returned (not including the terminating null character).

Strlen

Prototype	<code>sub function strlen(dim byref s as string[100]) as word</code>
Description	The function returns the length, in words, of the string s. The length does not include the null terminating character.

Strncat


Prototype	sub procedure strncat(dim byref s1, s2 as string [100] , dim size as byte)
Description	The function appends at most size characters from the string s2 to the string s1 and terminates s1 with a null character. If s2 is shorter than the size characters, s2 is copied up to and including the null terminating character.

Strncmp

Prototype	sub function strncmp(dim byref s1, s2 as string [100] , dim len as byte) as integer								
Description	The function lexicographically compares the first len words of the strings s1 and s2 and returns a value indicating their relationship: <table> <tr> <th>Value</th><th>Meaning</th></tr> <tr> <td>< 0</td><td>s1 "less than" s2</td></tr> <tr> <td>= 0</td><td>s1 "equal to" s2</td></tr> <tr> <td>> 0</td><td>s1 "greater than" s2</td></tr> </table> The value returned by the function is determined by the difference between the values of the first pair of words that differ in the strings being compared (within first len words).	Value	Meaning	< 0	s1 "less than" s2	= 0	s1 "equal to" s2	> 0	s1 "greater than" s2
Value	Meaning								
< 0	s1 "less than" s2								
= 0	s1 "equal to" s2								
> 0	s1 "greater than" s2								

Strncpy

Prototype	sub procedure strncpy(dim byref s1, s2 as string [100] , dim size as byte)
Description	The function copies at most size characters from the string s2 to the string s1. If s2 contains fewer characters than size, s1 is padded out with null characters up to the total length of the size characters.



Strpbrk

581

page

Prototype	<code>sub procedure strpbrk(dim byref s1, s2 as string[100])</code>
Description	The function searches s1 for the first occurrence of any character from the string s2. The null terminator is not included in the search. The function returns an index of the matching character in s1. If s1 contains no characters from s2, the function returns \$FFFF.

Strrchr

Prototype	<code>sub function strrchr(dim byref s as string[100] , dim ch as byte) as word</code>
Description	The function searches the string s for the last occurrence of the character ch. The null character terminating s is not included in the search. The function returns an index of the last ch found in s; if no matching character was found, the function returns \$FFFF.

Strspn

Prototype	<code>sub function strspn(dim byref s1, s2 as string[100]) as word</code>
Description	The function searches the string s1 for characters not found in the s2 string. The function returns the index of first character located in s1 that does not match a character in s2. If the first character in s1 does not match a character in s2, a value of 0 is returned. If all characters in s1 are found in s2, the length of s1 is returned (not including the terminating null character).

Strstr

Prototype	<code>sub function strstr(dim byref s1, s2 as string[100]) as word</code>
Description	The function locates the first occurrence of the string s2 in the string s1 (excluding the terminating null character). The function returns a number indicating the position of the first occurrence of s2 in s1; if no string was found, the function returns \$FFFF. If s2 is a null string, the function returns 0.

Time Library

The Time Library contains functions and type definitions for time calculations in the UNIX time format which counts the number of seconds since the "epoch". This is very convenient for programs that work with time intervals, the difference between two UNIX time values is a real-time difference measured in seconds.

What is the epoch?

Originally it was defined as the beginning of 1970 GMT. (January 1, 1970 Julian day) GMT, Greenwich Mean Time, is a traditional term for the time zone in England.


The TimeStruct type is a structure type suitable for time and date storage.

Library Routines

```
Time_dateToEpoch
Time_epochToDate
Time_dateDiff
```

Time_dateToEpoch

Prototype	sub function Time_dateToEpoch(dim byref ts as TimeStruct) as longint
Returns	Number of seconds since January 1, 1970 0h00mn00s.
Description	This function returns the unix time : number of seconds since January 1, 1970 0h00mn00s. Parameters : - ts: time and date value for calculating unix time.
Requires	Nothing.
Example	<pre>dim ts1 as TimeStruct Epoch as longint ... ' what is the epoch of the date in ts ? epoch = Time_dateToEpoch(ts1)</pre>



Time_epochToDate

583

page

Prototype	sub procedure Time_epochToDate(dim e as longint, dim byref ts as TimeStruct)
Description	Converts the unix time to time and date. Parameters : - e: unix time (seconds since unix epoch) - ts: time and date structure for storing conversion output
Example	<pre>dim ts2 as TimeStruct epoch as longint ... ' what date is epoch 1234567890 ? epoch = 1234567890 Time_epochToDate(epoch,ts2)</pre>

Time_dateDiff

Prototype	sub function Time_dateDiff(dim byref t1, t2 as TimeStruct) as longint
Returns	Time difference in seconds as a signed long.
Description	This function compares two dates and returns time difference in seconds as a signed long. The result is positive if t1 is before t2, null if t1 is the same as t2 and negative if t1 is after t2. Parameters : - t1: time and date structure (the first comparison parameter) - t2: time and date structure (the second comparison parameter)
Requires	Nothing.
Example	<pre>dim ts1, ts2 as TimeStruct diff as longint ... ' how many seconds between these two dates ' contained in ts1 and ts2 buffers? diff = Time_dateDiff(ts1, ts2)</pre>

Library Example

Demonstration of Time library routines usage for time calculations in UNIX time format.

```

program Time_Demo

    '*
    '* simple time structure
    '*

    structure TimeStruct
        dim ss as byte ' seconds
        dim mn as byte ' minutes
        dim hh as byte ' hours
        dim md as byte ' day in month, from 1 to 31
        dim wd as byte ' day in week, monday=0, tuesday=1...sunday=6
        dim mo as byte
            ' month number, from 1 to 12 (and not from 0 to 11 as with
            ' unix C time !)
        dim yy as word ' year Y2K compliant, from 1892 to 2038
    end structure

    dim ts1, ts2 as TimeStruct
        epoch, diff as longint

    main:
        ts1.ss = 0
        ts1.mn = 7
        ts1.hh = 17
        ts1.md = 23
        ts1.mo = 5
        ts1.yy = 2006

        '*
        '* what is the epoch of the date in ts ?
        '*
        epoch = Time_dateToEpoch(ts1)          ' epoch = 1148404020

' continues...

```

```
' continued...

'*
'* what date is epoch 1234567890 ?
'*

epoch = 1234567890
Time_epochToDate(epoch, ts2)      ' ts2.ss = 30
                                   ' ts2.mn = 31
                                   ' ts2.hh = 23
                                   ' ts2.md = 13
                                   ' ts2.wd = 4
                                   ' ts2.mo = 2
                                   ' ts2.yy = 2009

'*
'* how much seconds between this two dates ?
'*

diff = Time_dateDiff(ts1, ts2)    ' diff = 86163870

end.
```

TimeStruct type definition

```
structure TimeStruct
  dim ss as byte ' seconds
  dim mn as byte ' minutes
  dim hh as byte ' hours
  dim md as byte ' day in month, from 1 to 31
  dim wd as byte ' day in week, monday=0, tuesday=1...sunday=6
  dim mo as byte
    ' month number, from 1 to 12 (and not from 0 to 11 as with
    ' unix C time !)
  dim yy as word ' year Y2K compliant, from 1892 to 2038
end structure
```

Util Library


The Util library contains miscellaneous routines useful for a project development.

Library Routines

Lo
Hi
Higher
Highest
LoWord
HiWord
Length

Lo

Prototype	sub function Lo(dim val as longint) as byte
Returns	Low byte of val, bits 7..0.
Description	The function returns low byte of val. The function does not interpret bit patterns of val – it merely returns 8 bits as found in register. Parameters : - val: input value
Example	<pre>d = 0x1AC30F4 tmp = Lo(d) ' Equals 0xF4</pre>



Hi

587

page

Prototype	sub function Hi(dim val as longint) as byte
Returns	High byte of val, bits 15..8.
Description	The function returns high byte of val. The function does not interpret bit patterns of val – it merely returns 8 bits as found in register. Parameters : - val: input value
Example	<pre>d = 0x1AC30F4 tmp = Hib(d) ' Equals 0x30</pre>

Higher

Prototype	sub function Higher(dim val as longint) as byte
Returns	Higher byte of val, bits 23..16.
Description	The function returns higher byte of val. The function does not interpret bit patterns of val – it merely returns 8 bits as found in register. Parameters : - val: input value
Example	<pre>d = 0x1AC30F4 tmp = Higherb(d) ' Equals 0xAC</pre>

Highest

Prototype	sub function Highest(dim val as longint) as byte
Returns	The highest byte of val, bits 31..24.
Description	The function returns the highest byte of val. The function does not interpret bit patterns of val – it merely returns 8 bits as found in register. Parameters : - val: input value
Example	<pre>d = 0x1AC30F4 tmp = Highestb(d) ' Equals 0x01</pre>

LoWord

Prototype	sub function LoWord(dim val as longint) as word
Returns	Low word of val, bits 15..0.
Description	The function returns low word of val. The function does not interpret bit patterns of val – it merely returns 16 bits as found in register. Parameters : - val: input value
Example	a = LoWord(\$AC10F4) ' <i>Equals \$10F4</i>

HiWord

Prototype	sub function HiWord(dim val as longint) as word
Returns	High word of val, bits 31..16.
Description	The function returns high word of val. The function does not interpret bit patterns of val – it merely returns 16 bits as found in register. Parameters : - val: input value
Example	a = HiWord(\$AC10F4) ' <i>Equals \$00AC</i>

Length

Prototype	sub function Length(dim byref s as string[255]) as word
Returns	Length of the string.
Description	The function returns length of passed string. Parameters : - s: input string
Example	len = Length(name) ' <i>len will contain length of string name</i>

If you are experiencing problems with any of our products or you just want additional information, please let us know.

Technical Support for the compiler

If you are experiencing any trouble with mikroBasic, please do not hesitate to contact us - it is in our mutual interest to solve these issues.

Discount for schools and universities

mikroElektronika offers a special discount for educational institutions. If you would like to purchase mikroBasic for purely educational purposes, please contact us.

Problems with transport or delivery

If you want to report a delay in delivery or any other problem concerning distribution of our products, please use the link given below.

Would you like to become mikroElektronika's distributor?

We in mikroElektronika are looking forward to new partnerships. If you would like to help us by becoming distributor of our products, please let us know.

Other

If you have any other question, comment or a business proposal, please contact us:

mikroElektronika
Admirala Geprata 1B
11000 Belgrade
EUROPE

Phone: + 381 (11) 30 66 377, + 381 (11) 30 66 378

Fax: + 381 (11) 30 66 379

E-mail: office@mikroe.com

Support: support@mikroe.com

Web: www.mikroe.com