(SF-HD850/SF-HD65/SF-HD62) LASER ASSEMBLIES

This document shows the differences in the three laser assemblies that are used in the following units:

 GIG-STAR
 SF-HD65/SF-HD850

 GIG-MASTER
 SF-HD65/SF-HD850

 DVX-880
 SF-HD62/SF-HD65/SF-HD850

 DVG-888
 SF-HD65/SF-HD850

 DVG-777
 SF-HD65/SF-HD850

Laser Assemblies

When somebody wants to order a laser assembly for one of the above units, you must first find out which assembly they need. Below the 3 above-mentioned laser assemblies are pictured.

Desolder Points


When these laser assemblies are shipped to us, they are shipped with some protective soldering that needs to be desoldered before installing. It is important to let those who are ordering a laser assembly this prior to shipping them out. The desolder points are illustrated below.

****The SF-HD65 and SF-HD850 laser assemblies can be used interchangeably.


To complete an order:

- 1) Check the above list of units and compatible laser assemblies to determine which assemblies are compatible.
- 2) Have the technician pull out the laser assembly and check which version is required by viewing the pictures below to identify.
- 3) Make sure that the technician is aware of the desolder point. If they have done desoldered a laser assembly before, instruct them to save the old laser assembly for comparison to see what a desoldered laser assembly looks like.


SF-HD62 TOP VIEW



SF-HD62 BOTTOM VIEW




SF-HD62 DESOLDER POINT




This is the DESOLDER point for the SF-HD62


SF-HD65 TOP VIEW




SF-HD65 BOTTOM VIEW




SF-HD65 DESOLDER POINT



SF-HD850 TOP VIEW



SF-HD850 BOTTOM VIEW



SF-HD65 DESOLDER POINT

