## **Al Way Finder**

**Warning!** Not suitable for children under 36 months because of small part(s) – Choking hazard. Only for use by children over 8 years old. To be used solely under the strict supervision of adults that have studied the precautions given in the experimental set. Hair entanglement may result if the child's head is too close to the motorized unit of this toy. This toy contains functional sharp point – on the component leads. Do not short-circuit the battery terminals and motors, which may cause overheating. Do not lock the motor or other moving parts, which may cause overheating. Use with care and only under supervision of adult.

Packaging materials are not toys. Please remove all packaging and packing tags/wires before giving this toy to your child.

**CAUTION!** Take extra care during unpacking and use.

Please take note: As an extra precaution, check this toy regularly for signs of wear or damage. Read the instructions carefully before use, then follow them and keep them for reference.

Warning! Do not short-circuit the battery terminals and motor, which may cause overheating. The wires are not to be inserted into socket outlets.

#### **Batteries required: 3 x AAA (Not included)**

#### IMPORTANT: Keep these instructions. DO NOT DISCARD.

- Only adults should install and replace batteries.
- Alkáline batteries are recommended.
- If the device has not been used for a long time, remove the batteries. 3.
- Do not use rechargeable batteries.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon zinc) or rechargeable (nickel cadmium) batteries.
- 7. Exhausted batteries are to be removed from the toy.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Only batteries of the same or equivalent type as recommended are to be used. Batteries are to be inserted with the correct polarity.
- 12. Do not dispose of batteries in fire, batteries may explode or leak.
- 13. Batteries may explode or leak if misused.



If at any time in the future you should need to dispose of this product please note that Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.(Waste Electrical and Electronic Equipment Directive)

### Introduction

Artificial Intelligence (A.I.) is a branch of *Science* which deals with helping machines find solutions to complex problems in a more human-like fashion. This generally involves borrowing characteristics from human intelligence, and applying them in a language the computer understands. Researchers are creating systems which can mimic human thought, understand speech, beat the best human chess player, and countless other feats never before possible.

The word "robot" originates from the Czech word robota, meaning drudgery. A robot is something that senses the world in some way, does some sort of computation, deciding what to do, and then acts on the world outside itself as a result. Basically a robot consists of:

- A mechanical device, such as a wheeled platform, arm, or other construction, capable of interacting with its environment
- Sensors on or around the device that are able to sense the environment and give useful feedback to the device
- Systems that process sensory input and instruct the device to perform actions in response to the situation

The science and technology that deals with robots is called robotics. These AI robot kits let you explore how robot sensors work to connect them to the outside world.

## What does it do?

The AI Way Finder will move freely and avoid any obstacle in front of it.

## How does it work?

The infrared transmitter at the front will emit an invisible infrared light beam. An obstacle ahead reflects the infrared light back to the robot. This reflection is picked up by the robot's infrared detector and signals the microcomputer on the circuit board there is something in front of it. The microcomputer controls the motors to back up and change direction to find another way.

### **Components:**

- 1 Chassis x1
- 2 Rear wheel x2
- 3 Front wheel x2
- 4 Hind leg x2
- 5 Foreleg x2
- 6 Lever x4
- 7 Leg support x1
- 8 Wheel ring x2
- 9 Long screw x4
- 10 Short screw x4
- 11 Battery box x1
- 12 Circuit board x1
- 13 Flag x1




Fig. 1

### **Steps:**

1. Insert the leg support (7) to the small slot on both sides of the chassis (1). (Fig. 2)




Fig. 2

2. Put the wheel rings (8) over the rear wheels (2) and attach them to axles of the chassis (1). (Fig. 3, Fig. 4)



Fig. 3




Fig. 4

3. Connect both forelegs (5) with the lever (6) using a short screw (10). (Fig. 5)



Fig. 5

4. Using the remaining long and short screws (9,10), connect the forelegs in the previous step, the remaining levers (6) and the hind legs (4) to the chassis as shown in Fig. 6.




Fig. 6

5. Install the battery box (11) and the circuit board (12) on the chassis. See Fig. 7.





Fig. 7

6. Use a screwdriver (not included) to loosen the screw of the battery cover and install 3 AAA size batteries into the battery box according to the polarity mark. Replace the battery cover and tighten the screw. (Fig 8)



7. Install the flag (13) as shown in Fig. 9.

To summer the second se

Fig. 9

- 8. As shown in Fig. 10 and 11, install the circuit board (12) on the chassis and connect the plugs to the circuit board:
  - i. Battery plug socket "3V" (A)
  - ii. Left motor socket "Left" (L)
  - iii. Right motor socket "Right" (R)




Fig. 10



Fig. 11

## How to Play:

Press the red button on the circuit board to start! Try blocking it at the front and see it backing up and move around!

# **Battery Installation:**

The unit uses three AAA/LR03 (1.5V X 3) batteries (not included)

- 1. Refer to Step 6 above to install batteries.
- 2. Replace with new batteries when the movement becomes slow or it does not respond.
- 3. Insert new batteries according to the polarity marks.